CCD-TRV15/TRV15E/TRV15EP/TRV15PK/TRV25/ TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/ TRV85/TRV93/TRV215/TRV615/TRV815

RMT-708

SERVICE MANUAL

Self Diagnostics
Supported model



Photo : CCD-TRV93
: RMT-708

Handycam Vision™
Video 8 XR
video Hi8 XR
B MECHANISM

US Model
CCD-TRV15/TRV25/TRV65/TRV85/TRV93/
TRV215/TRV615/TRV815
Canadian Model
CCD-TRV15/TRV25/TRV65/TRV93/
TRV215/TRV615
E Model
CCD-TRV15/TRV15EP/TRV15PK/TRV25PK/
TRV35/TRV35E/TRV65PK
AEP Model
UK Model
East European Model
North European Model
Russian Model
CCD-TRV15E/TRV35E
Hong Kong Model
CCD-TRV15/TRV35/TRV35E
Tourist Model
CCD-TRV35/TRV35E
Australian Model
Chinese Model
CCD-TRV35E
Brazilian Model
CCD-TRV15/TRV65

For MECHANISM ADJUSTMENTS, refer to the "8mm Video MECHANICAL ADJUSTMENT MANUAL VII" (9-973-801-11).

SPECIFICATIONS

Video camera recorder

System

Video recording system
CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 : 4 rotary heads (SP/LP independent heads)
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215 : 2 Rotary heads
Helical scanning FM system

Audio recording system
Rotary heads, FM system

Video signal
CCD-TRV15/TRV15PK/TRV25/TRV25PK/TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815 :
NTSC color, EIA standards
CCD-TRV15E/TRV15EP/TRV35E :
PAL color CCIR standards

Usable cassette
8mm video format cassette
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215 : standard 8
CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 : Hi8 or standard 8

Recording / Playback time
CCD-TRV15/TRV15PK/TRV25/TRV25PK/TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815 :
(using 120 min. cassette)
SP mode: 2 hours
LP mode: 4 hours
CCD-TRV15E/TRV15EP/TRV35E :
(using 90 min. cassette)
SP mode: 1 hours and 30 minutes
LP mode: 3 hours

Fastforward/rewind time
CCD-TRV15/TRV15PK/TRV25/TRV25PK/TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815 :
(using 120 min. cassette) Approx. 5 min.
CCD-TRV15E/TRV15EP/TRV35E :
(using 90 min. cassette) Approx. 5 min.

Image device
CCD (Charge Coupled Device)

Viewfinder
Electronic viewfinder
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV215/TRV615/TRV815 :
Monochrome
CCD-TRV93 :
Color 113,578 (521 x 218)

Lens
Combined power zoom lens
Filter diameter 17/16 in. (37 mm)
CCD-TRV15 (US,CND)/TRV15E (AEP,UK)/TRV25 (AEP,UK)/TRV215 :
16 x (Optical), 64 x (Digital)
CCD-TRV15 (E,HK,BR)/TRV15PK/TRV15E (NE,EE,RU)/TRV15EP/TRV25PK : 16 x (Optical), 200 x (Digital)
TRV35E (AEP,UK)/TRV65/TRV85/TRV93/TRV615/TRV815 :
18 x (Optical), 72 x (Digital)
CCD-TRV35/TRV35E (EE,NE,RU,E,AUS,HK,CN,JE)/TRV65PK :
18 x (Optical), 220 x (Digital)

Focal distance
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215 :
3/16 - 2 5/8 in. (4.1 - 65.6 mm)
CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 : 3/16 - 8 in. (4.1 - 73.8 mm)
When converted to a 35 mm still camera
CCD-TRV15/TRV15PK/TRV15E/TRV15EP :
1 9/16 - 24 7/8 in. (39.4 - 630 mm)
CCD-TRV25/TRV25PK/TRV215 :
1 7/8 - 29 3/4 in. (47.2 - 755 mm)
CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 :
1 7/8 - 33 1/2 in. (47.2 - 850 mm)

— Continued on next page —

8 VIDEO CAMERA RECORDER

CCD-TRV15/TRV15E/TRV15PK/TRV15EP/TRV25/
TRV25PKTRV35/TRV35E/TRV215

Hi8 VIDEO CAMERA RECORDER

CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815

MICROFILM

SONY®

Color temperature
Auto
Minimum illumination
CCD-TRV15/TRV15PK 0 4 lux (F 1 4)
CCD-TRV15E/TRV15EP 0 4 lux (F 1 4)(Visible minimum low light 0 2 lux)
CCD-TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815
0 7 lux (F 1 4)
CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
0 lux (in NightShot mode)*
* Object invisible for the dark can be shot with infrared lighting
Illumination range
CCD-TRV15/TRV15PK/TRV15E/TRV15EP 0 4 lux to 100,000 lux
CCD-TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815
0 7 lux to 100,000 lux
Recommended illumination
More than 100 lux

LCD screen

Picture
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615
2 5 inches measured diagonally
2 x 1 1/2 in (50 3 x 37 4 mm)
CCD-TRV85/TRV815
3 5 inches measured diagonally
2 7/8 x 2 in (72 4 x 50 4 mm)
CCD-TRV93
3 inches measured diagonally
2 3/8 x 1 3/4 in (59 5 x 43 2 mm)
On-screen display
TN LCD/TFT active matrix method
Total dot number
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615 61,380 (279 x 220)
CCD-TRV85/TRV815
105,380 (479 x 220)
CCD-TRV93 89,622 (383 x 234)

Input and output connectors

S video input/output(CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 only)
4-pin mini DIN
Luminance signal 1 Vp-p, 75 ohms, unbalanced
Chrominance signal 0 286 Vp-p, 75 ohms, unbalanced
Video input(CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 only)/output
Phono jack, 1 Vp-p, 75 ohms, unbalanced
Audio input (CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 only)/output
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215
Monaural, Phone jack, 327 mV
CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 Phono jacks (2 stereo L and R) 327 mV, (at output impedance 47 kilohms) impedance less than 2 2 kilohms
RFU DC OUT
Special minijack, DC 5V
Headphone jack(CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 only)
Stereo minijack (ø 3 5 mm)
Earphone jack(CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215 only)
Monaural minijack (ø 3 5 mm)
LANC control jack
Stereo minijack (ø 2 5 mm)
MIC jack
Mini jack, 0 388mV low impedance with 2 5 to 3 0 V DC, output impedance 6 8 kilohms (ø 3 5 mm)
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215 Monaural type
CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 Stereo type
Speaker
Dynamic speaker
Intelligent accessory shoe(CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 only)
8-pin connector

General

Power requirements
7 2 V (battery pack)
8 4 V (AC power adaptor)

Averege power consumption(when using the battery pack)

During camera recording using LCD
CCD-TRV15/TRV15PK/TRV15E/TRV15EP 3 1 W
CCD-TRV25/TRV25PK/TRV35/TRV35E/TRV215 3 2 W
CCD-TRV65/TRV65PK/TRV615
3 3 W
CCD-TRV85/RV815 3 6 W
CCD-TRV93 3 4 W
Viewfinder
CCD-TRV15/TRV15PK/TRV15E/TRV15EP 2 5 W
CCD-TRV25/TRV25PK/TRV35/TRV35E/TRV215 2 6 W
CCD-TRV65/TRV65PK/TRV85/TRV615/TRV815 2 7 W
CCD-TRV93 2 6 W
Operating temperature
32°F to 104°F(0°C to 40°C)
Storage temperature
-4°F to +140°F(-20°C to +60°C)
Dimentions (Approx)
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615
4 1/4 x 4 1/4 x 8 1/4 in
(107 x 107 x 209 mm)(w/h/d)
CCD-TRV85/TRV815
4 1/2 x 4 3/8 x 8 1/2 in
(114 x 111 x 214 mm)(w/h/d)
CCD-TRV93
4 1/2 x 4 3/8 x 8 1/2 in
(114 x 109 x 214 mm)(w/h/d)
Mass (Approx)
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215
1 lb 15 oz (890 g)
CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV615 1 lb 15 oz (900 g)
CCD-TRV85/TRV815 2 lb 1 oz (950 g)
CCD-TRV93 2 lb (930 g)
excluding the battery pack, lithium battery, cassette and shoulder strap
2 lb 3 oz (1 kg)
including the battery pack NP-F330, lithium battery CR2025, cassette and shoulder strap
Microphone
CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215 Monaural type
CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815 Stereo type
Supplied accessories
See page 4

AC power adaptor

Power requirements
100 -240 V AC, 50/60 Hz
Power consumption
23 W
Output voltage
DC OUT 8 4 V, 1 5 A in operating mode
Operating temperature
32°F to 104°F(0°C to 40°C)
Storage temperature
-4°F to +140°F(-20°C to +60°C)
Dimentions (Approx)
5 x 1 9/16 x 2 1/2 in (125 x 39 x 62 mm)(w/h/d) excluding projecting parts
Mass (Approx)
9 8 oz (280 g) excluding power cord (Main lead)

Design and specifications are subject to change without notice

- Abbreviation

CND	Canadian Model
EE	East European Model
NE	North European Model
RU	Russian Model
HK	Hong Kong Model
AUS	Australian Model
JE	Tourist Model
CN	Chinese Model
BR	Brazilian Model

SAFETY CHECK-OUT

After correcting the original service problem, perform the following safety checks before releasing the set to the customer.

1. Check the area of your repair for unsoldered or poorly-soldered connections. Check the entire board surface for solder splashes and bridges.
2. Check the interboard wiring to ensure that no wires are "pinched" or contact high-wattage resistors
3 Look for unauthorized replacement parts, particularly transistors, that were installed during a previous repair. Point them out to the customer and recommend their replacement
4 Look for parts which, though functioning, show obvious signs of deterioration Point them out to the customer and recommend their replacement
5. Check the B+ voltage to see it is at the values specified
6. Flexible Circuit board Repairing
   - Keep the temperature of the soldering iron around 270°C during repairing
   - Do not touch the soldering iron on the same conductor of the circuit board (within 3 times)
   - Be careful not to apply force on the conductor when soldering or unsoldering.

SAFETY-RELATED COMPONENT WARNING !!

COMPONENTS IDENTIFIED BY MARK ⚠ OR DOTTED LINE WITH MARK ⚠ ON THE SCHEMATIC DIAGRAMS AND IN THE PARTS LIST ARE CRITICAL TO SAFE OPERATION. REPLACE THESE COMPONENTS WITH SONY PARTS WHOSE PART NUMBERS APPEAR AS SHOWN IN THIS MANUAL OR IN SUPPLEMENTS PUBLISHED BY SONY.

ATTENTION AU COMPOSANT AYANT RAPPORT À LA SÉCURITÉ!!

LES COMPOSANTS IDENTIFIÉS PAR UNE MARQUE ⚠ SUR LES DIAGRAMMES SCHÉMATIQUES ET LA LISTE DES PIÈCES SONT CRITIQUES POUR LA SÉCURITÉ DE FONCTIONNEMENT. NE REMPLACER CES COMPOSANTS QUE PAR DES PIÈCES SONY DONT LES NUMÉROS SONT DONNÉS DANS CE MANUEL OU DANS LES SUPPLÉMENTS PUBLIÉS PAR SONY.

Table for difference of function

Model		CCD-TRV15	CCD-TRV15/ TRV15PK	CCD-TRV15E	CCD-TRV15EP	CCD-TRV25	CCD-TRV25PK	CCD-TRV215	CCD-TRV35	CCD-TRV35E		Remark
Destination		US,CND	E,HK,BR	AEP,UK,EE, NE,RU	E	US,CND	E	US,CND	E,HK,JE	AEP,UK,EE, NE,RU	E,HK,AUS, CN,JE	
Classification		TYPE A		TYPE G		TYPE C			TYPE D	TYPE F		
Color System		NTSC	NTSC	PAL	PAL	NTSC	NTSC	NTSC	NTSC	PAL	PAL	
Hi8		×	×	×	×	×	×	×	×	×	×	
Standard 8		○	○	○	○	○	○	○	○	○	○	
Lens	Optical	16X	16X	16X	16X	16X	16X	16X	18X	18X	18X	16X : LSV601A, 18X : LSV600A
	Digital	64X	200X	64X(Note 1)	200X	64X	200X	64X	220X	72X(Note 2)	220X	
CCD		510H	510H	510H	510H	760H	760H	760H	760H	760H	760H	
Night shot		×	×	×	×	×	×	×	○	○	○	○ : LSV600A
Steady shot		×	×	×	×	○	○	○	○	○	○	○ : with SE-66/67 board SE451,452,IC451
5heads/3heads		3heads	3heads	3heads	3heads	3heads	3heads	3heads	3heads	3heads	3heads	
Audio System		Mono	Mono	Mono	Mono	Mono	Mono	Mono	Mono	Mono	Mono	
TBC&DNR		×	×	×	×	×	×	×	×	×	×	
VTR REC		×	×	×	×	×	×	×	×	×	×	
Laser Link		×	×	×	×	×	×	×	○	×	×	
Color EVF		×	×	×	×	×	×	×	×	×	×	
B/W EVF		○	○	○	○	○	○	○	○	○	○	○ : with VF-99 board
LCD		2.5 inch	2.5 inch	2.5 inch	2.5 inch	2.5 inch	2.5 inch	2.5 inch	2.5 inch	2.5 inch	2.5 inch	2.5 inch : PD-92 board, 3/3.5 inch : PD-93 board
Monitor IN		×	×	×	×	×	×	×	×	×	×	
Intelligent Accessory Shoe		×	×	×	×	×	×	×	×	×	×	
Normal Accessory Shoe		×	×	×	×	×	×	×	○	○	○	
Video light		×	×	×	×	×	×	×	×	×	×	
Display window indicator backlight		×	×	×	×	×	×	×	×	×	×	
Manual Focus		×	×	×	×	×	×	×	○	○	○	

Model		CCD-TRV65	CCD-TRV65/ TRV65PK	CCD-TRV615	CCD-TRV85	CCD-TRV815	CCD-TRV93	Remark
Destination		US,CND	BR/E	US,CND	US	US	US,CND	
Classification		TYPE B					TYPE E	
Color System		NTSC	NTSC	NTSC	NTSC	NTSC	NTSC	
Hi8		○	○	○	○	○	○	With S VIDEO terminal
Standard 8		×	×	×	×	×	×	
Lens	Optical	18X	18X	18X	18X	18X	18X	16X : LSV601A, 18X : LSV600A
	Digital	72X	220X	72X	72X	72X	72X	
CCD		760H	760H	760H	760H	760H	760H	
Night shot		○	○	○	○	○	○	○ : LSV600A
Steady shot		○	○	○	○	○	○	○ : with SE-66/67 board SE451,452,IC451
5heads/3heads		5heads	5heads	5heads	5heads	5heads	5heads	
Audio System		Stereo	Stereo	Stereo	Stereo	Stereo	Stereo	
TBC&DNR		○	○	○	○	○	○	○ : with VC-195 board IC204
VTR REC		○	○	○	○	○	○	○ : with FK-8500 block S005,007
Laser Link		○	○	○	○	○	○	○ : with VC-195 board IC751
Color EVF		×	×	×	×	×	○	○ : with VF-119,120 board, LB-54 board
B/W EVF		○	○	○	○	○	×	○ : with VF-99 board
LCD		2.5 inch	2.5 inch	2.5 inch	3.5 inch	3.5 inch	3 inch	2.5 inch : PD-92 board, 3/3.5 inch : PD-93 board
Monitor IN		○	○	○	○	○	○	○ : with VC-195 board X151
Intelligent Accessory Shoe		○	○	○	○	○	×	○ : with VC-195 board CN909
Normal Accessory Shoe		×	×	×	×	×	×	
Video light		×	×	×	×	×	○	○ : with VL-19 board
Display window indicator backlight		○	○	○	○	○	○	○ : with CF-50/51 board Q003,005
Manual Focus		○	○	○	○	○	○	○ : with MF-8500/MR-8500

Note1 : EE,NE,RU model is 200X
Note2 : EE,NE,RU model is 220X

- Abbreviation

CND	:	Canadian Model
EE	:	East European Model
NE	:	North European Model
RU	:	Russian Model
HK	:	Hong Kong Model
AUS	:	Australian Model
JE	:	Tourist Model
CN	:	Chinese Model
BR	:	Brazilian Models

Supplied accessories

1



2



3



4



5



6



7



8



9



10



11



12



13



1 **Wireless Remote Commander (1)**

2 **AC-L10A/L10B/L10C AC power adaptor**

3 **NP-F330 Battery pack (1)**

4 **CR2025 Lithium Battery (1)**
The lithium battery is already installed in your camcorder.

5 **Size AA (R6) battery for Remote Commander (2)**

6 **A / V connecting cable (1)**
Stereo : CCD-TRV65/TRV65PK/TRV615/TRV85/TRV815/TRV93
Monaural : Except CCD-TRV65/TRV65PK/TRV615/TRV85/TRV815/TRV93

7 **Shoulder strap (1)**

8 **Battery case (1)**
CCD-TRV15 (US, CND)/TRV25/TRV65/TRV85/TRV93

9 **21 pin adaptor (1) MVC-89**
CCD-TRV15E/35E : AEP, EE, NE, RU, UK

10 **8mm tape**
CCD-TRV15E only

11 **2 pin conversion adaptor (1)**
CCD-TRV15 : E, HK/TRV15PK/TRV25PK/TRV35 : E, HK/TRV35E : E, HK

12 **2 pin conversion adaptor (1)**
CCD-TRV35 : JE/TRV35E : JE

13 **3 pin conversion adaptor (1)**
CCD-TRV15 : HK/TRV35 : HK

- Abbreviation
  CND : Canadian Model
  EE : East European Model
  NE : North European Model
  RU : Russian Model
  HK : Hong Kong Model
  AUS : Australian Model
  JE : Tourist Model
  CN : Chinese Model
  BR : Brazilian Models

SERVICE NOTE

1. POWER SUPPLY DURING REPAIRS

In this unit, about 10 seconds after power is supplied (8 4V) to the battery terminal using the service power cord (J-6082-223-A), the power is shut off so that the unit cannot operate
This following two methods are available to prevent this Take note of which to use during repairs

Method 1.
Connect the servicing remote commander RM-95 (J-6082-053-B) to the LANC jack, and set the remote commander switch to the "ADJ" side

Method 2.
Use the DC IN terminal (Use the AC power adaptor)


Battery switch
Battery terminal ⊕
DC IN terminal
Battery SIG terminal
Battery terminal ⊖

2. TO TAKE OUT A CASSETTE WHEN NOT EJECT (FORCE EJECT)

① Refer to 2-1-1 to remove the front panel assembly
② Refer to 2-1-2 to remove the cabinet (R) assembly
③ Refer to 2-1-11 to remove the battery panel assembly
④ Refer to 2-1-13 to remove the cabinet (L) assembly
⑤ Add +5V from the DC POWER SUPPLY and unload with a pressing the cassette lid



⑥ *Pull the timing belt in the direction of arrow Ⓐ with a pinsette while pressing the cassette lid (take care not to damage) to adjust the bending of a tape*

⑦ *Let go your hold the cassette lid and rise the cassette compartment to take out a cassette*

Ⓐ
Pinsette
Timing belt
Press the cassette lid not to rise the cassette compartment
[DC power supply] (+5V)
+
−
Loading motor
Adjust the bending of a tape
Timing belt

SELF-DIAGNOSIS FUNCTION

1. Self-diagnosis Function

When problems occur while the unit is operating, the self-diagnosis function starts working, and displays on the viewfinder or Display window what to do. This function consists of two display; self-diagnosis display and service mode display.
Details of the self-diagnosis functions are provided in the Instruction manual.

2. Self-diagnosis display

When problems occur while the unit is operating, the counter of the viewfinder or Display window shows a 4-digit display consisting of an alphabet and numbers, which blinks at 3.2 Hz. This 5-character display indicates the "repaired by ", "block" in which the problem occurred, and "detailed code" of the problem.


Viewfinder
C : 3 1 : 1 1
Display window
C : 3 1 : 1 1
Blinks at 3.2 Hz
C
31
11
Repairede by
Block
Detailed Code

Refer to page7
Self-diagnosis Code table


Display window

C Corrected by customer
H Corrected by dealer
E Corrected by service engineer

Indicates the appropriate step to be taken
E.g.
31 Reload the tape
32 Turn on power again

3. Service Mode Display

The service mode display shows up to six self-diagnosis codes shown in the past.

3-1. Display Method

While pressing the "STOP" key, set the switch from OFF to "VTR or PLAYER", and continue pressing the "STOP" key for 5 seconds continuously. The service mode will be displayed, and the counter will show the backup No. and the 5-character self-diagnosis codes.


Viewfinder
[3] C : 3 1 : 1 1
Display window
3 C : 3 1 : 1 1
Lights up
[3]
C : 3 1 : 1 1
Backup No.
Self-diagnosis codes
Order of previous errors


Control dial

3-2. Switching of Backup No.

By rotating the control dial, past self-diagnosis codes will be shown in order. The backup No. in the [] indicates the order in which the problem occurred. (If the number of problems which occurred is less than 6, only the number of problems which occurred will be shown.)

[1] Occurred first time	[4] Occurred fourth time
[2] Occurred second time	[5] Occurred fifth time
[3] Occurred third time	[6] Occurred the last time

3-3. End of Display

Turning OFF the power supply will end the service mode display.

Note: The self-diagnosis display data will be backed up by the coin-type lithium battery. When this coin-type lithium battery is disconnected, the self-diagnosis data will be lost by initialization.

4. Self-diagnosis Code Table

Self-diagnosis Code			Symptom/State	Correction
Repaired by.	Block Function	Detailed Code		
C	21	00	Condensation.	Remove the cassette, and insert it again after one hour
C	22	00	Video head is dirty.	Clean with the optional cleaning cassette.
C	23	00	Non-standard battery is used.	Use the InfoLITHIUM battery
C	31	10	LOAD direction Loading does not complete within specified time	Load the tape again, and perform operations from the beginning
C	31	11	UNLOAD direction Loading does not complete within specified time	Load the tape again, and perform operations from the beginning
C	31	20	T reel side tape slacking when unloading	Load the tape again, and perform operations from the beginning
C	31	21	S reel side tape slacking when unloading	Load the tape again, and perform operations from the beginning.
C	31	22	T reel fault	Load the tape again, and perform operations from the beginning.
C	31	23	S reel fault	Load the tape again, and perform operations from the beginning.
C	31	30	FG fault when starting capstan	Load the tape again, and perform operations from the beginning.
C	31	31	FG fault during normal capstan operations	Load the tape again, and perform operations from the beginning
C	31	40	FG fault when starting drum	Load the tape again, and perform operations from the beginning
C	31	41	PG fault when starting drum	Load the tape again, and perform operations from the beginning
C	31	42	FG fault during normal drum operations	Load the tape again, and perform operations from the beginning
C	31	43	PG fault during normal drum operations	Load the tape again, and perform operations from the beginning
C	31	44	Phase fault during normal drum operations	Load the tape again, and perform operations from the beginning.
C	32	10	LOAD direction loading motor time-out	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	11	UNLOAD direction loading motor time-out	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	20	T reel side tape slacking when unloading	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	21	S reel side tape slacking when unloading.	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	22	T reel fault	Remove the battery or power cable, connect, and perform operations from the beginning.
C	32	23	S reel fault	Remove the battery or power cable, connect, and perform operations from the beginning.
C	32	30	FG fault when starting capstan	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	31	FG fault during normal capstan operations	Remove the battery or power cable, connect, and perform operations from the beginning.
C	32	40	FG fault when starting drum	Remove the battery or power cable, connect, and perform operations from the beginning.
C	32	41	PG fault when starting drum	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	42	FG fault during normal drum operations	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	43	PG fault during normal drum operations	Remove the battery or power cable, connect, and perform operations from the beginning
C	32	44	Phase fault during normal drum operations	Remove the battery or power cable, connect, and perform operations from the beginning
E	61	00	Difficult to adjust focus (Cannot initialize focus)	Inspect the lens block focus reset sensor (Pin ⑲ of CN551 of VC-195 board) when focusing is performed when the focus dial is rotated in the focus manual mode and the focus motor drive circuit (IC552 of VC-195 board) when the focusing is not performed Note Use the remote commander RM-95 only for the model without the focus dial.
E	61	10	Zoom operations fault (Cannot initialize zoom lens)	Inspect the lens block zoom reset sensor (Pin ㉑ of CN551 of VC-195 board) when zooming is performed when the zoom lens is operated and the zoom motor drive circuit (IC552 of VC195 board) when zooming is not performed
E	62	00	Handshake correction function does not work well (With pitch angular velocity sensor output stopped)	Inspect pitch angular velocity sensor (SE451 of SE-66/67 board) peripheral circuits
E	62	01	Handshake correction function does not work well (With yaw angular velocity sensor output stopped)	Inspect yaw angular velocity sensor (SE452 of SE-66/67 board) peripheral circuits

TABLE OF CONTENTS

SERVICE NOTE

1. Power Supply During Repairs 5
2. To Take out a Cassette when not Eject (Force Eject) 5

Self-Diagnosis Function

1. Self-diagnosis function 6
2. Self-diagnosis Display 6
3. Service Mode Display 6
   3-1. Display Method 6
   3-2. Switching of Backup No. 6
   3-3. End of Display 6
4. Self-diagnosis Code Table 7

1. GENERAL

Using this manual 1-1
Checking supplied accessories 1-1
Installing and Charging the battery pack 1-1
Inserting a cassette 1-3
Camera recording 1-3
Hints for better Shooting 1-4
Checking the recorded picture 1-5
Playing back a tape 1-5
Searching for the end of the picture 1-6
Using alternative power sources 1-6
Changing the mode settings 1-7
Shooting with backlighting 1-8
Using the FADER function 1-8
Shooting in the dark (NightShot) 1-9
Using the wide mode function 1-9
Using the PROGRAM AE function 1-10
Focusing manually 1-10
Enjoying picture effect 1-11
Adjusting the exposure 1-11
Superimposing a title 1-12
Making your own titles 1-12
Recording with the date/time 1-12
Optimizing the recording condition 1-13
Releasing the STEADY SHOT function 1-13
Watching on a TV screen 1-13
Editing onto another tape 1-14
Recording from a VCR or TV 1-14
Charging the lithium battery in the camcoder 1-14
Resetting the date and time 1-15
Simple setting of clock by time difference 1-15
Usable cassettes and playback modes 1-15
Tips for using the battery pack 1-16
Maintenance information and precautions 1-16
Using your camcorder abroad 1-18
Self-diagnosis display 1-18
Identifying the parts 1-18
Warning Indicators 1-20

2. DISASSEMBLY

2-1. Removal of Front Panel Block and Video Light Block 2-1
2-2. Removal of Cabinet (R) Block 2-2
2-3. Removal of EVF Block 2-2
2-4. Removal of LCD Block (3/3.5 inch) 2-2
2-5. Removal of LCD Block (2.5 inch) 2-2
2-6. Removal of CF-51 Board and Control Switch Block (MR-8500) (Color) 2-3
2-7. Removal of CF-50 Board and Control Switch Block (MF-8500) (B/W) 2-3
2-8. Removal of EVF Block-2 (Color) 2-3
2-9. Removal of EVF Block-2 (B/W) 2-4
2-10. Removal of Cabinet (L) Block and Battery Panel Block 2-4
2-11. Removal of Cassette Lid Assembly 2-5
2-12. Removal of Control Switch Block (FK-8500) 2-5
2-13. Removal of Zoom Lens Block and VL-19 Board 2-5
2-14. Removal of DD-105 Board and PJ-84 (PJ-83) Board 2-5
2-15. Removal of VC-195 and SE-67 (SE-66) Board 2-6
2-16. Service Position 2-6
2-17. Circuit Board Location 2-7

3. BLOCK DIAGRAMS

3-1. Overall Block Diagram 3-1
3-2. Camera/Video 1 Block Diagram 3-5
3-3. VTR/Camera Control Block Diagram 3-9
3-4. Servo Block Diagram 3-12
3-5. Mode Control Block Diagram 3-15
3-6. Audio Block Diagram 3-19
3-7. LCD (S Type) Block Diagram 3-23
3-8. LCD (C Type) Block Diagram 3-26
3-9. Color EVF Block Diagram 3-29
3-10. B/W EVF Block Diagram 3-32
3-11. Power Block Diagram 3-35

4. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. Frame Schematic Diagram (1) 4-1
- Frame Schematic Diagram (2) 4-4

4-2. Printed Wiring Boards and Schematic Diagrams 4-7
- CD-197/198 (CCD Imager) (2.5 Inch LCD, 3 Inch/3.5 Inch LCD Model) Board 4-8
- VC-195 (Camera, Y/C Processor, IN/OUT, REC/PB Head Amp, Servo/System Control, Servo, Audio, IR Transmiter, Mode Control) Board 4-10
- VC-195 (Camera 1) Board 4-16
- VC-195 (Camera 2) Board 4-19
- VC-195 (Y/C Process) Board 4-23
- VC-195 (IN/OUT) Board 4-27
- VC-195 (REC/PB Head Amp) Board 4-31
- VC-195 (Servo/System Control) Board 4-35
- VC-195 (Servo) Board 4-38
- VC-195 (Audio) Board 4-41
- VC-195 (IR Transmiter) Board 4-46
- VC-195 (Mode Control) Board 4-49
- SE-67/66 (Steady Shot) (2.5 Inch, 3 Inch/3.5 Inch LCD Model) Board 4-52
- PJ-83/84 (AV IN/OUT) (2.5 Inch, 3 Inch/3.5 Inch LCD Model) Board 4-55
- MA-311/331 (Stereo Mic, Laser Link) (2.5 Inch LCD Model) Board 4-58
- MA-312 (Stereo Mic, Laser Link) (3 Inch/3.5 Inch LCD Model) Board 4-59
- VL-19 (Video Light) Board 4-63
- CF-50 (Control (2.5 Inch LCD Model)) Board 4-64
- CF-51 (Control (3 Inch/3.5 Inch LCD Model)) Board .. 4-73
- Control Switch Block (FK-8500/SS-8500) 4-77
- PD-92 (RGB Decorder, LCD Drive, Back Light LCD (2.5 Inch LCD Model)) Board 4-78
- PD-92 (RGB Decorder) Board 4-81
- PD-92 (LCD Drive) Board 4-84
- PD-92 (Back Light) Board 4-87
- PD-92 (LCD) Board 4-88
- PD-93 (RGB Decorder, LCD Drive, Back Light LCD (3 Inch/3.5 Inch LCD Model)) Board 4-90
- PD-93 (RGB Decorder) Board 4-93
- PD-93 (LCD Drive) Board 4-96
- PD-93 (Back Light) Board 4-99
- PD-93 (LCD) Board 4-100
- VF-120 (Color EVF (Color EVF Model)) Board 4-107
- LB-54 (Back Light) Board 4-107
- VF-99 (B/W EVF (B/W EVF Model)) Board 4-115
- DD-105 (Power) Board 4-118

5. ADJUSTMENTS

5-1. CAMERA SECTION ADJUSTMENTS 5-1

1-1. Preparations before Adjustment (Camera Section) 5-1
- 1-1-1. List of Service Tools 5-1
- 1-1-2. Preparations 5-2
- 1-1-3. Precautions 5-5
  - 1. Setting the Switch 5-5
  - 2. Adjusting Procedure 5-5
  - 3. Subject 5-5
- 1-1-4. Adjusting Remote Commander 5-6
  - 1. Using the adjusting remote commander 5-6
  - 2. Precautions upon using the adjusting remote commander 5-6
- 1-1-5. Data Processing 5-7

1-2. Initialization of D, E, F Page Data 5-8
- 1. Initialization of D, E, F Page Data 5-8
- 2. Modification of D, E, F Page Data 5-8
- 3. D Page Table 5-9
- 4. F Page Table 5-10
- 5. E Page Table 5-12

1-3. Camera System Adjustments 5-14
- 1. G-CAM flip Adjustment 5-14
- 2. Hall Adjustment 5-15
- 3. Flange Back Adjustment 5-16
- 3-1. Flange Back Adjustment (1) 5-16
- 3-2. Flange Back Adjustment (2) 5-16
- 4. Flange Back Check 5-17
- 5. Picture Frame Setting 5-17
- 6. Color Reproduction Adjustment 5-18
- 7. IRIS IN/OUT Adjustment 5-19
- 8. MAX GAIN Adjustment 5-19
- 9. Auto White Balance Standard Data Input 5-20
- 10. White Balance Adjustment 5-20
- 11. White Balance Check 5-21
- 12. Angular Velocity Sensor Sensitivity Adjustment 5-22

1-4. Color Electronic Viewfinder System Adjustments (CCD-TRV93) 5-23
- 1. EVF Initial Data Input 5-23
- 2. VCO Adjustment (VF-119 board) 5-24
- 3. Bright Adjustment (VF-119 board) 5-24
- 4. Contrast Adjustment (VF-119 board) 5-25
- 5. Backlight Comsumption Current Adjustment (VF-120 board) 5-25
- 6. White Balance Adjustment (VF-119 board) 5-25

1-5. Monochrome Electronic Viewfinder System Adjustments (CCD-TRV15/TRV15E/TRV15EP/TRV15PK/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV215/TRV615/TRV815) 5-26
- 1-5-1. Horizontal Slant Check 5-26
- 1-5-2. Centering Adjustment 5-26
- 1-5-3. Focus Adjustment 5-26
- 1-5-4. Aberration Adjustment 5-27
- 1-5-5. Horizontal Amplitude Adjustment (VF-99 board) .. 5-27
- 1-5-6. Vertical Amplitude Adjustment (VF-99 board) 5-28
- 1-5-7. Brightness Adjustments (VF-99 board) 5-28
- 1-5-8. Horizontal Amplitude, Vertical Amplitude, Focus Check 5-28

1-6. LCD System Adjustment 5-29
- 1. LCD initial data input 5-29
- 2. VCO adjustment (PD-92/93 board) 5-30
- 3. D range adjustment (PD-92/93 board) 5-30
- 4. Bright adjustment (PD-92/93 board) 5-31
- 5. Contrast adjustment (PD-92/93 board) 5-31
- 6. V-COM level adjustment (PD-92/93 board) 5-32
- 7. Color adjustment (PD-92/93 board) 5-32
- 8. V-COM adjustment (PD-92/93 board) 5-33
- 9. White balance adjustment (PD-92/93 board) 5-33

5-2. MECHANICAL SECTION ADJUSTMENT 5-34
2-1. Operating without a Cassette 5-34
2-2. Tape path Adjustment 5-34
  1. Preparations for adjustments 5-34

5-3. VIDEO SECTION ADJUSTMENTS 5-35
3-1. Preparations before Adjustment 5-35
  3-1-1. Equipments to be Used 5-35
  3-1-2. Precautions on Adjusting 5-36
  3-1-3. Adjusting Connectors 5-36
  3-1-4. Connecting the Equipments 5-37
  3-1-5. Alignment Tape 5-37
  3-1-6. Input/Output Level and Impedance 5-39
  3-1-7. Recording Mode (Standard 8/Hi8) switching (Hi8 model) 5-39
  3-1-8. Service Mode 5-39
  1. Test mode setting 5-39
  2. Emergency memory address 5-40
  2-1. EMG CODE (Emergency Code) 5-40
  2-2. MSW Codes 5-41
  3. Bit value discrimination 5-42
  4. Switch check (1) 5-42
  5. Switch check (2) 5-43
  6. Headphone jack check 5-43
  7. Input/output selection check 5-43
  8. LED, LCD (display window) check 5-44
  9. Record of use check 5-44
3-2. System Control System Adjustment 5-45
  1. Initialization of D, E, F Page Data 5-45
  2. Battery End Adjustment (VC-195 board) 5-45
3-3. Servo System Adjustments 5-46
  1. CAP FG Offset Adjustment (VC-195 board) 5-46
  2. Switching Position Adjustment (VC-195 board) 5-46
  3. NTSC LP Mode Switching Position Adjustment (VC-195 board) (CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815) 5-47
3-4. Video System Adjustments 5-47
  1. 28 MHz Origin Oscillation Adjustment (VC-195 board) 5-47
  2. AFC f0 Adjustment (VC-195 board) 5-48
  3. Filter f0 Adjustment (VC-195 board) 5-48
  4. Y OUT Level Adjustment (VC-195 board) 5-49
  5. C OUT Level Adjustment (VC-195 board) 5-49
  6. RP Filter f0 Adjustment (VC-195 board) 5-50
  7. Hi8 REC Y Current Adjustment (VC-195 board) (CCD-TRV85/TRV93/TRV615/TRV815) 5-50
  8. Standerd8 REC Y Current Adjustment (VC-195 board) (CCD-TRV15/TRV15E/TRV15EP/TRV15PK/TRV25/TRV25PK/TRV35/TRV35E/TRV215) 5-51
  9. Hi8 REC L Level Adjustment (VC-195 board) (CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815) 5-52
  10. Standerd8 REC L Level Adjustment (VC-195 board) (CCD-TRV15/TRV15E/TRV15EP/TRV15PK/TRV25/TRV25PK/TRV35/TRV35E/TRV215) 5-53
  11. REC C Current Adjustment (VC-195 board) 5-54
3-5. IR Transmitter Adjustments (CCD-TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815) 5-55
  1. IR Video Carrier Frequency Adjustment (VC-195 board) 5-55
  2. IR Video Deviation Adjustment (VC-195 board) 5-55
  3. IR Audio Deviation Adjustment (VC-195 board) ... 5-56
3-6. Stereo Audio System Adjustment (CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815) 5-57
  1. 1.5 MHz Deviation Adjustment (VC-195 board) 5-58
  2. 1.7 MHz Deviation Adjustment (VC-195 board) 5-58
  3. BPF f0 Adjustment (VC-195 board) 5-59
3-7. Monaural Audio System Adjustment (CCD-TRV15/TRV15E/TRV15EP/TRV15PK/TRV25/TRV25PK/TRV35/TRV35E/TRV215) 5-59
  1. 1.5 MHz Deviation Adjustment (VC-195 board) 5-60
  2. BPF Adjustment (VC-195 board) 5-60
3-8. Arrangement Diagram for Adjustment Parts 5-62

6. REPAIR PARTS LIST

6-1. Exploded Views 6-1
  6-1-1. Cabinet (L) Block Assembly 6-1
  6-1-2. Front Panel Block Assembly (TRV93) 6-2
  6-1-3. Front Panel Block Assembly (Except TRV93) 6-3
  6-1-4. Cabinet (R) Block Assembly (TRV85/TRV815/TRV93) 6-4
  6-1-5. Cabinet (R) Block Assembly (Except TRV85/TRV815/TRV93) 6-5
  6-1-6. LCD Block Assembly (3/3.5 Inch) (TRV85/TRV815/TRV93) 6-6
  6-1-7. LCD Block Assembly (2.5 Inch) (Except TRV85/TRV815/TRV93) 6-7
  6-1-8. EVF Block Assembly (Color EVF) (TRV93) 6-8
  6-1-9. EVF Block Assembly (B/W EVF) (Except TRV93) 6-9
  6-1-10. Main Boards Assembly 6-10
  6-1-11. Battery Panel and CCD Block Assembly 6-11
  6-1-12. Device Lens (LSV-600A/LSV-601A) 6-12
  6-1-13. Cassette Compartment Assembly 6-13
  6-1-14. LS Chassis Assembly 6-14
  6-1-15. Mechanism Chassis Assembly 6-15
6-2. Electrical Parts List 6-16

< PARTS REFERENCE SHEET >

You can find the parts position of mount locations applying to boards of a set

Take a copy CAMERA COLOR REPRODUCTION FRAME and Parts reference sheets with a clear sheet for use


SIDE B
9
8
7
6
5
4
3
2
1
G
F
E
D
C
B
A
CN909
CN551
IC204
CN907
VC-195 BOARD
CN910
CN914
IC402
CN904
IC301
IC421
10
11
12
13
14
15
16
17
18
SIDE A

FOR CAMERA COLOR REPRODUCTION ADJUSTMENT

Take a copy CAMERA COLOR REPRODUCTION FRAME and Parts reference sheets with a clear sheet for use.

For NTSC 510H model


R-Y
MG
R
YL
B-Y
B
G
CY

CCD-TRV15/TRV15PK

For PAL 510H, 760H model


R-Y
MG
R
YL
B-Y
B
G
CY

CCD-TRV15E/TRV15EP/TRV35E

For NTSC 760H model


R-Y
MG
R
YL
B-Y
B
G
CY

CCD-TRV25/TRV25PK/TRV35/TRV65/TRV65PK/
TRV85/TRV93/TRV215/TRV615/TRV815

Sony Corporation
Personal A&V Products Company

98A0990-1

Printed in Japan © 1998. 1

Published by Quality Engineering Dept.
(Osaki East)

SECTION 1
GENERAL

This section is extracted from instruction manual of CCD-TRV15/25/35/65/615.

Before you begin

Using this manual

The instructions in this manual are for the seven models listed below. Before you start reading this manual and operating the unit, check your model number by looking at the bottom of your camcorder. The CCD-TRV65 is the model used for illustration purposes. Otherwise, the model name is indicated in the illustrations. Any differences in operation are clearly indicated in the text, for example, "CCD-TRV65 only."
As you read through this manual, buttons and settings on the camcorder are shown in capital letters.
e.g. Set the POWER switch to CAMERA.
You can hear the beep sound to confirm your operation.

Types of differences

CCD-	TRV15	TRV25/TRV215	TRV35	TRV65/TRV615
System	8	8	8	Hi8
VIDEO/AUDIO IN*	—	—	—	●
S VIDEO	—	—	—	●
Optical zoom	16x	16x	18x	18x
Digital zoom	64x	64x	72x	72x
NightShot	—	—	●	●
Steady Shot	—	●	●	●
LASER LINK	—	—	●	●
Fader function	—	—	●	●
Stripe	—	—	—	●
Manual focus	—	—	●	●
Exposure	—	—	●	●
Audio	monaural	monaural	monaural	stereo

* The models without VIDEO/AUDIO IN have CAMERA, OFF and PLAYER mode on the POWER switch.

Using this manual

Note on TV color systems

TV color systems differ from country to country. To view your recordings on a TV, you need an NTSC system-based TV.

Precaution on copyright

Television programs, films, video tapes, and other materials may be copyrighted. Unauthorized recording of such materials may be contrary to the provision of the copyright laws.

Precautions on camcorder care

- **The LCD screen and/or the color viewfinder are manufactured using high-precision technology. However, there may be some tiny black points and/or bright points (red, blue or green in color) that constantly appear on the LCD screen and/or in the viewfinder. These points are normal in the manufacturing process and do not affect the recorded picture in any way. Over 99.99% are operational for effective use.**
- Do not let the camcorder get wet. Keep the camcorder away from rain and sea water. Letting the camcorder get wet may cause the unit to malfunction, and sometimes this malfunction cannot be repaired **[a]**.
- Never leave the camcorder exposed to temperatures above 140°F (60°C), such as in a car parked in the sun or under direct sunlight **[b]**.

[a]



[b]



Checking supplied accessories

Check that the following accessories are supplied with your camcorder.



1. **Wireless Remote Commander** (1) (p. 84)
2. **AC-L10A/L10B/L10C AC power adaptor** (1), **Power cord** (1) (p. 8, 26)
3. **NP-F330 Battery pack** (1) (p. 7, 26)
4. **CR2025 Lithium Battery** (1) (p. 59)
   The lithium battery is already installed in your camcorder.
5. **Size AA (R6) battery for Remote Commander** (2) (p. 85)
6. **A/V connecting cable** (1) (p. 54)
   *for stereo model
7. **Shoulder strap** (1) (p. 85)
8. **Battery case** (1) (p. 27)
   CCD-TRV15/TRV25/TRV35/TRV65 only

Contents of the recording cannot be compensated if recording or playback is not made due to a malfunction of the camcorder, video tape, etc.

Getting started

Installing and charging the battery pack

Before using your camcorder, you first need to install and charge the battery pack.

Installing the battery pack

(1) While pressing BATT RELEASE, slide the battery terminal cover in the direction of the arrow.
(2) Install the battery pack in the direction of the ▼ mark on the battery pack. Slide the battery pack down until it catches on the battery release lever and clicks. Attach the battery pack to the camcorder securely.



Note on the battery pack
Do not carry the camcorder by grasping the battery pack.

Charging the battery pack

Charge the battery pack on a flat surface without vibration. The battery pack is charged a little in the factory.

(1) Open the DC IN jack cover and connect the supplied AC power adaptor to the DC IN jack with the plug's ▲ mark up.
(2) Connect the power cord to the AC power adaptor.
(3) Connect the power cord to a wall outlet.
(4) Slide the POWER switch to OFF. Remaining battery time is indicated by the minutes on the display window. Charging begins.

When the remaining battery indicator becomes ▬, **normal charge** is completed. For **full charge**, which allows you to use the battery longer than usual, leave the battery pack attached for about 1 hour after normal charge is completed until FULL appears in the display window.
Before using the camcorder with the battery pack, unplug the AC power adaptor from the DC IN jack of the camcorder. You can also use the battery pack before it is completely charged.



Notes
- "– – – min" appears in the display window until the camcorder calculates remaining battery time.
- Remaining battery time indication in the display window roughly indicates the recording time with the viewfinder. Use it as a guide. It may differ from the actual recording time.

Charging time

Battery pack	NP-F330 (supplied)	NP-F530/F550	NP-F730/F730H/ F750	NP-F930/F950
Charging time* (min.)	150 (90)	210 (150)	300 (240)	390 (330)

The time required for a normal charge is indicated in parentheses.
* Approximate minutes to charge an empty battery pack using the supplied AC power adaptor. (Lower temperatures require a longer charging time.)

Battery life

Upper numbers are the time when recording with the viewfinder. Lower numbers are the time when recording with the LCD screen. Using both will further reduce recording time.

CCD-TRV15

Battery pack	NP-F330 (supplied)	NP-F530	NP-F550	NP-F730	NP-F730H /F750	NP-F930	NP-F950
Continuous recording time*	130 (115) 100 (90)	225 (200) 170 (155)	260 (230) 205 (185)	450 (405) 350 (310)	530 (480) 425 (380)	710 (640) 555 (500)	815 (730) 650 (590)
Typical recording time**	65 (60) 55 (45)	115 (105) 90 (85)	135 (120) 110 (100)	235 (210) 190 (170)	280 (250) 230 (205)	375 (335) 305 (275)	430 (385) 355 (320)
Playing time on LCD	100 (90)	165 (150)	200 (180)	335 (300)	410 (365)	535 (480)	630 (570)

CCD-TRV25/TRV35/TRV215

Battery pack	NP-F330 (supplied)	NP-F530	NP-F550	NP-F730	NP-F730H /F750	NP-F930	NP-F950
Continuous recording time*	125 (110) 100 (90)	215 (190) 165 (150)	250 (220) 200 (180)	430 (385) 335 (300)	510 (460) 410 (365)	680 (610) 535 (480)	780 (700) 630 (570)
Typical recording time**	65 (55) 55 (45)	110 (100) 90 (80)	130 (115) 110 (95)	225 (200) 180 (165)	270 (240) 225 (200)	360 (320) 290 (260)	410 (370) 345 (310)
Playing time on LCD	100 (90)	165 (150)	200 (180)	335 (300)	410 (365)	535 (480)	630 (570)

CCD-TRV65/TRV615

Battery pack	NP-F330 (supplied)	NP-F530	NP-F550	NP-F730	NP-F730H /F750	NP-F930	NP-F950
Continuous recording time*	120 (105) 95 (85)	205 (180) 160 (145)	240 (210) 195 (175)	410 (370) 325 (290)	490 (440) 395 (355)	650 (585) 515 (465)	750 (675) 610 (550)
Typical recording time**	60 (55) 50 (45)	105 (95) 85 (75)	125 (110) 105 (95)	215 (195) 175 (155)	255 (230) 215 (195)	340 (310) 280 (255)	395 (355) 335 (300)
Playing time on LCD	95 (85)	160 (145)	195 (175)	325 (290)	395 (355)	515 (465)	610(550)

Numbers in parentheses indicate the time when you use a normally charged battery.
Battery life will be shorter if you use the camcorder in a cold environment.
* Approximate continuous recording time at 77°F (25°C).
** Approximate minutes when recording while you repeat recording start/stop, zooming and turning the power on/off. The actual battery life may be shorter.

Notes on remaining battery time indication during recording
- Remaining battery time is displayed in the viewfinder or on the LCD screen. However, the indication may not be displayed properly, depending on using conditions and circumstances.
- When you close the LCD panel and open it again, it takes about 1 minute for the correct remaining time to be displayed.

To remove the battery pack

While pressing BATT RELEASE, slide the battery pack in the direction of the arrow.



You can look at the demonstration of the functions available with this camcorder (p. 32).

Inserting a cassette

Make sure that the power source is installed. When you want to record in the Hi8 system, use Hi8 video cassette **Hi8**.(CCD-TRV65/TRV615 only)

(1) While pressing the small blue button on the EJECT switch, slide it in the direction of the arrow. The cassette compartment automatically lifts up and opens.
(2) Insert a cassette with the window facing out.
(3) Close the cassette compartment by pressing the "PUSH" mark on the cassette compartment. The cassette compartment automatically goes down.



To eject the cassette

While pressing the small blue button on the EJECT switch, slide it in the direction of the arrow.

To prevent accidental erasure

Slide the tab on the cassette to expose the red mark. If you insert the cassette with the red mark exposed and close the cassette compartment, the beeps sound for a while. If you try to record with the red mark exposed, the ▣ and ⏏ indicators flash, and you cannot record.
To re-record on this tape, slide the tab back out covering the red mark.



Basic operations

Camera recording

Make sure that the power source is installed and a cassette is inserted and that the START/STOP MODE switch inside the LCD panel is set to ☝ . Before you record one-time events, you may want to make a trial recording to make sure that the camcorder is working correctly.
When you use the camcorder for the first time, power on it and reset the date and time to your time before you start recording (p. 61). The date is automatically recorded for 10 seconds after you start recording **(AUTO DATE feature)**. This feature works only once a day.

(1) While pressing the small green button on the POWER switch, set it to CAMERA.
(2) Turn STANDBY up to STANDBY.
(3) Press START/STOP. The camcorder starts recording. The "REC" indicator appears. The red lamp lights up in the viewfinder. The camera recording/battery lamp located on the front of the camcorder also lights up.



To stop recording momentarily [a]

Press START/STOP again. The "STBY" *indicator appears in the viewfinder* **(Standby mode)**.

To finish recording [b]

Press START/STOP again. Turn STANDBY down to LOCK and set the POWER switch to OFF. Then, eject the cassette.



Note
There is a little wear on the battery pack which is installed with the camcorder. However, for getting remaining battery time indicated correctly, leave the battery pack installed after use.

To focus the viewfinder lens

If you cannot see the indicators in the viewfinder clearly, or after someone else has used the camcorder, focus the viewfinder lens. Turn the viewfinder lens adjustment ring so that the indicators in the viewfinder come into sharp focus.



Note on Standby mode
If you leave the camcorder in Standby mode for 5 minutes while the cassette is inserted, the camcorder turns off automatically for saving battery power as well as for preventing the battery and tape from wearing down. To resume Standby mode, turn STANDBY down and up again. To start recording, press START/STOP.

Note on recording
When you record from the beginning of a tape, run the tape for about 15 seconds before starting the actual recording. This will ensure that you won't miss any start-up scenes when you play back the tape.

Notes on the tape counter
- The tape counter indicates the recording or playback time. Use it as a guide. There will be a time lag of several seconds from the actual time. To set the counter to zero, press COUNTER RESET.
- If the tape is recorded in SP and LP modes mixed, the tape counter shows incorrect recording time. When you intend to edit the tape using the tape counter as a guide, record in same (SP or LP) mode.

Note on the beep sound
The beep sounds when you operate the camcorder. Several beeps also sound as a warning of any unusual condition of the camcorder.
Note that the beep sound is not recorded on the tape. If you do not want to hear the beep sound, select "OFF" in the menu system.

Note on the AUTO DATE feature
The clock is set to East Coast Standard Time at the factory. You can reset the clock in the menu system. You can change the AUTO DATE settings by selecting ON or OFF in the menu system. The AUTO DATE feature shows the date automatically once a day.
However, the date may automatically appear more than once a day when:
- you reset the date and time.
- you eject and insert the tape again.
- you stop recording within 10 seconds.
- you set AUTO DATE to OFF once and set it to ON again in the menu system.

Using the zoom feature

Zooming is a recording technique that lets you change the size of the subject in the scene.
For more professional-looking recordings, use the zoom function sparingly.
"T" side: for telephoto (subject appears closer)
"W" side: for wide-angle (subject appears farther away)



Zooming speed (Variable speed zooming)

Move the power zoom lever a little for a slower zoom, move it further for a faster zoom.

When you shoot a subject using a telephoto zoom
If you cannot get a sharp focus while in extreme telephoto zoom, move the power zoom lever to the "W" side until the focus is sharp. You can shoot a subject that is at least about 2 5/8 feet (about 80 cm) away from the lens surface in the telephoto position, or about 1/2 inch (about 1 cm) away in the wide-angle position.

Notes on digital zoom
- More than 16x (CCD-TRV15/TRV25/TRV215) or 18x (CCD-TRV35/TRV65/TRV615) zoom is performed digitally, and the picture quality deteriorates as you go toward the "T" side. If you do not want to use the digital zoom, set the D ZOOM function to OFF in the menu system.
- The right side **[a]** of the power zoom indicator shows the digital zooming zone, and the left side **[b]** shows the optical zooming zone. If you set the D ZOOM function to OFF, the **[a]** zone disappears.



Selecting the START/STOP mode

Your camcorder has three modes. These modes enable you to take a series of quick shots resulting in a lively video.

(1) While pressing OPEN, open the LCD panel.

(2) Set START/STOP MODE to the desired mode.

⊻ : Recording starts when you press START/STOP, and stops when you press it again (normal mode).

ANTI GROUND SHOOTING ⊥ : The camcorder records only while you press down START/STOP so that you can avoid recording unnecessary scenes.

5SEC: When you press START/STOP, the camcorder records for 5 seconds and then stops automatically.

(3) Turn STANDBY up to STANDBY and press START/STOP. Recording starts.

If you selected 5SEC, the tape counter disappears and five dots appear. The dots disappear at a rate of one per second as illustrated below.



To extend the recording time in 5SEC mode

Press START/STOP again before all the dots disappear. Recording continues for about 5 seconds from the moment you press START/STOP.

Notes on START/STOP mode

- If you have turned off the indicators on the LCD screen, the dots do not appear.
- You cannot use FADER in 5SEC or ⊥ mode.

Shooting with the LCD screen

You can also record the picture while looking at the LCD screen.
When using the LCD screen, the viewfinder turns off automatically. You cannot monitor the sound from the speaker during recording.

(1) While pressing OPEN, open the LCD panel.

(2) Adjust the angle of the LCD panel.

The LCD panel moves about 90 degrees to this side and about 210 degrees to the other side.

To adjust the brightness of the LCD screen, press LCD BRIGHT.

+ side: to brighten the LCD screen

– side: to dim the LCD screen

The battery life is longer when the LCD panel is closed. Use the viewfinder instead of the LCD screen to save the battery power.



Backlighting the LCD screen

If the LCD screen is insufficiently illuminated even after adjusting LCD BRIGHT, select LCD B. L. in the menu system and set to BRIGHT. You can select LCD B. L. only while using the battery pack as a power source.

Notes on the LCD panel

- When closing the LCD panel, turn it vertically until it clicks **[a]**.
- When turning the LCD panel, turn it always vertically; otherwise, the camcorder body may be damaged or the LCD panel may not close properly **[b]**.
- Close the LCD panel completely when not in use.

[a]



[b]



Letting the subject monitor the shot (Mirror mode)

You can turn the LCD panel over so that it faces the other way and you can let the subject monitor the shot while shooting with the viewfinder.

Turn the LCD panel vertically first until it clicks, then turn it over. The ◎ indicator appears on the LCD screen **(Mirror mode)** and the date and remaining tape indicators disappear.

To cancel mirror mode

Turn the LCD panel back toward the viewfinder.

Notes on mirror mode

- The picture on the LCD looks as a mirror-image while recording in mirror mode. The STBY indicator appears as **●II** and REC as **●**. The other indicators may not appear in mirror mode.
- While recording in mirror mode, you cannot operate the following buttons: TITLE, DATE, TIME and MENU.
- The date appears in reverse when the AUTO DATE feature is turned on. When recorded, it will be normal.

Hints for better shooting

For hand-held shots, you'll get better results by holding the camcorder according to the following suggestions:

- Hold the camcorder firmly and secure it with the grip strap so that you can easily manipulate the controls with your thumb.



- Place your right elbow against your side.
- Place your left hand under the camcorder to support it. Be sure to not touch the built-in microphone.
- Place your eye firmly against the viewfinder eyecup.
- Use the viewfinder frame as a guide to determine the horizontal plane.
- You can also record in a low position to get an interesting angle. Lift the viewfinder up for recording from a low position **[a]**.
- You can also record in a low position or even in a high position using the LCD panel **[b]**.
- When you use the LCD screen outdoors in direct sunlight, the LCD screen may be difficult to see. If this happens, we recommend that you use the viewfinder.

[a]



[b]



Hints for better shooting

Place the camcorder on a flat surface or use a tripod
Try placing the camcorder on a table top or any other flat surface of suitable height. If you have a tripod for a still camera, you can also use it with the camcorder.
When attaching a non-Sony tripod, make sure that the length of the tripod screw is less than 9/32 inch (6.5 mm). Otherwise, you cannot attach the tripod securely and the screw may damage the camcorder.

Cautions on the viewfinder and the LCD
- Do not pick up the camcorder by the viewfinder or by the LCD panel **[c]**.
- Do not place the camcorder so as to point the viewfinder or the LCD screen toward the sun. The inside of the viewfinder may be damaged. Be careful when placing the camcorder under sunlight or by a window **[d]**.



Checking the recorded picture

Using EDITSEARCH, you can review the last recorded scene or check the recorded picture in the viewfinder or on the LCD screen.
(1) While pressing the small green button on the POWER switch, set it to CAMERA.
(2) Turn STANDBY up to STANDBY.
(3) Press the – (⊖) side of EDITSEARCH momentarily; the last few seconds of the recorded portion play back **(Rec Review)**.
You can monitor the sound from the speaker, headphones (CCD-TRV65/TRV615 only) or an earphone (CCD-TRV15/TRV25/TRV35/TRV215/only).
Hold down the – side of EDITSEARCH until the camcorder goes back to the scene you want. The last recorded portion is played back. To go forward, hold down the + side **(Edit Search)**.



To stop playback
Release EDITSEARCH.

To go back to the last recorded point after edit search
Press END SEARCH. The last recorded point is played back for about 5 seconds (10 seconds in LP mode) and stops. Note that this function does not work once you eject the cassette after you recorded on the tape.

To begin re-recording
Press START/STOP. Re-recording begins from the point you released EDITSEARCH. Provided you do not eject the cassette, the transition between the last scene you recorded and the next scene you record will be smooth.

Playing back a tape

You can monitor the playback picture on the LCD screen.
(1) While pressing the small green button on the POWER switch, set it to VTR (CCD-TRV65/TRV615) or PLAYER (CCD-TRV15/TRV25/TRV35/TRV215).
The video control buttons light up (CCD-TRV35/TRV65 TRV615 only).
(2) Insert the recorded tape with the window facing out.
(3) While pressing OPEN, open the LCD panel. Adjust the angle of the LCD panel or the brightness of the LCD screen if necessary.
(4) Press ◀◀ to rewind the tape.
(5) Press ▶ to start playback.
(6) Adjust the volume using VOLUME and adjust the brightness of the LCD screen using LCD BRIGHT.
You can also monitor the picture on a TV screen, after connecting the camcorder to a TV or VCR.



To stop playback, press ■.
To rewind the tape, press ◀◀.
To fast-forward the tape rapidly, press ▶▶.

Playing back a tape

When monitoring on the LCD screen
You can turn the LCD panel over and move back to the camcorder with the LCD screen facing out **[a]**. You can adjust the angle of the LCD screen by turning the LCD screen up to 15 degrees **[b]**.



Using the remote commander
You can control playback using the supplied Remote Commander. Before using the Remote Commander, insert the size AA (R6) batteries.

Note on DISPLAY button
Press DISPLAY to display the screen indicators on the LCD screen. To erase the indicators, press DISPLAY again. If the POWER switch is set to CAMERA, you can erase the indicator by pressing DISPLAY.

Using headphones or an earphone
Connect headphones (not supplied) to the ∩ jack (CCD-TRV65/TRV615 only) or an earphone (not supplied) to the ⊚ jack (CCD-TRV15/TRV25/TRV35/TRV215 only). You can adjust the volume using VOLUME. When you use headphones or an earphone, the speaker on the camcorder is silent.

To view the playback picture in the viewfinder
Close the LCD panel. The viewfinder turns on automatically. When using the viewfinder, you can monitor sound only by using headphones or an earphone.
To view on the LCD screen again, open the LCD panel. The viewfinder turns off automatically.

Note on the lens cover
The lens cover does not open when the POWER switch is set to VTR/PLAYER. Do not open the lens cover manually. It may cause malfunction.

Various playback modes

You can enjoy clear pictures on the LCD screen during still, slow and picture search. **(Crystal-clear still/slow/picture search)**

To view a still picture (playback pause)

Press ❚❚ during playback. To resume playback, press ❚❚ or ▶.

To locate a scene (picture search)

Keep pressing ◀◀ or ▶▶ during playback. To resume normal playback, release the button.

To monitor the high-speed picture while advancing the tape or rewinding (skip scan)

Keep pressing ◀◀ while rewinding or ▶▶ while advancing the tape. To resume normal playback, press ▶.

To view the picture at 1/5 speed (slow playback)

Press ❙▶ on the Remote Commander during playback. To resume normal playback, press ▶. If slow playback lasts for about 1 minute, it shifts to normal speed automatically.

To select the playback sound

– CCD-TRV65/TRV615 only

Change the "HiFi SOUND" mode setting in the menu system.

Notes on playback

- Noise may appear when you use the crystal-clear still/slow/picture search function to play back the tape recorded in LP mode.
- Streaks appear and the sound is muted in the various playback modes.
- When playback pause mode lasts for 5 minutes, the camcorder automatically enters stop mode.
- You can play back the tapes recorded in the Hi8 video system on the standard 8 mm camcorder (CCD-TRV15/TRV25/TRV35/TRV215 only).

Searching for the end of the picture

You can go to the end of the recorded portion after you record and play back the tape to make the transition between the last scene you recorded and the next scene smooth. The tape starts rewinding or fast-forwarding and the last 5 seconds (10 seconds in LP mode) of the recorded portion play back. Then the tape stops at the end of the recorded picture **(End Search)**.

Note that the End Search function does not work once you eject the cassette after you have recorded on the tape.

(1) While pressing OPEN, open the LCD panel.

(2) Press END SEARCH.

This function works when the POWER switch is set to either CAMERA or VTR/PLAYER.



If you start recording after using END SEARCH

Occasionally, the transition between the last scene you recorded and the next scene may not be smooth.

Advanced operations

Using alternative power sources

You can choose any of the following power sources for your camcorder: battery pack, house current, alkaline batteries (CCD-TRV15/TRV25/TRV35/TRV65 only) and 12/24 V car battery. Choose the appropriate power source depending on where you want to use your camcorder.

Place	Power source	Accessory to be used
Indoors	House current	Supplied AC power adaptor
Outdoors	Battery pack	Battery pack NP-F330 (supplied), NP-F530, NP-F550, NP-F730, NP-F730H, NP-F750, NP-F930, NP-F950
	Size AA (LR6) Alkaline battery	Supplied battery case (CCD-TRV15/TRV25/TRV35/TRV65 only)
In the car	12 V or 24 V car battery	Sony car battery charger DC-V515A

Notes on power sources

- Disconnecting the power source or removing the battery pack during recording or playback may damage the inserted tape.
- The DC IN jack has power source priority. This means that the battery pack cannot supply any power if the power cord is connected to the DC IN jack, even when the power cord is not plugged into a wall outlet.

Using the house current

(1) Open the DC IN jack cover, and connect the AC power adaptor to the DC IN jack on the camcorder.

(2) Connect the power cord to the AC power adaptor.

(3) Connect the power cord to a wall outlet.



WARNING

The power cord must only be changed at a qualified service shop.

PRECAUTION

The set is not disconnected from the AC power source (house current) as long as it is connected to the wall outlet, even if the set itself has been turned off.

Note

Keep the AC power adaptor away from the camcorder if the picture is disturbed.

Using alkaline batteries

– CCD-TRV15/TRV25/TRV35/TRV65 only

Use the battery case (supplied) and six size AA (LR6) Sony Alkaline batteries (not supplied).

(1) Remove the battery holder from the battery case.

(2) Insert six new alkaline batteries into the battery holder, following the marking on the holder to be sure the batteries are installed in the correct direction.

(3) Insert the battery holder with the alkaline batteries.

(4) Insert the battery case with the alkaline batteries to the battery mounting surface of the camcorder in the same way as the battery pack.



Battery life

Using alkaline batteries at 77°F (25°C).

Upper numbers are the time when recording with the viewfinder. Lower numbers are the time when recording with the LCD screen.

CCD-	TRV15	TRV25/TRV35	TRV65
Continuous recording time	305 min. 210 min.	285 min. 200 min.	265 min. 190 min.
Typical recording time	160 min. 115 min.	150 min. 110 min.	140 min. 100 min.

PRECAUTION

When the battery case is installed with the camcorder, do not connect the AC power adaptor to the camcorder.

Notes

- You may not use the battery case in cold environment.
- The battery life may be shorter depending on the using environment.
- The above battery lives are estimates. The battery life may be shorter depending on the storage condition of the battery before being purchased and temperature.

To remove the battery case

The battery case is removed in the same way as the battery pack.

When you replace the batteries, be sure to remove the battery case from the camcorder to prevent malfunction.

Remove the battery case after using it.

Using a car battery

Use Sony DC-V515A car battery charger (not supplied). Connect the car battery cord to the cigarette lighter socket of a car (12 V or 24 V).
Refer to the operating instructions of your car battery charger.

To remove the car battery charger
The car battery charger is removed in the same way as the battery pack.

This mark indicates that this product is a genuine accessory for Sony video products.
When purchasing Sony video products, Sony recommends that you purchase accessories with this "GENUINE VIDEO ACCESSORIES" mark.

Changing the mode settings

You can change the mode settings in the menu system to further enjoy the features and functions of the camcorder.

(1) Press MENU to display the menu.
(2) Turn the control dial to select the desired icon in the left side of the menu, then press the dial.
(3) Turn the control dial to select the desired item, then press the dial.
(4) Turn the control dial to select the desired mode, and press the dial. If you want to change the other modes, repeat steps 3 and 4. If you want to change the other items, select ⮐ RETURN and press the dial, then repeat steps from 2 to 4.
(5) Press MENU or select ⮐ icon to erase the menu display.



Note on the menu display
Depending on the model of your camcorder, the menu display may be different from that in this illustration.

Notes on changing the mode setting
- Menu items differ depending on the setting of the POWER switch to VTR/PLAYER or CAMERA.
- When you let the subject monitor the shot (mirror mode), the menu display does not appear.

Selecting the mode setting of each item

Items for both CAMERA and VTR/PLAYER modes

LCD B. L.* <BRT NORMAL/BRIGHT>
- Normally select BRT NORMAL.
- Select BRIGHT when the LCD screen is dark.

When you select BRIGHT, battery life is about 10 percent shorter during recording. When you use the power sources other than the battery pack, BRIGHT is automatically selected, and LCD B.L. is not displayed in the menu.

LCD COLOR*
Select this item to adjust the color on the LCD screen.

REC MODE* <SP/LP>
- Select SP when recording in SP (standard play) mode.
- Select LP when recording in LP (long play) mode.

When a tape recorded on this camcorder in LP mode is played back on other types of 8mm camcorders or VCRs, the playback quality may not be as good as that on this camcorder.
In PLAYER mode, this item is not displayed in the menu (CCD-TRV15/TRV25/TRV35/TRV215 only).

REMAIN* <AUTO/ON>
- Select AUTO when you want to display the remaining tape bar
  - for about 8 seconds after the camcorder is turned on and calculates the remainder of the tape.
  - for about 8 seconds after a cassette is inserted and the camcorder calculates the remainder of the tape.
  - for about 8 seconds after ▶ is pressed in VTR/PLAYER mode.
  - for about 8 seconds after DISPLAY is pressed to display the screen indicators.
  - for the period of tape rewinding, forwarding or picture search in VTR/PLAYER mode.
- Select ON to always display the remaining tape indicator.

AUTO TV ON* <ON/OFF> (CCD-TRV35/TRV65/TRV615 only)
You can use this feature only with Sony TVs.
- Select ON to turn on the TV automatically when using the LASER LINK function.
- Select OFF not to turn on the TV.

TV INPUT* <VIDEO1/VIDEO2/VIDEO3/OFF> (CCD-TRV35/TRV65/TRV615 only)
Select 1 or 2 or 3 of the video input on the TV which the IR receiver (not supplied) is connected to when using the LASER LINK function.

LTR SIZE* <NORMAL/2x>
- Normally select NORMAL.
- Select 2x to display selected menu item by twice size of normal.

BEEP* <ON/OFF>
- Select ON so that beeps sound when you start/stop recording, etc.
- Select OFF when you do not want to hear the beep sound.

COMMANDER <ON/OFF>
- Select ON when using the supplied Remote Commander for the camcorder.
- Select OFF when not using the Remote Commander.

DISPLAY* <LCD or V-OUT/LCD>
- Normally select LCD. The display appears on the LCD screen.
- Select V-OUT/LCD to show the display both on the TV screen and LCD screen.

INDICATOR* <BL ON/BL OFF> (CCD-TRV65/TRV615 only)
- Select BL ON to light up the display window.
- Select BL OFF to turn off the back light of display window.

When you use the AC power adaptor as a power source, this item is not displayed in the menu.

Items for CAMERA mode only

D ZOOM* <ON/OFF>
- Select ON to activate digital zooming.
- Select OFF to not use the digital zoom. The camcorder goes back to 16x (CCD-TRV15/TRV25/TRV215) or 18x (CCD-TRV35/TRV65/TRV615) zoom.

16:9WIDE* <OFF/CINEMA/16:9FULL>
- Normally select OFF.
- Select CINEMA to record in CINEMA mode.
- Select 16:9FULL to record in 16:9FULL mode.

STEADYSHOT* <ON/OFF> (CCD-TRV25/TRV35/TRV65/TRV215/TRV615 only)
- Normally select ON.
- Select OFF to release the Steady Shot function.

N.S.LIGHT* <ON/OFF> (CCD-TRV35/TRV65/TRV615 only)
- Normally select ON.
- Select OFF to not use the NightShot Light function.

WIND <ON/OFF> (CCD-TRV65/TRV615 only)
- Select ON to reduce wind noise when recording in strong wind.
- Normally select OFF.

ORC TO SET*
Select this item to automatically adjust the recording condition to get the best possible recording.
If you have already performed this function, "ORC ON" is displayed.

CLOCK SET*
Reset the date or time.

AUTO DATE* <ON/OFF>
- Select ON to record the date for 10 seconds after recording has started.
- Select OFF to not record the date.

DEMO MODE* <ON/OFF>
- Select ON to make the demonstration appear.
- Select OFF to deactivate the demonstration mode.

Notes on DEMO MODE
- DEMO MODE is set to STBY (Standby) at the factory and the demonstration starts about 10 minutes after you set the POWER switch to CAMERA without inserting a cassette.
  Note that you cannot select STBY of DEMO MODE in the menu system.
- You cannot select DEMO MODE when a cassette is inserted in the camcorder.
- If you insert a cassette during the demonstration, the demonstration stops. You can start recording as usual. DEMO MODE automatically returns to STBY.
- When NIGHTSHOT is set to ON, "NIGHTSHOT" appears in the viewfinder or on the LCD screen and you cannot select DEMO MODE (CCD-TRV35/TRV65/TRV615 only).

To look at the demonstration at once
Eject the cassette, if inserted. Select ON of DEMO MODE and erase the menu display. The demonstration will begin.
When you turn off the camcorder once, DEMO MODE automatically returns to STBY.

ETC WORLD TIME*
Select this item to set the clock by a time difference.

ETC REC LAMP* <ON/OFF>
- Select OFF when you do not want the camera recording/battery lamp at the front of the unit to light up.
- Normally select ON.

Items for VTR/PLAYER mode only

HiFi SOUND <STEREO/1/2> (CCD-TRV65/TRV615 only)
- Normally select STEREO.
- Select 1 or 2 to play back a dual sound track tape.

/ EDIT <ON/OFF>
- Select ON to minimize picture deterioration when editing.
- Normally select OFF.

TBC* <ON/OFF> (CCD-TRV65/TRV615 only)
- Normally select ON, to correct for jitter.
- Select OFF to not correct for jitter. The picture may not be steady when played back.

Note on TBC setting
Set TBC to OFF when:
- Playing back a tape you have dubbed over.
- Playing back a tape on which you recorded the signal of a TV game or similar machine.
- The playback picture fluctuates.

DNR* <ON/OFF> (CCD-TRV65/TRV615 only)
- Normally select ON to reduce picture noise.
- Select OFF if the picture has a lot of movement, causing a conspicuous afterimage.

The following settings work only during playback
EDIT, HiFi SOUND, TBC, and DNR.

* These settings are retained even when the battery is removed, as long as the lithium battery is in place.

Shooting with backlighting

When you shoot a subject with the light source behind the subject or a subject with a light background, use the BACK LIGHT function.

Press BACK LIGHT. The ▨ indicator appears in the viewfinder or on the LCD screen.



[a] Subject is too dark because of backlight.
[b] Subject becomes bright with backlight compensation.

After shooting

Be sure to release this adjustment condition by pressing BACK LIGHT again. The ▨ indicator disappears. Otherwise, the picture will be too bright under normal lighting condition.

This function is also effective under the following conditions:
- A subject with a light source nearby or a mirror reflecting light
- A white subject against a white background. Especially when you shoot a person wearing shiny clothes made of silk or synthetic fiber, his or her face tends to become dark if you do not use this function.

To make a fine adjustment

You can adjust the exposure manually. However, when you adjust the exposure manually, BACK LIGHT does not operate.

Using the FADER function

– CCD-TRV35/TRV65/TRV615 only

Selecting the fader function

You can fade in or out to give your recording a professional appearance.
When the picture fades in, the sound gradually increases. When the picture fades out, the sound gradually decreases.



MONOTONE
When fading in, the picture gradually changes from black and white to color.
When fading out, the picture gradually changes from color to black and white.

* CCD-TRV65/TRV615 only

Using the fader function

When fading in [a]

(1) While the camcorder is in Standby mode, press FADER until the desired fade indicator flashes.
(2) Press START/STOP to start recording. The fade indicator stops flashing.

When fading out [b]

(1) During recording, press FADER until the desired fade indicator flashes.
(2) Press START/STOP to stop recording. The fade indicator stops flashing, and then recording stops.

The fading mode selected last is indicated first of all.



Note on the bounce function
When you use the following functions or D ZOOM is set to ON in the menu system, "BOUNCE" indicator does not appear.
- Wide mode
- Functions using the PICTURE EFFECT button
- Functions using the PROGRAM AE button

To cancel the fader function

Before pressing START/STOP, press FADER until the indicator disappears.

When the date or time indicator or title is displayed
The date or time indicator and title do not fade in or fade out.

When the START/STOP MODE switch is set to 5SEC or ⊥
You cannot use the fader function.

Note on the fader function
While using the bounce function, you cannot use the following functions.
- Exposure
- Focus
- Zoom

Shooting in the dark (NightShot)

– CCD-TRV35/TRV65/TRV615 only

The NightShot function enables you to shoot a subject in a dark place. You can achieve a satisfactory recording of the ecology of nocturnal animals for observation with this function.
This function may record picture nearly in monochrome.



(1) While the camcorder is in Standby mode, slide NIGHTSHOT to ON.
(2) Press START/STOP to start recording.
◘ and "NIGHTSHOT" indicators flash.



To cancel the NightShot function

Slide NIGHTSHOT to OFF.

Using the N.S.Light

When you set N.S.LIGHT to ON in the menu system, the picture will be more clear. The maximum limit of NightShot Light is about 10 feet (about 3 meters).

Notes on the NightShot
- When you keep setting NIGHTSHOT to ON in normal recording, picture may be recorded in incorrect/unnatural color.
- If focusing is difficult with the autofocus mode when using the NightShot function, focus manually.

Using the wide mode function

Selecting the desired mode

You can record a cinemalike picture (CINEMA) or a 16:9 wide picture to watch on the 16:9 wide-screen TV (16:9 FULL).



CINEMA
Black bands appear at the top and the bottom of the screen, and the viewfinder or LCD screen **[a]** and a normal TV screen **[b]** look wide. You can also watch the picture without black bands on a wide-screen TV **[c]**.

16:9 FULL
The picture in the viewfinder or LCD screen **[d]** or on a normal TV **[e]** is horizontally compressed. You can watch the picture of normal images on a wide-screen TV **[f]**.

Using the wide mode function

You can select the wide mode (OFF, CINEMA, 16:9FULL) in the menu system (p. 29).

To cancel wide mode

Select OFF in the menu system.

To watch the tape recorded in wide mode

To watch the tape recorded in CINEMA mode, set the screen mode of the wide-screen TV to zoom mode. To watch the tape recorded in 16:9 FULL mode, set it to full mode. For details, refer to the instruction manual of your TV.
Note that the picture recorded in 16:9 FULL mode looks compressed on a normal TV.

Notes on wide mode
- If wide mode is set to 16:9FULL, the Steady Shot function does not work and the '✋' indicator flashes (CCD-TRV25/TRV35/TRV65/TRV215/TRV315/TRV615 only).
- In wide mode, you cannot select the bounce function with FADER (CCD-TRV35/TRV65/TRV615 only).
- When you record in 16:9 FULL mode, the date or time indicator will be widened on the wide-screen TV.
- If you dub a tape, the tape is copied in the same mode as the original recording.
- The wide mode is cancelled automatically 5 minutes after you remove the power source.
- When recording, you cannot change the mode.

Using the PROGRAM AE function

Selecting the best mode

You can select one of six PROGRAM AE (Auto Exposure) modes to suit your shooting situation, referring to the following.



● Spotlight mode
For subjects in spotlight, such as at the theater or a formal event.

Soft Portrait mode
For zooming in on a still subject in telephoto mode, or for a subject behind an obstacle such as a screen. Creates a soft background for subjects such as people or flowers, and faithfully reproduces skin color.

Sports Lesson mode
For recording fast-moving subjects such as in tennis or golf games.

Beach & Ski mode
For people or faces in strong light or reflected light, such as at a beach in midsummer or on a ski slope.

Sunset & Moon mode
For recording subjects in dark environments such as sunsets, fireworks, neon signs, or general night views.

Landscape mode
For distant subjects such as mountains or when recording a subject behind an obstacle such as a window or screen.

Using the PROGRAM AE function

(1) Press PROGRAM AE.
(2) Turn the control dial to select the desired PROGRAM AE mode.



To turn off program AE

Press PROGRAM AE.

Notes on focus setting

- In the Spotlight, Sports lesson and Beach & Ski modes, you cannot take close-ups because the camcorder is set to focus only on subjects in the middle to far distance.
- In the Sunset & Moon and Landscape modes, the camcorder is set to focus only on distant subjects.

Focusing manually

– CCD-TRV35/TRV65/TRV615 only

When to use manual focus

In the following cases you should obtain better results by adjusting the focus manually.

[a]



[b]



[c]



[d]



- Insufficient light **[a]**
- Subjects with little contrast - walls, sky, etc. **[b]**
- Too much brightness behind the subject **[c]**
- Horizontal stripes **[d]**
- Subjects through frosted glass
- Subjects beyond nets, etc.
- Bright subject or subject reflecting light
- Shooting a stationary subject when using a tripod

Focusing manually

When focusing manually, first focus in telephoto before recording, and then reset the shot length.

(1) Set FOCUS to MANUAL. The indicator appears in the viewfinder or on the LCD screen.
(2) Move the power zoom lever to the "T" side on the optical zoom zone until the lever reaches the end.
(3) Turn the NEAR/FAR dial to achieve a sharp focus.
(4) Set the desired shot length using the power zoom lever.



To return to autofocus mode

Set FOCUS to AUTO. The indicator in the viewfinder or on the LCD screen disappears.

Shooting in relatively dark places
Shoot at wide-angle after focusing in the telephoto position.

To record a very distant subject

Push FOCUS down to INFINITY. The lens focuses on the most distant subject while FOCUS is held down. When it is released, manual focus mode is resumed.
Use this function when shooting through a window or a screen, to focus on a most distant subject.

Note on manual focusing
The following indicators may appear:
▲ when recording a very distant subject.
● when the subject is too close to focus on.

Enjoying picture effect

Selecting picture effect

You can make pictures like those of television with the Picture Effect function.



PASTEL [a]
The contrast of the picture is emphasized, and the picture looks like an animated cartoon.

NEG. ART [b]
The color and brightness of the picture is reversed.

SEPIA
The picture is sepia.

B&W
The picture is monochrome (black and white).

SOLARIZE [c]
The light intensity is more clear, and the picture looks like an illustration.

MOSAIC [d]
The picture is mosaic.

SLIM [e]
The picture expands vertically.

STRETCH [f]
The picture expands horizontally.

Using picture effect function

(1) Press PICTURE EFFECT.
(2) Turn the control dial to select the desired picture effect mode.



To turn off picture effect

Press PICTURE EFFECT. The indicator in the viewfinder or on the LCD screen goes out.

Note on the picture effect
When you turn the power off, the camcorder returns automatically to normal mode.

Adjusting the exposure

– CCD-TRV35/TRV65/TRV615 only

When to adjust the exposure

Adjust the exposure manually under the following cases.



[a]
- The background is too bright (back lighting)
- Insufficient light: most of the picture is dark

[b]
- Bright subject and dark background
- To record the darkness faithfully

Adjusting the exposure

(1) Press EXPOSURE.
(2) Turn the control dial to adjust the brightness.



To return to automatic exposure mode

Press EXPOSURE again.

Shooting with the sun behind you
If the light source is behind your subject, or in the following situations, the subject will be recorded too dark.
- The subject is indoors and there is a window behind the subject.
- Bright light sources are included in the scene.
- When shooting a person wearing white or shiny clothes in front of a white background, the face will be recorded too dark.

Shooting in the dark
We recommend you to use a video light (not supplied). To get the best color, you must maintain a sufficient light level.

When you adjust the exposure manually
- BACK LIGHT does not work.
- If you change the PROGRAM AE mode, the camcorder automatically returns to automatic exposure mode.

Superimposing a title

You can select one of eight preset titles and two custom titles. You can also select the language, color, size and position of titles.

Superimposing titles

(1) Press TITLE to display the title menu.
(2) Turn the control dial to select 🗀, then press the dial.
(3) Turn the control dial to select the desired title, then press the dial. The titles are displayed in the language you selected.
(4) Turn the control dial to select the color, size, or position, then press the dial.
(5) Turn the control dial to select the desired item, then press the dial.
(6) Repeat step 4 and 5 until the title is arranged as desired.
(7) Press control dial again to complete the setting.
(8) When you want to stop recording the title, press TITLE.



To superimpose the title from beginning
After step 7, press START/STOP to start recording.

To superimpose the title while you are recording
After pressing START/STOP to start recording, start from step 1. In this case, beep is not heard.

To select the language of preset title
When you want to select the language, select ◙ before step 2. Then select language and return to step 2.

To use the custom title
When you want to use the custom title, select ▭ in step 2.

Notes on superimposing a title
- If you have not given any custom title, "– – – – ..." appears on the display.
- The FADER function works while the title is displayed, however, the title does not fade (CCD-TRV35/TRV65/TRV315/TRV615 only).
- If you display the menu or title menu while superimposing a title, the title is not recorded while the menu or title menu is being displayed.

Title color changes as follows :
WHITE ←→ YELLOW ←→ VIOLET ←→ RED ←→ CYAN ←→ GREEN ←→ BLUE

Title size changes as follows :
SMALL ←→ LARGE

Title position changes as follows :
When you select the title size "SMALL", you can choose 9 positions. When you select the title size "LARGE" you can choose 8 positions.

Notes on the title
- Depending on size or position of the title, both of date and time or either of them is not displayed.
- If you input 13 characters or more for a LARGE title, the title is automatically reduced into a proper size after the position is set.
- When the title is displayed, LCD BRIGHT and VOLUME indicators do not appear.

Making your own titles

You can make up to two titles and store them in the camcorder. We recommend to set the POWER switch to VTR/PLAYER or eject the cassette before you begin.
Your title can have up to 20 characters.
(1) Press TITLE to display the title menu.
(2) Turn the control dial to select 1⊘, then press the dial.
(3) Turn the control dial to select the first line (CUSTOM1) or second line (CUSTOM2), then press the dial.
(4) Turn the control dial to select the column of the desired character, then press the dial.
(5) Turn the control dial to select the desired character, then press the dial.
(6) Repeat step 4 and 5 until you finish the title.
(7) For finishing the titling work, turn the control dial to select SET, then press the dial.



To edit a title you have stored
In step 3, select CUSTOM1 or CUSTOM2, depending on which title you want to edit, then change the title.

Note
You can not enter over 20 characters title.

If you take 5 minutes or longer to enter characters while a cassette is in the camcorder
The power goes off automatically. Characters you have entered remain. Turn STANDBY down once and then up again, then proceed from step 1.

To delete a title
In step 4, turn the control dial to select [←] then press the dial. The last character is erased. Repeat this step until all characters are deleted. Do not erase the title by selecting empty spaces. If you do so, a title full of empty spaces is stored.

Recording with the date/time

Before you start recording or during recording, press DATE or TIME. You can record the date or time displayed in the viewfinder or on the LCD screen with the picture. Press DATE (or TIME), then press TIME (or DATE) to display the date and time together.
The clock is set to East Coast Standard time at the factory. You can reset the clock in the menu system.



To stop recording with the date and/or time
Press DATE and/or TIME again. The date and/or time indicator disappears. The recording continues.

Optimizing the recording condition

Use this feature to check the tape condition before recording, so that you can get the best possible picture (ORC).

(1) While the camcorder is in Standby mode, press MENU to display the menu.
(2) Turn the control dial to select 📼, then press the dial.
(3) Turn the control dial to select ORC TO SET, then press the dial.
"START/STOP KEY" flashes.
(4) Press START/STOP.
The camcorder takes about 5 to 10 seconds to check the tape condition and then returns to Standby mode.



Each time you insert the cassette

Perform the above procedures.

Notes on the ORC function

- When you set ORC TO SET, the recording on the tape is erased for about 0,1 second so that the camcorder can check the tape condition. Be careful when you use a recorded tape. The 0.1 second blank is erased if you record from the point where you set ORC TO SET for more than 2 seconds, or if you record over the blank.
- You cannot use this function on a tape with the red mark on the cassette exposed.

Releasing the STEADY SHOT function

– CCD-TRV25/TRV35/TRV65/TRV215/TRV615 only

When the Steady Shot function is working, the camcorder compensates for camera-shake.

You can release the Steady Shot function when you do not need to use the Steady Shot function. The "" indicator appear in the viewfinder or on the LCD screen. Do not use the Steady Shot function when shooting a stationary object with a tripod.
You can select ON or OFF in the menu system (p. 29).

To activate the Steady Shot function again

Set STEADYSHOT to ON in the menu system.

Notes on the Steady Shot function

- The Steady Shot function will not correct excessive camera-shake.
- When you set STEADYSHOT ON or OFF in the menu system, the exposure may fluctuate.
- Steady Shot does not operate in 16:9 FULL mode. If you set STEADYSHOT to ON in the menu system, the "" indicator flashes.

Watching on a TV screen

Connect the camcorder to your TV or VCR to watch the playback picture on the TV screen. When monitoring the playback picture by connecting the camcorder to your TV, we recommend you to use house current for the power source.

While playing back on a TV screen, close the LCD panel. Otherwise, picture distortion may occur.

Connecting directly to a TV/VCR with Video/Audio input jacks

When connecting the A/V connecting cable, make sure you connect the plug to jacks of the same color.
Open the jack cover. With using the supplied A/V connecting cable, connect the camcorder to the LINE IN inputs on the TV or VCR connected to the TV. Set the TV/VCR selector on the TV to VCR. When connecting to the VCR, set the input selector on the VCR to LINE.

CCD-TRV15/TRV25/TRV35/TRV215



CCD-TRV65/TRV615



– CCD-TRV65/TRV615 only
If your TV or VCR has an S video jack, connect using the S video cable (not supplied) **[a]** to obtain a high quality picture. If you are going to connect the camcorder using the S video cable (not supplied) **[a]**, you do not need to connect the yellow (video) plug of the A/V connecting cable **[b]**.

If your TV or VCR is a monaural type
– CCD-TRV65/TRV615 only
Connect only the white plug for audio on both the camcorder and the TV or the VCR. With this connection, the sound is monaural even in stereo model.

To connect to a TV or VCR without Video/Audio input jacks
Use an RFU-95UC RFU adaptor (not supplied).

Using the AV cordless IR receiver

–CCD-TRV35/TRV65/TRV615 only

Once you connect the AV cordless IR receiver (not supplied) having the ⚡ LASER LINK mark to your TV or VCR, you can easily view the picture on your TV. For details, refer to the operating instructions of the AV cordless IR receiver.
LASER LINK is a system which transmits and receives a picture and sound between video equipment having the ⚡ mark by using infrared rays.
LASER LINK is a trademark of Sony Corporation.

To play back on a TV

(1) After connecting your TV and AV cordless IR receiver, set the POWER switch on the AV cordless IR receiver to ON.
(2) Set the POWER switch on the camcorder to VTR/PLAYER.
(3) Turn the TV on and set the TV/VCR selector on the TV to VCR.
(4) Press LASER LINK. The lamp of the LASER LINK button lights up.
(5) Press ▶ on the camcorder to start playback.
(6) Point the LASER LINK emitter at the AV cordless IR receiver.

To cancel the LASER LINK function

Press LASER LINK.

If you use a Sony TV

- You can turn on the TV automatically when you press the LASER LINK or ▶ button. To do so, set the AUTO TV ON to ON in the menu system and turn the TV's main switch on, then do either of the following;
  - Point the LASER LINK emitter towards the TV's remote sensor and press LASER LINK.
  - Turn on the LASER LINK button and press ▶.
- You can switch the video input of the TV automatically to the one which the AV cordless IR receiver is connected. To do so, set the AUTO TV ON to ON and the TV INPUT to the same video input (1,2,3) in the menu system. With some models, however the picture and sound may be disconnected momentarily when the video input is switched.
- The above feature may not work with some TV models.

Note
When LASER LINK is activated (the LASER LINK button is lit), the camcorder consumes power. Press and turn off the LASER LINK button when it is not needed.

Editing onto another tape

You can create your own video program by editing with any other 8 8 mm, Hi8 Hi8, VHS VHS, SVHS S-VHS, VHSC VHSC, SVHSC S-VHSC, β Betamax or EDBeta ED Betamax VCR that has video/audio inputs.

Before editing

Connect the camcorder to the VCR using the supplied A/V connecting cable.
Set the input selector on the VCR to LINE, if available.
Set EDIT to ON in the menu system (p. 29).

Starting editing

Turn down the volume of the camcorder while editing. Otherwise, picture distortion may occur.
(1) Insert a blank tape (or a tape you want to record over) into the VCR, and insert your recorded tape into the camcorder.
(2) Play back the recorded tape on the camcorder until you locate the point just before where you want to start editing, then press II to set the camcorder in playback pause mode.
(3) On the VCR, locate the recording start point and set the VCR in recording pause mode.
(4) First press II on the camcorder, and after a few seconds press II on the VCR to start editing.

To edit more scenes

Repeat steps 2 to 4.

To superimpose the title while you are editing

You can superimpose the title while you are editing. Refer to "Superimposing a title" (p. 48).

To stop editing

Press ■ on both the camcorder and the VCR.

Note on Fine Synchro Edit
If you connect a video deck that has the Fine Synchro Edit feature to the LANC ⓛ jack of the camcorder, using a LANC cable (not supplied), the edit will be even more precise.

Recording from a VCR or TV

–CCD-TRV65/TRV615 only

You can record a tape from another VCR or a TV program from a TV that has video/audio outputs. Connect the camcorder to the VCR or TV using the supplied A/V cable. Turn down the volume of the camcorder while editing. Otherwise, picture distortion may occur.
(1) While pressing the small green button on the POWER switch, set it to VTR.
(2) Set DISPLAY to LCD in the menu system. Then press ● REC and the button on the right together on the camcorder at the point where you want to start recording.
In recording and recording pause mode, S video and VIDEO/AUDIO jacks automatically work as input jacks.



⇦ : Signal flow

If your VCR or TV has an S video jack, connect using the S video cable (not supplied) **[a]** to obtain a high quality picture.

If your VCR or TV is a monaural type, connect only the white plug for audio on both the camcorder and the VCR or TV.
If your VCR or TV does not have an S VIDEO OUT jack, connect cable **[b]**. Do not connect the S video cable (not supplied) **[a]** to the camcorder.

To stop recording
Press ■.

Note on recording
You cannot record a picture that has a copyright control signal for copyright protection of software. "COPY INHIBIT" appears if you try to record such a picture.

Changing the lithium battery in the camcorder

Your camcorder is supplied with a lithium battery installed. When the battery becomes weak or dead, the ⟲ indicator flashes in the viewfinder for about 5 seconds when you set the POWER switch to CAMERA. In this case, **replace the battery with a Sony CR2025 or Duracell DL-2025 lithium battery. Use of any other battery may present a risk of fire or explosion.** Discard used batteries according to the manufacturer's instructions.
The lithium battery for the camcorder lasts for about 1 year under normal operation. (The lithium battery that comes installed at the factory may not last 1 year.)



Notes on lithium battery

- **Keep the lithium battery out of the reach of children. Should the battery be swallowed, immediately consult a doctor.**
- Wipe the battery with a dry cloth to assure a good contact.
- Do not hold the battery with metallic tweezers, otherwise a short-circuit may occur.
- Note that the lithium battery has a positive (+) and a negative (–) terminals as illustrated. **Be sure to install the lithium battery so that terminals on the battery match the terminals on the camcorder.**



WARNING
The battery may explode if mistreated. Do not recharge, disassemble, or dispose of in fire.

Changing the lithium battery in the camcorder

Changing the lithium battery

When replacing the lithium battery, keep the battery pack or other power source attached. Otherwise, you will need to reset the date, time and other items in the menu system retained by the lithium battery.

(1) Open the LCD panel and open the lid of the lithium battery compartment.
(2) Push the lithium battery down once and pull it out from the holder.
(3) Install the lithium battery with the positive (+) side facing out. Close the lid.



Resetting the date and time

You can reset the date and time in the menu system.

(1) While the camcorder is in Standby mode, press MENU to display the menu.
(2) Turn the control dial to select 🖭, then press the dial.
(3) Turn the control dial to select CLOCK SET, then press the dial.
(4) Turn the control dial to adjust the desired year, then press the dial.
(5) Set the month, day, hour and minute by turning the control dial and pressing the dial.
(6) Press MENU to erase the menu display.



To correct the date and time setting

Repeat the above procedure.

To check the preset date and time

Press DATE to display the date indicator.
Press TIME to display the time indicator.
When you press the same button again, the indicator goes off.

The year changes as follows:

1997 ←→ 1998 ← ···· → 2029

Note on the time indicator
The internal clock of this camcorder operates on a 12-hour cycle.

- 12:00 AM stands for midnight.
- 12:00 PM stands for noon.

Simple setting of clock by time difference

You can easily set the clock for a local time by a time difference in the menu system.

(1) While the camcorder is the standby mode, press MENU to display the menu.
(2) Turn the control dial to select ETC, then press the dial.
(3) Turn the control dial to select WORLD TIME, then press the dial.
(4) Turn the control dial to set a time difference, and press the dial. The hour of clock changes in relation to a time difference which you set.
(5) Press MENU to erase the menu display.



Note on WORLD TIME
If the time is not set, WORLD TIME does not work.

Usable cassettes and playback modes

Selecting cassette types

– CCD-TRV65/TRV615 only
This Hi8 system is an extension of the standard 8 mm system, and was developed to realize higher picture quality.
You can use either Hi8 or standard 8 mm video cassette for this camera. When you use a Hi8 video cassette, the recording is made in the Hi8 system. When you use a standard 8 mm video cassette, the recording is made in the standard 8 mm system. Standard 8 mm video cassette is incapable of recording in the Hi8 system.
If you intend to use a standard 8 mm video recorder/player to play back a video tape, you are required to use a standard 8 mm video cassette for recording.

What is video 8 XR/video Hi8 XR

"XR", that is an abbreviation of "Extended Resolution", represents the new type of 8 mm camcorder that has the property to realize more quality picture compared with the conventional camcorders including the Hi8 models. You can record and play back pictures more clearly in detail with the "XR" camcorder.
Video tape recorded by a camcorder having the "XR" function shows excellent picture quality at maximum when it is played back by the "XR" camcorder.
When video tape recorded by this "XR" camcorder is played back by a conventional 8/Hi8 camcorder or when video tape recorded by a conventional 8/Hi8 camcorder is played back by this "XR" camcorder, the playback picture quality is in the normal quality of the 8/Hi8 camcorder.

When you play back

The playback mode (SP/LP) and system (Hi8/standard 8 mm) are selected automatically according to the format in which the tape has been recorded. The quality of the recorded picture in LP mode, however, will not be as good as that in SP mode.

Note on AFM HiFi stereo

– CCD-TRV65/TRV615 only
When you play back a tape, the sound will be in monaural if:

- You record the tape using this camcorder, then play it back on an AFM HiFi monaural video recorder/player.
- You record the tape on an AFM HiFi monaural video recorder, then play it back on this camcorder.

Foreign 8 mm video

Because the TV color systems differ from country to country, you may not be able to play back foreign pre-recorded tapes. Refer to the list of "Using your camcorder abroad" to check the TV color system of foreign countries.

Tips for using the battery pack

This section shows you how you can get the most out of your battery pack.

Preparing the battery pack

Always carry additional batteries

Have sufficient battery pack power to do 2 to 3 times as much recording as you have planned.

Battery life is shorter in a cold environment

Battery efficiency is decreased, and the battery will be used up more quickly, if you are recording in a cold environment.

To save battery power

Turn STANDBY down when not recording to save battery power.
A smooth transition between scenes can be made even if recording is stopped and started again. While you are positioning the subject, selecting an angle, or looking through the viewfinder lens or on the LCD screen, the lens moves automatically and the battery is used. The battery is also used when a tape is inserted or removed.

When to replace the battery pack

While you are using your camcorder, the remaining battery indicator decreases gradually as battery power is used up. Remaining time in minutes appears.

When the remaining battery indicator reaches the lowest point, the ▭ indicator may appear and start flashing in the viewfinder or on the LCD screen.
When the ▭ indicator changes from slow flashing to rapid flashing while you are recording, set the POWER switch to OFF on the camcorder and replace the battery pack. Leave the tape in the camcorder to obtain a smooth transition between scenes after the battery pack has been replaced.

Notes on the rechargeable battery pack

Caution

Never leave the battery pack in temperatures above 140°F (60°C), such as in a car parked in the sun or under direct sunlight.

The battery pack heats up

During charging or recording, the battery pack heats up. This is caused by energy that has been generated and a chemical change that has occurred inside the battery pack. This is not cause for concern and is normal.

Be sure to observe the following

- Keep the battery pack away from fire.
- Keep the battery pack dry.
- Do not open nor try to disassemble the battery pack.
- Do not expose the battery pack to any mechanical shock.

The life of the battery pack

If the battery indicator flashes rapidly just after turning on the camcorder with a fully charged battery pack, the battery pack should be replaced with a new fully charged one.

Charging temperature

You should charge batteries at temperatures from 50°F to 86°F (from 10°C to 30°C). Lower temperatures require a longer charging time.

Notes on the "InfoLITHIUM" battery pack

What is "InfoLITHIUM"

The "InfoLITHIUM" is a lithium ion battery pack which can exchange data with compatible video equipment about its battery consumption. Sony recommends that you use the "InfoLITHIUM" battery pack with video equipment having the ⓘ InfoLITHIUM mark.
When you use this battery pack with video equipment having the ⓘ InfoLITHIUM mark, the video equipment will indicate the remaining battery time in minutes*. However, if you use it with video equipment not having this mark, the remaining battery capacity will not be indicated in minutes.
"InfoLITHIUM" is a trademark of Sony Corporation.
* The indication may not be accurate depending on the condition and environment which the equipment is used under.

How the battery consumption is displayed
The power consumption of the camcorder changes depending on its use, such as how the autofocusing is working.
While checking the condition of the camcorder, the "InfoLITHIUM" battery pack measures the battery consumption and calculates the remaining battery power. If the condition changed drastically, the remaining battery indication may suddenly decrease or increase by more than 2 minutes.
Even if 5 to 10 minutes is indicated as the battery remaining time on the LCD screen or in the viewfinder, the ▭ indicator may also flash under some condition.

To obtain more accurate remaining battery indication
Set the camcorder to recording standby mode and point towards a stationary object. Do not move the camcorder for 30 seconds or more.

- If the indication seems incorrect, recharge the battery pack fully (Full charge[1]). Note that if you have used the battery in a hot or cold environment for long time, or you have repeated charging many times, the battery pack may not be able to show the correct time even after being fully charged.
- After you have used the "InfoLITHIUM" battery pack with an equipment not having the ⓘ InfoLITHIUM mark, make sure that you use up the battery pack on the equipment having the ⓘ InfoLITHIUM mark and then recharge fully.

Why the remaining battery indication does not match the continuous recording time in the operating instructions
The recording time is affected by the environmental temperature and conditions. The recording time becomes very short in a cold environment. The continuous recording time in the operating instructions is measured under the condition of using a fully charged (or normal charged) battery pack in 77°F (25°C). As the environmental temperature and condition are different when you actually use the camcorder, the remaining battery time is not same as the continuous recording time in the operating instructions.

[1] Full charge: Charging until FULL appears in the display window.

Maintenance information and precautions

Notes on the battery case

– CCD-TRV15/TRV25/TRV35/TRV65 only

- **Use only with alkaline batteries. You cannot use the battery case with manganese batteries or size AA (LR6) rechargeable NiCd batteries.**
- **Using with Sony alkaline batteries is preferable.**
- Battery life is remarkably shorter in a cold environment (lower than 50°F/10°C).
- Keep the metal part clean. If it gets dirty, wipe it with a soft cloth.
- Do not disassemble or convert the battery case.
- Do not expose the battery case to any mechanical shock.
- During recording, the battery case heats up. This is not cause for concern.
- Prevent the electrode in the battery case from coming in contact with a metal object.
- If you will not use the battery case for a long time, detach the battery case from the camcorder and remove the batteries from the battery case.

Moisture condensation

If the camcorder is brought directly from a cold place to a warm place, moisture may condense inside the camcorder, on the surface of the tape, or on the lens. In this condition, the tape may stick to the head drum and be damaged or the unit may not operate correctly. To prevent possible damage under these circumstances, the camcorder is furnished with moisture sensors. Please, take the following precautions.

Inside the camcorder

If there is moisture inside the camcorder, the beep sounds and the ▣ indicator flashes. If this happens, none of the functions except cassette ejection will work. Open the cassette compartment, turn off the camcorder, and leave it about 1 hour. When ⏏ indicator flashes at the same time, the cassette is inserted in the camcorder. Eject the cassette, turn off the camcorder, and leave also the cassette about 1 hour. The camcorder can be used again if the ▣ indicator does not appear when the power is turned on again.

On the lens

If moisture condenses on the lens, no indicator appears, but the picture becomes dim. Turn off the power and do not use the camcorder for about 1 hour.

How to prevent moisture condensation

When bringing the camcorder from a cold place to a warm place, put the camcorder in a plastic bag and allow it to adapt to room conditions over a period of time.

(1) Be sure to tightly seal the plastic bag containing the camcorder.
(2) Remove the bag when the air temperature inside it has reached the temperature surrounding it (after about 1 hour).

Video head cleaning

To ensure normal recording and clear pictures, clean the video heads. When the ⊗ *indicator* and "*CLEANING CASSETTE*" message appear one after another or playback pictures are "noisy" or hardly visible, the video heads may be dirty.

[a] Slightly dirty
[b] Very dirty

If this happens, clean the video heads with the Sony V8-25CLH/V8-25CLD cleaning cassette (not supplied). After checking the picture, if it is still "noisy," repeat the cleaning. (Do not repeat cleaning more than 5 times in one session.)

Caution

Do not use a commercially available wet-type cleaning cassette. It may damage the video heads.

Note

If the Sony V8-25CLH/V8-25CLD cleaning cassette is not available in your area, consult your nearest Sony dealer.

Removing dust from inside the viewfinder

(1) Remove the screw with a screwdriver (not supplied). Then, while sliding the RELEASE knob, turn the eyecup in the direction of the arrow and pull it out.
(2) Clean the surface with a commercially available blower.



To reattach the eyecup

(1) Align the groove on the eyecup with the • mark on the barrel.
(2) Turn the eyecup in the direction of the arrow. Then replace the screw.



Caution
Do not remove any other screws. You may remove only the screw to remove the eyecup.

Precautions

Camcorder operation

- Operate the camcorder on 7.2 V (battery pack) or 8.4 V (AC power adaptor).
- For DC or AC operation, use the accessories recommended in this manual.
- Should any solid object or liquid get inside the casing, unplug the camcorder and have it checked by a Sony dealer before operating it any further.
- Avoid rough handling or mechanical shock. Be particularly careful of the lens.
- Keep the POWER switch setting to OFF when not using the camcorder.
- Do not wrap up the camcorder and operate it since heat may build up internally.
- Keep the camcorder away from strong magnetic fields or mechanical vibration.
- Do not push the LCD screen.
- If the camcorder is used in a cold place, a residual image may appear on the LCD screen. This is not a malfunction.
- While using the camcorder, the back of the LCD screen may heat up. This is not a malfunction.

On handling tapes

Do not insert anything in the small holes on the rear of the cassette. These holes are used to sense the type of tape, thickness of tape and if the recording tab is in or out.

Camcorder care

- When the camcorder is not to be used for a long time, remove the tape. Periodically turn on the power, operate the camera and player sections and play back a tape for about 3 minutes.
- If fingerprints or debris make the LCD screen dirty, we recommend using a LCD Cleaning Kit (not supplied) to clean the LCD screen.
- Clean the lens with a soft brush to remove dust. If there are fingerprints on it, remove them with a soft cloth.
- Clean the camcorder body with a dry soft cloth, or a soft cloth lightly moistened with a mild detergent solution. Do not use any type of solvent which may damage the finish.
- Do not let sand get into the camcorder. When you use the camcorder on a sandy beach or in a dusty place, protect it from the sand or dust. Sand or dust may cause the unit to malfunction, and sometimes this malfunction cannot be repaired.

AC power adaptor

- Unplug the unit from the wall outlet when not in use for a long time. To disconnect the power cord, pull it out by the plug. Never pull the power cord itself.
- Do not operate the unit with a damaged cord or if the unit has been dropped or damaged.
- Do not bend the power cord forcibly, or put a heavy object on it. This will damage the cord and may cause a fire or electrical shock.
- Be sure that nothing metallic comes into contact with the metal parts of the connecting plate. If this happens, a short may occur and the unit may be damaged.
- *Always keep the metal contacts clean.*
- Do not disassemble the unit.
- Do not apply mechanical shock or drop the unit.
- While the unit is in use, particularly during charging, keep it away from AM receivers and video equipment because it will disturb AM reception and video operation.
- The unit becomes warm while in use. This is normal.
- Do not place the unit in locations that are:
  - Extremely hot or cold
  - Dusty or dirty
  - Very humid
  - Vibrating

Notes on dry batteries

To avoid possible damage from battery leakage or corrosion, observe the following.

- Be sure to insert the batteries in the correct direction.
- Dry batteries are not rechargeable.
- Do not use a combination of new and old batteries.
- Do not use different types of batteries.
- The batteries slowly discharge while not in use.
- Do not use a battery that is leaking.

If battery leakage occurred

- Wipe off the liquid in the battery case carefully before replacing the batteries.
- If you touch the liquid, wash it off with water.
- If the liquid get into your eyes, wash your eyes with a lot of water and then consult a doctor.

If any difficulty should arise, unplug the unit and contact your nearest Sony dealer.

Using your camcorder abroad

Each country or area has its own electric and TV color systems. Before using your camcorder abroad, check the following points.

Power sources

You can use your camcorder in any country or area with the supplied AC power adaptor within 100 V to 240 V AC, 50/60 Hz.
Use a commercially available AC plug adaptor **[a]**, if necessary, depending on the degign of the wall outlet **[b]**.



Difference in color systems

This camcorder is an NTSC system based camcorder. If you want to view the playback picture on a TV, it must be an NTSC system based TV.
Check the following list.

NTSC system
Bahama Islands, Bolivia, Canada, Central America, Chile, Colombia, Ecuador, Jamaica, Japan, Korea, Mexico, Peru, Surinam, Taiwan, the Philippines, the U.S.A., Venezuela, etc.

PAL system
Australia, Austria, Belgium, China, Czech Republic, Denmark, Finland, Germany, Great Britain, Holland, Hong Kong, Italy, Kuwait, Malaysia, New Zealand, Norway, Portugal, Singapore, Slovak Republic, Spain, Sweden, Switzerland, Thailand, etc.

PAL-M system
Brazil

PAL-N system
Argentina, Paraguay, Uruguay

SECAM system
Bulgaria, France, Guyana, Hungary, Iran, Iraq, Monaco, Poland, Russia, Ukraine, etc.

Self-diagnosis display

The camcorder has a self-diagnosis display.
This function displays the camcorder's condition with five digits (a combination of a letter and figures) in the viewfinder or on the LCD screen. If this occurs, check the following code chart. The five-digit display informs you of the camcorder's current condition. The last two digits (indicated by □□) will differ depending on the state of the camcorder.

LCD screen



Self-diagnosis display

- C:□□:□□
  You can service the camcorder yourself.
- E:□□:□□
  Contact your Sony dealer or local autorized Sony facilitiy.

Five-digit display	Cause and/or Corrective Actions
C:21:□□	• Moisture condensation has occurred. → Remove the cassette and leave the camcorder for at least 1 hour. (p. 67)
C:22:□□	• The video heads are dirty. → Clean the heads using the Sony V8-25CLH/V8-25CLD cleaning cassette (not supplied). (p. 68)
C:23:□□	• You are using a battery pack that is not an "InfoLITHIUM" battery pack. → Use an "InfoLITHIUM" battery pack. (p. 66)
C:31:□□ C:32:□□	• A servicable situation not malfunctioned above has occurred. → Remove the cassette and insert it again, then operate the camcorder. → Disconnect the power cord of the AC power adaptor or remove the battery pack. After reconnecting the power source, operate the camcorder.
E:61:□□ E:62:□□	• A camcorder malfunction which you cannot service has occurred. → Contact your Sony dealer or local authorized Sony service facility and inform them of the five digits. (example: E:61:10)

If you are unable to resolve the problem, contact your Sony dealer or local authorized Sony service facility.

Identifying the parts



1 **EDITSEARCH button** (p. 21)
2 **LASER LINK button** (CCD-TRV35/TRV65/TRV615 only) (p. 56)
3 **Intelligent accessory shoe** (CCD-TRV65/TRV615 only) (p. 80) / **Accessory shoe** (CCD-TRV35 only)
4 **Lens cover**
5 **POWER switch** (p. 13)
6 **FOCUS switch** (CCD-TRV35/TRV65/TRV615 only) (p. 43)
7 **NEAR/FAR dial** (CCD-TRV35/TRV65/TRV615 only) (p. 43)
8 **Video control buttons** (p. 22)
  - ■ STOP (stop)
  - ◀◀ REW (rewind)
  - ▶ PLAY (playback)
  - ▶▶ FF (fastforward)
  - ❚❚ PAUSE (pause)
  - ● REC (recording) (CCD-TRV65/TRV615 only)

9 **Power zoom lever** (p. 15)
10 **NIGHTSHOT switch** (CCD-TRV35/TRV65/TRV615 only) (p. 37)
11 **Display window** (p. 86)
12 **FADER button** (CCD-TRV35/TRV65/TRV615 only) (p. 36)
13 **Tripod receptacle** (p. 20)
Make sure that the length of the tripod screw is less than 9/32 inch (6.5 mm) otherwise, you cannot attach the tripod securely and the screw may damage the camcorder.

Identifying the parts



14 **Viewfinder** (p. 14)
15 **Speaker** (p. 23)
16 **LCD screen** (p. 17)
17 **LCD BRIGHT buttons** (p. 17)
18 **OPEN button** (p. 16)
19 **VOLUME buttons** (p. 22)
20 **Lithium battery compartment** (p. 60)
21 **Hook for shoulder strap** (p. 85)
22 **Eyecup**
23 **BATT RELEASE lever** (p. 7, 11)
24 **Hook for shoulder strap** (p. 85)
25 **STANDBY switch** (p. 13)
26 **START/STOP button** (p. 13)
27 **Battery mounting surface**
28 **DC IN jack** (p. 8, 26)

Note on the intelligent accessory shoe
–CCD-TRV65/TRV615 only
Supplies power to optional accessories such as a video light or microphone. The intelligent accessory shoe is linked to the STANDBY switch, allowing you to turn on and off the power supplied by the shoe. Refer to the instruction manual of the accessory for further information. To connect an accessory, press down and push it to the end, and then tighten the screw. To remove an accessory, loosen the screw, and then press down and pull out the accessory.
If the camcorder does not work correctly with using the AC power adaptor, use the battery pack.



29 **COUNTER RESET button** (p. 14)
30 **TIME button** (p. 51)
31 **DATE button** (p. 51)
32 **DISPLAY button** (p. 23)
33 **TITLE button** (p. 48)
34 **END SEARCH button** (p. 25)
35 **PICTURE EFFECT button** (p. 45)
36 **START/STOP MODE switch** (p. 16)
37 **BACK LIGHT button** (p. 34)
38 **PROGRAM AE button** (p. 41)
39 **EXPOSURE button** (CCD-TRV35/ TRV65/ TRV615 only) (p. 46)
40 **Control dial** (p. 29)
41 **MENU button** (p. 29)



42 **Eyecup RELEASE knob** (p. 69)
43 **EJECT switch** (p. 12)
44 **LANC ⓛ control jack**
ⓛ stands for Local Application Control Bus System. The ⓛ control jack is used for controlling the tape transport of video equipment and peripherals connected to it. This jack has the same function as the jack indicated as CONTROL L or REMOTE.
45 **Cassette compartment** (p. 12)
46 **Grip strap** (p. 19)
47 **RFU DC OUT (RFU adaptor DC output) jack** (p. 55)
48 **Viewfinder lens adjustment ring** (p. 14)
49 **S VIDEO jack** (CCD-TRV65/TRV615 only) (p. 55)
50 **VIDEO/AUDIO jacks** (p. 54)
51 **∩ (headphones) jack** (CCD-TRV65/ TRV615 only) (p. 23) **/⑨ (earphone) jack** (CCD-TRV15/TRV25/TRV35/ TRV215 (p. 23)



52 **MIC jack (PLUG IN POWER)**
Connect an external microphone (not supplied). This jack also accepts a "plug-in-power" microphone.
53 **Camera recording/battery lamp** (p. 13)
54 **LASER LINK emitter** (CCD-TRV35/ TRV65/ TRV615 only) (p. 56)
55 **Remote sensor** (p. 84)
Aim the Remote Commander here for remote control.
56 **Microphone**

To watch the demonstration

You can start the demonstration by setting DEMO MODE in the menu system.
You can also start the demonstration by the following operation.
When NIGHTSHOT is set to ON, you cannot watch the demonstration (CCD-TRV35/ TRV65/ TRV615 only).

To enter demo mode
(1) Eject the cassette and set the POWER switch to VTR/PLAYER.
(2) Turn STANDBY up to STANDBY.
(3) While holding down ► set the POWER switch to CAMERA.

To exit demo mode
(1) Set the POWER switch to VTR/PLAYER.
(2) Turn STANDBY up to STANDBY.
(3) While holding down ■ set the POWER switch to CAMERA.

Remote Commander

The buttons that have the same name on the Remote Commander as on the camcorder function identically.



1 **Transmitter**
Point toward the remote sensor to control the camcorder after turning on the camcorder.
2 **Video control buttons** (p. 22)
3 **DISPLAY button** (p. 23)
4 **START/STOP button** (p. 13)
5 **Power zoom button** (p. 15)

Notes on the Remote Commander
- Keep the remote sensor away from strong light sources such as direct sunlight or illumination. Otherwise, the remote control may not be effective.
- Be sure that there is no obstacle between the remote sensor on the camcorder and the Remote Commander.
- This camcorder works in commander mode VTR 2. The commander modes (1, 2 and 3) are used to distinguish this camcorder from other Sony VCRs to avoid remote control misoperation. If you use another Sony VCR in commander mode VTR 2, we recommend you change the commander mode or cover the remote sensor of the VCR with black paper.

To prepare the Remote Commander

Insert two size AA (R6) batteries by matching the + and – on the batteries to the diagram inside the battery compartment.



Note on battery life
The batteries for the Remote Commander last about 6 months under normal operation. When the batteries become weak or dead, the Remote Commander does not work.

To avoid damage from possible battery leakage
Remove the batteries when you will not use the Remote Commander for a long time.

Attaching the shoulder strap

Attach the supplied shoulder strap to the hooks for the shoulder strap .



Operation indicators

Viewfinder



Display window



1. **Recording mode indicator** (p. 30)/ **Mirror mode indicator** (p. 18)
2. **Playing back or recording in Hi8 format** (CCD-TRV65/TRV615 only) (p. 63)
3. **Remaining battery time indicator**



4. **Exposure indicator** (CCD-TRV35/ TRV65/ TRV615 only) (p. 46)/ **Zoom indicator** (p. 15)
5. **FADER indicator** (CCD-TRV35/TRV65/ TRV615 only) (p. 36)
6. **Wide mode indicator** (p. 39)
7. **PICTURE EFFECT indicator** (p. 45)
8. **LCD BRIGHT indicator** (p. 17) / **VOLUME indicator** (p. 22)
9. **PROGRAM AE indicator** (p. 40)
10. **Backlight indicator** (p. 34)
11. **WIND indicator** (CCD-TRV65/TRV615 only) (p. 31)
12. **Steady Shot off indicator** (CCD-TRV25/TRV35/TRV65/TRV215/ TRV615 only) (p. 53)
13. **Manual focusing** (CCD-TRV35/ TRV65/ TRV615 only) (p. 43)
14. **Video control mode** (p. 13)
15. **Tape counter** (p. 14)/**Self-diagnosis functions indicator** (p. 76)/**5SEC mode indicator** (p. 16)
16. **Remaining tape indicator**



17. **END SEARCH indicator** (p. 25)
18. **NIGHTSHOT indicator** (CCD-TRV35/ TRV65/ TRV615 only) (p. 37)
19. **AUTO DATE indicator** (p. 13)/**Date indicator** (p. 51)
20. **Time indicator** (p. 51)
21. **Warning indicators** (p. 87)
22. **Recording lamp** (p. 13)
23. **Date or time indicator** (p. 51)/**Tape counter indicator** (p. 14)/**Self-diagnosis functions indicator** (p. 76)/**Remaining battery time indicator**
24. **FULL charge indicator** (p. 8)

Warning indicators

If indicators flash in the viewfinder or in the display window, check the following:
♪♪... : you can hear the beep sound when the BEEP is set to ON.



1. **The battery is weak or dead.**
   Slow flashing: The battery is weak.
   Fast flashing: The battery is dead.
2. **The tape is near the end.**
   The flashing is slow.
3. **The tape has run out.**
   The flashing becomes rapid.
4. **No tape has been inserted.**
5. **The tab on the tape is out (red).**
6. **Moisture condensation has occurred.**
7. **The video heads may be contaminated.**
8. **Some other trouble has occurred.**
   Use the self-diagnosis function (p. 76).
   If the display does not disappear contact your Sony dealer or local authorized Sony service facility.
9. **The lithium battery is weak or is not installed.**
10. **You tried to record a picture that has a copyright control signal.**
    (CCD-TRV65/TRV615 only) (P. 58)

SECTION 2
DISASSEMBLY

The eqipment can be removed using the following procedure


VIDEO CAMERA RECORDER
2-1 FRONT PANEL BLOCK VIDEO LIGHT BLOCK
2-8 EVF BLOCK-2(COLOR) (LB-5/VF-119/VF-120 BOARDS)
2-9 EVF BLOCK-2(B/W) (VF-99 BOARD)
2-11 CASSETTE LID ASSEMBLY
2-2 CABINET (R) BLOCK
2-3 EVF BLOCK-1
2-4 LCD BLOCK-2 (3-3,5INCH)
2-5 LCD BLOCK-2 (2,5INCH)
2-6 CF-51BOARD AND CONTROL SWITCH BLOCK(MR-8500)
2-7 CF-50BOARD AND CONTROL SWITCH BLOCK(MF-8500)
The [ ] means that each model has different operating procedure
2-10 CABINET (L) AND BATTERY PANEL BLOCK
2-13 ZOOM LENS BLOCK VL-19 BOARD
2-12 CONTROL SWITCH BLOCK (FK-8500)
2-14 DD-105/PJ-84 (PJ-83)BOARDS
2-15 VC-195/SE-67(SE-66) BOARDS

NOTE : Follow the disassembly procedure in the numerical order given

2-1. REMOVAL OF FRONT PANEL BLOCK AND VIDEO LIGHT BLOCK


TRV93
②Cabinet (LT)
①Two screws (M2x4)
③Screw (M2x4)
⑥Front panel block
⑧Video light block
⑤Two screws (M2x4)
⑦FP-629 flexible board CN303, 20P
Claw
④Screw (M2x4)
①Two screws (M2x4)
②Cabinet (S)
③Screw (M2x4)
⑥Front panel block
⑦FP-629 flexible board CN303, 20P
Claw
④Screw (M2x4)
⑤Two screws (M2x4)
EXCEPT TRV93

2-2. REMOVAL OF CABINET (R) BLOCK


Pin
⑥Connector
CN933,11P
②Two screws
(M2x4)
③Three screws
(M2x4)
④Cabinet (R) block
①Two screws (M2x4)
⑤Flat cable (FFC-236)
CN001, 50P
Hole (Night shot lever)

2-4. REMOVAL OF LCD BLOCK (3/3.5 INCH)


⑦LCD block
⑥Four tapping screws
⑤Connector
CN005,12P
⑧Hinge ground plate
④Connector
CN006,6P
③IR knob
①Five tapping screws
②IR cover

2-3. REMOVAL OF EVF BLOCK


② VF flexible retainer sheet
③ Tapping screw
④ Tapping screw
⑤ VF base
⑦ Three
tapping screw
① FP-638 flexible board
CN007, 20P
(COLOR EVF MODEL)
① Flate cable(FCC-235)
CN008,4P
(B/W EVF MODEL)
⑥ Tilt-up the EVF block
to the direction of arrow.

2-5. REMOVAL OF LCD BLOCK (2.5 INCH)


⑦LCD block
⑥Four tapping screws
⑤Connector
CN005,12P
④Connector
CN006,6P
③IR knob
①Five tapping screws
②IR cover

2-6. REMOVAL OF CF-51 BOARD AND CONTOROL SWITCH BLOCK (MR-8500) (COLOR)


⑧Flat cable (FFC-236)
CN001, 50P
⑦FP-638 flexible board
CN007, 20P
(COLOR EVF MODEL)
⑦Flate cable(FCC-235)
CN008,4P
(B/W EVF MODEL)
④Five tapping screws
⑥Ground plate
⑤CF-51board
③Five tapping screws
②Control switc block(MR-8500) CN002,8P
①Tow tapping screws

2-7. REMOVAL OF CF-50 BOARD AND CONTOROL SWITCH BLOCK (MF-8500) (B/W)


⑧Flat cable (FFC-236)
CN001, 50P
⑨Flate cable(FCC-235)
CN008,4P
④Three tapping screws
⑦Connector
CN003,2P
⑥Ground plate
⑤CF-50board
③Five tapping screws
②Control switc block(MF-8500) CN002,8P
①Tow tapping screws

2-8. REMOVAL OF EVF BLOCK-2 (COLOR)


① Tilt-up the EVF block to the direction of arrow Ⓐ.
④ VF insullating sheet
⑤ FP-638 flexible board
CN5401,20P
③ Remove the EVF rear cabinet assembly to the direction of arrow Ⓑ.
⑩ Back light cushion
(Turn the cushion (Sponge rubber) face to the LB-54 board side for installation.)
⑭ VF-119 board
Four claws
⑥ FP-638 flexible board
CN5301,8P
VF lens assmebly
⑬ LCD Cushion (1)
② Two screws (M2x3)
Ⓑ
⑫ LCX024AK-5
⑪ Cushion
Three claws
Ⓐ
⑨ LB-54 board
⑦ VF light interception sheet
⑧ VF-120 board

2-9. REMOVAL OF EVF BLOCK-2 (B/W)


⑥ CRT holder assmebly
⑦ CRT assembly
③ Remove the EVF rear cabinet assembly
to the direction of arrow Ⓑ.
④ VF electrostatic sheet
② Three screws (M2x3)
Ⓑ
Ⓐ
⑧VF-99 board
⑤Flexible flat cable(FCC-235)
CN901,4P

① Tilt-up the EVF block to the direction of arrow Ⓐ.

2-10. REMOVAL OF CABINET (L) BLOCK AND BATTERY PANEL BLOCK


④ Battery panel block
① Connector
CN801,7P
⑥ Screw (M2x3)
⑤Control switch block
③ Screw (M2x4)
⑧ Flexible connector
CN934,12P
⑦ Cabinet(L)block
② Screw (M2x4)

2-11. REMOVAL OF CASSETTE LID ASSEMBLY


①Two screws (M2x4)
②Cassette lid assembly

2-12. REMOVAL OF CONTROL SWITCH BLOCK (FK-8500)


① Remove the Control switch block (FK-8500) in the direction of arrow with pushing the claw.
Screwdriver(−)
Two claws
Two claws
②Flexible connector
CN935, 10P

2-13. REMOVAL OF ZOOM LENS BLOCK AND VL-19 BOARD


CCD-TRV93
⑦Two screws
(M2x3)
⑧Shoe bracket
③Screw (M2x3)
⑤FP-623 flexible board
CN501, 16P
④Zoom lens block
⑥Lens flexible board
CN551, 23P
①Screw
(M2x3)
②Screw
(M2x3)
⑨FP-632 flexible board
(VC side)CN909, 10P
(VL side)CN151, 8P
⑧VL-19
board
⑦Screw (M2x3)
CCD-TRV93

2-14. REMOVAL OF DD-105 BOARD AND PJ-84 (PJ-83) BOARD


②Three screws (M2 x 3)
①FP-622 flexible board
CN932,16P
CN931,48P
④FP-621 flexible board
CN902,12P
③DD-105 board
⑥PJ-83 board
⑤Two screws (M2 x 4)
EXCEPT CCD-TRV85/
TRV815/TRV93
⑥PJ-84 board
⑤Two screws (M2 x 4)
CCD-TRV85/TRV815/
TRV93

2-15. REMOVAL OF VC-195 AND SE-67 (SE-66) BOARD


① FP-220 flexible board
CN105, 8P from loading motor
② Flexible board
CN101, 16P
from video head
⑦ FP-629 flexible board
⑪ Screw (M2x3)
③ Flexible board
CN104, 10P
from drum motor
⑧ FP-621 flexible board
CN902,12P
⑨ FP-620 flexible board
CN904,10P
④ FP-248 flexible board
CN103, 12P
⑩ Three screws (M2x3)
⑬ Four screws (M2x3)
⑫ VC-195 board
⑤ FP-221 flexible board
CN102, 15P
⑭ SE-67/SE-66 board
⑥ FP-622 flexible board
CN912,16P

2-16. SERVICE POSITION

PREPARATION; Refer to the previous section “DISASSMBLY”, and connect as shown in the figure after each parts has been removed.


J-6082-188-A
EXTENSION CORD
J-6082-382-A
CPC-7 Jig
Screw(M2x4)

2-17. CIRCUIT BOARDS LOCATION

2.5 INCH LCD MODEL : CCD-TRV15/TRV15E/TRV15EP/
TRV15PK/TRV25/TRV25PK/
TRV35/TRV35E/TRV65/
TRV65PK/TRV215/TRV615
3 INCH LCD MODEL : CCD-TRV93
3 5 INCH LCD MODEL : CCD-TRV85/TRV815




VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3.5 INCH LCD MODEL)
(CCD IMAGER)
MA-311/331 (2.5 INCH LCD MODEL)
MA-312 (3 INCH/3 5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
CF-50 (2.5 INCH LCD MODEL)
CF-51 (3 INCH/3.5 INCH LCD MODEL)
(CONTROL)
PJ-83 (2.5 INCH LCD MODEL)
PJ-84 (3 INCH/3.5 INCH LCD MODEL)
(AV IN/OUT)


LB-54
(BACK LIGHT)
VF-120
(COLOR EVF)
PD-92 (2 5 INCH LCD MODEL)
PD-93 (3 INCH/3 5 INCH LCD MODEL)
(RGB DECODER, LCD, LCD DRIVE, BACK LIGHT)
VL-19
(VIDEO LIGHT)
VC-195
CAMERA, Y/C PROCESSOR,VIDEO IN/OUT,
REC/PB HEAD AMP,SERVO/SYSTEM CONTROL,
SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
SE-66 (2.5 INCH LCD MODEL)
SE-67 (3 INCH/3 5 INCH LCD MODEL)
(STEADY SHOT)

SECTION 3
BLOCK DIAGRAMS

3-1. OVERALL BLOCK DIAGRAM

CD-197 BOARD
CD-198 BOARD
IC401
VC-195 BOARD
IC501
IC551
IC552
SE-66 BOARD
SE-67 BOARD
IC451
PJ-83 BOARD
PJ-84 BOARD
IC151
IC502
IC202
IC204
IC201
IC152
IC001
IC401
IC301
IC321
IC322
IC751
IC301
MA-311 BOARD(1/2)
MA-331 BOARD(1/2)
MA-312 BOARD(1/2)
CONTROL SWITCH BLOCK (CF-50)(1/2)
CONTROL SWITCH BLOCK (CF-51)(1/2)
INTELLIGENT ACCESSORY SHOE
IC371
VF-99 BOARD
IC901
VF-119 BOARD
IC5402
IC5401
IC5404
VF-120 BOARD
IC5301
LB-54 BOARD
PD-92 BOARD(1/2)
PD-93 BOARD(1/2)
IC5501/IC4501
IC5502/IC4502
IC5601/IC4601
IC5701/IC4701
VL-19 BOARD
FP-220 (FLEXIBLE)
IC452
FP-249 (FP-355, 356) (FLEXIBLE)
IC452
B-MECHA CHASSIS
IC451
IC801
IC452
IC001
DD-105 BOARD(1/2)
IC402
MA-311 BOARD(1/2)
MA-331 BOARD(1/2)
MA-312 BOARD(1/2)
IC604
IC602
IC603
PD-92 BOARD(1/2)
PD-93 BOARD(1/2)
IC5801/IC4801
CONTROL SWITCH BLOCK (MF-8500)
CONTROL SWITCH BLOCK (MR-8500)
CONTROL SWITCH BLOCK (CF-50)(1/2)
CONTROL SWITCH BLOCK (CF-51)(1/2)
CONTROL SWITCH BLOCK (SS-8500)
VTR CONTROL SWITCH BLOCK (FK-8500)
IC802
IC801
DD-105 BOARD

STEADY SHOT MODEL CCD-TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815
2 5 LCD MODEL:CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615
3 LCD MODEL:CCD-TRV93
3 5 LCD MODEL:CCD-TRV85/TRV815
Hi8 MODEL:CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
STEREO MODEL:CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
MONAURAL MODEL:CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215
IR TRANSMITTER MODEL:CCD-TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
COLOR EVF MODEL:CCD-TRV93
B/W EVF MODEL:CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615/TRV815
TBC&DNR MODEL:CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
5 HEAD MODEL:CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
VIDEO LIGHT MODEL:CCD-TRV93
INTELLIGENT ACCESSORY SHOE MDOEL:CCD-TRV65/TRV65PK/TRV85/TRV615/TRV815

3-2. CAMERA/VIDEO 1 BLOCK DIAGRAM

CD-197 BOARD
(2.5 LCD MODEL)
CD-198 BOARD
(3/3.5 LCD MODEL)
(SEE PAGE 4-9)
IC401
CCD IMAGER
VC-195 BOARD
(SEE PAGE 4-17·23·27·31)
IC502
S/H AGC A/D CONVERTER
IC501
TIMING GENERATOR
IC202
CAMERA Y/C PROCESS
VTR Y/C PROCESS ATF FOCUS/ZOOM MOTOR CONTROL
IC001
REC/PB AMP
IC204
MEMORY
IC152
D/A CONVERTER (EVR)
IC201
CHARACTER GENERATOR
IC151
PJ-83 BOARD(1/3)
(2.5 LCD MODEL)
PJ-84 BOARD(1/3)
(3/3.5 LCD MODEL)
(SEE PAGE 4-56)
CF-50 BOARD(1/6)
(SEE PAGE 4-67)
(2.5 LCD MODEL)
CF-51 BOARD(1/6)
(SEE PAGE 4-70)
(3/3.5 LCD MODEL)
(SEE PAGE 3-32)
(SEE PAGE 3-29)
(SEE PAGE 3-23·26)
AUDIO
(SEE PAGE 3-19·20)
SERVO
(SEE PAGE 3-12)
VTR/CAMERA CONTROL
(SEE PAGE 3-9)
MODE CONTROL
(SEE PAGE 3-17)
CAMERA REC
PB
VIDEO HEAD
FLYING ERASE
LCD BL CONT
POWER (CD-105)

NTSC MODEL:CCD-TRV15/TRV15PK/TRV25/TRV25PK/TRV35/TRV65/TRV65PK/
TRV85/TRV93/TRV215/TRV615/TRV815
PAL MODEL CCD-TRV15E/TRV15EP/TRV35E
CCD 510H MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP
2 5 LCD MODEL CCD-TRV15E/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/
TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615
3 LCD MODEL CCD-TRV93
3 5 LCD MODEL CCD-TRV85/TRV815
B/W EVF MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35
TRV35E/TRV65/TRV65PK/TRV85/TRV215/TRV615/TRV815
COLOR EVF MODEL CCD-TRV93
Hi8 MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
STANDARD 8 MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/
TRV35/TRV35E/TRV215
MONITOR IN MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
TBC&DNR MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
3 HEAD MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/
TRV35/TRV35E/TRV215
5 HEAD MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815

3-3. VTR/CAMEARA CONTROL BLOCK DIAGRAM


SE-66 BOARD(1/2)
(2.5 LCD MODEL)
SE-67 BOARD(1/2)
(3/3.5 LCD MODEL)
(SEE PAGE 4-53)
IC451
PITCH/YAW SENSOR AMP
SE451
PITCH SECSOR
SE452
YAW SECSOR
LPF
LIA1
VREF1
LIA2
VREF2
OUT1
CRST
OUT2
VCC
CN451
PITCH AD
VST C RESET
YAW AD
A 3.1V
CN904
(STEADY SHOT MODEL)
VC-195 BOARD
(SEE PAGE 4-35, 38)
IC402 (1/2)
VTR/CAMERA CONTROL
D 3.1V
VDD
AVDD
AVRH
XTAL
EXTAL
X401 20MHz
IC402 ①
MODE CONTROL
(SEE PAGE 3-17)
SWP
XCC DOWN
DEW AD
XSYS RST
XCS VC
HI SO
HI SI
HI SCK
SYS V
XRST VC
LENS FILTER ON SW
LENS RST LED
VST C CHARGE
ZM RST SENS
YAW AD
PITCH AD
IRIS PWM
LENS TEMP AD
HALL AD
FC RST SENS
PLA/GLASS
XCS SYSTEM
AUDIO OUT
XCS AU
AUDIO
(SEE PAGE 3-20)
AU XIN/OUT
VC SI
VC SO
VC SCK
XVC SCK
CAMERA/VIDEO
(SEE PAGE 3-8)
XREC SP1
XREC LP2
XREC SP2
XREC LP1
RP PB MODE
XFE ON
X1/2 SWP
XTBC V RESET
XRST SYSTEM
XCS IO
MECHA VD
TBC VD
MECHA HD
MECHA FLD
MEM VD
CK CONT
XSG V RST
XCS TG
DA STB
XCS EEPROM
XWE EEPROM
JOG VD
LCD HOLD
XMP/ME
MEMJ VDI
CAM XLINE
DOP
GCAM PB
ATF SAMPLE
SL SHUTTER
PB XREC
LP XSP
AGC SLOW
UN LOAD
LOAD
LM LIM CONT
XLM LIM ON
M SW C
M SW B
M SW A
TAPE TOP
TAPE END
S REEL FG AD
T REEL FG AD
TAPE LED ON
XREEL HALL ON
ME SW
HI8 MP
REC PROOF
V LIGHT PWM
CAM XLINE
SL SHUTTER ME
PB XREC
LP XSP
AGC SLOW
FOCUS A AD
FOCUS B AD
ZOOM SW AD
LCD DD ON
EVF DD ON
LCD HOLD
XCS LCD DA
XCS EVF DA
IC401
EEPROM
DO
DI
XSCK
VCC
XCS
RST
IC452 (1/3)
LOADING MOTOR DRIVE
VTR UNREG
VCC2
VCC1
DEC2
DEC1
LIMIT ENABLE
LIMIT OUT
OUT1
OUT2
IC452 (1/3)
TAPE TOP/END DETECT
TOP OUT
END OUT
TOP IN
END IN
IC452 (1/3)
WAVE SHAPER
LED DRIVE
MT 4.75V
SR FG
TR FG
DEW AD
XCC DOWN
CN901
LM(+)
LM(-)
M SW(C)
M SW(B)
M SW(A)
CN905
DEW(+)
CN908
TAPE TOP(C)
TAPE END(C)
TAPE LED(A)
SENSOR VCC
S REEL(-)
S REEL(+)
T REEL(-)
T REEL(+)
HALL COM
TAPE LED(K)
ME/MP
Hi8 MP
REC PROOF
C LOCK SW
B-MECHA CHASSIS
(SEE PAGE 4-38)
M903 LOADING MOTOR
MODE SWITCH
DEW SENSOR
D001 TAPE LED
Q001 TAPE TOP SENSOR
Q002 TAPE END SENSOR
H001 S REEL SENSOR
H002 T REEL SENSOR
S001
S002 CC DOWN SW
CN909
LIGHT PWM
POWER (VL-19)
(VIDEO LIGHT MODEL)
CN911
CN001
CN002
CF-50 BOARD(1/6)
(SEE PAGE 4-67)
(2.5 LCD MODEL)
CF-51 BOARD(1/6)
(SEE PAGE 4-70)
(3/3.5 LCD MODEL)
MF-8500 BOARD(1/2)
(SEE PAGE 4-67)
(2.5 LCD MODEL)
MA-8500 BOARD(1/2)
(SEE PAGE 4-70)
(3/3.5 LCD MODEL)
RV001 FOCUS DIAL
CN005
LCD HOLD
XCS LCD DA
VC SO
XVC SCK
LCD
(PD-92) (SEE PAGE 3-23, 26)
(2.5 LCD MODEL)
(PD-93) (SEE PAGE 3-23, 26)
(3/3.5 LCD MODEL)
CN007
XCS EVF D/A
VC SI
VC SO
XVC SCK
COLOR EVF (VF-119)
(SEE PAGE 3-29)
(COLOR EVF MODEL)
CN912
CN914
LCD DD ON
EVF DD ON
POWER (DD-105)
CN932
CN935
DD-105 BOARD (1/4)
(SEE PAGE 4-121)
FK-8500 BOARD (1/2)
(SEE PAGE 4-77)
RV001 ZOOM
D 3.1V
CN551
TEMP COM
TEMP OUT
DRIVE(+)
DRIVE(-)
CONT(-)
CONT(+)
BIAS(+)
HALL(-)
HALL(+)
BIAS(-)
GND
SENSE VCC
ZM RST
FC RST
ZM XA
ZM A
ZM XB
ZM B
FC A
FC XA
FC B
FC XB
M904 IRIS METER
ZOOM LENS UNIT
ZOOM SENSER
FOCUS SENSER
M906 ZOOM MOTOR
M905 FOCUS MOTOR
IC551 (1/4)
IRIS DRIVE
Q552 DRIVE
LPF
IRIS PWM
LENS FILTER ON SW
LENS TEMP AD
IC551 (1/4)
HALL BIAS CONTROL
IC551 (1/4)
HALL AMP
HALL AD
Q553
IC551 (1/4)
HALL GAIN CONTROL
HALL GAIN
HALL OFFSET
HALL REF
ZM RST SENS
LENS RST LED
FC RST SENS
PLA/GLASS
IRIS COM (IC202 ⑬)
HALL GAIN (IC152 ⑩)
HALL OFFSET (IC152 ⑨)
HALL REF (IC152 ⑪)
ZM RST (IC202 ⑬)
FC RST (IC202 ⑬)
IC522
ZOOM MOTOR DRIVE
FOCUS MOTOR DRIVE
EN1 (IC202 ⑬)
DIR1B (IC202 ⑬)
DIR1A (IC202 ⑬)
EN0 (IC202 ⑫)
DIR0B (IC202 ⑫)
DIR0A (IC202 ⑫)
CAMERA/VIDEO
(SEE PAGE 3-6)
D 3.1V
AU 4.75V
VM1 VM2 VM3 VC
09

2.5 LCD MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/
TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/
TRV215/TRV615
3 LCD MODEL CCD-TRV93
3.5 LCD MODEL CCD-TRV85/TRV815
STEADY SHOT MODEL CCD-TRV25/TRV25PK/TRV35/TRV35E/
TRV65/TRV65PK/TRV85/TRV93/
TRV215/TRV615/TRV815
COLOR EVF MODEL CCD-TRV93

3-4. SERVO BLOCK DIAGRAM


VC-195 BOARD
(SEE PAGE 4-23, 31, 35, 38)
DD-105 BOARD(1/4)
(SEE PAGE 4-121)
B-MECHA(1/2)
(SEE PAGE 4-38)
B-MECHA(1/2)
(SEE PAGE 4-38)
IC451 (1/2)
DRUM FG/PG WAVE SHAPER
LPF
WAVE SHAPER
V REF
WAVE SHAPER
IC402 (1/2)
SERVO
DRUM SERVO
DRUM FG
DRUM PWM
DRUM PG
CAPSTAN SERVO
CAP FG
CAP PWM
VTR/CAMERA CONTROL
IC452 (1/4)
LPF
PROTECT
0.29V
Q454, 455
BUFFER
DRUM ERROR
CAP ERROR
CAP ON
IC001 (2/2)
CAPSTAN FG
CAPSTAN FG WAVE SHAPER
CFG Vcc
CFG(+)
CFG GND
CFG(-)
OFFSET ADJ
CFG DUTY
(IC152 ㉑)
CAMERA/VIDEO
(SEE PAGE 3-8)
CPC
(FOR CHECK)
D 3.1V
X401
20MHz
DRUM START
DRUM ON
CAP ON
CAP FWD
MECHA VD
MECHA FLD
XCS SYSTEM
VC SI
VC SO
VC SCK
SWP
ATF SAMPLE
VIDEO/CAMERA BLOCK
VIDEO HEAD
CH SP1
CH SP2
CH LP1
CH LP2
(5 HEAD MODEL)
IC001
REC/PB AMP
IC202
LPF
A/D
D/A
REC C RF
REC ATF
PB ATF
ATF
Q217
IC801 (1/2)
DRUM/CAPSTAN PWM DRIVE
SHORT CIRCUIT PROTECT
SWITCHING DRIVE
OSC
OUTPUT VCC 56
MT UNREG
L806
D803
Q814 SWITCHING
L808
D804
Q815 SWITCHING
VTR D/D ON
(CN931 ⑱)
CN905
CN906
CN910
CN914
CN931
VTR UNREG
D 3.1V
DRUM VS
DRUM ON
STBY
CONTROL LOGIC
OUTPUT DRIVE BUFFER
OUTPUT DRIVE
COM
VS
U IN
V IN
W IN
IC451 (1/2)
DRUM MOTOR DRIVE
CSPL1
CSPL2
I COM
R452-454
DRUM DRIVE CURRENT SENS
SW
Q452, 453
M901
DRUM MOTOR
CAP VS
VTR UNREG
VCC 2
STANDBY
FRC
CAP ON
CAP FWD
IC001 (1/2)
CAPSTAN MOTOR DRIVE
120° LOGIC
POWER OFF
HE POWER
M902
CAPSTAN MOTOR
CAP U
CAP V
CAP W
C HALL GND
C HALL VCC
H1(+)
H1(-)
H2(+)
H2(-)
H3(+)
H3(-)
09
5 HEAD MODEL: CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815

3-5. MODE CONTROL BLOCK DIAGRAM


MR-8500 BOARD
(SEE PAGE 4-70)
(3/3.5 LCD MODEL)
MF-8500 BOARD
(SEE PAGE 4-67)
(2.5 LCD MODEL)
CF-50 BOARD
(SEE PAGE 4-67)
(2.5 LCD MODEL)
CF-51 BOARD
(SEE PAGE 4-70)
(3/3.5 LCD MODEL)
VC-195 BOARD
(SEE PAGE 4-49)
PD-92 BOARD
(SEE PAGE 4-88)
(2.5 LCD MODEL)
PD-93 BOARD
(SEE PAGE 4-100)
(3/3.5 LCD MODEL)
FP-642
(FLEXIBLE)
(SEE PAGE 4-100)
IC5801/IC4801
LED DRIVE
LCD903
LCD INDICATOR
BACK LIGHT
(LCD BACKLIGHT MODEL)
S002 FADER
S001 FOCUS
RV001 FOCUS DIAL
S024 START/STOP MODE
S015 CONTROL DIAL
S021 TIME
EXECUTE
S010 MENU
S006 PICTURE EFFECT
S027 FADER
S017 BACK LIGHT
S012 EXPOSURE
S022 DISPLAY
S018 TITLE
S013 END SEARCH
S008 COUNTER RESET
S003 DATE
S004 PROGRAM AE
BACK LIGHT DRIVE Q003,005
Q001 LED DRIVE
BH001 LITHIUM BATTERY
IC604 MODE CONTROL
IC602 INITIAL RESET BACKUP VCC
X601 20MHz
X602 32.768KHz
MA-311 BOARD(1/2)
MA-331 BOARD(1/2)
(2.5 LCD 1/LCD 2 MODEL)
MA-312 BOARD(1/2)
(3/3.5 LCD MODEL)
(SEE PAGE 4-61)
REMOTE COMMANDER RECEIVER
IC301
S301 VIDEO LIGHT
(VIDEO LIGHT MODEL)
S303 CAMERA
S302 PLAYER
POWER
VTR CONTROL SWITCH BLOCK(FK-8500)
(SEE PAGE 4-77)
S010 EDIT SEARCH (-)
S009 EDIT SEARCH (+)
S005,007 REC
(VTR REC MODEL)
S003 FF
S001 STOP
S008 IR ON
(IR TRANSMITTER MODEL)
S006 PLAY
S004 REW
S002 PAUSE
RV001 ZOOM
D008 IR
VTR LED D001-007
DD-105 BOARD(1/3)
(SEE PAGE 4-121)
Q932 LED DRIVE
Q933,934
MT 4.75V
D 3.1V
CONTROL SWITCH BLOCK
(SS-8500)
(SEE PAGE 4-77)
S001 STANDBY
S002 START/STOP
S003 EJECT
J001 LANC
IC603 LANC I/O
Q620
E 3.15V
D608
Q608,610 MOD
Q619 (STEREO MODEL)
Q609,611 MOD
(IR TRANSMITTER MODEL)
I/F BLOCK Q607
D509
D502
D501
D510
VTR/CAMERA CONTROL
(SEE PAGE 3-9)
AUDIO
(SEE PAGE 3-20)
CAMERA/VIDEO
(SEE PAGE 3-7)
POWER (DD-105)
FP-633(FLEXIBLE)
(SEE PAGE 4-51)
INTELLIGENT ACCESSORY SHOE
(INTELLIGENT ACCESSORY SHOE MODEL)

2 5 LCD MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/
TRV35E/TRV65/TRV65PK/TRV215/TRV615
3 LCD MODEL CCD-TRV93
3 5 LCD MODEL CCD-TRV85/TRV815
STEREO MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
LCD BACKLIGHT MODEL:CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
IR TRANSMITTER MODEL CCD-TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
INTELLIGENT ACCESSORY SHOE MODEL CCD-TRV65/TRV65PK/TRV85/TRV615/TRV815
B/W EVF MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/
TRV35E/TRV65/TRV65PK/TRV85/TRV215/TRV615/TRV815
VTR REC MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
EXPOSURE MODEL CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815

3-6. AUDIO BLOCK DIAGRAM

VC-195 BOARD
(SEE PAGE 4-41)
IC301
AFM PROCESS
BPF
MOD/DEMOD
NR
AGC
MX MTX
BUS DECODER
ON/OFF MUTE SWITCH
BUFFER
IC751
IR TRANSMITTER
VIDEO SIGNAL PROCESS
AUDIO SIGNAL PROCESS
MIX
DRIVE
AMP
FP-633(FLEXIBLE)
INTELLIGENT ACCESSORY SHOE
SE-66 BOARD(1/2) SE-67 BOARD(1/2)
(SEE PAGE 4-53)
PJ-83 BOARD(1/3) PJ-84 BOARD(1/3)
(SEE PAGE 4-56)
IC371
SPEAKER/HEAD PHONE AMP
CF-50 BOARD
(SEE PAGE 4-67)
CF-51 BOARD
(SEE PAGE 4-70)
SP901 SPEAKER
IC321
MIC AMP
FILTER
IC322
MIC AMP
ZOOM-STEREO BALANCE
EQ AMP
INV
GAIN CONT
BUFFER
LED DRIVE
IC301
REMOTE COMMANDER RECEIVER
CAMERA
PLAYER
POWER
J301 MIC (PLUG IN POWER)
MIC901 MIC L
MIC902 MIC R
MA-311 BOARD
MA-312 BOARD
MA-331 BOARD
(SEE PAGE 4-61)
CAMERA/VIDEO (SEE PAGE 3-8)
VTR/CAMERA CONTROL (SEE PAGE 3-9)
MODE CONTROL (SEE PAGE 3-17)

2 5 LCD 1 MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35E/TRV65/TRV65PK/TRV215/TRV615
2 5 LCD 2 MODEL CCD-TRV35
3 LCD MODEL CCD-TRV93
3 5 LCD MODEL CCD-TRV85/TRV815
STEREO MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
MONAURAL MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215
IR TRANSMITTER MODEL CCD-TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
INTELLIGENT ACCESSORY SHOE MODEL CCD-TRV65/TRV65PK/TRV85/TRV615/TRV815

3-7. LCD (CCD-TRV35/TRV65/TRV65PK/TRV93/TRV615) BLOCK DIAGRAM


CF-50 BOARD
(SEE PAGE 4-67)
(2.5 LCD MODEL)
CF-51 BOARD
(SEE PAGE 4-70)
(3 LCD MODEL)
PD-92 BOARD
(SEE PAGE 4-81, 84, 87, 88)
(2.5 LCD MODEL)
PD-93 BOARD
(SEE PAGE 4-93, 96, 99, 100)
(3 LCD MODEL)
VTR/CAMERA CONTROL (VC-195)
(SEE PAGE 3-10)
CAMERA/VIDEO (VC-195)
(SEE PAGE 3-5)
MODE CONTROL (VC-195)
XCS LCD DA
XVC SCK
VC SO
PANEL HOLD
LCD Y
LCD V
LCD U
LCD VD
XCS LCD DRIVER
LCD COM/XDATA
OSD SO
OSD SCK
CHARGE LED ON
LCD LED ON
KEY AD6
CN001
CN005
CN5804/CN4804
CN5803/CN4803
IC5501/IC4501
EVR
COMP
IC5502/IC4502
LCD DRIVER
SYNC SEP
R OUT
G OUT
B OUT
COM OUT
VSH
PANEL 4.75V
PANEL 6.5V
PANEL 3.1V
H FIL
Q5501/Q4501 BUFFER
IC5801/IC4801
LED DRIVE
DISP LCD VDD
LCD902
LCD INDICATOR
BACK LIGHT
Q003, 005 BACK LIGHT DRIVE
(LCD BACKLIGHT MODEL)
FP-642
S5801/S4801 BRIGHT+
S5802/S4802 BRIGHT-
S5803/S4803 VOLUME+
S5804/S4804 VOLUME-
PANEL REVERSE
PANEL CLOSE
CN5805/CN4805
CN5501/CN4501
PANEL COM
H START
SYNC
VCO VOLTAGE
(FOR CHECK)
CN5802/CN4802
BL REG
POWER (DD-105)
PANEL -15.3V
PANEL 13.2V
PANEL 4.75V
PANEL 6.5V
PANEL 3.1V
D 3.1V
BL DET
L5701/L4701
Q5701/Q4701 INVERTER DRIVE
T5701/T4701
C5705/C4705
CN5701/CN4701
ND901 (BACK LIGHT)
BL HIGH
BL LOW
IC5701/IC4701
BL DET
Q5702/Q4702 LED SWITCH
D5703
(2.5 LCD MODEL)
D901
(3 LCD MODEL)
CN5601/CN4601
VB GENERATOR
VGL GENERATOR
VCC GENERATOR
IC5602/IC4602
COM AMP
Q5605-5608/Q4605-4608 BUFFER
COM-D
VCOM
IC5601/IC4601
LCD TIMING GENERATOR
VCO
COMTST
V REV
H REV
NTSC
XWIDE
LCD HOLD
PANEL XVD
Q5602/Q4602 SWITCH
Q5601/Q4601 SWITCH
LPF
HSY
FRPV
FRPT
W MSKV
W MSKT
VCO VOLT
LCD901
LCD PANEL
VR
VG
VB
VB12
VSH
COM
VGL
VSS
VCC
CLS
SPS
EX2
EX1
CLD
SPD
RES
MD1
MD2
CTR
EX3

2 5 LCD(S TYPE) MODEL CCD-TRV35/TRV65/TRV65PK/TRV615
3 LCD(S TYPE) MODEL CCD-TRV93
LCD BACKLIGHT MODEL CCD-TRV93

REF NO 5 000 SERIES 2 5 LCD MODEL
REF NO 4 000 SERIES 3 LCD MODEL

3-8. LCD (CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV85/TRV215/TRV815) BLOCK DIAGRAM


CF-50 BOARD
(SEE PAGE 4-67)
(2.5 LCD MODEL)
CF-51 BOARD
(SEE PAGE 4-70)
(3.5 LCD MODEL)
PD-92 BOARD
(SEE PAGE 4-81, 84, 87, 88)
(2.5 LCD MODEL)
PD-93 BOARD
(SEE PAGE 4-93, 96, 99, 100)
(3.5 LCD MODEL)
VTR/CAMERA CONTROL (VC-195)
(SEE PAGE 3-10)
XCS LCD DA
XVC SCK
VC SO
PANEL HOLD
CN001
CN005
CN5804/CN4804
LCD HOLD
CAMERA/VIDEO (VC-195)
(SEE PAGE 3-5)
LCD Y
LCD V
LCD U
LCD VD
PANEL XVD
IC5501/IC4501
EVR
COMP
XWIDE
NTSC
V REV
H REV
BRIGHT
COLOR
BRT R
BRT B
CONTRAST
RGB AMP
COM ADJ
VCO
V COM
H POS
BRT TST
COM TST
SO
XEN
CLK
SI
D 3.1V
PANEL 3.1V
VCC
VDD
VDDA
IC4502/5502 ⑯ 3Vp-p
IC4502/5502 ⑬ 0.7Vp-p
IC4502/5502 ⑧ 0.44Vp-p
IC4502/5502 ⑨ 0.2Vp-p
IC4502/5502 ⑩ 0.2Vp-p
IC5502/IC4502
LCD DRIVER
H FIL
SYNC SEP
Q5501/Q4501
BUFFER
Y
V
U
SYNC IN
SYNC OUT
COLOR
BRT TST
RGB AMP
CONTRAST
SUB CONT R
SUB CONT B
SUB BRT R
SUB BRT B
BRIGHT
COM AMP
COM ADJ
LCD DRIVER
VSH
PANEL 4.75V
R OUT
G OUT
B OUT
COM OUT
W MSKV
W MSKT
FRP
VCC1
VCC2
PANEL 6.5V
PANEL 3.1V
IC4502 ⑳ 3.3Vp-p
IC5502 ⑳ 3.6Vp-p
IC4502 ㉒ 3.3Vp-p
IC5502 ㉒ 3.6Vp-p
IC4502 ㉔ 3.3Vp-p IC5502 ㉔ 3.6Vp-p
CN5501/CN4501
PANEL COM
H START
SYNC
VCO VOLTAGE
VR
VG
VB
(FOR CHECK)
PANEL COM
HSY
VCO VOLT
POWER (DD-105)
CN5802/CN4802
BL REG
PANEL -15.3V
PANEL 13.2V
PANEL 4.75V
PANEL 6.5V
PANEL 3.1V
D 3.1V
BL DET
L5701/L4701
Q5701/Q4701
INVERTER DRIVE
T5701/T4701
C5705/C4705
CN5701/CN4701
ND801
(BACK LIGHT)
BL HIGH
BL LOW
IC5701/IC4701
BL REG
BL DET
PANEL 4.75V
Q5702/Q4702
LED SWITCH
D5703
(2.5 LCD MODEL)
LED
D901
(3.5 LCD MODEL)
CN5601/CN4601
VR
VG
VB
COM-O
IC5602/IC4602
VCOM AMP
Q5605-5608/Q4605-4608
BUFFER
VCOM
LCD901
LCD PANEL
VCOM
IC5601/IC4601
LCD
TIMING GENERATOR
IC4601 ㉖ Approx 9.5MHz 3.3Vp-p
IC5601 ㉖ Approx 5.8MHz 3.2Vp-p
VCO
V REV
H REV
NTSC
COMTST
XWIDE
IC4601/5601 ㊲ 3Vp-p
LCD HOLD
Q5602/Q4602
SWITCH
PANEL XVD
Q5601/Q4601
SWITCH
LPF
PANEL 3.1V
VCO VOLT
IC4601/5601 ㉞ 3Vp-p
20msec
IC4601/5601 ④ 3Vp-p
PANEL COM
W MSKV
W MSKT
HSY
FRP
GRES
GPCK
GSRT
SRT2
SRT1
OE
CLR
HCNT
MCLK
MODE1
RESET
MODE2
IC4601 ㉔ 3Vp-p Approx 4.8 MHz
IC5601 ㉔ 3.4Vp-p Approx 2.9 MHz
MODE 1
MCLK
HCNT
CLR
OE
SRT 1
SRT 2
MODE 2
RESET
GSRT
GPCK
GRES
(2.5 LCD MODEL) PANEL 4.75V
(3.5 LCD MODEL) PANEL 6.5V
PANEL 3.1V
PANEL -15.3V
PANEL 13.2V
VSH
VDD
VGL
VREFH
VGH
MODE CONTROL (VC-195)
XCS LCD DRIVER
LCD COM/XDATA
OSD SO
OSD SCK
CHARGE LED ON
LCD LED ON
KEY AD6
CN006
CN5803/CN4803
Q003 005
BACK LIGHT DRIVE
DISP LCD VDD
IC5801/IC4801
LED DRIVE
CS
C/XD
SO
SCK
VDD
COM1
COM4
SEG1
SEG16
CN5801/CN4801
LCD902
LCD INDICATOR
BACK LIGHT
(LCD BACKLIGHT MODEL)
S5801/S4801
BRIGHT+
S5802/S4802
BRIGHT-
S5803/S4803
VOLUME+
S5804/S4804
VOLUME-
FP-642
(PANEL REVERSE)
(PANEL CLOSE)
CN5805/CN4805
09

2.5 LCD(C TYPE) MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215
3.5 LCD(C TYPE) MODEL CCD-TRV85/TRV815
LCD BACKLIGHT MODEL CCD-TRV85/TRV815

REF NO 5 000 SERIES 2.5 LCD MODEL
REF NO 4 000 SERIES 3.5 LCD MODEL

3-9. COLOR EVF BLOCK DIAGRAM


CF-51 BOARD
(SEE PAGE 4-70)
FP-638(FLEXIBLE)
VF-119 BOARD
(SEE PAGE 4-102)
VC-195 BOARD
(SEE PAGE 4-34)
LB-54 BOARD
(SEE PAGE 4-110)
VF-120 BOARD
(SEE PAGE 4-109)
CN001
CN007
VTR/CAMERA CONTROL (VC-195)
(SEE PAGE 3-11)
VC SO
XVC SCK
XCS EVF D/A
VC SI
CAMERA/VIDEO (VC-195)
(SEE PAGE 3-5)
LCD Y
LCD U
LCD V
LCD HD
LCD VD
POWER (VC-195)
A 4 75V
EVF 3 1V
D 3 1V
EVF 12V
CN911
EVF VG
VCO
EVF BL 4 75V
R2070
R2071
EVF VG
VCO
EVF BL 4 75V
EVF BL
CN910
(FOR CHECK)
HD OUT
INV CURRENT
EVF 12 0V
CN5301
Q5304
5305
IC5301
DC/AC CONVERTER
IC5301 ⑮
12Vp-p
Vcc1
Vcc2
PWM COMP
OUTPUT
Q5301
DISCHARGE SW
SCP
SCP COMP
CURRENT ERROR AMP
PROTECT DET
TRIANGLE OSC
VREF (2 5V)
CT
SYNC
IC5301 ④
2 4Vp-p
D5301(1/3)
D5302
CN5302
CN5351
T5351
ND5351 BACK LIGHT
Q5351 SWITCHING
09
CN5401
D 3 1V
EVF 3 1V
EVF 12V
IC5402
EVR(D/A CONVERTER)
SI
XSCK
XCS
SO
X NTSC
ADJ
WIDE
BRT
COLOR
SUB BRT R
SUB BRT B
CONTRAST
D CLIP
GAMMA
VCO
INV CURRENT
LOOK LEVEL
PICTURE
AGC LEVEL
VCC D
VDD A
VDD
NTSC
VXO
IC5401
PICTURE
AGC LEVEL
COLOR
BRIGHT
GAMMA 1
BLACK LIMIT
CONTRAST
SUB BRT R
SUB BRT B
VCC2
VCC1
EVF 12V
EVF 3 1V
Y
R-Y
B-Y
RGB DRIVER
R OUT
G OUT
B OUT
LPF
FRP
HD
EXT BGP
SH B
SH R
SH A
SH G
RGB BLK
IC5401 ⑳
7 2Vp-p
IC5401 ㉒
7 5Vp-p
IC5401 ㉔
7 6Vp-p
IC5401 ⑭
3Vp-p
2H
CN5402
LCD903
LCD PANEL
R
G
B
COM(5 7V)
LIQUID CRYSTAL DISPLAY
IC5404 ㊺
IC5404 ㉒
IC5404
LCD TIMING GENERATOR
XVD
XCLP
XHD
VDD
SLYT
WIDE
PLNT
ADJ
WIDE
NTSC
SH1
SH2
SH3
SH4
SBLK
FRP
EN
BLK
HCK1
HCK2
HST1
VCK2
VCK1
VST1
CLR
1 84 MHz
IC5404 ㉓ ㉔
3 4Vp-p
7.852 kHz
IC5404 ⑳ ㉑
RPD
CKI
CKO
D5401
11 06 MHz
IC5404 ㊶
2 7Vp-p
IC5404 ⑱
EN
BLK
HCK1
HCK2
HST
VCK2
VCK1
VST
CLR
V VDD
RGT

3-10. B/W EVF BLOCK DIAGRAM


CF-50 BOARD(1/6)
(SEE PAGE 4-67)
(2.5 LCD MODEL)
CF-51 BOARD(1/6)
(SEE PAGE 4-70)
(3.5 LCD MODEL)
MODE CONTROL
(VC-195)
TALLY LED
(SEE PAGE 3-15)
VIDEO/CAMERA
(VC-195)
B/W EVF Y
(SEE PAGE 3-5)
CN001
CN008
18
12
4
3
VF-99 BOARD
(SEE PAGE 4-113)
CN901
EVF 4.9V
D901
(TALLY)
1Vp-p
H
IC901 ⑪
IC901
⑪
⑭
⑮
⑨
⑯
⑬
AFC
H
OSC
H
DRIVE
SYNC
SEP
VIDEO AMP/BLKG MIX
V SYNC
SEP
V
OSC
V
OUT
VCC
VCC
②
⑫
⑧
⑥
⑦
⑤
③
①
EVF 4.9V
RV903
V SIZE
09
Q903
VIDEO
AMP
Q904
VIDEO
DRIVE
2.2Vp-p
IC901 ⑬
Q902
H OUT
C909
H SIZE
SOL901
T901
FBT
EVF 4.9V
D902
DUMPER
RV904
BRIGHT
W901
G1
H
H
HV
G2
CN902
DH2
DH1
EVF 4.9V
DV2
DV1
V901
PICTURE TUBE
DEFLECTION
YOKE
H
V

2.5 LCD MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRVTRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615
3.5 LCD MODEL CCD-TRV85/TRV815

3-11. POWER BLOCK DIAGRAM

DD-105 BOARD (SEE PAGE 4-121)
CONTROL SWITCH BLOCK (SS-8500) (SEE PAGE 4-77)
VC-195 BOARD (SEE PAGE 4-17, 19, 23, 27, 31, 35, 38, 41, 47, 49)
BATTERY TERMINAL
DC IN
IC801 DC/DC CONVERTER
IC802 DC/DC CONVERTER
VTR CONTROL SWITCH BLOCK (FK-8500) (SEE PAGE 4-77)
IC151
IC152
IC201
IC204
IC202
IC502
IC501
IC603
IC604
IC602
IC402
IC401
IC452
IC451
IC001
IC751
IC301
IC371
IC551
IC552
B-MECHA (SEE PAGE 4-38)
IC301
IC322
IC321
MA-311 BOARD
MA-331 BOARD
MA-312 BOARD (SEE PAGE 4-61)
MF-8500 BOARD (SEE PAGE 4-67)
MR-8500 BOARD (SEE PAGE 4-70)
VF-99 BOARD (SEE PAGE 4-113)
IC901
CF-50 BOARD (SEE PAGE 4-67)
CF-51 BOARD (SEE PAGE 4-70)
VF-119 BOARD (SEE PAGE 4-102)
IC5401
IC5404
IC5402
LB-54 BOARD (SEE PAGE 4-109)
IC5301
VF-120 BOARD (SEE PAGE 4-109)
PJ-83 BOARD
PJ-84 BOARD (SEE PAGE 4-56)
VL-19 BOARD (SEE PAGE 4-63)
INTELLIGENT ACCESSORY SHOE
IC401
CD-197 BOARD
CD-198 BOARD (SEE PAGE 4-13)
IC451
SE-66 BOARD
SE-67 BOARD (SEE PAGE 4-53)
PD-92 BOARD (SEE PAGE 4-81, 84, 87, 88)
PD-93 BOARD (SEE PAGE 4-93, 96, 99, 100)
IC5501 IC4501
IC5502 IC4502
IC5601 IC4601
IC5602 IC4602
IC5701/IC4701
IC5801 IC4801
LCD PANEL
BACK LIGHT
A

VIDEO LIGHT MODEL CCD-TRV93
INTELLIGENT ACCESSORY SHOE MODEL CCD-TRV65/TRV65PK/TRV85/TRV615/TRV815
COLOR EVF MODEL CCD-TRV93
B/W EVF MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV215/TRV615/TRV815
2 5 LCD MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615
3 LCD MODEL CCD-TRV93
3 5 LCD MODEL CCD-TRV85/TRV815
IR TRANSMITTER MODEL CCD-TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
TBC&DNR MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
VTR REC MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
STEREO MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
MONAURAL MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/TRV215
LCD BACKLIGHT MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
STEADY SHOT MODEL CCD-TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815
LCD TYPE S MODEL CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV93/TRV615
LCD TYPE C MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV85/TRV215/TRV815

SECTION 4
PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

4-1. FRAME SCHEMATIC DIAGRAM (1)


LENS
CD-197 BOARD (2 5INCH LCD MODEL)
CD-198 BOARD (3INCH/3 5INCH LCD MODEL)
FP-623
S902 (NIGHT SHOT MODEL)
CN551 22P
CN551 16P
PJ-83 BOARD (2 5INCH LCD MODEL)
PJ-84 BOARD (3INCH/3 5INCH LCD MODEL)
J101
S VIDEO
VIDEO
RFU DC OUT
AUDIO
L (MONO)
R
(STEREO MODEL)
FP-621
CN907 16P
OPEN
VL-19 BOARD
(VIDEO LIGHT MODEL)
VIDEO LIGHT
FP-632
INTELLIGENT ACCESSORY SHOE
(INTELLIGENT ACCESSORY SHOE MODEL)
FP-633
SE-66 BOARD (2 5INCH LCD MODEL)
SE-67 BOARD (3INCH/3 5INCH LCD MODEL)
SE452 PITCH
SE451 YAW
(STEADY SHOT MODEL)
J451
FP-620
MA-311 BOARD (2 5INCH LCD 1 MODEL)
MA-312 BOARD (3INCH/3 5INCH LCD MODEL)
MA-331 BOARD (2 5INCH LCD 2 MODEL)
IC301
D303 TALLY
S302 VTR PLAYER (VTR REC MODEL) (PLAYER MODEL)
POWER
S303 CAMERA
D301 D302 LASER LINK
(IR TRANSMITTER MODEL)
ON → AUTO → OFF S301
(VIDEO LIGHT MODEL)
J301 MIC (PLUG IN POWER)
MIC901(L-CH)
MIC902(R-CH) (STEREO MODEL)
FP-629
SP901 SPEAKER
SP-149 HARNESS
CN003 2P
SP(+)
SP(-)
(MANUAL FOCUS MODEL)
S001 INFINITY FOCUS MANUAL AUTO
RV001 NEAR FAR
S002 FADER
(FADER MODEL)
CONTROL SWITCH BLOCK
(MR-8500) (3INCH/3.5INCH LCD MODEL)
(MF-8500) (2 5INCH LCD MODEL)
CN002 8P
(2 5INCH LCD MODEL)
(3INCH/3 5INCH LCD MODEL)
CPC (FOR CHECK)
LITHIUM BATTERY
S003 004 006 008 010 012
S013 017 018 021 022
DATA PROGRAM AE PICTURE EFFECT
COUNTER RESET MENU EXPOSURE
END SEARCH BACK LIGHT TITLE
TIME DISPLAY
S015 SEL/PUSH EXEC
S024 START/STOP MODE
5SEC
CF-50 BOARD (2 5INCH LCD MODEL)
CF-51 BOARD (3INCH/3 5INCH LCD MODEL)
CN907 20P
CN908 4P
FP-638
FFC-235
CONTINUED ON PAGE 4-4
CN005 8P
CN005 12P
CONTINUED ON PAGE 4-4
CN001 50P
FFC-236
CN910 16P
CN911 50P
VC-195 BOARD
(1/10) CH BLOCK
(2/10) LD BLOCK
(3/10) CL BLOCK
(4/10) IO BLOCK
(5/10) RR BLOCK
(6/10) MC BLOCK
(7/10) SB BLOCK
(8/10) AU BLOCK
(9/10) IR BLOCK
(10/10) HI BLOCK
CN912 16P
FP-622
CONTINUED ON PAGE 4-4
CN914 48P
B TO B
CONTINUED ON PAGE 4-4
FP-220
FP-248
FP-221
FP-249
FP-655
FP-356
L903 LOADING MOTOR
S901 MODE SWITCH
VIDEO HEAD
(3 HEAD MODEL)
(5 HEAD MODEL)
M901 DRUM MOTOR
M902 CAPSTAN MOTOR
B-MECH
Hi8 MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
STANDERD 8 MODEL EXCEPT CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
2 5INCH LCD MODEL EXCEPT CCD-TRV85/TRV93/TRV815
3INCH/3 5INCH LCD MODEL CCD-TRV85/TRV93/TRV815
COLOR EVF MODEL CCD-TRV93
B/W EVF MODEL EXCEPT CCD-TRV93
VTR REC MODEL CCD-TRV65/TRV65PK/TRV83/TRV93/TRV615/TRV815
PLAYER MODEL EXCEPT CCD-TRV65/TRV65PK/TRV83/TRV93/TRV615/TRV815
STEREO 5 HEAD MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
3 HEAD MODEL EXCEPT CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
IR TRANSMITTER MODEL CCD-TRV35/TRV35PK/TRV65/TRV85/TRV93/TRV315/TRV615/TRV815
INTELLIGENT ACCESSORY SHOE MODEL CCD-TRV65/TRV65PK/TRV85/TRV615/TRV815
STEADY SHOT MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP
VIDEO LIGHT MODEL CCD-TRV93
C-61K C105K MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV85/TRV215/TRV815
S-61K S89K MODEL CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV93/TRV615
NIGHT SHOT MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215
FADER MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215
MANUAL FOCUS MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215
09

FRAME SCHEMATIC DIAGRAM (2)


CONTINUED ON PAGE 4-3
FFC-235
(COLOR EVF MODEL)
VF-119 BOARD
CN5401 20P
CN5402 16P ZIF
LCD902 COLOR LCD UNIT
FP-638
VF-120 BOARD
CN5301 8P 0.5 ZIF
CN5301 12P
LB-54 BOARD
CN5351 12P
B to B
ND802 BACK LIGHT
(B/W EVF MODEL)
VF-99 BOARD
W901 4P CRT SOCKET
FBT
HV
V901 CRT ASSY
CN901 4P
CN902 4P
CONTINUED ON PAGE 4-3
ND801 BACK LIGHT
D901
LCD901 2.5INCH/3INCH/3.5INCH COLOR LCD UNIT
(S-61K S-89K MODEL)
(C-61K C105K MODEL)
DD-105 BOARD
CN933 11P
(2.5INCH LCD MODEL)
DP-70 HARNESS
DP-71 HARNESS
(3INCH/3.5INCH LCD MODEL)
CN802 11P (3INCH/3.5INCH LCD MODEL)
CN802 11P (2.5INCH LCD MODEL)
(2.5INCH LCD MODEL)
(3INCH/3.5INCH LCD MODEL)
PD-92 BOARD (2.5INCH LCD MODEL)
PD-93 BOARD (3INCH/3.5INCH LCD MODEL)
(1/4) RGB BLOCK
(2/4) TG BLOCK
(3/4) BL BLOCK
(4/4) LCD BLOCK
CN932 16P
CONTINUED ON PAGE 4-3
FP-622
CN934 12P
CONTROL SWITCH BLOCK (SS-8500)
S002 START/STOP
S003 EJECT
J001 LANC
S001 LOCK STANDBY
CPC
(FOR CHECK)
S903 (PANEL MIRROR)
S904 (PANEL CLOSE)
FP-642
(Hi8 MODEL)
FP-679
FP-680
(STANDARD 8 MODEL)
01 23 45
Hi8
LCD903
CN931 48P
CONTINUED ON PAGE 4-3
B TO B
CN935 10P
VTR CONTROL SWITCH (FK-8500)
S001 STOP
S002 PAUSE
S003 FF
S004 REW
(VTR REC MODEL)
S005 007 REC
S006 PLAY
S008
S009 (+) EDIT SEARCH (-)
S010
D008 LASER LINK
RV001 ZOOM
(IR TRANSMITTER MODEL)
(IR TRANSMITTER MODEL)
CN901 7P 1.5mm
J901 BATTERY TERMINAL
09

Hi8 MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
STANDERD 8 MODEL EXCEPT CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
2.5INCH LCD MODEL EXCEPT CCD-TRV85/TRV93/TRV815
3INCH/3.5INCH LCD MODEL CCD-TRV85/TRV93/TRV815
COLOR EVF MODEL CCD-TRV93
B/W EVF MODEL EXCEPT CCD-TRV93
VTR REC MODEL CCD-TRV65/TRV65PK/TRV83/TRV93/TRV615/TRV815
PLAYER MODEL EXCEPT CCD-TRV65/TRV65PK/TRV83/TRV93/TRV615/TRV815
STEREO 5 HEAD MODEL CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
3 HEAD MODEL EXCEPT CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815

IR TRANSMITTER MODEL CCD-TRV35/TRV65/TRV85/TRV93/TRV615/TRV815
INTELLIGENT ACCESSORY SHOE MODEL CCD-TRV65/TRV65PK/TRV85/TRV615/TRV815
STEADY SHOT MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP
VIDEO LIGHT MODEL CCD-TRV93
C-61K C105K MODEL CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV85/TRV215/TRV815
S-61K S89K MODEL CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV93/TRV615
NIGHT SHOT MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215
FADER MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215
MANUAL FOCUS MODEL EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215

4-2. PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS

THIS NOTE IS COMMON FOR PRINTED WIRING BOARDS AND SCHEMATIC DIAGRAMS.
(In addition to this, the necessary note is printed in each block.)

- **For printed wiring boards.**
- ▨ : Pattern from the side which enable seeing.
  (The other layer's patterns are not indicated.)
- Circled numbers refer to waveforms.
- Through hole is omitted.
- There are few cases that the part printed on diagram isn't mounted in this model.
- Chip parts.


Transistor
Diode
C
B E
6 5 4
1 2 3
4 5 6
3 2 1
4 5
3 2 1
1 2
5 4 3
Q
3
2 1
3
2 1
3
2 1

- **For schematic diagrams.**
- All capacitors are in μF unless otherwise noted. pF: μμF.
  50 V or less are not indicated except for electrolytics and tantalums.
- Chip resistor are 1/16W unless otherwise noted.
  kΩ : 1000Ω, MΩ : 1000kΩ.
- Caution when replacing chip parts.
  New parts must be attached after removal of chip.
  Be careful not to heat the minus side of tantalum capacitor, because it is damaged by the heat.
- Some chip part will be indicated as follows.

Example	C541	L452
	22U	10UH
	TA A	2520
Kinds of capacitor	Temperature chracteristics	External dimensions (mm)

- Constants of resistors, capasitors, ICs and etc with XX indicate tha they are not used. In such cases, the unused circuits may be indicated.
- Parts with ☆ differ according to the model/destination. Refer to the mount table for each function.
- All variable and adjustable resistors have characteristic curve B, unless otherwise noted.
- Signal name
  XEDIT → $\overline{\text{EDIT}}$ PB/XREC → $\overline{\text{PB/REC}}$
- ▭ : non flammable resistor.
- ▭ : fusible resistor.
- ▭ : panel designation.
- ━━ : B+ Line
- ▬ ▬ ▬ : B– Line
- ⇨ : IN/OUT direction of (+, –) B LINE.
- ☐ : adjustment for repair.
- Circled numbers refer to waveforms.

The components identified by mark ⚠or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une piéce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

Refer to page 3 as for "Table for difference of functions" of models and classification.

- **Measuring conditions voltage value and waveform.**
- The object is color bar chart of pattern box.
- Voltages and dc between ground and measurement points. Readings are taken with a digital multimeter (DC 10MΩ).
- Voltages variations may be noted due to normal production tolerances.

1. Connection


Pattern box
1.5m
Lens reference plane
surface Imaging surface
of CCD imager
(IC401 on CD-197/198 board)

2. Adjust the distance so that the output waveform of Fig. a and the Fig. b can be obtain.


H
Yellow
Cyan
Green
White
Magenta
Red
Blue
A
B
A=B
B
A

Fig. a (Video output terminal output waveform)


Electron beam
scanned frame
Yellow
Cyan
Green
White
Magenta
Red
Blue
CRT picture frame

Fig. b (Picture on monitor TV)

CD-197/198 (CCD IMAGER) (2.5 INCH LCD, 3 INCH/3.5 INCH LCD MODEL) PRINTED WIRING BOARD

– Ref No. CD-197 BOARD: 4,000 series, CD-198 BOARD: 9,000 series –


CD-197/198 BOARD (SIDE B)
CD-197/198 BOARD (SIDE A)
B
A
09
1
2
3
4
L401
③
②
①
8
14
Q402
Q403
R405
C405
R401
1-668-945-
1-668-936-
12
22
12

CD-197/ CD-198 BOARD	
C401	A-3
C403	B-3
C405	A-3
C406	A-3
C407	B-3
CN401	B-4
IC401	A-1
L401	B-1
Q402	B-3
R401	A-3
R404	B-3
R405	A-3

- **For Printed Wiring Boards.**

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip transistor




VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3.5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2.5 INCH LCD MODEL)
CF-51 (3 INCH/3.5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2.5 INCH LCD MODEL)
MA-312 (3 INCH/3.5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2.5 INCH LCD MODEL)
PJ-84 (3 INCH/3.5 INCH LCD MODEL)
(AV IN/OUT)

CD-197 BOARD (2.5INCH LCD MODEL)

CD-198 BOARD (3INCH/3.5INCH LCD MODEL)

CCD IMAGER

-REF NO CD-197 BOARD 4,000 CD-198 BOARD 9,000 SERIES-
XX MARK NO MOUNT
NC MARK CAMERA REC MODE


1
2
3
4
5
6
7
A
B
C
D
E
F
CN401 16P
V4 16
V3 15
V2 14
V1 13
GND 12
H2 11
H1 10
RG 9
GND 8
CAM_7 0V 7
VSHT 6
GND 5
CAM_15V 4
GND 3
CCD OUT 2
GND 1
TO
VC-195 BOARD(1/10)
CN501
(SEE PAGE 4-17)
IC401
ICX206AK-43 (NTSC 510H MODEL)
ICX207AK-43 (PAL 510H MODEL)
ICX209AK-43 (NTSC 760H MODEL)
ICX211AK-43 (PAL 760H MODEL)
IC401
CCD IMAGER
V4
V3
V2
V1
NC
GND
CCD_OUT
H2
H1
RG
VL
SHT
DGND
VDD
R405 100
R401 XX
C401 0.1u F
C405 4.7u 10V TA
L401 100uH
C406 4.7u 20V TA
Q402 2SC4178-F13F14-T1
Q402 BUFFER
R404 4700
C403 XX
C407 XX
LND401
GND
09

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC			➡》
PB			

2.5INCH LCD MODEL EXCEPT [illegible] TRV6 [illegible] /TRV8E/TRV9E/TRV[illegible]/TRV815
3INCH/3.5INCH LCD MODEL [illegible] TRV[illegible] /TRV8E/TRV9E/TRV61E/TRV815
NTSC 510H MODEL [illegible]
PAL 510H MODEL [illegible]
NTSC 760H MODEL [illegible]
PAL 760H MODEL [illegible]

CD-197/198 BOARD CAMERA REC


①
7Vp-p
H
IC401 ①,②
②
7Vp-p
H
IC401 ③,④
③
1.3Vp-p
H
IC401 ⑦

Note on the CCD imager replacement

- The CCD imager is not mounted for the already mounted CD-197/198 board supplied as the repair parts. When replacing the CD-197/198 board, remove the CCD imager from the old board and install on the new board.
- Perform all adjustments of the camera block when the CCD imager has been replaced
- Handle the CCD imager with attention such as MOS IC as it may be broken by static electricity in the structure. Also, prevent the receiving light section from dust attached and strong light.

VC-195 BOARD
(SIDE B)

C002	A-5	C213	D-5	C481	A-1	C774	A-8	L156	C-7	Q454	A-1	R112	C-7	R428	B-2	R628	E-2	R773	B-8
C003	A-5	C217	D-4	C482	A-2	C775	A-8	L201	D-3	Q455	A-1	R152	D-8	R429	B-1	R629	F-1	R774	B-9
C008	A-4	C218	D-4	C483	A-2	C776	B-8	L202	D-4	Q551	G-7	R154	D-8	R430	B-1	R630	F-2	R775	A-8
C009	B-5	C227	D-5	C484	A-2	C777	A-8	L203	D-6	Q607	F-2	R157	D-8	R432	C-2	R631	G-2	R921	B-1
C011	B-5	C229	E-5	C485	A-1	C778	B-9	L204	D-4	Q619	E-3	R179	D-8	R433	C-2	R632	G-1	R922	D-1
C012	B-5	C232	D-3	C504	E-6	C781	B-8	L205	D-6	Q620	F-2	R180	D-8	R434	C-2	R633	E-2	R923	D-1
C013	B-6	C233	D-5	C505	E-6			L206	D-3	Q705	F-7	R183	E-8	R452	A-3	R634	E-2	R924	D-1
C014	B-6	C234	D-5	C506	E-7	CN904	A-9	L207	E-4			R184	E-8	R453	A-3	R635	E-2	R925	D-1
C015	B-5	C235	D-3	C507	E-6	CN907	D-9	L209	E-4	R001	A-6	R202	D-3	R454	A-3	R636	E-2	R926	G-7
C016	B-5	C236	D-3	C508	E-6	CN910	D-1	L402	C-2	R002	A-6	R203	D-4	R455	A-3	R637	G-2	R927	G-7
C017	B-5	C239	E-4	C509	E-7			L501	E-6	R008	A-4	R204	D-3	R456	A-3	R638	G-2		
C019	B-5	C241	E-3	C510	E-6	D001	C-4	L552	F-7	R009	A-5	R205	D-3	R457	A-3	R639	G-2	RB12	C-8
C020	B-6	C243	F-3	C514	E-5	D201	D-3	L553	G-7	R010	B-6	R206	D-4	R459	A-3	R640	F-2	RB151	D-8
C022	B-5	C244	F-3	C515	E-5	D202	D-3	L602	E-3	R011	B-5	R208	D-3	R460	A-3	R641	F-3		
C025	B-6	C245	D-4	C518	F-5	D371	E-8	L701	F-7	R012	B-5	R210	D-3	R461	A-3	R642	F-2	TH401	B-4
C038	B-6	C246	D-4	C553	G-6	D502	F-5	L702	F-7	R013	B-6	R211	D-3	R462	A-3	R643	F-2		
C040	B-6	C247	D-4	C554	G-7	D601	E-2	L704	F-8	R014	B-4	R212	D-6	R463	A-3	R644	F-2	X151	D-7
C042	B-5	C249	E-4	C556	G-7	D602	E-2	L751	B-8	R015	B-5	R214	D-5	R467	A-2	R645	E-2	X401	B-3
C043	B-5	C252	F-3	C557	G-5	D604	F-2	L752	B-8	R016	B-6	R215	D-5	R468	A-2	R646	F-2	X501	F-5
C048	B-6	C301	B-9	C558	G-5	D608	F-1	L753	B-8	R017	B-6	R216	D-5	R469	A-2	R647	F-2		
C050	C-6	C312	C-9	C559	F-7	D609	F-2			R018	B-5	R217	E-4	R470	A-2	R648	F-2		
C051	B-5	C371	E-8	C563	F-6	D611	E-2	Q003	A-5	R019	B-5	R223	D-3	R471	A-2	R649	F-2		
C054	B-5	C372	E-8	C564	F-7	D910	G-1	Q004	A-6	R020	B-4	R224	D-3	R472	A-3	R651	F-2		
C056	B-5	C378	F-7	C566	G-7			Q005	A-5	R021	B-5	R226	D-4	R473	A-1	R652	F-3		
C058	B-6	C380	E-7	C569	G-6	FB202	E-4	Q006	A-5	R023	B-6	R240	D-4	R475	A-1	R653	F-3		
C060	C-5	C381	E-7	C572	F-6	FB203	E-4	Q007	A-6	R025	B-6	R244	D-3	R477	A-2	R654	F-3		
C066	B-6	C382	F-8	C603	F-1	FB204	F-3	Q008	B-6	R029	B-5	R246	D-3	R479	A-2	R655	F-2		
C067	C-6	C383	E-8	C607	E-2	FB205	F-3	Q009	B-6	R031	B-5	R247	D-3	R480	A-2	R662	E-3		
C068	C-6	C384	E-8	C610	F-2	FB206	D-4	Q010	B-5	R040	B-5	R248	E-3	R481	A-2	R663	F-3		
C069	C-5	C385	E-8	C611	F-2	FB501	E-5	Q011	B-5	R041	B-5	R249	E-3	R482	A-2	R665	F-3		
C070	C-6	C387	F-8	C613	E-1	FB502	E-6	Q012	B-5	R042	B-5	R250	F-3	R483	A-1	R678	F-3		
C072	C-6	C388	E-8	C625	E-2	FB503	E-5	Q016	B-5	R047	B-5	R254	D-1	R484	A-1	R686	E-2		
C074	C-6	C402	C-1	C626	E-2	FB504	E-5	Q017	B-6	R048	B-5	R255	E-5	R485	A-1	R687	E-2		
C076	C-5	C413	B-2	C627	F-2	FB505	E-5	Q018	C-5	R049	B-6	R257	D-4	R486	B-1	R689	F-3		
C077	C-5	C451	A-3	C630	F-3	FB506	E-5	Q019	C-6	R050	B-6	R304	B-9	R487	A-1	R690	F-2		
C080	C-5	C452	A-3	C634	F-3			Q021	B-6	R051	B-6	R305	C-9	R504	E-6	R691	E-2		
C083	C-5	C453	A-3	C636	F-2	IC152	C-8	Q023	C-6	R056	B-6	R329	A-6	R505	E-6	R692	F-1		
C086	C-4	C454	A-3	C704	F-7	IC201	E-5	Q025	C-6	R058	B-6	R330	A-7	R508	E-5	R704	G-8		
C087	C-4	C455	A-3	C714	F-8	IC204	F-4	Q026	C-6	R066	B-6	R371	D-8	R510	E-5	R705	G-7		
C090	C-6	C456	A-4	C715	F-8	IC371	E-7	Q030	C-5	R067	C-6	R372	D-8	R511	E-5	R716	G-8		
C152	D-8	C457	A-3	C751	B-6	IC401	C-2	Q031	C-5	R068	C-7	R373	D-9	R512	F-5	R717	F-8		
C157	E-8	C458	A-4	C752	A-7	IC403	B-2	Q032	C-7	R069	C-5	R374	D-8	R527	E-5	R718	F-7		
C158	D-8	C459	A-4	C753	A-7	IC404	B-2	Q035	C-4	R069	C-6	R375	D-8	R552	G-6	R719	F-8		
C159	C-8	C460	A-4	C754	A-7	IC451	A-4	Q037	C-4	R070	C-6	R376	D-8	R555	G-7	R723	F-7		
C174	D-8	C461	A-3	C755	A-7	IC452	A-2	Q038	C-5	R076	C-6	R377	E-8	R563	G-5	R752	A-7		
C175	D-8	C462	A-4	C756	A-7	IC501	E-6	Q039	C-5	R077	C-6	R378	E-8	R564	G-6	R753	A-7		
C176	D-8	C463	A-3	C757	A-7	IC552	G-6	Q041	B-5	R078	C-6	R379	E-7	R566	G-5	R754	B-6		
C182	D-8	C464	B-3	C758	A-8	IC602	E-2	Q042	C-4	R079	C-6	R382	E-8	R567	G-6	R755	B-6		
C183	D-8	C465	B-4	C759	B-6	IC751	A-8	Q151	D-8	R080	C-6	R383	E-8	R570	F-5	R757	A-7		
C190	D-8	C466	B-3	C760	B-6			Q202	D-3	R083	C-5	R384	E-7	R579	G-6	R758	A-7		
C191	C-7	C467	B-3	C761	B-8	L002	B-4	Q203	D-3	R084	C-5	R385	F-8	R582	G-6	R759	A-7		
C192	C-7	C468	B-3	C762	B-8	L003	B-4	Q204	D-5	R087	C-5	R386	F-8	R603	F-2	R760	B-8		
C202	D-3	C469	B-4	C763	B-8	L007	C-6	Q205	E-5	R088	C-5	R386	F-8	R604	F-2	R761	A-8		
C203	D-3	C470	B-4	C764	B-8	L008	C-6	Q208	D-6	R090	C-5	R388	E-8	R608	F-2	R762	A-8		
C204	D-4	C471	B-4	C765	A-8	L010	C-6	Q217	D-4	R094	C-5	R389	E-8	R612	E-1	R763	A-8		
C205	E-4	C473	A-1	C766	A-8	L011	C-6	Q218	D-4	R095	C-7	R403	C-2	R618	F-1	R764	B-8		
C206	D-4	C474	A-2	C767	B-8	L014	C-5	Q306	B-9	R097	C-5	R404	C-3	R619	F-1	R765	B-8		
C207	D-3	C475	A-2	C768	B-8	L015	C-5	Q307	C-9	R100	C-5	R415	B-2	R620	F-1	R766	A-8		
C208	D-3	C476	A-2	C769	A-8	L017	C-5	Q311	A-6	R104	C-5	R416	B-2	R621	F-1	R767	B-8		
C209	D-6	C477	A-2	C770	A-8	L019	B-6	Q312	A-7	R105	C-6	R417	B-2	R622	F-2	R768	A-8		
C210	D-6	C478	A-2	C771	B-8	L152	D-8	Q451	B-3	R106	C-6	R418	B-2	R624	F-1	R770	A-8		
C211	D-3	C479	A-2	C772	A-8	L153	D-7	Q452	B-4	R109	B-4	R426	C-2	R625	F-2	R771	A-8		
C212	D-3	C480	A-2	C773	B-8	L154	D-7	Q453	B-4	R110	B-5	R427	B-2	R627	E-2	R772	A-8		

- **For Printed Wiring Boards.**
- This board is four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

There are few cases that the part isn't mounted in this model is printed on this diagram

- Chip transistor



Chip diode




LB-54
(BACK LIGHT)
VF-120
(COLOR EVF)
VL-19
(VIDEO LIGHT)
VC-195
CAMERA, Y/C PROCESSOR, IN/OUT,
REC/PB HEAD AMP, SERVO/SYSTEM CONTROL,
SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
PD-92 (2 5 INCH LCD MODEL)
PD-93 (3 INCH/3.5 INCH LCD MODEL)
(RGB DECODER, LCD DRIVE, BACK LIGHT, LCD)
SE-66 (2.5 INCH LCD MODEL)
SE-67 (3 INCH/3 5 INCH LCD MODEL)
(STEADY SHOT)

VC-195 (CAMERA, Y/C PROCESSOR, IN/OUT, REC/PB HEAD AMP, SERVO/SYSTEM CONTROL, SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL) PRINTED WIRING BOARD

– Ref No VC-195 BOARD 1,000 series –

VC-195 BOARD (SIDE B)



CAMERA, Y/C PROCESSOR, IN/OUT, REC/PB HEAD AMP, SERVO/SYSTEM CONTROL, SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
VC-195 (SIDE B)

VC-195 BOARD (SIDE A)



4-13

4-14

VC-195 BOARD
(SIDE A)

C001	A-13	C328	C-11	CN908	A-17	R074	C-12	R527	B-17
C004	A-14	C330	C-11	CN909	G-11	R075	C-13	R529	E-12
C004	B-13	C331	C-11	CN911	D-17	R081	D-13	R551	G-11
C005	B-14	C332	A-11	CN912	F-18	R082	D-13	R552	G-15
C006	B-14	C333	A-11	CN914	B-18	R085	C-13	R553	G-13
C007	A-13	C334	C-12			R092	C-14	R554	G-12
C010	B-13	C335	A-11	D002	C-13	R093	C-13	R556	G-13
C018	B-14	C336	C-11	D501	F-13	R096	C-14	R557	G-12
C021	A-14	C337	A-11	D551	G-13	R098	D-14	R558	F-15
C023	A-13	C338	B-12	D610	E-18	R099	C-14	R559	G-15
C024	A-13	C339	A-11	D911	D-10	R101	D-14	R560	G-15
C026	B-13	C340	C-12			R102	C-14	R561	G-15
C027	B-13	C341	A-11	FB001	A-13	R103	C-14	R562	G-15
C028	B-12	C342	B-12	FB002	A-13	R107	C-14	R565	F-15
C029	B-13	C343	C-11	FB003	A-13	R113	C-14	R568	G-13
C030	B-14	C344	B-12	FB004	A-14	R161	D-11	R569	F-15
C031	B-13	C345	A-12	FB201	E-16	R162	C-11	R571	F-15
C032	B-13	C346	B-12	FB701	F-12	R165	D-10	R573	G-15
C033	B-14	C347	B-12	FB702	E-12	R166	D-10	R574	G-14
C034	B-14	C348	A-12			R167	D-10	R575	G-13
C035	C-14	C349	B-12	IC001	B-13	R170	D-10	R576	G-13
C036	B-13	C404	C-16	IC151	D-11	R175	D-12	R577	G-13
C037	B-14	C405	B-16	IC202	E-15	R176	D-12	R605	G-16
C039	B-14	C406	B-16	IC301	B-11	R177	D-10	R606	G-16
C041	B-14	C410	C-17	IC402	B-16	R178	D-10	R610	G-16
C045	B-14	C411	B-17	IC502	D-13	R218	D-14	R611	G-16
C046	C-14	C412	B-17	IC551	G-15	R219	D-15	R613	G-16
C047	B-14	C414	C-17	IC701	E-11	R220	D-15	R614	G-16
C049	C-14	C415	C-17			R222	C-15	R650	F-16
C052	C-13	C416	C-17	L001	B-13	R225	C-15	R666	E-17
C053	C-14	C417	C-16	L004	B-12	R227	D-14	R667	E-17
C055	C-13	C418	A-16	L005	C-13	R228	D-14	R668	E-17
C057	C-13	C419	B-17	L006	C-15	R229	D-14	R669	E-17
C059	C-12	C420	C-17	L009	C-13	R230	D-15	R670	E-17
C061	C-13	C472	A-17	L012	C-13	R231	D-15	R671	E-17
C062	C-14	C486	A-12	L013	C-14	R232	C-15	R672	E-16
C065	C-14	C487	A-18	L016	D-14	R233	D-14	R673	E-16
C071	C-15	C488	A-18	L018	C-14	R234	D-15	R675	F-16
C073	C-13	C489	A-15	L155	C-12	R236	D-14	R676	F-16
C075	C-13	C490	B-18	L502	D-13	R237	D-14	R679	G-17
C078	C-14	C501	F-13	L555	G-12	R238	D-15	R680	G-17
C079	C-13	C502	E-13			R239	D-15	R681	F-17
C081	C-14	C503	E-13	Q001	B-14	R241	D-14	R682	F-17
C082	C-14	C511	E-13	Q002	B-14	R242	D-15	R683	F-17
C084	D-14	C512	D-13	Q020	C-12	R243	D-16	R684	F-17
C085	C-14	C513	E-13	Q022	C-14	R251	E-16	R685	F-17
C088	C-14	C516	E-13	Q024	C-13	R252	E-16	R693	F-17
C089	C-13	C517	E-13	Q027	C-13	R253	F-16	R695	G-16
C156	E-12	C519	E-13	Q028	C-13	R256	F-14	R696	G-16
C160	D-12	C520	E-13	Q029	C-13	R302	C-10	R701	F-11
C161	E-12	C521	E-13	Q033	C-14	R303	B-10	R702	F-11
C162	E-11	C522	D-13	Q034	C-14	R306	B-12	R703	F-11
C163	E-11	C523	D-13	Q036	D-14	R308	B-11	R706	F-11
C164	D-11	C524	D-13	Q040	C-14	R309	B-12	R707	G-12
C166	D-12	C525	D-13	Q043	C-13	R310	B-11	R708	F-12
C168	D-11	C526	D-13	Q044	C-13	R311	B-10	R709	F-12
C169	D-12	C527	D-13	Q153	D-11	R312	B-12	R710	F-12
C170	D-11	C528	D-14	Q154	D-11	R313	A10	R711	F-11
C171	D-12	C529	D-14	Q156	D-10	R314	B-10	R712	E-12
C172	D-12	C530	D-14	Q213	C-15	R315	A10	R713	E-12
C173	D-12	C531	D-13	Q214	C-15	R316	A10	R714	E-12
C177	D-12	C532	D-13	Q215	C-15	R317	A-11	R715	E-12
C178	D-12	C533	D-13	Q216	C-15	R318	C-12	R720	E-12
C179	D-12	C534	E-13	Q301	C-10	R319	A-11	R721	E-12
C180	D-12	C535	E-13	Q302	B-10	R321	A10	R722	E-12
C181	C-11	C551	G-11	Q303	B-12	R322	A-12	R724	E-11
C184	D-11	C552	G-13	Q304	A-12	R323	B-12	R725	F-11
C185	C-12	C555	G-15	Q305	A10	R325	B-12	R726	F-11
C186	E-11	C560	F-14	Q308	C-10	R326	A-12	R916	E-16
C187	C-11	C561	F-15	Q309	C-10	R327	C-1	R917	C-17
C188	C-12	C562	F-15	Q310	A-11	R328	B-12	R918	C-17
C189	C-12	C565	F-15	Q329	A-11	R331	B-12	R919	C-17
C201	E-16	C567	G-14	Q371	A10	R343	A-12	R920	C-17
C214	D-14	C568	G-13	Q372	A10	R350	A-12		
C215	D-15	C570	G-14	Q456	A-18	R402	B-16	X601	G-17
C219	D-15	C571	G-14	Q501	D-13	R405	A-16	X602	F-15
C220	D-14	C604	F-17	Q553	G-15	R406	A-16		
C221	D-14	C605	G-16	Q608	G-16	R407	A-16		
C222	D-14	C612	E-16	Q609	G-16	R409	A-16		
C223	D-15	C615	E-16	Q610	G-16	R410	A-17		
C224	D-15	C616	E-17	Q611	G-15	R411	C-16		
C225	D-15	C617	E-17	Q701	G-11	R412	C-17		
C226	D-16	C618	E-17	Q702	F-12	R413	C-17		
C228	D-15	C619	E-17	Q703	F-12	R414	C-17		
C230	D-14	C620	E-17	Q704	F-11	R419	C-17		
C237	D-16	C621	E-17			R420	B-17		
C245	D-15	C622	E-17	R003	A-14	R421	B-17		
C248	E-16	C623	E-17	R004	A-14	R424	C-17		
C250	D-15	C624	E-16	R005	B-14	R425	A-17		
C303	A-12	C628	F-16	R006	B-14	R431	C-17		
C304	A-12	C629	F-16	R007	B-14	R435	C-17		
C306	B-10	C637	F-16	R026	B-13	R440	B-17		
C307	A10	C702	F-11	R027	B-13	R441	C-17		
C308	B-10	C703	F-11	R032	B-13	R458	A-15		
C309	B-10	C705	F-12	R033	B-14	R464	A-16		
C310	B-10	C706	F-12	R034	B-13	R465	A-16		
C311	C-10	C707	F-12	R035	B-14	R466	A-16		
C312	A10	C708	F-12	R037	B-14	R474	A-17		
C313	B-10	C709	F-11	R038	B-14	R476	A-17		
C314	A-11	C710	E-12	R039	B-14	R488	A-18		
C315	B-10	C711	E-12	R043	C-13	R490	A-18		
C316	B-10	C712	E-12	R045	B-14	R501	F-13		
C317	A-11	C713	E-12	R046	C-14	R502	F-13		
C318	B-10	C716	F-12	R052	C-14	R503	F-13		
C319	B-11	C717	F-12	R055	C-14	R507	E-13		
C320	A10			R057	C-14	R509	E-13		
C321	A10	CN001	A-13	R059	C-13	R513	D-13		
C322	C-11	CN501	F-14	R060	C-13	R514	E-13		
C323	A-11	CN551	G-12	R062	B-12	R521	D-13		
C324	A-11	CN901	A-11	R063	C-14	R522	D-13		
C324	A-12	CN902	C-10	R064	C-14	R523	D-13		
C325	C-11	CN903	B-10	R065	C-14	R524	D-13		
C326	C-11	CN905	A-15	R072	C-13	R525	D-13		
C327	A-11	CN906	A-16	R073	C-13	R526	D-13		

CAMERA, Y/C PROCESSOR, IN/OUT, REC/PB HEAD AMP, SERVO/SYSTEM CONTROL, SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL

VC-195 (SIDE A)

VC-195 BOARD (1/10)

①

CAMERA REC



NTSC 28.636 MHz
PAL 28.375 MHz

IC501 ⑤

②

CAMERA REC



NTSC 14.32 MHz
PAL 14.18 MHz

IC501 ⑪,⑫

③

CAMERA REC



IC501 ㉕,㉖

④

CAMERA REC



IC501 ㉘,㉛

⑤

CAMERA REC



IC501 ㊹

⑥

CAMERA REC



IC501 ㊺

⑦

CAMERA REC



IC502 ②—⑩

⑧

CAMERA REC



IC502 ㉖

⑨

PB



IC502 ㊱


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
A
B
C
D
E
F
G
H
I
J
K
CN501 16P
V4
V3
V2
V1
GND
H2
H1
RG
GND
CAM_-7 0V
VSHT
GND
CAM_15V
GND
CCD_OUT
GND
TO
CD-197 BOARD
CD-198 BOARD
CN401
(SEE PAGE 4-9)
R501
D501
C502
R502
R503
C501
C503
C504
C505
C506
C507
C508
C509
C510
C511
R504
R505
R506
FB501
FB502
XSHP
XSHD
X501
28 6363MHz
28 375MHz
D502
1T379-04-T8A
R512
470k
IC501
TIMING GENERATOR
CXD2486R-T4
VDD2
VSS3
XSHP
XSHD
XRS
RG
VDD3
VDD4
H1
H2
VSS4
XSHT/NC
ID
WEN
CKINH
AVD
AHD
VDD5
DSGAT
XV1
RST
SEN
SSI
SSK
XRST_TANUKI
XCS_TANUKI
VC_SO
XVC_SCK
F8506
CAM_15V
REG_GND
A_3 1V
CAM_-7 0V
D_3 1V
A_4 75V
TO
JC-19 BOARD(7/10)
MCK
CKL_510
CL
PBLK
AVD
AHD
AD10
AD9
AD8
AD7
AD6
AD5
AD4
AD3
AD2
AD1
TO
VC-195 BOARD(3/10)
V_STOP
XV1
XSG1
CLP1
ADCK_510
CAM_DD_ON
TO
VC-195 BOARD(10/10)
SL_SHUTTER_WE
CK_CONT
XVC_SCK
VC_SO
XCS_TANUKI
XRST_TANUKI
XCS_TG
TO
VC-195 BOARD(6/10)
CAM/XLINE
GCAM_PB
PB_C_RF
TO
VC-195 BOARD(5/10)
LINE_Y
TO
VC-195 BOARD(4/10)
FRQ_TUNE
FLIP
ACC/RF_CONT
AGC_CONT1
AGC_CONT2
TO
VC-195 BOARD(4/10)
IC502
S/H AGC
A/D CONVERTER
IC502
AD9800JCSTRL
DRVSS
DSUBST
DVSS
ADCLK
DVDD
STBY
PBLK
CLPOB
XSHP
XSHD
CLPDM
FMC
VRT
VRB
SUBST
ADVSS
REF SLOW
ADVDD
CAM/VIDEO
PB/REC
MODE1
MODE2
VTRBYP
CMLEVEL
L501
10uH
R513
2200
Q501
2SB1462J-QR(K8).SO
L502
22uH
R514
1k
C532
C533
Q501
Y GCA
09

VC-195 BOARD(1/10)

CAMERA1(CH BLOCK)

-REF NO 1,000 SERIES-
XX MARK NO MOUNT

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡	➡»	➡»»
PB	⇨		

[illegible] /TRV35E
PAL MODEL [illegible] V15E/ [illegible]
[illegible] /TRV15EP
[illegible] /TRV15E/TRV15EP
[illegible] 615/TRV815
PLAYER MODEL [illegible] TRV85/TRV93/TRV615/ [illegible]
[illegible] /TRV815
[illegible] /TRV815

CAMERA (1)
VC-195 (1/10)

- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
A
B
C
D
E
F
G
H
I
J
VC-195 BOARD(2/10)
CAMERA2(LD BLOCK)
-REF NO 1,000 SERIES-
XX MARK NO MOUNT
NO MARK CAMERA REC mode
* Can not be measured
IC551
HALL/IRIS DRIVE AMP
IC551 NJM324V(TE2)
OUT2
IN2-
IN2+
Vcc
IN1+
IN1-
OUT1
OUT3
IN3-
IN3+
GND
IN4+
IN4-
OUT4
Q552
IRIS METER DRIVE
Q552 2SD2216J-QR(K8) SO
Q553
AMP
Q553 2SD2216J-QR(K8) SO
Q551
ZOOM SENSOR SWITCH
Q551 2SB1462J-QR(K8) SO
IC552
FOCUS/ZOOM MOTOR DRIVER
IC552 MPC17A34RV (NTSC MODEL) uPD16833AG (PAL MODEL)
C1H
C2H
DGND
VG
B1_FA
PGND2
B2_FB
VM2
B3_ZA
PGND4
B4_ZB
EN4
IN4
EN3
IN3
C1L
C2L
VC
VM1
A1_FA
PGND1
A2_FB
A3_ZA
PGND3
A4_ZB
VM3
EN1
IN1
EN2
IN2
CN551 23P
BIAS(+) 1
HALL(+) 2
BIAS(-) 3
HALL(-) 4
CONT(-) 5
CONT(+) 6
DRIVE(-) 7
DRIVE(+) 8
ZM_XA 9
ZM_XB 10
ZM_B 11
ZM_A 12
FC_XA 13
FC_XB 14
FC_B 15
FC_A 16
PLA/GLASS 17
SENSE 18
FC_RST 19
GND 20
ZM 21
TEMP 22
TEMP 23
ZOOM LENS BLOCK
C558 0.22u B
R567 2200
R566 15k
R576 1k
R574 1k
R563 470k
C557 470p B
R564 470k
C567 0.001u B
R556 10 1/10W 2012
L555 10uH 2520
C568 XX B
C570 0.01u B
C571 10u 10V
C569 0.1u 2012
C553 0.01u B
D551 MA111-TX
C552 4700p B
C572 10u 10V
R568 XX
R560 1k
R559 XX
R558 0 1/10W 2012
C555 0.1u B
R562 220k
R561 470k
R569 2200
C560 0.1u F
R565 10k
R577 10k
R575 1k
R573 330
C565 0.1u F
C562 2200p B
C561 0.01u B 1608
R570 47k
R571 22k
R572 100k
R582 0
R552 XX
R553 XX
R579 1k
L552 10uH 3225
R555 4700
R554 68k
R557 68k
R551 47k
C551 XX
C559 0.01u B
C563 0.01u B
C564 33u 6.3V TA B
C554 0.01u B
C556 0.01u B
L553 10uH 2520
C566 1u F
HALL_REF
HALL_OFFSET
HALL_GAIN
⑦ TO VC-195 BOARD(4/10)
D_3.1V
REG_GND
AU_4.75V
MT_GND
⑧ TO VC-195 BOARD(7/10)
IRIS_PWM
HALL_AD
LENS_FILTER_ON_SW
PLA/GLASS
FC_RST
LENS_RST_LED
ZM_RST
LENS_TEMP_AD
⑨ TO VC-195 BOARD(6/10)
IRIS_COM
ZM_RST
FC_RST
DIR1B
DIR1A
EN1
EN0
DIR0A
DIR0B
⑩ TO VC-195 BOARD(3/10)
09

• ZOOM LENS BLOCK is replaced as a block so that these SCHEMATIC DIAGRAM and PRINTED WIRING BOARD are omitted

NTSC MODEL EXCEPT CCD-TRV15E/TRV15EP/TRV35E
PAL MODEL CCD-TRV15E/TRV15EP/TRV35E

VC-195 BOARD (3/10)



- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board.


VC-195 BOARD(3/10)
Y/C PROCESSOR(CL BLOCK)
-REF NO 1,000 SERIES-
XX MARK NO MOUNT
TO VC-195 BOARD(6/10 10/10) ⑪
TO VC-195 BOARD(7/10) ⑫
TO VC-195 BOARD(4/10) ⑬
TO VC-195 BOARD(5/10) ⑭
TO VC-195 BOARD(10/10) ⑮
TO VC-195 BOARD(6/10) ⑯
TO VC-195 BOARD(8/10 9/10) ⑰
TO VC-195 BOARD(1/10) ②
TO VC-195 BOARD(2/10) ⑩
TO VC-195 BOARD(10/10) ⑱
Q204 Y BUFFER
Q208 Y TRAP SWITCH
Q214 B-Y BUFFER
Q213 R-Y BUFFER
Q216 Y BUFFER
Q215 Y BUFF
Q217 PB C AMP
Q218 MUTE SWITCH
Q202-203 VCO
Q205 OSD SWITCH
IC202 Y/C PROCESSOR
IC204 MEMORY
IC201 CHARACTOR GENERATOR
C.OUT
Y.OUT
C.RF
Y.RF
PANEL.V
PANEL.U
PANEL.Y
Bult A/D
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
A
B
C
D
E
F
G
H
I
J
K
L

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡	➡	➡
PB	⇨	⇨	

• SIGNAL PATH

	REC	REC/PB	PB
Ref. signal	⇨		

- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board.


VC-195 BOARD(4/10)
IN/OUT(IO BLOCK)
-REF NO 1,000 SERIES-
XX MARK NO MOUNT
TO VC-195 BOARD(3/10) 13
4FSC
IKA_C_OUT
TANUKI_Y_OUT
TANUKI_C_OUT
AFC_FO_ADJ
510_TRAP_ON
TO VC-195 BOARD(1/10) 47
LINE_Y
CN902 12P
S_Y_I/O
S_GND
S_C_I/O
XS_JACK_IN
VIDEO_I/O
VIDEO_GND
V_JACK_IN
A_4.75V
AUDIO_L_I/O
AUDIO_GND
AUDIO_R_I/O
XJACK_MONO
TO PJ-B3 BOARD
PJ-B4 BOARD
CN101
(SEE PAGE 4-57)
TO VC-195 BOARD(8/10) 19
AUDIO_R_I/O
AUDIO_L_I/O
TO VC-195 BOARD(10/10) 20
XJACK_MONO
V_JACK_IN
XS_JACK_IN
TO VC-195 BOARD(6/10) 21
XCS_IO
VC_SO
XVC_SCK
SWP
DA_STB
Q151
V ON SIWTCH
Q151 UN9113J-(K8) SO
Q154, 156
VIDEO MUTE
Q156 2SC5376-B(TE85L)
Q154 2SC5376-B(TE85L)
Q153 2SC5376-B(TE85L)
Q153
VIDEO MUTE
IC151
SIGNAL SELECTOR
IC151 CXA2030R-T6
SEP D Y IN
GND7
SEP D C IN
GND1
AGC V OUT
CLAMP TC
CSYNC IN
CSYNC OUT
CLAMP TC2
V1 IN
AGC TC
V2 IN
GCA CONT1
V3 IN
GCA CONT2
C1 IN
Fsc OUT
Vcc3
V COMP IN
DRIVE V OUT
GND3
EZ V OUT
Vcc4
DRIVE Y OUT
Y COMP IN
GND4
DDS B
EZ Y OUT
DDS W
EZ C OUT
Vcc5
C OUT
IC152
D/A CONVERTER(EVR)
IC152 M88344
5V
3V
AUDIO_DEV
VIDEO_CAR
VIDEO_DEV
FLIP
LCD_BL_CONT
V_ON
1.5M_DEV
AU_BPF
1.7M_DEV
A_FADE
ZM_MIC_CONT
ACC/RF_CONT
RP_IR
AFC_FO_ADJ
FRQ_TUNE
CFG_DUTY
SP_VOL
E/XL
510_TRAP_ON
AGC_CONT2
AGC_CONT1
TO VC-195 BOARD(7/10) 22
A_4.75V
D_3.1V
REG_GND
A_3.1V
TO VC-195 BOARD(5/10) 23
RP_IR
MT_G
DOC_DET
MT_FO
REC_L_CONT
RF_AGC_CONT
REC_Y/MT_CONT
XMP/ME
E/XL
RF_AGC_OFF
*LP/XSP
IR_VIDEO
TO VC-195 BOARD(7/10) 24
CFG_DUTY
LCD_BL_CONT
TO VC-195 BOARD(9/10) 25
IR_VIDEO
AUDIO_DEV
VIDEO_CAR
VIDEO_DEV
TO VC-195 BOARD(2/10) 7
HALL_GAIN
HALL_OFFSET
HALL_REF
FRQ_TUNE
TO VC-195 BOARD(1/10) 6
AGC_CONT1
AGC_CONT2
ACC/RF_CONT
FLIP
TO VC-195 BOARD(8/10) 26
1.5M_DEV
1.7M_DEV
AU_BPF
A_FADE
*LP/XSP
SP_VOL
ZM_MIC_CONT
R183 16k ±0.5%
R184 1k ±0.5%
• SIGNAL PATH
VIDEO SIGNAL
CHROMA
Y
Y/CHROMA
AUDIO SIGNAL
REC
PB

VC-195 BOARD (4/10)
CAMERA REC

㉚



IC151 ③

㉛



IC151 ⑤

㉜



IC151 ⑰, (64)

㉝



IC151 ㉕, (60)

(34)



IC151 ㉙ (2.1Vp-p)
IC151 (62) (1.6Vp-p)

- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board.

VC-195 BOARD (5/10)




1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
26
27
28
29
30
31
A
B
C
D
E
F
G
H
I
J
K
L
VC-195 BOARD(5/10)
REC/PB HEAD AMP(RR BLOCK)
-REF NO 1,000 SERIES-
XX MARK NO MOUNT
LND001
LND002
LND003
VIDEO HEAD
LP 2CH
LP 1CH
SP 1CH
SP 2CH
FLYING ERASE
CN001 16P
Q004-008 REC/PB LP2 HEAD SWITCH
Q007,009 REC/PB LP1 HEAD SWITCH
Q005,010 REC/PB SP1 HEAD SWITCH
Q006,011 REC/PB SP2 HEAD SWITCH
Q002 ERASE CURRENT SWITCH
Q001,003 ERASE HEAD OSC
Q012 ERASE HEAD ON SWITCH
IC001 VIDEO HEAD REC/PB AMP
Q017 PB RF AMP
Q019 AGC SLOW SWITCH
Q022 REC C AMP
Q021,023 FILTER
Q025,026 FILTER SWITCH
Q030 FILTER
Q039 RF AGC AMP
Q041 PB 4.75V SWITCH
Q042 REC/PB SWITCH
Q020 BUFFER
Q024 REC Y AMP
Q027 AMP
Q028,029 TRAP SWITCH
Q033 MP/ME SWITCH
Q034-036 FILTER
Q038 SWITCH
Q040 SWITCH
Q043 SWITCH
Q044 MP/ME SWITCH
Q032 RF AGC OFF SWITCH
IC701
CPC (FOR CHECK)
(27) TO VC-195 BOARD(6/10)
(23) TO VC-195 BOARD(4/10)
(4) TO VC-195 BOARD(1/10)
(14) TO VC-195 BOARD(3/10)
(28) TO VC-195 BOARD(8/10)
(29) TO VC-195 BOARD(7/10)
(32) TO VC-195 BOARD(10/10)
(30) TO VC-195 BOARD(10/10)
(31) TO VC-195 BOARD(7/10)

• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	➡	➡	➡	
PB	⇢	⇢	⇢	

• SIGNAL PATH

	REC	REC/PB	PB
Ref. signal			

* MARKED MOUNT TABLE

Model / Ref No	NTSC		PAL
	Hi8	STANDARD 8	STANDARD 8
C075	330p	470p	470p
C080	10p	22p	22p
C083	82p	68p	56p
C088	220p	68p	68p
C089	47p	22p	22p
R057	680	0	0
R063	470	560	560
R064	3900	0	0
R077	xx	330	270
R105	680	270	270

09

- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board.


VC-195 BOARD(6/10)
SERVO/SYSTEM CONTROL
(MC BLOCK)
·REF NO 1,000 SERIES·
XX MARK NO MOUNT
TO VC-195 BOARD(8/10) 34
TO VC-195 BOARD(4/10) 21
TO VC-195 BOARD(5/10) 27
TO VC-195 BOARD(3/10) 16
TO VC-195 BOARD(1/10) 5
TO VC-195 BOARD(2/10) 9
TO VC-195 BOARD(10/10) 36
TO VC-195 BOARD(8/10) 37
TO VC-195 BOARD(3/10 10/10) 11
TO VC-195 BOARD(7/10) 33
TO VC-195 BOARD(7/10) 35
IC402
SERVO/SYSTEM CONTROL
IC402
MB91191PFF-G-BND-ER
IC401
EEP ROM
IC401
AK6480AM-E2
IC403
IC404
CN907 16P
OPEN
X401 20MHz
REG.GND
D.3 1V
MT.GND
MT.4 75V
09

• SIGNAL PATH

	REC	REC/PB	PB
Drum speed servo		▶	
Drum phase servo		▶··	
Drum servo(speed and phase)		▶···	
Capstan speed servo		➤	
Capstan servo(speed and phase)		➤››	

★ MARKED MOUNT TABLE

Model / Ref No	TYPE A	TYPE B	TYPE C	TYPE D	TYPE E	TYPE F	TYPE G
R917	22k	22k	22k	22k	47k	22k	22k
R919	56k	100k	47k	22k	100k	100k	100k
R920	68k	XX	100k	100k	XX	47k	22k

VC-195 BOARD (6/10)
CAMERA REC


㊻
1.7Vp-p
20 MHz
IC402 ①
㊼
2V
3Vp-p
IC402 ㊼
㊽
4V
3Vp-p
IC402 ㊽
㊾
2V
3Vp-p
IC402 (55), (57)
㊿
13usec
3Vp-p
IC402 (68)
(51)
13usec
3Vp-p
IC402 (69)
(52)
13usec
3Vp-p
IC402 (70)
(53)
1.2msec
3Vp-p
IC402 (115)
(54)
2.8msec
3Vp-p
IC402 (116)
(55)
2V
3Vp-p
IC402 (117)

- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board.


VC-195 BOARD(7/10)
SERVO(SB BLOCK)
-REF NO 1,000 SERIES-
XX MARK NO MOUNT
MECHA DECK
S901 MODE SW
M903 LOADING MOTOR
FP-220 (FLEXIBLE)
M901 DRUM MOTOR
FP-248 (FLEXIBLE)
M902 CAPSTAN MOTOR
DEW SENSOR
FP-356 (FLEXIBLE)
Q002 TAPE END
Q001 TAPE TOP
S REEL DETECT
T REEL DETECT
H001
H002
S002
FP-249 (FLEXIBLE)
FP-355 (FLEXIBLE)
D001 TAPE LED
FP-221 (FLEXIBLE)
IC451
DRUM MOTOR DRIVER
DRUM PG/FG WAVEFORM SHAPER
IC451 LB1950V-TLM
Q452, 453 DRUM MOTOR ON SWITCH
Q452 UN9213J-(K8) SO
Q453 UN9213J-(K8) SO
Q454, 455 CAPSTAN ERROR AMP
Q454 2SB1462J-QR(K8) SO
Q455 2SB1462J-QR(K8) SO
IC452
LOADING MOTOR DRIVE SENSOR AMP
IC452 LB8112V-TLM TA8482FN-EL
Q456 TAPE LED ON/OFF SWITCH
Q456 2SD2216J-QR(K8) SO
CN914 48P
TO DD-105 BOARD CN931 (SEE PAGE 4-121)
CN901 8P
CN905 10P
CN906 12P
CN908 15P
TO VC-195 BOARD(5/10) ㉛
TO VC-195 BOARD(6/10) ㉝
TO VC-195 BOARD(4/10) ㉔
TO VC-195 BOARD(10/10) ㊳
TO VC-195 BOARD(1/10) ①
TO VC-195 BOARD(2/10) ⑧
TO VC-195 BOARD(3/10) ⑫
TO VC-195 BOARD(4/10) ㉒
TO VC-195 BOARD(5/10) ㉙
TO VC-195 BOARD(6/10) ㉟
TO VC-195 BOARD(10/10) ㊶
TO VC-195 BOARD(9/10) ㊵
TO VC-195 BOARD(8/10) ㊴
㊷
09

• SIGNAL PATH

	REC	REC/PB	PB
Drum speed servo		▶	
Drum phase servo		▶>	
Drum servo(speed and phase)		▶>>	
Capstan phase servo		➤>	
Capstan servo(speed and phase)		➤>>	

VC-195 BOARD (7/10)
CAMERA REC



- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board.

VC-195 BOARD(8/10)

AUDIO(AU BLOCK)
-REF NO : 1,000 SERIES-
XX MARK : NO MOUNT
NO MARK : CAMERA REC mode

• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC				
PB			⇨》	


TO VC-195 BOARD(10/10)
44
HP_SENSE
SHOE_MIC_L
HOT_SHOE_ID1
XVTR_MODE_SW
XCAM_MODE_SW
EXT_MIC_DET
XWIND_ON
F_TALLY_LED
XSIRCS_SIG
SP-
SP+
SP_SEL
SP_ON
HP_ON
BEEP
TO VC-195 BOARD(7/10)
39
VTR_UNREG
A_4 75V
A_3 1V
REG_GND
AU_3 1V
MT_4 75V
AU_4 75V
TO VC-195 BOARD(4/10)
19
AUDIO_R_I/O
AUDIO_L_I/O
TO VC-195 BOARD(9/10)
45
HP_L_OUT
HP_R_OUT
CN903 23P
TO MA-311 BOARD
MA-312 BOARD
MA-331 BOARD
CN303
(SEE PAGE 4-62)
CN904 10P
TO SE-66 BOARD
SE-67 BOARD
CN650
(SEE PAGE 4-53)
TO VC-195 BOARD(6/10)
37
PITCH_AD
VST_C_RESET
YAW_AD
FOCUS_B_AD
FOCUS_A_AD
TO VC-195 BOARD(9/10)
43
IR_DRV_ME
IR_DRV_CL
IC371
HEADPHONE/SPEAKER OUT AMP
BA7783FS-E2
Q371 UN9216J-(K8) SO HP L MUTE
Q372 UN9216J-(K8) SO HP R MUTE
Q305 UN9115J-(K8) SO MUTE SWITCH
Q306 UN9215J-(K8) SO IN/OUT SWITCH
Q307 UN9215J-(K8) SO IN/OUT SWITCH
Q301 UN9216J-(K8) SO AU R SWITCH
Q302 UN9216J-(K8) SO AU L SWITCH
Q308, 309 AUDIO IN/OUT SWITCH
Q310 UN9213J-(K8) SO PB/REC SWITCH
IC301
AFM PROCESSOR
AN2982FH-EB
AN2984FH-EB
62
61
60
59
ZM_MIC_CONT
SP_VOL
1 5M_DEV
AU_BPF
A_FADE
1 7M_DEV
XLP/XSP
26
TO VC-195 BOARD(4/10)
FSC
17
TO VC-195 BOARD(3/10,9/10)
BPF_MONI
REC_AFM
PB_5V
28
TO VC-195 BOARD(5/10)
PB_RF
SWP
VC_SI
VC_SO
XVC_SCK
XCS_AU
AU_XIN/OUT
PB/XREC
34
TO VC-195 BOARD(6/10)
R325 330k : STEREO MODEL 220k : MONAURAL MODEL
R322 220k : STEREO MODEL 100k : MONAURAL MODEL

VC-195 BOARD (8/10)

(59) CAMERA REC



IC301 ㉑

(60) PB



IC301 ㉔

(61) CAMERA REC



IC301 ㉙

(62) CAMERA REC



3.58 MHz

IC301 ㉜

- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board

VC-195 BOARD (9/10)
PB




1
2
3
4
5
6
7
8
9
10
11
12
13
14
A
B
C
D
E
F
G
H
VC-195 BOARD(9/10)
IR TRANSMITTER(IR BLOCK)
-REF NO 1,000 SERIES-
XX MARK NO MOUNT
TO VC-195 BOARD(7/10) (40)
A_4.75V
REG_GND
TO VC-195 BOARD(4/10) (25)
VIDEO_CAR
VIDEO_DEV
AUDIO_DEV
IR_VIDEO
TO VC-195 BOARD(8/10) (45)
HP_L_OUT
HP_R_OUT
TO VC-195 BOARD(3/10 8/10) (17)
FSC
TO VC-195 BOARD(10/10) (46)
SIRCS_PWM
IR_ON
TO VC-195 BOARD(8/10) (43)
IR_DRV_CL
IR_DRV_EM
IC751
VIDEO/AUDIO PROCESSOR
IC751 LA9511W-TBM
CLAMP C1
NC
V DEV ADJ
V IN
REG
REF
A DEV ADJ
Lch IN
ALC C
Rch IN
DRV CL OUT
DRV EM OUT
DRV SW
MIX OUT
MIX IN
VRF OUT
ARF OUT
STBY
CHUP C
CLAMP C2
CAR ADJ
PRE EM IN
PRE EM OUT
VCC
V GND
HPF OUT
V REF
VRF IN
BAND SEL
REF R
[ALC OUT Lch]
X tal SEL
[ALC OUT Rch]
[OSC OUT]
X tal IN
A GND
LPF L
LPF R
OSC VCC
(63)
(64)
(65)
(66)
(67)
C763 0.01u B
C764 10u 6.3V TA A
C761 0.01u B
C762 510p CH
L751 5.6uH 2520
C768 4p CH
C771 33p CH
C773 39p CH
L752 33uH 2520
L753 33uH 2520
C767 0.1u B
R764 330
R765 1k
R767 470
R755 22k
R760 15k
R756 4700
R757 4700
C753 0.01u B
C759 0.01u B
C760 4.7u 6.3V TA A
C751 10u 4V TA A
C756 0.01u B
C757 10u 4V TA A
R754 XX
C754 0.47u B 2012
R752 47k
R753 47k
C755 0.47u B 2012
C752 10u 6.3V TA A
R758 10k
R759 10k
R761 1M
C758 1u B 2012
R763 22k ±0.5%
R766 XX
R768 150k
R770 150k
C765 0.01u B
C766 1u B 2012
C769 0.47u B 2012
C770 0.47u B 2012
C772 1u B 2012
C774 1u B 2012
C775 0.1u B
R773 470
R771 560
C776 0.01u B
R772 6800
C777 0.01u B
C778 0.01u B
R774 39k
C781 22u 4V TA A
R762 XX 1608
R775 0 1608
09

• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC				
PB			⇨	

IR TRANSMITTER
VC-195 (9/10)

VC-195 BOARD (10/10)

(68)



20 MHz

IC604 ㊶

(69)



32 kHz

IC604 52

- **For schematic diagrams.**
- Refer to page 4–11 for Printed Wiring Board
- Refer to page 4–48 for Waveforms


VC-195 BOARD(10/10)
MODE CONTROL(HI BLOCK)
-REF NO 1,000 SERIES-
XX MARK NO MOUNT
Q620 LANC ON SWITCH
IC603 LANC IN/OUT
Q608 BUFFER
Q609 BUFFER
Q610 SWITCH
Q611 SWITCH
IC602 INITIAL RESET BACKUP VCC
IC604 MODE CONTROL
Q607 BATTERY CHARGE DETECTOR
Q619 SWITCH
TO VC-195 BOARD(1/10)
TO VC-195 BOARD(3/10)
TO VC-195 BOARD(4/10)
TO VC-195 BOARD(7/10)
TO VC-195 BOARD(5/10)
TO VC-195 BOARD(3/10,6/10)
TO VC-195 BOARD(6/10)
TO VC-195 BOARD(9/10)
TO VC-195 BOARD(8/10)
TO VL-19 BOARD CN151
(SEE PAGE 4-63)
FP-633 FLEXIBLE
INTELLIGENT ACCESSORY SHOE
TO CF-50 BOARD CN001
(SEE PAGE 4-67)
TO CF-51 BOARD CN001
(SEE PAGE 4-70)
TO DD-105 BOARD CN932
(SEE PAGE 4-124)
CN909 10P
CN911 50P
CN912 16P
SIGNAL PATH
VIDEO SIGNAL
CHROMA
Y
Y/CHROMA
AUDIO SIGNAL
REC
PB

MODE CONTROL
VC-195 (10/10)

SE-66/67 (STEADY SHOT) (2.5 INCH LCD, 3 INCH/3.5 INCH LCD MODEL) PRINTED WIRING BOARD

– Ref No SE-66 BOARD 4,000 series, SE-67 BOARD 9,000 series –


SE-67 BOARD (SIDE B)
SE-66 BOARD (SIDE B)
SE-67 BOARD (SIDE A)
SE-66 BOARD (SIDE A)
E
D
C
B
A
09
1
2
3
4
5
6
7
8
SE452
SE451
C458
C457
C463
C465
C455
C456
C452
R453
R452
R456
L452
L451
C471
R462
L454
C469
C467
L453
C460
C454
R455
IC451
C466
C459
C461
C462
C464
R451
C453
D452
D451
C470
J451
1-668-938-
1-668-947-
12
12
22

SE-66 SE-67 BOARD	
C451	C-6
C452	D-3
C453	B-6
C454	E-6
C455	C-3
C456	C-3
C457	C-2
C458	C-3
C459	C-6
C460	E-6
C461	C-6
C462	C-6
C463	C-3
C464	C-6
C465	C-3
C466	C-6
C467	A-2
C468	A-6
C469	A-2
C470	A-6
C471	B-3
CN451	A-3
D451	A-6
D452	A-6
IC451	C-6
J451	A-8
L451	B-3
L452	B-2
L453	A-3
L454	A-2
R451	C-6
R452	D-3
R453	D-3
R454	C-6
R455	D-6
R456	C-3
R457	C-3
R458	C-6
R459	C-6
R460	C-3
R461	C-6
R462	B-3
R463	B-3
SE451	B-3
SE452	D-3

- **For Printed Wiring Boards.**

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip diode


1
2
3
4
5
6
7
8
9
10
A
B
C
D
E
F
SE-66 BOARD
SE-67 BOARD
STEADY SHOT
-REF NO SE-66 BOARD 4,000 SE-67 BORAD 9,000 SERIES-
XX MARK NO MOUNT
NO MARK CAMERA REC mode
• SIGNAL PATH
AUDIO SIGNAL
REC
PB
(STEADY SHOT MODEL)
SE451 YAW
SE452 PITCH
IC451 BUFFER
IC451 UPC6756GR-8JG-E2
GND
LIB1
LIA1
LO1
HI1
HO1
Vref1
AM1
OUT1
PASS
LIB2
LIA2
LO2
HI2
HO2
Vref2
AM2
OUT2
CRST
VCC
C453 22u 4V TA A
R451 22k
C451 0 1u B 2012
R454 22k
C461 0 056u B
C462 22u 6 3V
C459 0 056u B
R458 10k
R461 15k
C464 0 33u B 2012
R459 1M
C465 10u 6 3V TA
C466 0 01u B
R455 0
C455 XX 6 3V TA A
C456 XX F
C457 0 056u B
R462 XX
R463 100
R456 1M
C458 0 056u B
C460 22u 6 3V
R460 XX
R457 10k
C463 XX
C471 XX
R452 22k
C454 22u 4V TA A
C452 0 1u B 2012
R453 22k
L451 10uH
L452 XX
CN451 10P
10 SE_GND
9 YAW_AD
8 VST_C_RESET
7 PITCH_AD
6 A_3 1V
5 A_4 75V
4 HP_SENSE
3 HEADPHONE_R
2 HEADPHONE_L
1 HEADPHONE_GND
TO VC-195 BOARD(8/10) CN904
(SEE PAGE 4-41)
J451
L454 0
L453 0
C470 XX B
C469 XX B
C468 XX B
C467 XX B
D452 MAZJ082DFLSO
D451 MAZJ082DFLSO
LN0451 GND
09


LB-54
(BACK LIGHT)
VF-120
(COLOR EVF)
VL-19
(VIDEO LIGHT)
VC-195
CAMERA, Y/C PROCESSOR, IN/OUT,
REC/PB HEAD AMP, SERVO/SYSTEM CONTROL,
SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
PD-92 (2 5 INCH LCD MODEL)
PD-93 (3 INCH/3 5 INCH LCD MODEL)
(RGB DECODER, LCD DRIVE, BACK LIGHT, LCD)
SE-66 (2.5 INCH LCD MODEL)
SE-67 (3 INCH/3 5 INCH LCD MODEL)
(STEADY SHOT)

PJ-83/84 (AV IN/OUT) (2.5 INCH LCD, 3 INCH/3.5 INCH LCD MODEL) PRINTED WIRING BOARD

– Ref No PJ-83 BOARD. 4,000 series, PJ-84 BOARD: 9,000 series –

PJ-84 BOARD (SIDE B)
PJ-83 BOARD (SIDE B)


C
C105
C108
2
3
1
D101
L103
L104
C106
CN101
1
2
R109
C104
C103
C107
L102
C111
2
3
1
IC102
L101
C101
R102
C102
Q102
R104
R105
Q101
R103
D105
D103
C109
R107
C110
R106
R108
R101
2
1
D102

PJ-84 BOARD (SIDE A)
PJ-83 BOARD (SIDE A)


B
A
R
AUDIO
L
J101
RFU DC OUT
VIDEO
S VIDEO
1-668-937-
1-668-946-
12
12
22
09
1
2
3
4
5

- **For Printed Wiring Boards.**

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip diode




VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3 5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2.5 INCH LCD MODEL)
CF-51 (3 INCH/3 5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2 5 INCH LCD MODEL)
MA-312 (3 INCH/3.5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2 5 INCH LCD MODEL)
PJ-84 (3 INCH/3 5 INCH LCD MODEL)
(AV IN/OUT)

PJ-83
PJ-84 BOARD

C101	C-4
C102	C-4
C103	C-3
C104	C-3
C105	C-1
C106	C-2
C107	C-1
C108	C-1
C109	C-5
C110	C-5
C111	C-1
CN101	C-2
D101	C-1
D102	C-3
D103	C-4
D105	C-5
D106	C-5
D107	C-5
J101	A-3
L101	C-3
L102	C-3
L103	C-2
L104	C-2
Q101	C-5
Q102	C-4
R101	C-4
R102	C-4
R103	C-4
R104	C-4
R105	C-4
R106	C-5
R107	C-5
R108	C-5
R109	C-3

PJ-83 BOARD
PJ-84 BOARD

AV IN/OUT

-REF NO　PJ-83 BOARD 4,000 PJ-84 BOARD 9,000 SERIES-
XX MARK　NO MOUNT

• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	➡	➡	➡	
PB	⇨	⇨	⇨	


1
2
3
4
5
6
7
8
9
10
11
12
13
A
B
C
D
E
F
J101
S VIDEO
VIDEO
RFU DC OUT
L
(MONO)
AUDIO
R
12 S C I/O
14 XS JACK IN
10 S GND
11 S GND
15 S GND
S Y I/O
13
2 VIDEO I/O
16 V JACK IN
1 VIDEO GND
6 RFU DC GND
5 RFU DC OUT
4 AUDIO L I/O
17 AUDIO GND
3 AUDIO GND
8 AUDIO R I/O
9 XJACK MONO
7 AUDIO GND
R101 0
C102 XX
Q101 2SB798-T1-DLDK
L101 1uH
C101 47u 6.3V
R102 3.3 1/8W
R104 820
R103 5600
R105 18k
Q102 2SD1819A-QRS-TX
L102 0
L103 0
L104 0
C103 XX B
C104 XX B
C105 XX B
C106 XX B
C107 XX B
C108 XX B
D101 MAZJ082DFL SO
D102 MAZJ082DFL SO
D103 MAZJ082DFL SO
D105 MAZJ082DFL SO
D106 MAZJ082DFL SO
D104 MA8082-TX
R106 0
R107 0
C109 XX
C110 XX
R108 1k
R109 1k
C111 XX
A LND101
CN101 12P
12 S_Y_I/O
11 S_GND
10 S_C_I/O
9 XS_JACK_IN
8 VIDEO_I/O
7 VIDEO_GND
6 V_JACK_IN
5 A_4.75V
4 AUDIO_L_I/O
3 AUDIO_GND
2 AUDIO_R_I/O
1 XJACK_MONO
TO
VC-195 BOARD(4/10)
(SEE PAGE 4-27)
09

MA-311/331 (STEREO MIC, LASER LINK) (2.5 INCH LCD MODEL) PRINTED WIRING BOARDS

– Ref No MA-311 BOARD: 3,000 series, MA-331 BOARD 4,000 series –

MA-311/331 BOARD (SIDE B) MA-311/331 BOARD (SIDE A)


D
C
B
A
VTR
PLAYER
POWER
CAMERA
MIC
(PLUG IN)
(POWER)
LASER LINK
IC322
IC321
IC301
CN303
S301
S302
S303
1-668-934-11
1-668-949-12 22
09
1
2
3
4
5
6
7

MA-331
MA-311 BOARD

C301	A-3	C344	B-5	C373	D-5	Q301	A-5	R327	B-5	R356	D-6
C302	A-3	C345	C-5	C374	B-6	Q302	A-1	R328	B-5	R357	D-6
C303	A-1	C346	D-4	C375	D-5	Q303	A-2	R329	B-5	R358	D-5
C304	A-2	C347	C-3	C376	B-7	Q304	B-3	R330	B-6	R359	C-2
C305	A-2	C348	D-3	C377	B-6	Q305	A-1	R331	B-6	R360	C-6
C306	A-1	C349	D-3	C378	C-6	Q321	B-5	R332	B-6	R361	D-5
C321	B-5	C350	D-3			Q322	B-6	R333	B-6	R362	D-6
C322	B-5	C351	D-3	CN301	B-2			R334	B-6	R363	D-5
C323	B-5	C352	D-3	CN302	B-3	R301	A-5	R335	C-4	R364	D-5
C324	B-6	C353	D-3	CN303	B-1	R302	A-1	R336	C-4	R365	C-5
C325	B-6	C354	D-5			R303	A-2	R337	C-3	R366	C-5
C326	B-6	C355	D-5	D301	A-6	R304	A-3	R338	D-3	R367	C-5
C327	B-5	C356	C-2	D302	A-6	R305	A-2	R339	C-5	R368	D-5
C328	B-6	C357	C-2	D303	B-5	R306	B-7	R340	C-3		
C329	B-6	C358	D-5	D305	B-7	R307	B-1	R341	C-5	S301	D-4
C330	C-7	C359	C-5	D307	D-5	R308	D-3	R342	C-3	S302	D-2
C331	B-6	C360	C-2	D308	B-7	R309	D-3	R343	C-5	S303	C-1
C332	B-6	C361	C-2	D309	A-5	R310	B-3	R344	C-5		
C333	C-3	C362	D-5	D322	B-5	R311	A-1	R345	D-3		
C334	C-3	C363	D-6	D323	B-6	R312	B-5	R346	C-3		
C335	C-3	C364	D-6			R313	B-5	R347	D-3		
C336	D-3	C365	D-5	IC301	A-7	R314	A-1	R348	D-5		
C337	C-4	C366	D-5	IC321	C-6	R315	A-1	R349	D-5		
C338	C-3	C367	D-6	IC322	D-3	R321	C-5	R350	D-5		
C339	C-3	C368	D-6			R322	B-3	R351	D-5		
C340	C-5	C369	C-6	J310	B-5	R323	A-4	R352	C-2		
C341	C-3	C370	D-6			R324	C-5	R353	D-5		
C342	C-4	C371	C-2	L301	B-1	R325	B-5	R354	D-5		
C343	C-3	C372	D-3			R326	B-5	R355	D-5		

- **For Printed Wiring Boards.**

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip transistor




VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3.5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2 5 INCH LCD MODEL)
CF-51 (3 INCH/3 5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2.5 INCH LCD MODEL)
MA-312 (3 INCH/3 5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2 5 INCH LCD MODEL)
PJ-84 (3 INCH/3 5 INCH LCD MODEL)
(AV IN/OUT)

MA-312 (STEREO MIC, LASER LINK) (3 INCH/3.5 INCH LCD MODEL) PRINTED WIRING BOARD

– Ref No MA-312 BOARD: 9,000 series –

MA-312 BOARD (SIDE B) MA-312 BOARD (SIDE A)


D
C
B
A
VTR
POWER
CAMERA
MIC
(PLUG IN)
(POWER)
ON
AUTO
OFF
IC322
IC321
IC301
CN303
S301
1-668-940-12
09
1
2
3
4
5
6
7
8

MA-312 BOARD

C301	A-3	C345	C-3	C375	D-5	Q302	A-1	R329	B-6	R359	C-2
C302	A-3	C346	D-4	C376	B-8	Q303	A-2	R330	B-6	R360	C-6
C303	A-1	C347	C-3	C377	B-3	Q304	B-3	R331	B-6	R361	D-6
C304	A-1	C348	D-3	C378	C-6	Q305	A-1	R332	B-7	R362	D-6
C305	A-3	C349	D-3			Q321	B-6	R333	B-7	R363	D-6
C306	B-8	C350	D-4	CN301	B-2	Q322	B-6	R334	B-6	R364	D-6
C321	B-6	C351	D-4	CN302	B-3			R335	C-4	R365	C-6
C322	B-6	C352	D-4	CN303	B-1	R301	A-2	R336	D-4	R366	C-6
C323	B-6	C353	D-3			R302	B-1	R337	C-4	R367	C-6
C324	B-6	C354	D-5	D301	A-6	R303	A-1	R338	D-4	R368	D-5
C325	B-7	C355	D-6	D302	A-7	R304	A-3	R339	C-5		
C326	B-7	C356	C-3	D303	B-5	R305	A-3	R340	C-2	S301	D-5
C327	B-6	C357	C-3	D305	B-8	R306	B-8	R341	C-5	S302	D-3
C328	B-6	C358	C-6	D307	D-3	R307	B-7	R342	C-3	S303	C-2
C329	B-6	C359	D-6	D308	B-7	R308	D-4	R343	C-5		
C330	C-7	C360	C-3	D321	C-5	R309	D-4	R344	C-5		
C331	B-7	C361	C-2	D322	B-3	R310	B-3	R345	D-3		
C332	B-6	C362	D-6	D323	B-7	R311	B-1	R346	C-3		
C333	C-4	C363	D-6			R312	A-6	R347	D-3		
C334	C-4	C364	D-6	F301	B-2	R313	B-6	R348	D-3		
C335	C-4	C365	D-6			R314	A-1	R349	D-5		
C336	D-4	C366	D-6	IC301	A-8	R315	A-1	R350	D-5		
C337	C-4	C367	D-6	IC321	B-7	R321	C-5	R351	C-6		
C338	C-4	C368	D-6	IC332	C-3	R322	B-3	R351	D-6		
C339	C-3	C369	C-6			R323	B-3	R352	C-3		
C340	C-6	C370	D-6	J301	B-5	R324	B-6	R353	D-6		
C341	C-6	C371	D-5			R325	B-6	R354	D-6		
C342	C-4	C372	D-5	L301	B-2	R326	B-6	R355	D-6		
C343	C-4	C373	D-5			R327	B-6	R356	D-6		
C344	C-3	C374	C-6	Q301	A-2	R328	B-6	R358	D-6		

- **For Printed Wiring Boards.**

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip transistor




MA-311 BOARD
MA-312 BOARD
MA-331 BOARD
STEREO MIC, LASER LINK
-REF NO MA-311 BOARD 3 000
MA-312 BOARD 9 000
MA-331 BOARD 4 000 SERIES-
MIC901
MIC
CN301 2P
INT.MIC.L
GND
J301
MIC (PLUG IN POWER)
STEREO MIC
D322 MA8082-TX
D321 MA8082-TX
D323 MA111
MIC902
CN302 2P
INT.MIC.R
IC322
STEREO MIC AMP
IC322 AN2900FH-E8
IC321
MIC AMP
IC321 NJM2115V-TE2
Q321 322
IN BUFFER
Q321 2SD1819A-QRS
Q322 2SB1218A-QRS
CN303 20P
REG.GND
IR.DRV.EN
IR.DRV.CL
VTR.UNREG
XS1ROL.SIG
F.TALLY
4.4.75V
REG.GND
XNIGHT.ON
ZOOM.MIC.CONT
XMIC.MONO
EXT.MIC.DET
MIC.R
REG.GND
MIC.L
SHOE.MIC.L
AU.3.1V
XCAM.MODE.SW
XVTR.MODE.SW
SHOE.ID
TO VC-195 BOARD(8/10) CN903
(SEE PAGE 4-41)
F301 (IR2001)
L301
Q301 LASER LINK
Q302 LASER LINK
Q303
D301
D302
D309
Q305 NIGHT SHOT SWITCH
Q301 302 303 LED DRIVE
Q304 UN5213-TX LED DRIVE
S301
LIGHT
ON
AUTO
OFF
S302
S303
PLAYER
VTR
CAMERA
POWER
IC301
REMOTE CONTROL RECEIVER
IC301 RS-180-T
D305 MA111-TX
C306 10u 6 3V TA A

- SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC				➡
PB			⇨⟫	›

* MARKED MOUNT TABLE

Ref No \ Mode	IR TRANSMITTER	NIGHT SHOT
C301	4 7u	XX
C302	0 1u	XX
C303	0 1u	XX
C304	0 1u	XX
C305	0 1u	XX
D301	DCR2810	XX
D302	DCC3810	DCC3810
D309	XX	CL-310IRS-X-T
F301	200mA/63V	200mA/63V
L301	10uH	0
Q301	2SB1218A-QRS	UN5110-QRS-T
Q302	2SA1226-T1E4	XX
Q303	2SD999-T1	2SD999-T1
Q305	XX	UN5213-TX
R301	1500	XX
R302	120	XX
R303	470	470
R304	6 8	5 6
R305	2 7	2 7
R312	0	XX
R313	XX	0
R314	XX	330
R315	0	XX

Note	Note
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifies par une marque ⚠ sont critiques pour la sécurite Ne les remplacer que par une pièce portant le numero specifié

VL-19 BOARD	
C151	A-4
C152	A-1
C153	A-1
CN151	A-1
D151	A-2
D152	A-4
D153	A-4
L151	A-4
Q151	A-4
Q152	A-1
R151	A-1
R152	A-1
R153	A-1
R154	A-1

VL-19 (VIDEO LIGHT) PRINTED WIRING BOARD

– Ref No VL-19 BOARD· 9,000 series –

VL-19 BOARD (SIDE B) VL-19 BOARD (SIDE A)


B
A
VL001
(VIDEO LIGHT)
D151
Q151
Q152
D152
D153
C153
R153
L151
1-668-939-
11
09
1
2
3
4


VL-19 BOARD
VIDEO LIGHT
-REF NO 9 000 SERIES-
XX MARK NO MOUNT
D151 EPH3105-TL
VIDEO LIGHT IB SWITCHING
TO VC-195 BOARD(10/10) CN909
(SEE PAGE 4-51)
CN151 8P
UNREG
UNREG
UNREG
V.LIGHT.PWM
GND
GND
GND
GND
L151 10uH
C151 4 7u 10V
C152 XX
R151 0
R152 220
R153 1k
C153 0.001u
R154 100k
D152
D153
D151
LND151 LIGHT VCC
LND152 LIGHT VCC
LND155 SEIDEN GND
LND153 LIGHT GND
LND154 LIGHT GND
VL901
VIDEO LIGHT
Q152 2SK1829
VIDEO LIGHT ON SWITCH

Note:
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified
Note
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié


LB-54 (BACK LIGHT)
VF-120 (COLOR EVF)
VL-19 (VIDEO LIGHT)
VC-195
CAMERA, Y/C PROCESSOR, IN/OUT, REC/PB HEAD AMP, SERVO/SYSTEM CONTROL, SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
PD-92 (2.5 INCH LCD MODEL)
PD-93 (3 INCH/3.5 INCH LCD MODEL)
(RGB DECODER, LCD, LCD DRIVE, BACK LIGHT)
SE-66 (2.5 INCH LCD MODEL)
SE-67 (3 INCH/3.5 INCH LCD MODEL)
(STEADY SHOT)

CF-50 (CONTROL (2.5 INCH LCD MODEL)) PRINTED WIRING BOARD

– Ref No. CF-50 BOARD 4,000 series –

CF-50 BOARD	
BH001	B-10
C001	B-6
C002	B-6
CN001	D-3
CN002	A-5
CN003	D-6
CN005	C-7
CN006	B-7
CN007	C-5
CN008	D-5
D001	D-6
D003	D-12
D004	A-13
D005	B-7
D006	B-6
D007	A-14
D008	B-6
D009	B-1
D102	A-4
Q001	D-5
Q002	C-1
Q003	B-3
Q005	B-2
R001	B-1
R002	B-13
R003	B-3
R005	A-13
R006	C-3
R007	D-3
R008	D-3
R009	D-1
R013	A-13
R015	C-14
R016	D-12
R019	C-14
R020	C-12
R023	B-14
R025	D-1
R026	C-12
R029	C-2
R031	B-4
R032	C-11
R036	C-2
R038	B-4
R039	C-2
R041	A-4
R049	B-3
R050	B-3
R051	B-3
R052	B-3
R053	A-4
S003	D-11
S004	C-15
S006	A-13
S008	D-13
S010	B-14
S012	C-15
S013	C-13
S015	A-15
S017	D-15
S018	C-12
S021	D-12
S022	C-11
S024	D-24


CF-50 BOARD (SIDE B)

CF-50 BOARD (SIDE A)

D
C
B
A
09
1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
R025
R009
D009
R051
R049
Q005
Q003
R007
R008
CN001
Q001
D001
CN003
CN008
CN007
CN002
CN005
CN006
D005
D006
A
K
BACK LIGHT
PROGRAM AE
EXPOSURE
MODE
S024
DATE
TIME
COUNTER
DISPLAY
TITLE
END SEARCH
D003
S021
R016
R019
R023
PICTURE EFFECT
R005
R013
D004
D007
12
22

• For Printed Wiring Boards.

There are few cases that the part isn't mounted in this model is printed on this diagram

• Chip transistor Chip diode




VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3.5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2.5 INCH LCD MODEL)
CF-51 (3 INCH/3.5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2.5 INCH LCD MODEL)
MA-312 (3 INCH/3.5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2.5 INCH LCD MODEL)
PJ-84 (3 INCH/3.5 INCH LCD MODEL)
(AV IN/OUT)


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
24
25
A
B
C
D
E
F
G
H
I
J
K
L
CF-50 BOARD (2.5 INCH LCD MODEL)
CONTROL
-REF NO. 4,000 SERIES-
XX MARK NO MOUNT
CN001 50P
1 LCD_Y
2 REG_GND
3 LCD_U
4 REG_GND
5 LCD_V
6 REG_GND
7 LCD_HD
8 LCD_VD
9 XCS_EVF_D/A
10 XCS_LCD_DA
11 REG_GND
12 BW_EVF_Y
13 REG_GND
14 SP_+/BEEP_SIG
15 SP_-
16 DIAL_A
17 DIAL_B
18 TALLY_LED
19 XCS_LCD_DRIVER
20 LCD_COM/XDATA
21 KEY_AD7
22 KEY_AD2
23 KEY_AD3
24 KEY_AD4
25 KEY_AD5
26 KEY_AD6
27 D_3 1V
28 XOSD_SCK
29 OSD_SO
30 FOCUS_A_AD
31 FOCUS_B_AD
32 XCAM_MODE_SW
33 XVTR_MODE_SW
34 LCD_LED_ON
35 BATT_LI_3V
36 CHARGE_LED_ON
37 EVF_4 75V
38 EVF_4 75V
39 EVF_BL_GND
40 VTR_UNREG
41 EVF_BL_GND
42 XVC_SCK
43 VC_SO
44 VC_SI
45 EVF_BL_4 75V
46 PANEL_HOLD
47 A_4 75V
48 EVF_13 5V
49 VCO
50 EVF_VG
TO
VC-195 BOARD(10/10)
CN911
(SEE PAGE 4-51)
Q001
TALLY LED
DRIVE
Q001
UN5213-TX
XTALLY_LED
R001
XX
D009
XX
Q002
XX
Q005
VTR UNREG
SWITCH
Q005
2SA1362-YG-EL
R003
10k
R049
220k
R050
470k
R051
22k
R052
4700
Q003
2SD1819A-QRS-TX
(BACKLIGHT OF LCD INDICATOR MODEL)
Q003
LCD +B ON
SWITCH
SP_+
SP_-
XCS_LCD
COM/XDATA
XOSD_SCK
OSD_SO
FOCUS_A
FOCUS_B
EVF_4 75V
XVC_SCK
VC_SO
VC_SI
EVF_BL_4 75V
LCD_HOLD
A_4 75V
EVF_13 5V
VCO
EVF_VG
FADER
INFINITY
AUTO
SEL/PUSH EXEC
S015
START/STOP MODE
5SEC
S024
AD2
R005
10k
PICTURE
EFFECT
R013 1200
S006
R022 1500
MENU
S010
R023 2200
R029 3900
TIME
S021
R036 8200
R039 27k
AD3(ESX)
R006
10k
AD4
R007
10k
R015 1200
R019 1500
EXPOSURE
S012
(EXPOSURE MODEL)
R025 2200
BACK LIGHT
S017
R031 3900
R038 8200
R041 27k
R053 0
(WITHOUT EXPOSURE MODEL)
FADER
INFINITY
AUTO
AD5
R008
10k
DATE
S003
R016 1200
COUNTER
RESET
S008
R020 1500
END
SEARCH
S013
R026 2200
TITLE
S018
R032 3900
DISPLAY
S022
AD6
R009
10k
PROGRAM
AE
S004
(MANUAL FOCUS MODEL)
CONTROL SWITCH
BLOCK(MF-8500)
(FADER MODEL)
FADER
S002
RV001
20k/20k
FAR
NEAR
FOCUS
INFINITY
MAMUAL
AUTO
S001
CN001 8P
1 FADER
2 REG_GND
3 FOCUS_A
4 FOCUS_B
5 D_3.1V
6 INFINITY
7 AUTO
8 REG_GND
CN002 8P
FADER 1
REG_GND 2
FOCUS_A 3
FOCUS_B 4
D_3 1V 5
INFINITY 6
AUTO 7
REG_GND 8
CN003 2P
SP(+) 1
SP(-) 2
SP901
SPEAKER
LND001
CH GND
LND002
CH GND
D012
XX
D001
MAZJ082DFLSO
D003
XX
D004
XX
D007
XX
C001
XX
C002
XX
D005
MA8082-TX
D006
MA8082-TX
D008
MA111-TX
BH001
LITHIUM BATTERY
HOLDER
CN005 12P
1 NC
2 AD6
3 XCS_LCD_DA
4 VC_SO
5 XVC_SCK
6 REG_GND
7 PANEL_XVD
8 LCD_HOLD
9 REG_GND
10 PANEL_U
11 PANEL_V
12 PANEL_Y
TO
PD-92 BOARD(4/4)
CN5804
(SEE PAGE 4-88)
XCS_LCD_DA
VC_SO
XVC_SCK
LCD_VD
LCD_HOLD
LCD_U
LCD_V
BW_EVF_Y
CN006 6P
1 XCS_LCD_DRIVER
2 LCD_COM/XDATA
3 OSD_SO
4 XOSD_SCK
5 DISP_LCD_VDD
6 DISP_BL
TO
PD-92 BOARD(4/4)
CN5803
(SEE PAGE 4-88)
XCS_LCD
COM/XDATA
OSD_SO
XOSD_SCK
CN007 XX
1 EVF_BL_4 75V
2 EVF_BL_GND
3 EVF_BL_GND
4 EVF_13 5V
5 EVF_4 75/3 1V
6 A_4 75V
7 D_3 1V
8 EVF_XHD
9 EVF_R-Y
10 EVF_Y
11 EVF_B-Y
12 EVF_XVD
13 EVF_VG
14 VCO
15 EVF_GND
16 EVF_GND
17 VC_SI
18 XVC_SCK
19 VC_SO
20 XCS_EVF_D/A
EVF_BL_4 75V
EVF_13 5V
EVF_4 75V
A_4 75V
LCD_HD
LCD_V
LCD_Y
LCD_U
LCD_VD
EVF_VG
VCO
VC_SI
XVC_SCK
VC_SO
XCS_EVF_D/A
CN008 4P
1 EVF_4 75V
2 EVF_GND
3 BW_EVF_Y
4 XTALLY_LED
TO
VF-99 BOARD
CN901
(SEE PAGE 4-113)
EVF_4 75V
BW_EVF_Y
XTALLY_LED
09

• CONTROL SWITCH BLOCK(MF-8500) is replaced as a block. so that this PRINTED WIRING BOARD is omitted.

2.5 INCH LCD MODEL : CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV35/TRV35E/
TRV65/TRV65PK/TRV615

EXPOSURE MODE : EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215

WITHOUT EXPOSURE MODEL : CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215

BACKLIGHT OF LCD INDICATOR MODEL : CCD-TRV65/TRV65PK/TRV615

FADER MODEL : EXCEPT CCD-TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215

MANUAL FOCUS MODEL : EXCEPT CCD-TRV35/TRV35E/TRV65/TRV65PK/TRV615

• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	➡	➡➡		
PB	⇨	⇨⇨		


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
20
21
22
23
A
B
C
D
E
F
G
H
I
J
K
CF-51 BOARD (3INCH/3 5INCH LCD MODEL)
CONTROL
-REF.NO 9.000 SERIES-
XX MARK NO MOUNT
NO MARK CAMERA REC mode
CN001 50P
1 LCD_Y
2 REG_GND
3 LCD_U
4 REG_GND
5 LCD_V
6 REG_GND
7 LCD_HD
8 LCD_VD
9 XCS_EVF_D/A
10 XCS_LCD_DA
11 REG_GND
12 BW_EVF_Y
13 REG_GND
14 SP_+/BEEP_SIG
15 SP_-
16 DIAL_A
17 DIAL_B
18 TALLY_LED
19 XCS_LCD_DRIVER
20 LCD_COM/XDATA
21 KEY_AD7
22 KEY_AD2
23 KEY_AD3
24 KEY_AD4
25 KEY_AD5
26 KEY_AD6
27 D_3 1V
28 XOSD_SCK
29 OSD_SO
30 FOCUS_A_AD
31 FOCUS_B_AD
32 XCAM_MODE_SW
33 XVTR_MODE_SW
34 LCD_LED_ON
35 BATT_LI_3V
36 CHARGE_LED_ON
37 EVF_4 75V
38 EVF_4 75V
39 EVF_BL_GND
40 VTR_UNREG
41 EVF_BL_GND
42 XVC_SCK
43 VC_SO
44 VC_SI
45 EVF_BL_4 75V
46 PANEL_HOLD
47 A_4 75V
48 EVF_13 5V
49 VCO
50 EVF_VG
TO
VC-195 BOARD(10/10)
CN911
(SEE PAGE 4-51)
LCD_Y
LCD_U
LCD_V
LCD_HD
LCD_VD
XCS_EVF_D/A
XCS_LCD_DA
BW_EVF_Y
SP_+
SP_-
XCS_LCD
COM/XDATA
XOSD_SCK
OSD_SO
FOCUS_A
FOCUS_B
EVF_4 75V
XVC_SCK
VC_SO
VC_SI
EVF_BL_4.75V
LCD_HOLD
A_4.75V
EVF_13 5V
VCO
EVF_VG
Q001
TALLY LED
DRIVE
(B/W EVF MODEL)
XTALLY_LED
Q001
UN5213-TX
R001
XX
D009
XX
Q002
XX
Q005
2SA1362-YG-EL
R003
10k
Q003
2SD1819A-QRS-TX
R051
22k
R049
220k
R050
470k
R052
4700
Q005
VTR UNREG
SWITCH
Q003
LCD +B ON
SWITCH
S015
SEL/PUSH EXEL
S024
START/STOP MODE
5SEC
AD2
R005
10k
AD3(ESX)
R006
10k
AD4
R007
10k
AD5
R008
10k
AD6
R009
10k
R013
1200
PICTURE EFFECT
S001
XX
S005
R022
1500
MENU
S010
R023
2200
R029
3900
TIME
S021
R036
8200
R039
27k
R015
1200
R019
1500
EXPOSURE
S012
R025
2200
BACK LIGHT
S017
R031
3900
FADER
S027
R038
8200
INFINITY
R041
27k
AUTO
DATE
S003
R016
1200
COUNTER RESET
S008
R020
1500
END SEARCH
S013
R026
2200
TITLE
S018
R032
3900
DISPLAY
S022
PROGRAM AE
S004
CN005 12P
1 N C
2 AD6
3 XCS_LCD_DA
4 VC_SO
5 XVC_SCK
6 REG_GND
7 PANEL_XVD
8 LCD_HOLD
9 REG_GND
10 PANEL_U
11 PANEL_V
12 PANEL_Y
XCS_LCD_DA
VC_SO
XVC_SCK
LCD_VD
LCD_HOLD
LCD_U
LCD_V
BW_EVF_Y
TO
PD-93 BOARD(4/4)
CN5804
(SEE PAGE 4-100)
CN006 6P
1 XCS_LCD_DRIVER
2 LCD_COM/XDATA
3 OSD_SO
4 XOSD_SCK
5 DISP_LCD_VDD
6 DISP_BL
XCS_LCD
COM/XDATA
OSD_SO
XOSD_SCK
TO
PD-93 BOARD(4/4)
CN5803
(SEE PAGE 4-100)
CN007 20P
(COLOR EVF MODEL)
1 EVF_BL_4 75V
2 EVF_BL_GND
3 EVF_BL_GND
4 EVF_13 5V
5 EVF_4 75/3 1V
6 A_4 75V
7 D_3 1V
8 EVF_XHD
9 EVF_R-Y
10 EVF_Y
11 EVF_B-Y
12 EVF_XVD
13 EVF_VG
14 VCO
15 EVF_GND
16 EVF_GND
17 VC_SI
18 XVC_SCK
19 VC_SO
20 XCS_EVF_D/A
EVF_BL_4 75V
EVF_13 5V
EVF_4 75V
A_4 75V
LCD_HD
LCD_V
LCD_Y
LCD_U
LCD_VD
EVF_VG
VCO
VC_SI
XVC_SCK
VC_SO
XCS_EVF_D/A
TO
VF-120 BOARD
CN5301
(SEE PAGE 4-109)
TO
VF-119 BOARD
CN5401
(SEE PAGE 4-102)
CN008 4P
(B/W EVF MODEL)
1 EVF_4 75V
2 EVF_GND
3 BW_EVF_Y
4 XTALLY_LED
EVF_4 75V
BW_EVF_Y
XTALLY_LED
TO
VF-99 BOARD
CN901
(SEE PAGE 4-113)
FOCUS
INFINITY
MANUAL
AUTO
S001
RV001
20K/20K
FAR
NEAR
CN001 8P
1 FADER
2 REG_GND
3 AUTO
4 INFINITY
5 REG_GND
6 FOCUS_A
7 FOCUS_B
8 D_3 1V
CONTROL SWITCH BLOCK
(MR-8500)
CN002 8P
FADER 1
REG_GND 2
AUTO 3
INFINITY 4
REG_GND 5
FOCUS_A 6
FOCUS_B 7
D_3 1V 8
AUTO
INFINITY
FOCUS_A
FOCUS_B
CN003 2P
SP(+) 1
SP(-) 2
SP901
SPEAKER
SP_+
SP_-
LND001
CH GND
LND002
CH GND
D012
XX
D001
MAZJ082DFLS0
D003
XX
D004
XX
D007
XX
C001
XX
C002
XX
D005
MA8082-TX
D006
MA8082-TX
D008
MA111-TX
BH001
LITHIUM
BATTERY
HOLDER
09

• CONTROL SWITCH BLOCK(MR-8500) is replaced as a block
So that this PRINTED WIRING BOARD is omitted

• SIGNAL PATH

	VIDEO SIGNAL			AUDIO SIGNAL
	CHROMA	Y	Y/CHROMA	
REC	➡	➡》		
PB	⇨	⇨》		▷

3INCH LCD MODEL CCD-TRV93
3 5INCH LCD MODEL CCD-TRV85/TRV815
COLOR EVF MODEL CCD TRV93
B/W EVF MODEL CCD-TRV85/TRV815

CF-51 (CONTROL (3 INCH/3.5 INCH LCD MODEL) PRINTED WIRING BOARD

– Ref No. CF-51 BOARD; 9,000 series –

CF-51 BOARD (SIDE B)


E
D
C
B
A
09
1
2
3
4
5
6
7
8
DATE
TIME
COUNTER RESET
START/STOP MODE
5 SEC
S003
S021
S008
S022
S018
S013
S024
DISPLAY
TITLE
END SEARCH
MENU
S010
D002
D009
R001
D001
D003
R032
R026
R036
R008
R016
R028
(LITHIUM BATTERY HOLDER)
BH001
S001
S006
R005
R013
DIGITAL EFFECT
PICTURE EFFECT

CF-51 BOARD (SIDE A)


9
10
11
12
13
14
15
16
FADER
S027
BACK LIGHT
S017
PROGRAM AE
S004
EXPOSURE
S012
R025
R019
R009
R015
R007
CN001
50
CN007
CN008
CN003
CN005
CN006
D006
D005
C002
C001
Q003
Q005
R051
R003
R023
R022
R029
S015
SEL/PUSH EXEC
D007
D012
1-668-941-
12

CF-51 BOARD

BH001	B-2
C001	B-16
C002	B-15
CN001	D-12
CN002	A-15
CN003	D-15
CN005	C-16
CN006	B-16
CN007	D-14
CN008	E-14
D001	C-15
D003	D-5
D004	C-10
D005	B-16
D006	B-15
D007	A-10
D008	B-15
D009	B-8
D012	A-16
Q001	E-5
Q002	B-8
Q003	B-12
Q005	A-12
R001	B-8
R003	A-12
R005	B-5
R006	D-6
R007	C-10
R008	D-6
R009	C-10
R013	B-5
R015	C-10
R018	D-6
R019	C-10
R020	D-6
R022	A-11
R023	A-10
R029	A-10
R031	D-10
R038	D-5
R038	D-10
R039	D-10
R041	A-16
R049	B-12
R050	B-11
R051	A-12
R052	B-11
S001	B-5
S002	C-4
S003	D-4
S004	C-9
S006	B-6
S008	D-6
S010	B-7
S012	C-9
S013	C-6
S015	A-9
S017	D-9
S018	C-5
S021	D-5
S024	D-7
S025	C-9
S027	E-10

- **For Printed Wiring Boards.**

There are few cases that the part isn't mounted in this model is printed on this diagram

- Chip transistor



Chip diode




VF-119
(COLOR EVF)
CD-197 (2 5 INCH LCD MODEL)
CD-198 (3 INCH/3.5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2.5 INCH LCD MODEL)
CF-51 (3 INCH/3 5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2 5 INCH LCD MODEL)
MA-312 (3 INCH/3 5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2.5 INCH LCD MODEL)
PJ-84 (3 INCH/3.5 INCH LCD MODEL)
(AV IN/OUT)


1
2
3
4
5
6
7
8
A
B
C
D
E
F
G
H
I
(SEE PAGE 4-124)
TO DD-105 BOARD
CN935
CN935 10P
1 ZOOM_VR
2 D_3 2V
3 KEY_AD1
4 XIR_SW
5 LED_5V
6 KEY_AD0
7 XIR_LED_ON
8 IR_3 2V
9 REG_GND
10 REG_GND
D008
R014
0
ZOOM
RV001
S008
D009
XX
■ STOP
▶▶ FF
● REC
+
EDIT SEARCH
−
S001
S003
S005
S007
S009
S010
R001
10k
R003
1200
R006
1500
R009
2200
R013
3900
R015
8200
(■ STOP)
(▶▶ FF)
● REC
D001
D003
D005
D007
R008
180
R012
180
II PAUSE
◀◀ REW
▷ PLAY
S002
S004
S006
R002
10k
R004
1200
R007
1500
R010
2200
(II PAUSE)
(◀◀ REW)
(▷ PLAY)
D002
D004
D006
R005
470
R011
180
VTR CONTROL SWITCH BLOCK(FK-8500)
S001
LOCK
STANDBY
S002
START/STOP
J001
LANC
V
A
S003
EJECT
S004
XX
CN934 12P
XCAM+STBY_SW 1
XCAM+PHOTO_SW 2
XCAM_MODE_SW 3
XS/S_SW 4
REG_GND 5
XLANC_JACK_IN 6
LANC_DC 7
LANC_SIG 8
XEJECT_SW 9
XPHOTO_FREEZ 10
REG_GND 11
A/D(PHOTO_START) 12
TO
DD-105 BOARD
CN934
(SEE PAGE 4-124)
CONTROL SWITCH BLOCK(SS-8500)

• CONTROL SWITCH BLOCK(FK-8500 SS-8500) are replaced as a block, so that this PRINTED WIRING BOARD is omitted

09

PD-92 BOARD

C5501	B-10
C5502	B-10
C5503	C-2
C5504	C-10
C5505	C-10
C5506	B-2
C5507	C-3
C5508	B-2
C5509	C-3
C5510	C-1
C5511	C-2
C5512	C-1
C5513	C-1
C5514	C-2
C5515	C-2
C5516	C-2
C5517	C-1
C5518	C-3
C5519	B-2
C5520	C-3
C5601	A-2
C5602	A-2
C5603	B-10
C5604	C-9
C5605	C-9
C5607	B-9
C5608	C-9
C5609	B-10
C5610	C-9
C5611	B-8
C5612	C-10
C5613	B-8
C5614	C-10
C5615	C-10
C5616	C-9
C5618	D-9
C5619	D-2
C5620	D-10
C5622	C-10
C5623	C-2
C5624	B-3
C5625	B-2
C5633	B-9
C5634	B-9
C5701	C-8
C5702	C-8
C5703	C-3
C5704	C-7
C5705	C-6
C5706	C-4
C5801	C-4
C5821	C-1
CN5501	D-9
CN5601	D-10
CN5701	D-6
CN5801	C-8
CN5802	C-7
CN5803	C-8
CN5804	C-10
CN5805	C-6
D5601	B-10
D5602	B-9
D5603	B-10
D5605	B-9
D5604	C-10
D5701	C-5
D5702	C-5
D5703	D-5
D5704	C-7
IC5501	B-10
IC5502	C-2
IC5601	C-9
IC5602	C-8
IC5701	C-4
IC5801	C-4
L5501	C-3
L5502	A-2
L5503	A-2
L5601	A-2
L5603	C-9
L5604	A-2
L5605	C-9
L5701	C-7
Q5501	C-2
Q5601	B-9
Q5602	B-9
Q5603	B-10
Q5604	C-10
Q5605	C-8
Q5606	C-9
Q5607	C-9
Q5608	C-8
Q5609	B-9
Q5701	C-3
Q5702	C-4
R5501	B-2
R5502	B-2
R5504	B-2
R5505	B-2
R5506	B-2
R5507	B-2
R5508	B-1
R5508	B-2
R5509	B-1
R5510	B-3
R5511	B-3
R5512	B-1
R5513	B-2
R5516	B-2
R5517	B-1
R5518	B-1
R5519	C-3
R5520	C-3
R5521	B-2
R5522	B-2
R5523	C-3
R5526	C-1
R5527	B-1
R5528	C-3
R5529	C-1
R5530	B-1
R5531	C-2
R5532	C-3
R5533	B-1
R5537	D-8
R5541	D-2
R5542	D-3
R5544	C-2
R5546	C-2
R5546	D-2
R5602	C-2
R5603	D-3
R5604	D-3
R5605	C-1
R5606	C-10
R5607	A-2
R5609	C-9
R5610	B-10
R5612	C-9
R5614	C-9
R5615	C-9
R5616	B-10
R5617	B-9
R5618	C-9
R5619	B-9
R5620	B-9
R5621	C-9
R5622	B-8
R5623	B-8
R5624	B-9
R5625	C-10
R5626	C-9
R5627	C-10
R5628	C-10
R5629	B-9
R5630	B-9
R5631	C-9
R5632	B-9
R5634	B-9
R5635	C-10
R5636	B-10
R5637	C-10
R5638	C-10
R5639	C-1
R5640	C-3
R5641	C-3
R5642	C-10
R5644	C-9
R5645	C-10
R5646	C-10
R5647	D-2
R5648	C-3
R5648	D-10
R5651	D-2
R5652	D-2
R5653	D-9
R5654	D-9
R5657	C-9
R5658	D-9
R5659	D-10
R5660	D-10
R5661	D-10
R5663	C-9
R5664	D-10
R5665	D-1
R5665	D-10
R5667	D-1
R5668	D-1
R5669	D-1
R5670	D-1
R5671	D-9
R5672	D-9
R5673	D-1
R5674	D-2
R5676	D-1
R5678	D-9
R5679	D-2
R5680	D-2
R5681	D-2
R5682	D-1
R5683	D-2
R5684	D-2
R5685	D-3
R5686	D-3
R5688	C-9
R5692	C-9
R5694	B-9
R5695	B-9
R5695	D-10
R5697	C-10
R5698	B-9
R5698	D-9
R5701	C-5
R5702	C-5
R5703	C-4
R5704	C-4
R5705	C-4
R5706	C-4
R5707	C-7
R5708	D-4
R5709	D-7
R5710	D-4
R5801	C-1
R5802	C-1
R5803	A-1
R5804	A-1
R5805	C-6
R5806	A-1
R5807	B-7
R5808	B-9
R5809	C-7
R5810	B-9
R5811	C-4
R5812	C-4
S5801	D-1
S5802	C-1
S5803	B-1
S5804	A-1
T5701	C-4

PD-92 (RGB DECODER, LCD DRIVE, BACK LIGHT, LCD (2.5 INCH LCD MODEL)) PRINTED WIRING BOARD

– Ref No. PD-92 BOARD· 10,000 series –

PD-92 BOARD (SIDE B)


LCD BRIGHT (+)
LCD BRIGHT (-)
VOLUME (+)
VOLUME (-)
D
C
B
A
S5601
S5602
S5603
S5604
IC5502
IC5801
T5701
D5703
D5701
D5702
Q5501
L5501
L5502
L5503
L5601
09
1
2
3
4
5

PD-92 BOARD (SIDE A)


CN5701
CN5501
CN5601
IC5601
IC5602
IC5501
L5701
C5701
C5702
CN5801
CN5802
CN5803
CN5804
CN5805
1-668-951-
11
6
7
8
9
10

- **For Printed Wiring Boards.**
- This board is four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip transistor




LB-54
(BACK LIGHT)
VF-120
(COLOR EVF)
VL-19
(VIDEO LIGHT)
VC-195
CAMERA, Y/C PROCESSOR, IN/OUT,
REC/PB HEAD AMP, SERVO/SYSTEM CONTROL,
SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
PD-92 (2.5 INCH LCD MODEL)
PD-93 (3 INCH/3.5 INCH LCD MODEL)
(RGB DECODER, LCD DRIVE, BACK LIGHT, LCD)
SE-66 (2.5 INCH LCD MODEL)
SE-67 (3 INCH/3.5 INCH LCD MODEL)
(STEADY SHOT)

PD-92 BOARD(1/4)

RGB DECODER(RGB BLOCK)

-REF NO 10,000 SERIES-
XX MARK NO MOUNT


1 2 3 4 5 6 7 8 9 10 11 12 13 14
A B C D E F G H
TO PD-92 BOARD(4/4) ①
PANEL_4 75V
PANEL_6 5V
PANEL_3 1V
D_3 1V
IC5501
I/O EXP
IC5501 M62376GP-65AD
VDD VCC H_REV V_REV NTSC XWIDE CLK SI SO XEN VDDA VSS
COMTST BRT_TST H_POS V-COM VCO COM_ADJ RGB_AMP CONT BRT_B BRT_R COLOR BRIGHT
C5501 0 1u
C5502 0 1u
XVC_SCK
VC_SO
XCS_PANEL_DA
TO PD-92 BOARD(4/4) ②
REG_GND
PANEL_Y
PANEL_V
PANEL_U
R5544 1k
R5541 2200
R5542 1800
Q5501 2SB1218A-QRS-TX BUFFER
C5518 1u 2012
C5503 0 01u
C5504 0 01u
C5505 0 01u
L5501 10uH
C5507 10u 10V TA A
C5508 0 1u
R5501 39k
R5502 XX
R5505 47k
C5506 0 1u 2012
R5503 XX
R5506 XX
R5504 XX
R5507 XX
BRT_TST
COM_ADJ
BRT_R BRT_B AMP
FRPV FRPT
R5508 XX R5509 XX R5512 22k R5513 12k R5516 22k R5517 15k R5518 33k R5521 12k R5522 ★
R5526 XX R5527 XX C5510 XX R5529 XX R5533 0 R5530 XX
L5503 10uH L5502 10uH
C5517 0 1u C5519 10u 10V TA A
C5513 0 1u C5512 10u 10V TA A
C5514 ★ 2012 C5515 ★ 2012 C5516 ★ 2012
IC5502
RGB DECODER
IC5502 IR3Y37M4
COM_BLK_LVL COM_AMP GAMMA2 GAMMA0 SUB_BRT_R SUB_BRT_B RGB_AMP FRP COM_FRP OUT_LIM VSH VCC2
COM_BLK XTEST BRIGHT CONT COM_OUT SUB_CON_B SUB_CON_R VCC1 OSD_B OSD_G OSD_R BLACK_IN
B_OUT B_DC_DET G_OUT G_DC_DET R_OUT R_DC_DET GND1 GND2 SYNC_OUT SYNC_IN EXT_BGP SYNC_SEP
PICTURE UV/CBR/XRGB_SW AGC_FIL AGC_OUT AGC_LVL COLOR H_FIL_IN G/Y R/R-Y/CR B/B-Y/CB H_FIL REG_OUT
W_MSKT W_MSKV COM-O
① ② ③ ④ ⑤ ⑥ ⑦ ⑧
R5546 XX C5511 1u 2012 R5531 1k R5545 XX
R5510 XX R5511 XX R5519 XX C5509 3 3u 4V TA A R5520 390k R5523 XX C5520 0 1u R5532 47k R5528 100k ±0 5%
P_4 75V
P_6 5V
VB VG VR
COM-O V-COM VCO H_POS
XWIDE NTSC V_REV H_REV COMTST
TO PD-92 BOARD(2/4) ③
SYNC HSY
FRPV FRPT W_MSKV W_MSKT
COLOR
VCO_VOLT PANEL_COM
CN5501 10P
VB VCO_VOLTAGE VG PANEL_COM VR N C SYNC H_START GND GND
1 2 3 4 5 6 7 8 9 10
VB VCO_VOLT VG PANEL_COM VR SYNC HSY
R5537 ★
CPC (FOR CHECK)
09

★MARKED MOUNT TABLE

Model / Ref No	S-61K NTSC	S-61K PAL	C-61K NTSC	C-61K PAL
C5514	0 1u	0 1u	0 33u	0 33u
C5515	0 1u	0 1u	0 33u	0 33u
C5516	0 1u	0 1u	0 33u	0 33u
R5522	39k	39k	68k	68k
R5537	5 6k	8 2k	1 5k	3 9k

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡	➡	
PB	⇨	⇨	

PD-92 BOARD (1/4)
CAMERA REC

①



IC5502 ⑧

②



IC5502 ⑨

③



IC5502 ⑩

④



IC5502 ⑬

⑤



IC5502 ⑯ (C-61K MODEL 3Vp-p)
IC5502 ⑯ (S-61K MODEL 4.7Vp-p)

⑥



IC5502 ⑳ (C-61K MODEL 3.6Vp-p)
IC5502 ⑳ (S-61K MODEL 4.2Vp-p)

⑦



IC5502 ㉒ (C-61K MODEL 3.6Vp-p)
IC5502 ㉒ (S-61K MODEL 4.2Vp-p)

⑧



IC5502 ㉔ (C-61K MODEL 3.6Vp-p)
IC5502 ㉔ (S-61K MODEL 4.2Vp-p)

- **For schematic diagrams.**
- Refer to page 4–79 for Printed Wiring Board

PD-92 BOARD (2/4)
CAMERA REC




1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
A
B
C
D
E
F
G
H
I
J
IC5602
FRPC AMP
Q5605-5608
FRPC BUFFER
TO
PD-92 BOARD(4/4)
④
PANEL_13 2V
PANEL_-15 3V
L5603
10uH
L5604
10uH
P_6 5V
P_4 75V
PANEL_3 1V
VCO_VOLT
REG_GND
VB
VG
VR
TO
PD-92 BOARD(1/4)
③
PANEL_COM
V-COM
COM-O
VCO
H_POS
XWIDE
NTSC
V_REV
H_REV
COMTST
SYNC
HSY
FRPV
FRPI
W_MSKV
W_MSKT
TO
PD-92 BOARD(4/4)
⑤
PANEL_HOLD
PANEL_XVD
IC5602
NJM062V(TE2)
OUT1
VCC+
IN1-
IN1+
OUT2
IN2-
IN2+
VCC-
Q5607
2SD1819A-QRS-TX
Q5606
2SB1218A-QRS-TX
Q5608
2SB1218A-QRS-TX
Q5605
2SD1819A-QRS-TX
Q5601
UN5213-TX
SWITCH
Q5602
UN5213-TX
SWITCH
Q5609
D5602
D5605
1T369-01-T8A
D5604
MA8047-H-TX
D5601
D5603
1T369-01-T8A
IC5601
TIMING GENERATOR
⑨
⑩
⑪
⑫
⑬
⑭
CSY/XHD
M6
M3
HRESET
M1
M8
VDD
DOWN
TES
RIGHT
COMTST
POCB
MCLK
CLR
OE
SRT1
SRT2
VDD
RIGHTO
RESET
GSRT
GPCK
GRES
DOWNO
TG.24
TG.23
TG.22
TG.21
TG.20
TG.18
TG.17
TG.16
TG.15
TG.14
TG.13
TG.12
Q5603
Q5604
INVERTER
CN5601 24P
VSH/CLD
VDD/SPD
VR/CTR
VB/EX3
VG/EX2
VSS/VB12
MODE1/RES
MCLK/TST
HCNT/VR
CLR/VG
OE/VB
SRTL/GND
SRTR/VSH
VBC/COM
VCOM/VGL
MODE2/VSS
RESET/MD2
GSRT/MD1
GPCK/EX1
GRES/SPS
VREFL/CLS
VGL/VCC
VREFH/VSH
VGH/VGH
LCD901
COLOR LCD
2 5INCH
MONITOR
09

PD-92 BOARD(2/4)

LCD DRIVE (TG BLOCK)

-REF NO 10,000 SERIES-
XX MARK NO MOUNT

★ MARKED MOUNT TABLE

Model / Ref No	S-61K	C-61K
C5601	XX	10u
C5603	0 1u	0 33u
C5614	330p	XX
C5615	220p	XX
C5618	6 8u	XX
C5619	0 01u	XX
C5623	XX	0 1u
IC5601	LZ9GH184	CM7017L2-T4
L5601	XX	10uH
Q5604	2SD1819A-QRS	XX
R5602	XX	0
R5605	XX	0
R5607	0	XX
R5608	0	XX
R5610	100k	56k
R5621	1M	XX
R5625	100k	68k
R5627	180k	100k
R5632	0	XX
R5635	4700	XX
R5636	22k	0
R5637	0	XX
R5638	10k	XX
R5639	10k	XX
R5642	4700	XX
R5645	82k	XX
R5646	82k	XX
R5647	XX	0
R5648	XX	0
R5651	33k	XX
R5652	22k	0
R5653	33k	XX
R5654	22k	XX
R5657	0	XX
R5658	0	XX
R5659	0	XX
R5660	0	XX
R5661	0	XX
R5663	XX	0
R5664	XX	0
R5665	XX	0
R5666	XX	0
R5667	XX	0
R5668	XX	0
R5669	0	XX
R5670	0	XX
R5671	0	XX
R5672	XX	220k
R5673	XX	0
R5674	0	XX
R5676	0	XX
R5678	XX	0
R5679	47	XX
R5680	47	XX
R5681	47	XX
R5682	XX	47
R5683	XX	47
R5684	XX	47
R5692	22k	47k
R5693	180k	470k
R5696	0	XX
R5697	XX	0
R5698	XX	0

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡		
PB	⇨		

- **For schematic diagrams.**
- Refer to page 4–79 for Printed Wiring Board.

PD-92 BOARD(3/4)

BACK LIGHT (BL BLOCK)

-REF NO 10,000 SERIES-
XX MARK NO MOUNT



TO PD-92 BOARD(4/4)
6
BL_REG
BL_GND
BL_DET
REG_GND
PANEL_4 75V
L5701 150uH (SB D8513)
R5703 1800 1/10W 2012
R5704 1800 1/10W 2012
T5701 INVERTER TRANS
(SB L0550)
C5703 0 033u 3216
C5701 33u 10V TA C
C5702 1u F 2012
Q5701 FP216-TL (SB U8813)
C5705 12p SL (SB D6372)
CN5701 10P (SB D8994)
10 BL_HIGH
9 N C
8 N C
7 N C
6 N C
5 N C
4 N C
3 BL_LOW
2 LED
1 LED_GND
ND801 BACK LIGHT
Q5701 INVERTER TRANS DRIVE
Q5702 LED SWITCH
Q5702 UN5111-TX
R5710 0
R5705 100k
R5708 120
D5703 PG1101H-TR (BACK LIGHT)
LND812
LND813
LND814
LND815
LND811
A
R5701 XX
D5701 XX
R5702 XX
D5702 XX
IC5701 TA75S393F-TE85R
(SB T8711)
IC5701 BACK LIGHT DRIVE
D5704 MA111-TX
R5706 6800
C5706 0 01u
R5707 22k
C5704 0 1u 2012
R5709 470

Note	Note
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

- **For schematic diagrams.**
- Refer to page 4–79 for Printed Wiring Board


PD-92 BOARD(4/4)
LCD(LCD BLOCK)
-REF NO 10,000 SERIES-
XX MARK NO MOUNT
TO PD-92 BOARD (3/4) ⑥
TO PD-92 BOARD (2/4) ④
TO PD-92 BOARD (1/4) ①
TO PD-92 BOARD (2/4) ⑤
TO PD-92 BOARD (1/4) ②
REG_GND
PANEL_3 1V
BL_DET
BL_GND
BL_REG
PANEL_13 2V
PANEL_-15 3V
PANEL_6 5V
D_3 1V
PANEL_3 1V
PANEL_4 75V
PANEL_XVD
PANEL_HOLD
PANEL_U
PANEL_V
XVC_SCK
PANEL_Y
REG_GND
XCS_PANEL_DA
VC_SO
LCD903
CN5801 24P
BL_VDD
BL_GND
COM1
COM2
SEG2
SEG3
SEG4
SEG5
SEG6
SEG7
SEG8
SEG9
SEG10
SEG11
SEG12
SEG13
SEG14
SEG1
SEG16
SEG15
COM4
COM3
R5809 XX
R5807 100
R5808 100
R5810 XX
TO DD-105 BOARD CN933
(SEE PAGE 4-124)
CN5802 11P
BL_GND 1
BL_GND 2
BL_REG 3
BL_REG 4
BL_DET 5
PANEL_-15 3V 6
PANEL_13 2V 7
PANEL_4 75V 8
PANEL_6 5V 9
PANEL_3 1V 10
D_3 1V 11
TO CF-50 BOARD CN006
(SEE PAGE 4-69)
CN5803 6P
XCS_LCD_DRIVER 1
LCD_COM/XDATA 2
OSD_SO 3
XOSD_SCK 4
DISP_LCD_VDD 5
DISP_BL 6
TO CF-50 BOARD CN005
(SEE PAGE 4-69)
CN5804 12P
N C 1
AD6 2
XCS_PANEL_DA 3
VC_SO 4
XVC_SCK 5
REG_GND 6
PANEL_XVD 7
PANEL_HOLD 8
REG_GND 9
PANEL_U 10
PANEL_V 11
PANEL_Y 12
XCS
C/XD
SD
SCK
R5812 680k
R5811 0 160B
C5801 0 01u
OSC1
OSC2
VSS
VC
VLCD
VDD
SCK
SD
⑮
IC5801
LCD CONTROLLER
IC5801 BU9729K-E2
SEG10
SEG9
SEG8
SEG7
SEG6
SEG5
SEG4
SEG3
XCS
C/XD
COM1
COM2
COM3
COM4
SEG1
SEG2
R5806 1200
R5801 1500
R5802 2200
R5803 3900
R5804 8200
R5805 27k
S5801
S5802
S5803
S5804
(+) LCD BRIGHT (-)
(+) VOLUME (-)
CN5805 6P
PANEL_REV 1
GND 2
GND 3
PANEL_CLOSE 4
GND 5
GND 6
S904 (PANEL MIRROR)
S903 (PANEL CLOSE)
FP-642 FLEXIBLE BOARD
09

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡	➡	
PB	⇨	⇨	

PD-92 BOARD (4/4)
CAMERA REC


⑮
2 9Vp-p
24 17 kHz
IC5801 ②

BACK LIGHT, LCD
PD-92 (3/4, 4/4) (2.5 INCH LCD MODEL)

PD-93 (RGB DECODER, LCD DRIVE, BACK LIGHT, LCD (3 INCH/3.5 INCH LCD MODEL) PRINTED WIRING BOARD

– Ref No PD-93 BOARD: 10,000 series –

PD-93 BOARD

C4501	B-2
C4502	B-2
C4503	B-11
C4504	B-11
C4505	B-11
C4506	B-3
C4507	A-3
C4508	B-11
C4509	B-3
C4510	A-3
C4511	B-2
C4512	A-2
C4513	B-2
C4514	B-2
C4515	B-2
C4516	B-2
C4517	A-2
C4518	A-11
C4519	A-3
C4520	C-3
C4601	A-10
C4602	B-11
C4603	C-2
C4604	D-3
C4605	C-3
C4607	C-10
C4608	C-10
C4609	B-12
C4610	C-11
C4611	C-3
C4612	B-12
C4613	C-3
C4614	C-2
C4615	C-2
C4616	D-4
C46181	D-11
C4619	D-3
C4620	D-3
C4621	D-12
C4622	D-2
C4623	D-10
C4624	C-4
C4625	C-4
C4633	C-10
C4634	C-11
C4701	C-9
C4702	B-10
C4703	C-4
C4704	D-5
C4705	D-8
C4706	D-4
C4707	C-4
C4801	A-4
CN4501	C-12
CN4601	D-12
CN4701	D-9
CN4801	B-9
CN4802	A-8
CN4803	A-9
CN4804	A-10
CN4805	A-7
CN4806	B-12
D4601	C-2
D4602	C-10
D4603	B-12
D4605	C-10
D4614	D-12
D4701	B-6
D4702	A-6
D4704	D-5
IC4501	A-12
IC4502	B-3
IC4601	C-11
IC4602	C-3
IC4701	D-4
IC4801	A-4
L4501	A-3
L4502	A-2
L4601	A-10
L4603	B-11
L4604	A-11
L4605	C-11
L4701	C-9
Q4501	A-11
Q4601	B-11
Q4602	B-11
Q4603	C-2
Q4604	C-2
Q4605	D-10
Q4606	D-10
Q4607	D-10
Q4608	D-10
Q4609	B-11
Q4701	C-4
Q4702	D-9
R4501	B-11
R4502	B-3
R4503	B-4
R4504	B-3
R4505	B-11
R4506	B-3
R4507	B-3
R4508	A-3
R4509	A-3
R4510	B-3
R4511	B-3
R4512	A-3
R4513	A-3
R4514	C-3
R4516	A-3
R4516	C-3
R4517	A-3
R4518	A-3
R4519	B-3
R4520	B-3
R4521	A-3
R4522	A-3
R4523	C-3
R4526	A-3
R4527	A-3
R4528	B-3
R4529	A-3
R4530	A-2
R4531	C-2
R4532	A-12
R4533	A-2
R4534	B-2
R4535	B-2
R4536	B-2
R4537	C-2
R4541	A-11
R4542	A-11
R4544	A-11
R4545	C-2
R4546	B-2
R4602	C-3
R4603	D-10
R4604	D-11
R4605	A-2
R4606	A-2
R4607	A-1
R4608	C-2
R4609	B-11
R4610	C-2
R4612	B-11
R4613	B-11
R4614	C-10
R4615	B-11
R4616	B-12
R4617	B-11
R4619	B-11
R4620	C-3
R4621	C-10
R4622	C-3
R4623	C-3
R4624	C-11
R4625	B-11
R4626	C-3
R4627	B-11
R4628	C-2
R4629	C-3
R4630	C-11
R4631	C-3
R4632	B-11
R4634	C-11
R4635	C-2
R4636	C-2
R4637	C-3
R4638	C-2
R4639	C-2
R4640	D-3
R4641	C-3
R4642	C-2
R4643	D-3
R4644	D-3
R4645	C-2
R4646	C-2
R4647	C-3
R4648	C-3
R4651	D-3
R4652	D-3
R4653	D-2
R4654	D-2
R4657	D-11
R4658	D-11
R4659	D-11
R4660	D-11
R4661	D-11
R4663	D-11
R4664	D-3
R4665	D-3
R4666	D-3
R4667	D-3
R4668	C-12
R4669	D-12
R4670	D-2
R4671	D-3
R4672	D-10
R4673	D-12
R4674	D-3
R4676	D-2
R4677	D-11
R4678	D-2
R4678	D-3
R4680	D-2
R4681	D-2
R4682	D-3
R4683	D-3
R4683	D-11
R4684	D-3
R4685	C-10
R4686	D-10
R4692	B-11
R4693	C-10
R4694	C-10
R4695	C-3
R4696	D-12
R4697	D-12
R4698	D-3
R4701	B-6
R4702	A-7
R4703	B-4
R4703	D-9
R4704	B-4
R4705	D-9
R4706	D-9
R4707	D-5
R4708	D-5
R4710	D-9
R4801	D-1
R4802	C-1
R4803	B-1
R4804	A-1
R4806	A-6
R4806	A-12
R4807	B-8
R4808	B-11
R4809	B-8
R4810	B-11
R4811	A-4
R4812	A-4
S4801	D-1
S4802	D-1
S4803	B-1
S4804	A-1
T4701	C-5


PD-93 BOARD (SIDE B)

PD-93 BOARD (SIDE A)

A
B
C
D
1
2
3
4
5
6
7
8
9
10
11
12
13
S4801
S4802
S4803
S4804
LCD BRIGHT (+)
LCD BRIGHT (-)
VOLUME (+)
VOLUME (-)
IC4502
IC4601
IC4701
IC4801
IC4501
T4701
CN4701
CN4601
CN4801
CN4802
CN4803
CN4804
CN4805
CN4806
L4701
1-668-952-11

- **For Printed Wiring Boards.**
- This board is four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

There are few cases that the part isn't mounted in this model is printed on this diagram

- Chip transistor




LB-54
(BACK LIGHT)
VF-120
(COLOR EVF)
VL-19
(VIDEO LIGHT)
VC-195
CAMERA, Y/C PROCESSOR, IN/OUT,
REC/PB HEAD AMP, SERVO/SYSTEM CONTROL,
SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
PD-92 (2.5 INCH LCD MODEL)
PD-93 (3 INCH/3.5 INCH LCD MODEL)
(RGB DECODER, LCD DRIVE, BACK LIGHT, LCD)
SE-66 (2.5 INCH LCD MODEL)
SE-67 (3 INCH/3.5 INCH LCD MODEL)
(STEADY SHOT)

PD-93 BOARD(1/4)

RGB DECODER (RGB BLOCK)

-REF NO 10,000 SERIES-
XX MARK NO MOUNT


1 2 3 4 5 6 7 8 9 10 11 12 13 14
A B C D E F G H
IC4501
I/O EXP
IC4501 M62376GP-65AD
IC4502
RGB DECODER
IC4502 IR3Y37M4
Q4501 2SB1218A-QRS-TX BUFFER
TO PD-93 BOARD(4/4) ①
PANEL_4 75V
PANEL_6 5V
PANEL_3 1V
D_3 1V
TO PD-93 BOARD(4/4) ②
XVC_SCK
VC_SO
XCS_PANEL_DA
REG_GND
PANEL_Y
PANEL_V
PANEL_U
TO PD-93 BOARD(2/4) ③
P_3 1V
P_4 75V
P_6 5V
REG_GND
VB
VG
VR
COM-O
V-COM
VCO
H_POS
XWIDE
NTSC
V_REV
H_REV
COMTST
SYNC
HSY
FRPV
FRPT
W_MSKV
W_MSKT
VCO_VOLT
PANEL_COM
CN4501 10P
VB 1
VCO_VOLTAGE 2
VG 3
PANEL_COM 4
VR 5
N C 6
C-SYNC/XHD 7
H_START 8
GND 9
GND 10
CPC
(FOR CHECK)
R4537 ★
BAT_TST
COM_ADJ
BAT_R
BAT_B
AMP
FRPV
FRPT
COM_BLK_LVL
COM_AMP
GAMMA2
GAMMA0
SUB_BAT_R
SUB_BAT_B
RGB_AMP
FRP
COM_FRP
OUT_LIM
VSH
VCC2
B_OUT
B_DC_DET
G_OUT
G_DC_DET
R_OUT
R_DC_DET
GND1
GND2
SYNC_OUT
SYNC_IN
EXT_BGP
SYNC_SEP
COM_BLK
XTEST
BRIGHT
CONT
COM_OUT
SUB_CON_B
SUB_CON_R
VCC1
OSD_B
OSD_G
OSD_R
BLACK_IN
PICTURE
UV/CBR/XRGB_SW
AGC_FIL
AGC_OUT
AGC_LVL
COLOR
H_FIL_IN
G/Y
R/R-Y/CR
B/B-Y/CB
H_FIL
REG_OUT
VDD
VCC
H_REV
V_REV
NTSC
XWIDE
CLK
SI
SO
XEN
VDDA
VSS
COMTST
BAT_TST
H_POS
V-COM
VCO
COM_ADJ
RGB_AMP
CONT
BAT_B
BAT_R
COLOR
BRIGHT
L4501 10uH
L4502 10uH
L4503 10uH
C4501 0 1u
C4502 0 1u
C4503 0 01u
C4504 0 01u
C4505 0 01u
C4506 0 1u 2012
C4507 10u 10V TA A
C4508 0 1u
C4509 3 3u 4V TA A
C4510 XX
C4511 1u 3216
C4512 10u 10V TA A
C4513 0 1u
C4514 0 1u 2012
C4515 0 1u 2012
C4516 0 1u 2012
C4517 0 1u
C4518 1u 2012
C4519 10u 10V TA A
C4520 0 1u
R4501 39k
R4502 XX
R4503 XX
R4504 XX
R4505 47k
R4506 XX
R4507 XX
R4508 XX
R4509 XX
R4510 XX
R4511 XX
R4512 22k
R4513 12k
R4514 XX
R4515 XX
R4516 22k
R4517 15k
R4518 33k
R4519 XX
R4520 390k
R4521 12k
R4522 ★
R4523 XX
R4526 1k
R4527 XX
R4528 100k ±0 5%
R4529 XX
R4530 XX
R4531 1k
R4532 47k
R4533 0
R4534 47
R4535 47
R4536 47
R4541 2200
R4542 1800
R4544 1k
R4545 XX
R4546 XX
① ② ③ ④ ⑤ ⑥ ⑦ ⑧
09

★ MARKED MOUNT TABLE

Model / Ref. No	3INCH LCD	3 5INCH LCD
R4522 R4537	39k 4700	68k 1k

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡	➡»	
PB	⇨	⇨»	

PD-93 BOARD (1/4)
CAMERA REC

①



IC4502 ⑧

②



IC4502 ⑨

③



IC4502 ⑩

④



IC4502 ⑬

⑤



IC4502 ⑯ (3.5 INCH LCD : 3Vp-p)
IC4502 ⑯ (3 INCH LCD : 4.7Vp-p)

⑥



IC4502 ⑳ (3.5 INCH LCD : 3.3Vp-p)
IC4502 ⑳ (3 INCH LCD : 2.2Vp-p)

⑦



IC4502 ㉒ (3.5 INCH LCD : 3.3Vp-p)
IC4502 ㉒ (3 INCH LCD : 2.3Vp-p)

⑧



IC4502 ㉔ (3.5 INCH LCD : 3.3Vp-p)
IC4502 ㉔ (3 INCH LCD : 2.3Vp-p)

- For schematic diagrams.
- Refer to page 4–90 for Printed Wiring Board.

PD-93 BOARD (2/4)
CAMERA REC

⑨


IC4601 ④ (3.5 INCH LCD 3Vp-p)
IC4601 ④ (3 INCH LCD 4.7Vp-p)

⑩


IC4601 ⑤ (3.5 INCH LCD 3Vp-p)
IC4601 ⑤ (3 INCH LCD 4.7Vp-p)

⑪


IC4601 ㉔ (3 INCH LCD 4.7Vp-p)

⑪


IC4601 ㉔ (3.5 INCH LCD 3Vp-p)

⑫


IC4601 ㉖ (3.5 INCH LCD Approx 9.5MHz / 3.3Vp-p)
IC4601 ㉖ (3 INCH LCD Approx 7.5MHz / 4.7Vp-p)

⑬


IC4601 ㉞ (3.5 INCH LCD 3Vp-p)
IC4601 ㉞ (3 INCH LCD 4.7Vp-p)

⑭


IC4601 ㊲ (3.5 INCH LCD 3Vp-p)
IC4601 ㊲ (3 INCH LCD 4.7Vp-p)

PD-93 BOARD(2/4) (3INCH/3.5INCH LCD MODEL)
LCD DRIVE (TG BLOCK)

-REF NO 10,000 SERIES-
XX MARK NO MOUNT

NO MARK : CAMERA REC mode
( ) : CAMERA REC mode(3.5INCH LCD MODEL)
< > : CAMERA REC mode(3 INCH LCD MODEL)

★MARKED MOUNT TABLE

Model / Ref No	3INCH LCD	3.5INCH LCD
C4603	0.1u	0.33u
C4614	330p	XX
C4615	220p	XX
C4618	6.8u	XX
C4619	0.01u	XX
IC4601	LZ9GH164	CM7017L3-T4
L4601	XX	10uH
L4605	18uH	10uH
Q4604	2SD1819A-QRS	XX
R4602	XX	0
R4606	XX	0
R4607	0	XX
R4608	0	XX
R4610	100k	56k
R4621	1M	XX
R4625	68k	47k
R4635	4700	XX
R4636	22k	0
R4637	0	XX
R4638	10k	XX
R4639	10k	XX
R4642	4700	XX
R4643	56k	47k
R4645	82k	XX
R4646	82k	XX
R4647	XX	0
R4648	XX	0
R4651	33k	XX
R4652	22k	0
R4653	33k	XX
R4654	22k	XX
R4657	0	XX
R4658	0	XX
R4659	0	XX
R4660	0	XX
R4661	0	XX
R4663	XX	0
R4664	XX	0
R4665	XX	0
R4666	XX	0
R4667	XX	0
R4668	XX	0
R4669	0	XX
R4670	0	XX
R4671	0	XX
R4672	XX	18k
R4673	XX	0
R4674	0	XX
R4676	0	XX
R4677	XX	0
R4678	XX	0
R4679	0	XX
R4680	0	XX
R4681	0	XX
R4682	XX	0
R4683	XX	0
R4684	XX	0
R4685	100k	56k
R4686	100k	56k
R4692	33k	56k
R4693	270k	82k
R4696	0	XX
R4697	XX	0
R4698	XX	0


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
A
B
C
D
E
F
G
H
I
IC4602
FRPC AMP
Q4605-4608
FRPC BUFFER
TO PD-93 BOARD(4/4) ④
PANEL_13.2V
PANEL_-15.3V
P_6.5V
P_4.75V
PANEL_3.1V
VCO_VOLT
REG_GND
L4603 10uH
L4604 10uH
IC4602 NJM062V(TE2)
Q4607 2SD1819A-QRS-TX
Q4605 2SB1218A-QRS-TX
Q4606 2SD1819A-QRS-TX
Q4608 2SB1218A-QRS-TX
D4604 MA8047-H-TX
COM-O
VB
VG
VR
TO PD-93 BOARD(1/4) ③
PANEL_COM
V-COM
COM-O
VCO
H_POS
PANEL_XVD
PANEL_HOLD
Q4601 UN5213-TX SWITCH
Q4602 UN5213-TX SWITCH
XWIDE
NTSC
V_REV
H_REV
COMTST
SYNC
HSY
FRPV
FRPT
W_MSKV
W_MSKT
IC4601 TIMING GENERATOR
TG.24
TG.23
TG.22
TG.21
TG.20
TG.18
TG.17
TG.16
TG.15
TG.14
TG.13
TG.12
Q4604 INVERTER
D4603 1T369-01-T8A
TO PD-93 BOARD(4/4) ⑤
PANEL_HOLD
PANEL_XVD
CN4601 24P
24 CLD/VSH
23 SPD/VDD
22 CTR/VR
21 EX3/VB
20 EX2/VG
19 VB12/VSS
18 RES/MODE1
17 TST/MCLK
16 VR/HCNT
15 VG/CLR
14 VB/OE
13 GND/SRTL
12 VSH/SRTR
11 COM/VBC
10 VGL/VCOM
9 VSS/MODE2
8 MO2/RESET
7 MO1/GSRT
6 EX1/GPCK
5 SPS/GRES
4 CLS/VREFL
3 VCC/VGL
2 VSH/VREFH
1 VGH/VGH
LCD901 COLOR LCD 3/3.5INCH MONITOR
09

- SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡		
PB	⇨		

LCD DRIVE
PD-93 (2/4) (3 INCH/3.5 INCH LCD MODEL)

- **For schematic diagrams.**
- Refer to page 4–90 for Printed Wiring Board.

PD-93 BOARD(3/4)

BACK LIGHT (BL BLOCK)

-REF.NO 10,000 SERIES-
XX MARK NO MOUNT



1
2
3
4
5
6
7
8
A
B
C
D
E
F
G
TO
PD-93 BOARD(4/4)
6
BL_REG
BL_GND
BL_DET
REG_GND
PANEL_4 75V
L4701
150uH
(SB D8513)
R4703
1800
1/10W
2012
R4704
1800
1/10W
2012
T4701
INVERTER TRANS
C4703
0 033u 3216
C4705
12p
10p
C4707
XX
3216
Q4701
FP216-TL
C4701
33u
10V
TA C
C4702
1u
F
2012
Q4701
INVERTER TRANS
DRIVE
C4705
3kv
SL
CN4701 10P (SB D8994)
10 BL_HIGH
9 N C
8 N C
7 N C
6 N C
5 N C
4 N C
3 BL_LOW
2 LED
1 LED_GND
ND802
BACK LIGHT
R4710
390
Q4702
UN5111-TX
R4708
120
R4705
100k
D901
(TALLY)
LND812
LND813
LND814
LND815
LND811
A
IC4701
TA75S393F-TE85R
(SB T8711)
Q4702
LED SWITCH
D4704
MA111-TX
R4701
XX
D4701
XX
R4702
XX
D4702
XX
R4707
22k
C4704
0 1u
2012
R4709
470
R4706
6800
C4706
0 01u
IC4701
BACK LIGHT
DRIVE
09

Note	Note
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

- **For schematic diagrams.**
- Refer to page 4–90 for Printed Wiring Board.


PD-93 BOARD (4/4)
LCD (LCD BLOCK)
-REF NO 10,000 SERIES-
XX MARK NO MOUNT
TO PD-93 BOARD (3/4) ⑥
TO PD-93 BOARD (2/4) ④
TO PD-93 BOARD (1/4) ①
TO PD-93 BOARD (2/4) ⑤
TO PD-93 BOARD (1/4) ②
LCD903
CN4801 24P
CN4802 11P
TO DD-105 BOARD CN933 (SEE PAGE 4-124)
BL_GND
BL_GND
BL_REG
BL_REG
BL_DET
PANEL_-15 3V
PANEL_13 2V
PANEL_4 75V
PANEL_6 5V
PANEL_3 1V
D_3 1V
CN4803 6P
TO CF-51 BOARD CN006 (SEE PAGE 4-72)
XCS_LCD_DRIVER
LCD_COM/XDATA
OSD_SO
XOSD_SCK
DISP_LCD_VDD
DISP_BL
CN4804 12P
TO CF-51 BOARD CN005 (SEE PAGE 4-72)
AD6
XCS_PANEL_DA
VC_SO
XVC_SCK
REG_GND
PANEL_XVD
PANEL_HOLD
REG_GND
PANEL_U
PANEL_V
PANEL_Y
R4809 XX
R4807 100
R4808 100
R4810 XX
R4812 680k
R4811 0 1608
C4801 0.01u
IC4801
LCD CONTROLLER
IC4801 BU9729K-E2
⑮
OSC1
OSC2
VSS
VC
VLCD
VDD
SCK
SD
XCS
C/XD
SEG10
SEG9
SEG8
SEG7
SEG6
SEG5
SEG4
SEG3
COM1
COM2
COM3
COM4
SEG1
SEG2
SEG11
SEG12
SEG13
SEG14
SEG15
SEG16
SEG17
SEG18
CN4806 XX
SP-
GND
SP+
BAT-
GND
BAT+
CN4805 6P
PANEL_REV
GND
GND
PANEL_CLOSE
GND
GND
R4806 1200
R4801 1500
R4802 2200
R4803 3900
R4804 8200
R4805 27k
S4801
S4802
S4803
S4804
(+) LCD BRIGHT (-)
(+) VOLUME (-)
FP-462 FLEXIBLE BOARD
S906 (PANEL MIRROR)
S905 (PANEL CLOSE)
PD-93 BOARD (4/4)
CAMERA REC
⑮
2 9Vp-p
24 48 kHz
IC4801 ②
09

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC	➡	➡	
PB	⇨	⇨	

BACK LIGHT, LCD
PD-93 (3/4, 4/4) (3 INCH/3.5 INCH LCD MODEL)

VF-119 BOARD
CAMERA REC




VF-119 BOARD
COLOR EVF
-REF NO 10,000 SERIES-
XX MARK NO MOUNT
• SIGNAL PATH
VIDEO SIGNAL
CHROMA
Y
Y/CHROMA
REC
PB
IC5401
LCD DRIVER
IC5401 CXA1115R-T4
IC5404
LCD TIMING GENERATOR
IC5404 CXD2458R-T4
(11.06MHz)
IC5402
EXP I/O
IC5402 M62376GP-65AD
LCD902 COLOR LCD UNIT
CN5402 16P
CN5401 20P
TO VF-120 BOARD CN5301
(SEE PAGE 4-109)
TO CF-51 BOARD CN007
(SEE PAGE 4-75)

VF-119 (COLOR EVF (COLOR EVF MODEL) PRINTED WIRING BOARD

– Ref No VF-119 BOARD· 10,000 series –


VF-119 BOARD (SIDE B)

VF-119 BOARD (SIDE A)
C
B
A
1
2
3
4
09
1-668-942-
11
IC5404
IC5401
C5408
L5404
48
37
24
13
1
12

VC-119 BOARD

C5401	C-2
C5402	B-2
C5403	A-3
C5404	B-3
C5405	B-3
C5406	B-3
C5407	C-3
C5408	C-3
C5409	B-4
C5410	C-4
C5411	C-4
C5413	C-3
C5415	C-3
C5416	B-4
C5417	B-1
C5418	B-2
C5419	B-1
C5420	B-1
C5421	B-1
C5422	A-2
C5423	A-2
C5424	A-1
C5427	A-4
C5428	A-1
C5429	A-1
CN5401	B-1
CN5402	A-4
D5401	B-1
IC5401	B-3
IC5402	C-4
IC5404	A-1
L5401	C-2
L5402	C-3
L5403	A-2
L5404	B-1
L5405	B-4
Q5401	C-1
R5401	C-2
R5402	C-1
R5403	C-1
R5404	C-1
R5405	C-2
R5406	A-2
R5407	A-2
R5408	C-1
R5409	C-2
R5410	C-1
R5411	B-2
R5412	B-2
R5414	C-2
R5414	C-2
R5415	B-2
R5416	C-1
R5417	B-3
R5418	B-3
R5418	C-2
R5419	C-1
R5420	C-1
R5421	C-1
R5422	C-1
R5423	A-3
R5424	C-1
R5425	C-1
R5426	C-1
R5427	C-2
R5428	C-2
R5429	C-1
R5430	C-1
R5431	B-2
R5432	B-2
R5433	C-2
R5434	C-2
R5435	B-2
R5436	B-2
R5437	B-2
R5438	B-2
R5439	B-2
R5440	C-2
R5441	C-2
R5444	B-1
R5445	B-1
R5446	B-1
R5447	B-1
R5448	B-1
R5449	B-2
R5452	B-2
R5456	A-4
R5457	A-4
R5458	A-4
R5460	A-1
R5464	A-1
R5468	A-2
R5469	A-4
R5470	B-1
R5471	B-4
R5472	C-2

- **For Printed Wiring Boards.**
- This board is four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip transistor




VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3.5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2.5 INCH LCD MODEL)
CF-51 (3 INCH/3.5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2 5 INCH LCD MODEL)
MA-312 (3 INCH/3.5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2 5 INCH LCD MODEL)
PJ-84 (3 INCH/3 5 INCH LCD MODEL)
(AV IN/OUT)

VF-120 (COLOR EVF (COLOR EVF MODEL)), LB-54 (BACK LIGHT) PRINTED WIRING BOARDS

– Ref No VF-120 BOARD: 10,000 series, LB-54 BOARD· 10,000 series –

VF-120 BOARD

C5301	B-3
C5302	A-4
C5303	A-4
C5304	A-3
C5305	A-4
C5306	B-4
C5307	B-4
C5308	B-3
C5309	A-3
C5310	B-4
C5311	A-4
C5312	A-3
C5313	B-3
CN5301	B-4
CN5302	A-1
D5301	A-3
D5302	A-4
IC5301	A-4
L5301	A-4
Q5301	B-3
Q5302	A-2
Q5303	A-2
Q5304	A-4
Q5305	B-4
R5302	A-2
R5302	A-4
R5303	A-1
R5303	A-3
R5304	A-3
R5305	A-4
R5306	A-4
R5307	A-3
R5309	A-3
R5310	A-3
R5311	A-3
R5312	B-4
R5313	B-4
R5314	B-3
R5315	B-3
R5316	A-3
R5317	B-3
R5318	B-4
R5319	A-4
R5320	A-2
R5321	A-3
R5322	A-3
R5323	A-4
R5324	A-4
R5325	B-4


VF-120 BOARD (SIDE B)
VF-120 BOARD (SIDE A)
B
A
09
1
2
3
4
11
CN5302
C5318
C5310
C5309
R5315
R5308
R5309
R5306
R5319
R5323
C5303
C5312
L5301
Q5302
C5305


VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3 5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2 5 INCH LCD MODEL)
CF-51 (3 INCH/3.5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2 5 INCH LCD MODEL)
MA-312 (3 INCH/3.5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2 5 INCH LCD MODEL)
PJ-84 (3 INCH/3 5 INCH LCD MODEL)
(AV IN/OUT)


VF-120
(COLOR EVF)
VL-19
(VIDEO LIGHT)
LB-54
(BACK LIGHT)
VC-195
CAMERA, Y/C PROCESSOR, IN/OUT,
REC/PB HEAD AMP, SERVO/SYSTEM CONTROL,
SERVO, AUDIO, IR TRANSMITTER, MODE CONTROL
PD-92 (2.5 INCH LCD MODEL)
PD-93 (3 INCH/3 5 INCH LCD MODEL)
(RGB DECODER, LCD DRIVE, BACK LIGHT, LCD)
SE-66 (2.5 INCH LCD MODEL)
SE-67 (3 INCH/3 5 INCH LCD MODEL)
(STEADY SHOT)

- **For Printed Wiring Boards.**
- This board is four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

There are few cases that the part isn't mounted in this model is printed on this diagram

- Chip diode

Chip transistor


3
2 1
6 5 4
Q
1 2 3
C
Q
B E

LB-54 BOARD

C5351	B-4
C5352	B-4
C5353	B-3
C5354	A-4
C5355	A-4
C5356	B-4
CN5351	B-3
D5351	B-2
L5351	B-3
L5352	B-4
ND5351	A-1
Q5351	A-4
R5351	B-3
T5351	A-3


LB-54 BOARD (SIDE B)
LB-54 BOARD (SIDE A)
B
A
09
1
2
3
4
11
ND5351
D5351
C5351
C5352
C5353
C5354
C5355
C5356
1-668-944-


1
2
3
4
5
6
7
8
9
10
11
12
13
14
15
16
17
18
19
A
B
C
D
E
F
G
H
09
VF-120 BOARD (COLOR EVF MODEL)
COLOR EVF
-REF NO 10,000 SERIES-
XX MARK NO MOUNT
NO MARK CAMERA REC mode
(SEE PAGE 4-102)
TO VF119 BOARD CN5401
TO CF-51 BOARD CN007
(SEE PAGE 4-75)
CN5301 8P
HD_OUT 1
INV_CURRENT 2
EVF_3 1V 3
EVF_12 0V 4
EVF_BL_GND 5
EVF_BL_GND 6
EVF_BL_4 75V 7
EVF_BL_4 75V 8
R5325 XX
L5301 47uH 3225
Q5304 UN5113-TX
Q5305 UN5213-TX
Q5304, 5305 B+ SWITCH
R5324 0
C5302 6 8u 20V TA B
R5305 47k ±0 5%
R5304 180k ±0 5%
C5304 0 01u B
R5307 27k
R5309 47k
R5310 56k
R5311 270k
R5306 68k
C5303 0 022u B
R5308 150k
C5312 1u B 2012
R5321 22k
R5322 470k
D5301 MA6S121-(TX)
Q5302 XX
R5302 XX
Q5303 XX
R5320 XX
R5303 XX
R5319 XX
D5302 1SS370(TE85L)
R5323 XX
R5301 100
①
②
GND
OUT
VCC2
CB
VCC
2 5V
OSC
SCP
IC5301
DC/AC CONVERTER
IC5301 MB3789PFV-G-BND-ER
C5310 150p CH
R5318 1200
C5311 0 1u B
C5313 0 22u F
Q5301 RN2305-TE85L
DISCHARGE SWITCH
R5313 56k
R5312 68k
C5308 0 022u B
R5314 270k
R5315 10k
R5316 330k
R5317 100k
C5309 0 01u B
C5307 4 7u 6 3V TA A
C5314 0 01u B
C5305 10u 10V TA A
C5306 2200p SL
C5301 XX
CN5302 12P
1 N C
2 N C
3 LED_A
4 FB
5 LED_K
6 BL_LOW
7 EVF_BL_GND
8 N C
9 DRIVE_PULSE
10 EVF_BL_4 75V
11 EVF_BL_GND
12 EVF_BL_4 75V
CN5351 12P
EVF_BL_4 75V 12
EVF_BL_GND 11
EVF_BL_4 75V 10
DRIVE_PULSE 9
N C 8
EVF_BL_GND 7
BL_LOW 6
LED_K 5
FB 4
LED_A 3
N C 2
N C 1
C5353 0 01u B
L5351 47uH 3225
R5351 33k
L5352 10uH 3225
T5351 INVERTER TRANS ⚠
Q5351 FX216-TL1 TRANS DRIVE
C5351 47u 10V TA C
C5352 4 7u B 3216
C5354 8200p B 2012
C5355 8200p B 2012
C5356 8200p B 2012
⚠ ND5351 BACK LIGHT
LND811
LND812
D5351 XX
LB-54 BOARD (COLOR EVF MODEL)
BACK LIGHT
-REF NO 10,000 SERIES-
XX MARK NO MOUNT
NO MARK REC/PB mode

Note	Note
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié.

COLOR EVF MODEL CCD-TRV93

VF-120 BOARD
CAMERA REC



COLOR EVF, BACK LIGHT
VF-120, LB-54 (COLOR EVF MODEL)

VF-99 BOARD (B/W EVF MODEL)

B/W EVF

-REF NO 10,000 SERIES-
NO MARK REC/PB mode


1
2
3
4
5
6
7
8
9
10
11
12
A
B
C
D
E
F
G
(2 5INCH LCD MODEL)
TO
CF-50 BOARD
CN008
(SEE PAGE 4-69)
TO
CF-51 BOARD
CN008
(SEE PAGE 4-75)
(3INCH/3 5INCH LCD MODEL)
CN901 4P
EVF_4 9V
EVF_GND
EVF_VIDEO
TALLY
D901
PR1102W-TR
(TALLY)
R903
2200
2012
C901
68
6 3V
TA C
Q903
VIDEO AMP
Q903
2SA1163G-TE85L
R927
1k
R928
3300
R918
4700
L902
33uH
±5%
3225
C908
27p
CH
Q904
2SD1819A-QRS-TX
Q904
VIDEO DRIVE
4 8
-14 3
-13 7
2 6
2 1
R919
68k
R920
22k
R901
470
R902
470
R904
10k
C902
0 1
F
2012
R905
1200
Q901
2SD1819A-QRS-TX
Q902
2SD1615-T1GLGK
R906
220
L901
47uH
3225
C909
1000p
B
2012
SOL901
C910
3900p
SL
3216
C911
6800p
SL
3216
C912
68
6 3V
TA C
0 5
0 4
4 6
Q901
4 9V DETECTOR
Q902
H OUT
L903
HLC
T901 FBT
D903
MA111-TX
C914
1 5u
35V
-25V
C916
1000p
500V
3216
2200V
250V
R921
6.8
R922
150k
R923
1M
RV904
1M
R924
2 7M
R925
2 7M
BRIGHT
R926
1k
C915
0 022
50V
2012
W901 5p CRT SOCKET
1 G1
2 H
3 H
4 N C
5 G2
C903
0 47
25V
TA A
C904
1500p
B
C905
33
6 3V
TA B
R910
15k
R909
10k
C913
0 47
25V
TA A
R907
100k
R908
390k
R911
27
1/8W
3216
C906
1
F
3216
R912
1M
①
②
IC901
BA7149F-E2
H DRIVE
H OSC
AFC
VIDEO AMP/MIX
SYNC SEP
V SYNC SEP
V OUT
V OSC
IC901
AFC VIDEO AMP
R929
560
C907
0 1
R913
820
R914
220
★ R916
★ R917
R915
4 7
TH901
470
RV903
470
V SIZE
V901
DEFLECTION YOKE
CN902 4P
1 DV1
2 DV2
3 DH1
4 DH2
G1
G2
H
H
HV
PICTURE TUBE
(M01KXX90WB)
09

• SIGNAL PATH

	VIDEO SIGNAL		
	CHROMA	Y	Y/CHROMA
REC		➡	
PB		⇨	

Note
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Note
Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

★ MARKED MOUNT TABLE

Ref No \ Model	NTSC	PAL
R916	22k	27k
R917	68k	82k

2 5INCHI LCD MODEL·EXCEPT CCD-TRV85/TRV93/TRV815
3INCH/3 5INCH LCD MODEL CCD-TRV85/TRV93/TRV815
B/W EVF MODEL EXCEPT CCD-TRV93
NTSC MODEL·EXCEPT CCD-TRV15E/TRV15EP/TRV35E
PAL MODEL CCD-TRV15E/TRV15EP/TRV35E

VF-99 BOARD
CAMERA REC


①
1Vp-p
H
IC901 ⑪
②
2 2Vp-p
H
IC901 ⑬

VF-99 (B/W EVF (B/W EVF MODEL)) PRINTED WIRING BOARD

– Ref No. VF-99 BOARD: 10,000 series –


VF-99 BOARD (SIDE B)

VF-99 BOARD (SIDE A)

D
C
B
A
1
2
3
09
D901
R903
C907
C906
R912
IC901
R929
R916
R917
C913
C903
R909
R908
C904
R910
R907
R927
R913
R928
TH901
CN902
R914
R915
W901
T901
RV903
RV904
L903
R911
C905
C901
CN901
R901
R902
R904
R905
Q901
C902
R906
L902
E
C
B
C908
R918
Q904
Q902
Q903
C909
R920
R919
L901
C910
C916
C911
R925
R924
C912
R921
C914
C915
D903
R923
R926
R922
1-660-357-
11

VF-99 BOARD

C901	D-3
C902	C-3
C903	C-1
C904	C-1
C905	D-3
C906	D-1
C907	D-2
C908	C-3
C909	C-3
C910	B-3
C911	B-3
C912	B-3
C913	D-1
C914	A-3
C915	A-3
C916	B-3
CN901	D-3
CN902	C-1
D901	D-1
D903	A-3
IC901	D-1
L901	B-3
L902	C-3
L903	A-1
Q901	C-3
Q902	C-3
Q903	C-3
Q904	C-3
R901	C-3
R902	C-3
R903	D-2
R904	C-3
R905	C-3
R906	C-3
R907	C-1
R908	C-1
R909	C-1
R910	C-1
R911	D-3
R912	D-1
R913	C-2
R914	C-2
R915	B-2
R916	D-2
R917	D-2
R918	C-3
R919	B-3
R920	C-3
R921	B-3
R922	A-3
R923	A-3
R924	B-3
R925	B-3
R926	A-3
R927	C-1
R928	C-1
R928	D-2
RV903	A-2
RV904	A-1
T901	B-1
TH901	C-2
W901	B-1



- **For Printed Wiring Boards.**
- This board is four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip transistor




VF-119
(COLOR EVF)
CD-197 (2.5 INCH LCD MODEL)
CD-198 (3 INCH/3.5 INCH LCD MODEL)
(CCD IMAGER)
CF-50 (2.5 INCH LCD MODEL)
CF-51 (3 INCH/3.5 INCH LCD MODEL)
(CONTROL)
MA-311/331 (2.5 INCH LCD MODEL)
MA-312 (3 INCH/3.5 INCH LCD MODEL)
(STEREO MIC, LASER LINK)
DD-105
(POWER)
PJ-83 (2.5 INCH LCD MODEL)
PJ-84 (3 INCH/3.5 INCH LCD MODEL)
(AV IN/OUT)

- **For Printed Wiring Boards.**
- This board is four-layer print board. However, the patterns of layers 2 to 3 have not been included in the diagram.

There are few cases that the part isn't mounted in this model is printed on this diagram.

- Chip transistor



Chip diode


3 4
D
2 1
3
2 1
3
2 1

DD-105 (POWER) PRINTED WIRING BOARD

– Ref No DD-105 BOARD 2,000 series –

DD-105 BOARD

C801	E-3
C802	E-3
C803	D-3
C804	E-3
C805	E-3
C806	E-3
C807	E-2
C808	E-3
C809	D-2
C810	D-3
C811	D-2
C812	D-4
C813	D-2
C814	E-8
C815	C-4
C816	E-9
C817	E-8
C819	C-3
C820	C-3
C821	C-2
C822	E-8
C823	C-4
C824	C-2
C825	B-3
C826	D-8
C827	E-2
C828	E-2
C829	E-2
C830	D-2
C831	E-2
C832	B-3
C833	B-3
C834	C-4
C836	B-2
C837	C-2
C838	C-3
C840	D-8
C841	B-4
C843	C-4
C844	A-3
C846	B-3
C847	B-7
C848	B-7
C849	A-2
C850	A-3
C851	B-4
C852	B-8
C853	B-7
C854	B-3
C855	A-3
C856	E-3
C857	A-2
C860	A-6
C861	A-7
C862	A-2
C863	B-6
C864	A-5
C866	A-6
C867	A-7
C868	B-6
C869	A-6
C871	B-2
C872	F-4
C873	A-2
C874	A-7
C875	B-2
C876	C-6
C877	D-6
C885	A-6
CN801	C-6
CN931	C-5
CN932	F-6
CN933	A-4
CN934	D-9
CN935	G-7
D801	B-3
D802	C-3
D803	C-2
D804	C-2
D805	C-3
D806	B-2
D807	D-8
D809	B-7
D810	B-2
D812	B-3
D813	F-4
D814	F-4
D815	F-3
D816	E-3
D817	F-3
D818	D-2
D819	E-3
D838	E-9
D932	G-2
D933	F-4
D934	G-3
D935	F-3
D936	G-3
FB931	D-9
FB932	E-9
FB933	D-9
FB934	D-9
IC801	D-3
IC802	E-2
L801	D-7
L802	D-7
L803	D-8
L804	E-9
L805	B-7
L806	C-8
L807	C-7
L808	B-8
L809	C-7
L810	B-4
L811	B-3
L812	B-3
L813	B-3
L814	A-3
L815	A-3
L816	B-3
L817	A-3
L818	A-2
L819	A-3
L820	D-8
LF801	D-7
PS801	F-3
PS802	F-2
PS803	F-3
PS804	F-2
PS805	F-2
PS806	F-3
Q801	F-4
Q802	E-4
Q803	E-3
Q804	F-3
Q805	F-3
Q806	C-2
Q807	C-3
Q808	C-3
Q809	B-3
Q810	C-2
Q812	C-3
Q813	C-2
Q814	C-2
Q815	C-2
Q817	C-3
Q819	D-8
Q820	E-3
Q823	A-2
Q824	E-2
Q826	A-7
Q827	A-2
Q828	B-5
Q829	B-6
Q830	B-6
Q831	A-7
Q832	B-6
Q833	A-2
Q834	B-6
Q835	A-8
Q836	A-8
Q837	A-7
Q838	A-8
Q839	B-8
Q840	A-8
Q841	A-7
Q842	A-7
Q843	A-7
Q844	A-8
Q845	A-8
Q846	A-7
Q847	A-6
Q848	A-8
Q849	A-7
Q850	A-8
Q851	E-4
Q852	B-2
Q853	B-2
Q854	B-2
Q855	B-2
Q856	A-6
Q932	G-3
Q933	G-3
Q934	G-3
R801	E-2
R802	E-3
R803	E-3
R804	D-3
R805	D-3
R807	E-3
R808	E-2
R808	E-3
R809	D-3
R810	E-2
R811	D-2
R812	D-2
R813	F-4
R814	D-4
R815	D-3
R816	D-4
R817	D-3
R818	D-2
R819	D-2
R820	D-3
R821	D-2
R822	E-3
R822	D-7
R822	D-8
R823	D-7
R824	D-2
R825	D-4
R826	D-4
R827	E-3
R828	F-3
R829	D-2
R830	D-2
R831	F-4
R832	D-4
R833	D-2
R834	D-2
R835	D-4
R836	D-4
R837	D-2
R838	D-3
R839	C-2
R840	C-3
R841	C-3
R842	E-2
R843	C-2
R849	E-2
R850	E-2
R852	D-2
R853	D-2
R854	D-2
R854	D-2
R859	E-3
R864	E-3
R865	A-2
R866	B-2
R867	E-2
R868	A-2
R870	A-7
R871	A-7
R872	B-6
R873	A-5
R874	B-5
R875	A-2
R876	B-5
R877	A-7
R878	A-2
R879	B-6
R880	B-6
R881	B-6
R882	B-6
R883	A-8
R884	B-8
R885	B-7
R887	B-8
R888	B-8
R889	A-7
R890	A-7
R891	A-8
R892	A-8
R893	B-8
R894	A-7
R895	A-6
R896	A-8
R897	A-8
R898	A-7
R899	A-7
R900	A-6
R901	A-6
R902	A-6
R903	A-8
R904	A-8
R905	A-8
R906	A-8
R907	A-8
R908	B-2
R910	B-2
R911	B-2
R912	B-2
R913	E-6
R914	D-2
R915	E-2
R916	A-7
R917	A-7
R918	A-2
R919	A-7
R920	A-7
R924	C-5
R932	G-3
R933	F-7
R934	F-6
R935	F-7
R936	F-6
R937	F-7
R938	F-7
R939	F-6
R940	F-3
R941	G-3
R942	E-9
R943	G-3
T801	B-7

DD-105 BOARD (SIDE B)



DD-105 BOARD (SIDE A)



DD-105 BOARD

POWER

-REF.NO 2,000 SERIES-
XX MARK NO MOUNT


J901 BATTERY TERMINAL
CN801 7P
CN931 48P
TO VC-195 BOARD(7/10) CN914 (SEE PAGE 4-40)
IC801 DRUM/CAPSTAN PWM DRIVE
IC802 BL/LCD POWER
Q801 SWITCHING
Q803-805 SWITCHING
Q813,806 BL CONTROL SWITCH
Q820 SHOE SWITCH
Q824 SHOE UNREG SWITCHING
Q819 BL REG SWITCHING
Q826 EVF SWITCH
Q831 EVF 3 1/4 75V SWITCH
Q841 EVF 12V REG
Q837,846 EVF 12V SWITCH
Q830 CAM-7 0 REG
Q843 CAM 15V REG
Q934 LED 5V UNREG SWITCHING
Q932 UNREG SWITCH
Q933 UNREG SWITCH
CN935 10P
TO CONTROL SWITCH BLOCK FK-8500 (SEE PAGE 4-77)
CN934 12P
TO CONTROL SWITCH BLOCK SS-8500 (SEE PAGE 4-77)
CN932 16P
TO VC-195 BOARD(10/10) CN912 (SEE PAGE 4-51)
CN933 11P
TO PD-92 BOARD(4/4) CN5802 (SEE PAGE 4-88)
TO PD-93 BOARD(4/4) CN4802 (SEE PAGE 4-100)
Q815 DRUM PWM DRIVE
Q852 MT 4.75V REG
Q814 DRUM PWM DRIVE
Q810 1 9V REG
Q853-855 MT 4 75V SWITCH
Q817 SWITCHING
Q808 3 1V REG
Q812 SWITCHING
Q829,834 CAM -7 0V SWITCH
Q844 PANEL -15 3/-10 5V REG
Q842,847,856 CAM 15V SWITCH
Q832 PANEL 3 1V SWITCH
Q828 LCD POWER SWITCH
Q836-839 PANEL -15 3/-10 5V SWITCH
T801 DC/DC CONVERTER TRANS
Q807 SWITCHING
Q823 EMERGENCY DET
Q809 4 7V REG
Q827 LCD POWER SWITCH
Q833 PANEL 4 75V SWITCHING
Q840 PANEL 6 5/12V REG
Q835,845,838 PANEL 6 5/12V SWITCH
Q849 PANEL 13 3/18 5V REG
Q848,850 PANEL 13.3/18 5V SWITCH

DD-105 BOARD
CAMERA REC



• SIGNAL PATH

	REC	REC/PB	PB
Drum servo(speed and phase)		▶- -	
Capstan servo(speed and phase)		➡ ›	

Note	Note
The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

SECTION 5
ADJUSTMENTS

Refer to page 3 as Table for distinction functions of models and classification

5-1. CAMERA SECTION ADJUSTMENTS

1-1. PREPARATIONS BEFORE ADJUSTMENT (CAMERA SECTION)

1-1-1. List of Service Tools

- Oscilloscope
- Adjusting driver
- Color monitor
- Regulated power supply
- Vectorscope
- Digital voltmeter

Ref. No	Name	Parts Code	Usage
J-1	Filter for color temperature correction (C14)	J-6080-058-A	Auto white balance adjustment/check White balance adjustment/check
J-2	ND filter 1.0	J-6080-808-A	White balance check
	ND filter 0.3	J-6080-818-A	White balance check
J-3	Pattern box PTB-450	J-6082-200-A	
J-4	Color chart for pattern box	J-6020-250-A	
J-5	Adjusting remote commander (RM-95-remodeled partly) Note 1	J-6082-053-B	
J-6	Siemens star	J-6080-875-A	For checking the flange back
J-7	Multi CPC jig	J-6082-311-A	For adjusting LCD block
J-8	CPC-7 jig	J-6082-382-A	For the color viewfinder adjustment For adjusting the video section
J-9	Power code Note 2	J-6082-223-A	For connecting the battery terminal and DC power supply
J-10	AFM DEV jig	J-6082-312-A	For adjusting the deviation
J-11	Clear chart	J-6080-621-A	
J-12	Extension cable (16P, 0.5 mm)	J-6082-357-A	For extension between the CD-197/198 board (CN401) and VC-195 board (CN501)
J-13	IR receiver jig	J-6082-383-A	For adjusting the IR transmitter
J-14	Extension cable (48P, 0.8 mm)	J-6082-188-A	For extension between the DD-105 board (CN401) and VC-195 board (CN914)

Note 1: If the micro processor IC in the adjusting remote commander is not the new micro processor (UPD7503G-C56-12), the pages cannot be switched. In this case, replace with the new micro processor (8-759-148-35).

Note 2: Connect the adjusting remote commander to the LANC jack, and set the HOLD switch to the "ADJ" side



Fig. 5-1-1.

1-1-2. Preparations

Note 1: For details of how remove the cabinet and boards, refer to "2. DISASSEMBLY".

Note 2: When performing only the adjustments, the lens block and boards need not be disassembled.

1) Connect the equipment for adjustments according to Fig. 5-1-3, 4.
2) By setting the "Forced Camera Power ON mode", the camera power can be turned ON even if the front panel block (MA-311/312/331 board, power switch, microphone unit) has been removed. When removing the front panel block disconnect the following connector.
   1. VC-195 board CN903 (23P 0.5mm)
3) The intelligent accessory shoe (Intelligent accessory shoe model) or video light (Video light model) need not be assembled. If removing it. disconnect the following connector.
   1. VC-195 board CN909 (10P, 0.5mm)

Note 3: As removing the cabinet (R) (removing the VC-195 board CN911) means removing the lithium 3V power supply (CF-50/51 board), data such as date, time, user-set menus will be lost. After completing adjustments, reset these data. If the cabinet (R) has been removed, the self-diagnosis data, data on history of use (total drum rotation time etc.) will be lost. Before removing, note down the self-diagnosis data and data on the history use. (Refer to the "Service Mode" of "VIDEO SECTION ADJUSTMENT" for the data on the history use.)

Note 4: Setting the "Forced Camera Power ON" Mode
1) Select page: 0, address: 01, and set data: 01.
2) Select page: D, address: 10, set data: 01, and press the PAUSE button of the adjusting remote commander.
The above procedure will enable the camera power to be turned on with the front panel block removed. After completing adjustments, be sure to exit the "Forced Camera Power ON Mode".

Note 5: Exiting the "Forced Camera Power ON" Mode
1) Select page: 0, address: 01, and set data: 01.
2) Select page: D, address: 10, set data: 00, and press the PAUSE button of the adjusting remote commander.
3) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-2.

2.5 INCH LCD MODEL

Note 1 : 2.5" LCD model : CCD-TRV15/TRV15E/TRV15EP/TRV15PK/TRV25/TRV25PK/TRV35/TRV35E/TRV65/TRV65PK/TRV215/TRV615



Color monitor
Vector scope
Terminated at 75 Ω
Lens block
CD-197 board
CN401
Extension cable(16P)
(J-6082-357-A)
Battery
terminal
(Note 2)
Regulaterd power supply
(8.4 ± 0.1 Vdc)
Adjusting
remote
commander
LANC
jack
Need not connected
VIDEO terminal
CN909
CN551
CN501
CN912
CN935
CN932
CN934
CN902
VC-195
board
CN911
CN910
CN914
CN801
CN931
CN933
DD-105
board
CN903
CN901
CN001
CN905
CN906
CN905
MA-311/331 board
CN303
Extension cable(48P)
(J-6082-188-A)
Must be connected when performing the VIDEO system adjustments.
CPC-7 jig
(J-6082-382-A)
PD-92 board
CN580
CF-50
board
CN001
CN5701
CN5501
CN5001
PD-92 board
Must be connected when performing the LCD system adjustments.
Multi CPC jig
(J-6082-311-A)
CN5805
CN5802
CN5803
CN5804

Note 2 : Connect the adjusting remote commander to the LANC jack, and set the HOLD switch to the "ADJ" side, or use the AC power adaptor.

Fig. 5-1-3.

3/3.5 INCH LCD MODEL



Note 1 : 3” LCD model . CCD-TRV93
3.5”LCD MODEL , CCD-TRV85/TRV815

Note 2 : Connect the adjusting remote commander to the LANC jack, and set the HOLD switch to the “ADJ” side, or use the AC power adaptor.

Color monitor
Vector scope
Terminated at 75 Ω
Lens block
CD-198 board
CN401
Extension cable(16P)
(J-6082-357-A)
Battery
terminal
(Note 2)
Regulaterd power supply
(8.4 ± 0.1 Vdc)
Adjusting
remote
commander
LANC
jack
Need not connected
VIDEO terminal
CN909
CN551
CN501
CN912
CN911
CN910
CN914
CN902
VC-195
board
CN903
CN901
CN001
CN905
CN906 CN905
CN935
CN932
CN934
CN801
CN931
CN933
DD-105
board
MA-312 board
CN303
Extension cable(48P)
(J-6082-188-A)
Must be connected when performing the VIDEO system or color EVF system adjustments
CPC-7 jig
(J-6082-382-A)
PD-93 board
CN580
CF-51
board
CN001
CN4701
CN4601
PD-93 board
CN4501
Must be connected when performing the LCD system adjustments
Multi CPC jig
(J-6082-311-A)
CN4805
CN4802
CN4803
CN4804

Fig. 5-1-4.

1-1-3.Precaution

1. Setting the Switch

Unless otherwise specified, set the switches as follows and perform adjustments without loading cassette.

1. POWER switch (MA-311/312/331 board) .... CAMERA
2. NIGHT SHOT switch (Lens Block) .... OFF
   (Night shot model)
3. VIDEO LIGHT switch (MA-312 board) .... OFF
   (Video light model)
4. DEMO MODE (Menu display) .... OFF
5. DIGITAL ZOOM (Menu display) .... OFF
6. STEADY SHOT (Menu display) .... OFF
7. DISPLAY (Menu display) .... V-OUT/LCD
8. FOCUS switch (MF-8500/MR-8500)
   (Manual Focus model) .... MANUAL
9. PROGRAM AE (CF-50/51 board) .... Auto
10. BACK LIGHT (CF-50/51 board) .... OFF
11. PICTURE EFECT (CF-50/51 board) .... OFF
12. 16 : 9 WIDE (MENU display) .... OFF

2. Adjusting Procedure

Adjust in the given order.


Color bar chart standard picture trame
H
Yellow
Cyan
Green
White
Magenta
Red
Blue
A
B
A=B
B
A
0± 0.1 msec
V
Enlargement
Difference in level
A
B
Electronic beam scanning frame
Yellow
Cyan
Green
White
Magenta
Red
Blue
CRT picture frame

Fig. a. (Video output terminal output wavefom)

Fig. b. (TV monitor picture)

Adjust the camera zoom and direction to obtain the output wavefom shown in Fig. a and the TV monitor display shown in Fig. b.

Fig. 5-1-5.

3. Subject

1) Color bar chart (Standard picture frame)
   Adjust the picture frame as shown in Fig. 5-1-5. if adjustments are performed using the color bar chart.
   (Standard picture frame)
2) White pattern (Standard picture frame)
   Remove the color bar chart from the pattern box, and insert a clear chart in its place. (Do not perform zoom operations during this time.)
3) Chart for flange back adjustment
   Combine a white A0 size (1189 mm x 841 mm) paper to a black one, and make the chart shown in Fig. 5-1-6.


White
Black
841 mm
1189 mm

Note : Use the non-reflecting and non-glazing vellum paper whose size is more than A0, and make the boundary between white and black to be smoothly flat.

1-1-4. Adjusting Remote Commander

The adjusting remote commander is used for changing the calculation coefficient in signal processing, EVR data, etc The adjusting remote commander performs bi-directional communication with the unit using the remote commander signal line (LANC) The resultant data of this bi-directional communication is written in the non-volatile memory

1. Using the adjusting remote commander

1) Connect the adjusting remote commander to the LANC terminal.
2) Adjust the HOLD switch of the adjusting remote commander to "HOLD" (SERVICE position)

If it has been properly connected, the LCD on the adjusting remote commander will display as shown in Fig 5-1-7



Fig. 5-1-7.

3) Operate the adjusting remote commander as follows.
   - Changing the page
     The page increases when the EDIT SEARCH+ button is pressed, and decreases when the EDIT SEARCH– button is pressed There are altogether 16 pages, from 0 to F

Hexadecimal notation	0	1	2	3	4	5	6	7	8	9	A	B	C	D	E	F
LCD Display	0	1	2	3	4	5	6	7	8	9	A	b	c	d	E	F
Decimal notation conversion value	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15

Table 5-1-1.

   - Changing the address
     The address increases when the FF (▶▶) button is pressed, and decreases when the REW (◀◀) button is pressed There are altogether 256 addresses, from 00 to FF
   - Changing the data (Data setting)
     The data increases when the PLAY (▶) button is pressed, and decreases when the STOP (■) button is pressed
     There are altogether 256 data, from 00 to FF
   - Writing the adjustment data
     The PAUSE button must be pressed to write the adjustment data (D, E, F page) in the nonvolatile memory
     (The new adjustment data will not be recorded in the nonvolatile memory if this step is not performed)
4) Select page 0, address 01, and set the data to 01, and enables Page D and E, F to be adjusted
5) After completing all adjustments, set data. 00 to page 0, address· 01 and turn off the main power supply (8 4V) once

2. Precautions upon using the adjusting remote commander

Mishandling of the adjusting remote commander may erase the correct adjustment data at times To prevent this, it is recommended that all adjustment data be noted down before beginning adjustments and new adjustment data after each adjustment

1-1-5. Data Processing

The calculation of the DDS display and the adjusting remote commander display data (hexadecimal notation) are required for obtaining the adjustment data of some adjustment items In this case, after converting the hexadecimal notation to decimal notation, calculate and convert the result to hexadecimal notation, and use it as the adjustment data Table 5-1-2. indicates the hexadecimal notation-the decimal notation calculation table

Hexadecimal notation-Decimal notation

② ↓

The lower digits of the hexadecimal notation / The upper digits of the hexadecimal notation	0	1	2	3	4	5	6	7	8	9	A (A)	B (b)	C (c)	D (d)	E (E)	F (F)
0	0	1	2	3	4	5	6	7	8	9	10	11	12	13	14	15
1	16	17	18	19	20	21	22	23	24	25	26	27	28	29	30	31
2	32	33	34	35	36	37	38	39	40	41	42	43	44	45	46	47
3	48	49	50	51	52	53	54	55	56	57	58	59	60	61	62	63
4	64	65	66	67	68	69	70	71	72	73	74	75	76	77	78	79
5	80	81	82	83	84	85	86	87	88	89	90	91	92	93	94	95
6	96	97	98	99	100	101	102	103	104	105	106	107	108	109	110	111
7	112	113	114	115	116	117	118	119	120	121	122	123	124	125	126	127
8	128	129	130	131	132	133	134	135	136	137	138	139	140	141	142	143
9	144	145	146	147	148	149	150	151	152	153	154	155	156	157	158	159
A (A)	160	161	162	163	164	165	166	167	168	169	170	171	172	173	174	175
①→ B (b)	176	177	178	179	180	181	182	183	184	185	186	187	188	189	190	191
C (c)	192	193	194	195	196	197	198	199	200	201	202	203	204	205	206	207
D (d)	208	209	210	211	212	213	214	215	216	217	218	219	220	221	222	223
E (E)	224	225	226	227	228	229	230	231	232	233	234	235	236	237	238	239
F (F)	240	241	242	243	244	245	246	247	248	249	250	251	252	253	254	255

Note: ( ) indicate the adjusting remote commander display

(Example) In the case that the DDS display and the adjusting remote commander display are BD (bd)
As the upper digit of the hexadecimal notation is B (b), and the lower digit is D (d), the intersection "189" of the ① and ② in the above table is the decimal notation to be calculated

Table 5-1-2.

1-2. INITIALIZATION OF D, E, F PAGE DATA

1. Initializing the D,E,F Page Data

Note 1: If "Initializing the D, E, F Page Data" is performed, all data of the D page, E page and F page will be initialized. (It is impossible to initialize a single page.)

Note 2: If the D,E,F page data has been initialized, "Modification of D, E, F Page Data" and all adjustments need to be performed again.

Note 3: < > : NTSC model (CCD-TRV15/TRV15PK/TRV25/TRV25PK/TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV815/TRV815)

[ ] : PAL model (CCD-TRV15E/TRV15EP/TRV35E)

Adjusting page	D
Adjusting Address	00 to 6F
Adjusting page	F
Adjusting Address	00 to FF
Adjusting page	E
Adjusting Address	00 to FF

Initializing Method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 2, address: 00, and set data: 55 <NTSC> or data : 51 [PAL].
3) Select page: 2, address: 01, set data: 55<NTSC> or data : 51 [PAL], and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address: 02, and check that the data is 01.
5) Select page: 3, address: 00, and set data: 29.
6) Select page: 3, address: 01, set data: 29, and press the PAUSE button of the adjusting remote commander.
7) Select page: 0, address: 01, and set data: 00.
8) Perform "Modification of D,E,F Page Data".

2. Modification of D, E, F Page Data

If the D, E, F page data has been initialized, change the data of the "Fixed data-2" address shown in the following tables by manual input.

Modifying Method:

1) Before changing the data, select page: 0, address: 01, and set data: 01.
2) New data for changing are not shown in the tables because they are different in destination. When changing the data, copy the data built in the same model.

Note : If copy the data built in the different model, the camcorder may not operate.

3) When changing the data, press the PAUSE button of the adjusting remote commander each time when setting new data to write the data in the non-volatile memory.
4) Check that the data of adjustment addresses is the initial value. If not, change the data to the inital value.
5) After compleating "Modification of D, E, F Paga Data" select page: 0, address: 01, and set data: 00. Also perform all adjustments.

3. D Page Table

Note1 :

Fixed data-1 : Initialized data.
(Refer to "1. Initializing the D,E,F Page Data".)
Fixed data-2 : Modified data.
(Refer to "2. Modification of D, E, F Page Data").

Address	Initial Value		Remark
	NTSC	PAL	
00 to 0F			
10	00	00	Fixed data-1 (Initialized data)
11	00	00	
12	00	00	
13			Fixed data-2 (Modified data, copy the data built in the same model.)
14			
15			
16			
17			
18			
19			
1A			
1B			
1C			
1D			
1E			
1F			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
2A			Fixed data-1 (Initialized data)
2B			
2C			
2D			
2E			Fixed data-2
2F			
30	88	88	Battery end adj.
31	8D	8D	
32	A8	A8	
33	BD	BD	
34	C8	C8	
35			Fixed data-2 (Modified data, copy the data built in the same model.)
36			
37			
38			
39			
3A			
3B			
3C			
3D			
3E			
3F			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
4A			

Address	Initial Value		Remark
	NTSC	PAL	
4B			Fixed data-1 (Initialized data)
4C			
4D			
4E			
4F			
50			Fixed data-2 (Modified data, copy the data built in the same model.)
51			
52			
53			
54			
55			
56			
57			
58			
59			
5A			
5B			
5C			
5D			
5E			
5F			
60			Fixed data-1 (Initialized data)
61			
62			
63			
64			
65			
66			
67			
68			
69			
6A			
6B			
6C			
6D			
6E			
6F			

4. F Page table

Note 1:

Fixed data-1 : Initialized data.
(Refer to "1. Initializing the D,E,F Page Data".)
Fixed data-2 : Modified data.
(Refer to "2. Modification of D, E, F Page Data").

Note 2: There are four models classified by CCD imager types as shown below, and the initial value of adjustment is different according to the model.

NTSC 510H model : CCD-TRV15/TRV15PK
NTSC 760H model : CCD-TRV25/TRV25PK/TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815
PAL 510H model : CCD-TRV15E/TRV15EP
PAL 760H model : CCD-TRV35E

Note 3 : There are three models classified by VTR formats as shown below, and the initial value of adjustment is different according to the model.

NTSC HI8 model : CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815
NTSC Standard8 model : CCD-TRV15/TRV15PK/TRV25/TRV25PK/TRV35/TRV215
PAL Standard8 model : CCD-TRV15E/TRV15EP/TRV35E

Address	Initial Value		Remark
	NTSC	PAL	
00 to 0F			
10	00	00	Emergency memory address
11	00	00	
12	00	00	
13	00	00	
14	00	00	
15	00	00	
16	00	00	
17	00	00	
18	00	00	
19	00	00	
1A	00	00	
1B	00	00	
1C			Fixed data-2
1D			
1E			
1F			
20			
21	D2	<D2>, [D0]	G-CAM flip adj. <> : CCD-TRV35E [ ] : CCD-TRV15E/TRV15EP
22			Fixed data-2
23			
24			Fixed data-1
25			(Color reproduction adj.)
26			Fixed data-2
27			
28			
29			Fixed data-1
2A			
2B			Fixed data-2
2C	A0	A0	28MHz origin osc. adj.
2D			Fixed data-2
2E			Fixed data-1
2F	80	80	Hall adj.
30	80	80	
31	18/08	18/08	Max gain adj. Note 2 : 510H model/ 760H model
32			Fixed data-1
33			
34	1B	1B	Color reproduction adj.
35			Fixed data-1
36	42	42	Color reproduction adj.
37			Fixed data-1
38			
39			

Address	Initial Value		Remark
	NTSC	PAL	
3A	89	89	Auto white balance adj.
3B	59	59	
3C	38	38	IRIS IN/OUT adj.
3D	41	41	
3E	25	25	Flange back adj.
3F	00	00	
40	19	19	
41	00	00	
42	35	35	
43	52	52	Angular velocity sensor sensitivity adj.
44	52	52	
45	7A	7A	1.5MHz deviation adj.
46	8D	8D	1.7MHz deviation adj.
47	7A	7A	BPF f0 adj.
48			Fixed data-1
49	6B	6B	Y OUT level adj.
4A	40	40	AFC f0 adj.
4B	9A	9A	C OUT level adj.
4C			Fixed data-1
4D	7B	7B	Filter f0 adj.
4E	60	60	RP filter f0 adj.
4F			Fixed data-1
50			
51			
52			
53	40	40	REC Y current adj.
54	40	40	(Addresses 57 to 5A are fixed data addresses.)
56	5F	40	
57	A0/80	80	Note 3 : HI8 model/ Standard8 model
55	5F	40	
58	80	80	
59	90/80	80	
5A	80	80	
5B	50	50	REC L level adj.
5C	50	50	(Addresses 63 to 64 are fixed data addresses.)
5D	43	50	
5E	43	50	
5F	66	66	
60	66	66	
61	67	66	
62	67	66	
63	7C/80	80	Note 3 : HI8 model/ Standard8 model
64	78/80	80	
65	80	80	REC C current adj.
66	41	41	IR video deviation Adj.
67	33	33	IR audio deviation Adj.
68	C7	C7	IR video carrier freq. Adj.
69	3C	3C	CAP FG offset adj.
6A			Fixed data-2
6B			Fixed data-1
6C			
6D			
6E			
6F			
70	3B	3B	AWB standard data input adj.
71	FF	FF	
72	56	56	
73	7D	7D	
74			Fixed data-1
75			
76	1B	1B	Flange back adj.
77	54	54	
78	25	25	
79	80	80	
7A	10	10	
7B	FF	FF	

Address	Initial Value		Remark
	NTSC	PAL	
7C	0A	0A	Switching position adj.
7D	00	00	
7E	0A	0A	
7F	00	00	
80			Fixed data-2
81			
82			Fixed data-1
83			
84			Fixed data-2
85			Fixed data-1
86			Fixed data-2
87			Fixed data-1
88			
89			
8A			
8B			
8C			
8D			
8E			Fixed data-2
8F			Fixed data-1
90			
91			
92			
93			
94			Fixed data-2
95			
96			Fixed data-1
97			
98			Fixed data-2
99			Fixed data-1
9A			Fixed data-2
9B			Fixed data-1
9C			Fixed data-2
9D			Fixed data-1
9E			Fixed data-2
9F			Fixed data-1
A0			Fixed data-2
A1			
A2			
A3			
A4			
A5			Fixed data-1
A6			Fixed data-2
A7			
A8			
A9			
AA			Fixed data-1
AB			
AC			Fixed data-2
AD			Fixed data-1
AE			Fixed data-2
AF			Fixed data-1
B0			
B1			
B2			
B3			
B4			
B5			
B6			
B7			
B8			
B9			
BA			
BB			
BC			
BD			

Address	Initial Value		Remark
	NTSC	PAL	
BE			Fixed data-2
BF			
C0			Fixed data-1
C1			
C2			
C3			
C4			
C5			Fixed data-2
C6			Fixed data-1
C7			
C8			Fixed data-2
C9			
CA			Fixed data-1
CB			
CC			
CD			
CE			
CF			
D0			
D1			
D2			
D3			
D4			
D5			
D6			
D7			
D8			
D9			Fixed data-2
DA			Fixed data-1
DB			
DC			Fixed data-2
DD			Fixed data-1
DE			
DF			
E0			
E1			
E2			
E3			Fixed data-2
E4			
E5			Fixed data-1
E6			Fixed data-2
E7			Fixed data-1
E8			
E9			
EA			
EB			Fixed data-2
EC			
ED			Fixed data-1
EE			
EF			
F0			
F1			
F2			Fixed data-2
F3			Fixed data-1
F4			
F5	FF	FF	Color reproduction adj.
F6	F6	F4	
F7			Fixed data-1
F8			
F9			
FA			
FB			
FC			
FD			
FE			
FF			

5. E Page Table

Note 1:

Fixed data-1 : Initialized data.
(Refer to "1. Initializing the D,E,F Page Data".)
Fixed data-2 : Modified data.
(Refer to "2. Modification of D, E, F Page Data").

Note 2: See "1-7. LCD SYSTEM ADJUSTMENT".

Address	Initial Value		Remark
	NTSC	PAL	
00			Fixed data-1
01			
02			
03			
04			
05			
06			
07			
08			
09			
0A			
0B			
0C			
0D			
0E			
0F			
10			
11			
12			
13			
14			Fixed data-2
15			Fixed data-1
16			
17			
18			
19			
1A			
1B			
1C			
1D			
1E			
1F			
20			
21			
22			
23			
24			
25			
26			
27			
28			
29			
2A			
2B			Fixed data-2
2C			
2D			
2E			
2F			Fixed data-1
30			
31			
32			
33			
34			
35			
36			
37			
38			Fixed data-2
39			
3A			
3B			Fixed data-1
3C			
3D			
3E			
3F			
40			
41			
42			
43			
44			
45			
46			
47			
48			
49			
4A			
4B			
4C			
4D			
4E			
4F			Fixed data-2
50			Fixed data-1
51			Fixed data-2
52			
53			Fixed data-1
54			
55			
56			
57			
58			
59			Fixed data-2
5A			
5B			Fixed data-1
5C			Fixed data-2
5D			Fixed data-1
5E			
5F			
60			Fixed data-2
61			
62			
63			
64			
65			
66			
67			
68			Fixed data-1
69			
6A			
6B			Fixed data-2
6C			
6D			Fixed data-1
6E			Fixed data-2
6F			
70			
71			
72			Fixed data-1
73			Fixed data-2
74			Fixed data-1
75			Fixed data-2
76 to 99			Fixed data-1

Address	Initial Value		Remark
	NTSC	PAL	
9A			Fixed data-2
9B			Fixed data-1
9C			Fixed data-2
9D			Fixed data-1
9E			
9F			
A0			Fixed data-2
A1			
A2			
A3			
A4			Fixed data-1
A5			
A6			
A7			
A8			
A9			
AA			
AB			
AC			
AD			
AE			
AF			
B0			
B1			
B2			
B3			
B4			
B5			
B6			
B7			
B8			
B9			
BA			
BB			
BC			Fixed data-2
BD			
BE			
BF	Note2	Note2	Fixed data (NTSC model) VCO adj. (LCD) (PAL model)
C0			Fixed data-2
C1			
C2	B0	B0	VCO adj. (Color EVF)
C3	80	80	Bright adj. (Color EVF)
C4	77	77	Contrast adj. (Color EVF)
C5	80	80	White balance adj. (Color EVF)
C6	80	80	
C7			Fixed data-2
C8			
C9			
CA			
CB			Fixed data-1
CC	B0	B0	Backlight consumption current adj. (Color EVF)
CD			Fixed data-1
CE			
CF			Fixed data-2
D0	Note 2	Note2	Bright adj. (LCD)
D1	Note 2	Note2	White balance adj. (LCD)
D2	Note 2	Note2	White balance adj. (LCD)
D3	Note 2	Note2	Contrast adj. (LCD)
D4	Note 2	Note2	D range adj. (LCD)
D5	Note 2	Note2	V-COM level adj. (LCD)
D6	Note 2	Note2	VCO adj. (LCD)
D7	Note 2	Note2	V-COM adj. (LCD)
D8			Fixed data-1

Address	Initial Value		Remark
	NTSC	PAL	
D9	Note 2	Note2	Fixed data (NTSC model) Color adj. (LCD) (PAL model)
DA			Fixed data-1
DB			Fixed data-2
DC			Fixed data-1
DD			
DE			
DF			
E0			
E1			
E2			
E3			
E4			
E5			
E6			
E7			
E8			
E9			
EA			Fixed data-2
EB			
EC			Fixed data-1
ED			
EE			
EF			Fixed data-2
F0			Fixed data-1
F1			
F2			
F3			Fixed data-2
F4			Fixed data-1
F5			
F6			
F7			
F8			
F9			
FA			
FB			
FC to FF			

1-3. CAMERA SYSTEM ADJUSTMENTS

Before perform the camera system adjustments, Check that the specified value of "28MHz Origin Oscillation Adjustment", "Y OUT level Adjustment" and "C OUT level Adjustment" of "VIDEO SYSTEM ADJUSTMENT" are satisfied.

1. G-CAM flip Adjustment

Set the color reproduction conditions to optimum

Subject	Color bar chart standard picture frame
Measurement Point	Display data of page 1 of the adjusting remote commander (Note 1)
Measuring Instrument	
Adjustment Page	F
Adjustment Address	21

Note 1. Displayed data of page 1 of the adjusting remote commander

```
1 . XX : XX
    |    └──→ S2
    └───────→ S1
```

Note 2. [ ] Except CCD-TRV15E/TRV15EP
< > CCD-TRV15E/TRV15EP

Adjusting method

1) Select page. 0, address. 01, and set data. 01
2) Select page: 0, address: 03, and set data: 16
3) Select page: F, address 21, set data [D2] <D0>, and press the PAUSE button of the adjusting remote commander
4) Select page 1 of the adjusting remote commander, and compare the higher 2 digits (S1) and lower 2 digits (S2) of the 4-degits display data.
   When S1<S2
   Perform steps 5) onwards
   When S1≧S2
   Perform steps "Processing after Completing Adjustments".
5) Select page: F, address 21, set data [52] <50>, and press the PAUSE button of the adjusting remote commander.

Processing after Completing Adjustments

1) Select page 0, address 03, and set data: 00.
2) Select page: 0, address 01, and set data: 00

2. HALL Adjustment

For detecting the position of the lens iris, adjust the hall AMP gain and offset

Subject	Not required
Measurement Point	DDS display data of LCD or TV monitor (Note 3)
Measuring Instrument	
Adjustment Page	F
Adjustment Address	2F, 30
Specified Value	90 to 94 during IRIS OPEN (Note 1) 19 to 1D during IRIS CLOSE (Note 2)

Note 1: Select page 2, address 01, set data 01, and press the PAUSE button of the adjusting remote commander

Note 2: Select page 2, address 01, set data 03, and press the PAUSE button of the adjusting remote commander.

Note 3: DDS display data of LCD or TV monitor

00 00XX
→ Object data

Adjusting method.

1) Select page: 0, address 01, and set data 01
2) Select page 0, address 03, and set data 03
3) Select page D, address 11, set data: 02, and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address 01, set data. 03, and press the PAUSE button
5) Select page F, address 30, set data 80, and press the PAUSE button.
6) Select page: F, address 2F, set data 40, and press the PAUSE button.
7) Read the DDS display data (the bottom two digits of the display data at the bottom right of the LCD display or the TV monitor), and this data is named K_2.
8) Select page: F, address: 2F, set data: 30, and press the PAUSE button
9) Read the DDS display data, and this data is named K_1
10) Select page. 2, address: 01, set data 01, and press the PAUSE button
11) Read the DDS display data, and this data is named W_1
12) Select page. F, address 2F, set data 40, and press the PAUSE button
13) Read the DDS display data, and this data is named W_2
14) Convert W_1, W_2, K_1, K_2, to decimal notation, and obtain W_1', W_2', K_1', K_2'. (Refer to Table 5-1-2 "Hexadecimal notation - decimal notation conversion table" of "Service mode")
15) Calculate X_1' using the following equations (decimal notation calculation).

    $A' = W_2' + K_1' - W_1' - K_2'$ Equation 1

    $B' = W_1' - K_1'$ Equation 2

    $X_1' = [1904 + (48 \times A') - (16 \times B')] / A'$ Equation 3
16) Convert X_1' to hexadecimal notation, and obtain X_1 (Round off to one decimal place)
17) Select page F, address. 2F, set data X_1, and press the PAUSE button
18) Select page: 2, address 01, and set data: 01, and press the PAUSE button
19) Select page F, address: 30, change the data and adjust the DDS display data to "92"
20) Press the PAUSE button of the adjusting remote commander
21) Select page: 2, address: 01, and set data 03, and press the PAUSE button
22) Read the DDS display data, and this data is named K_0 If K_0 lies within the "19" to "1D" range, perform "Processing after completing adjustments" If it is lies outside the range, perform the following adjustments
23) Convert K_0 to decimal notation, and obtain K_0'
24) Calculate X_2' using the following equations (decimal notation calculation)

    $C' = 146 - B' - K_0'$ Equation 4

    $X_2' = [(119 - B') \times (X_1' - 48) + (48 \times C')] / C'$ Equation 5

    (X_1' and B' are values obtained from equations 2) and 3))
25) Convert X_2' to hexadecimal notation, and obtain X_2 (Round off to one decimal place)
26) Select page F, address 2F, set data: X_2, and press the PAUSE button
27) Select page 2, address 01, set data 03, and press the PAUSE button
28) Select page F, address 30, change the data and adjust the DDS display data to "1B"
29) Press the PAUSE button of the adjusting remote commander
30) Select page 2, address 01, set data: 01, and press the PAUSE button
31) Check the DDS display data lies within the "90" to "94" range

Processing after Completing Adjustments

1) Select page D, address 11, and set data 00, and press the PAUSE button
2) Select page 0, address: 01, and set data 00
3) Select page: 2, address 01, and set data 00, and press the PAUSE button
4) Select page: 0, address 03, and set data 00

3. Flange Back Adjustment

The inner focus lens flange back adjustment is carried out automatically. In whichever case, the focus will be deviated during auto focusing/manual focusing.

3-1. Flange Back Adjustment(1)

Subject	Flange back adjustment chart (2.0 m from the front of the lens) (Luminance: 200 ± 50 lux)
Measurement Point	Check operation on TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	3E to 42, 76 to 7B

Switch setting:

1) NIGHT SHOT switch .... OFF

Adjusting method:

1) Check that at both the zoom lens TELE end and WIDE end, the center of the chart for the flange back adjustment and center of the exposure screen coincide.
2) Select page: 0, address: 01, and set data: 01.
3) Check that the data of page: F, address: 3E to 42, 76 to 7B is the initial value (See table below).

Address	Data	Address	Data
3E	25	77	54
3F	00	78	25
40	19	79	80
41	00	7A	10
42	35	7B	FF
76	1B		

4) Select page: 2, address: 02, and check that the data is "00 ".
5) Select page: 2, address: 01, set data: 13, and press the PAUSE button of the adjusting remote commander.
6) Select page: 2, address: 01, set data: 15, and press the PAUSE button of the adjusting remote commander.
   (The adjustment data will be automatically input to page: F, addresses: 3E to 42, 76 to 7B.)
7) Select page: 2, address: 02, and check that the data is „01".

Processing after Completing Adjustments

1) Turn OFF the main power supply (8.4V).
2) Perform "Flange Adjustment (2)".

3-2. Flange Back Adjustment (2)

Perform this adjustment after performing "Flange Back Adjustment (1)".

Subject	Subject more than 500m away (Subjects with clear contrast such as buildings, etc.)
Measurement Point	Check operation on TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	3E to 42, 76 to 7B

Switch setting:

1) NIGHT SHOT switch .... OFF

Adjusting method:

1) Set the zoom lens to the TELE end and expose a subject that is more than 500 m away (subject with clear contrast such as building, etc.). (Nearby subjects less than 500 m away should not be in the screen.)
2) Select page: 0, address: 01, and set data: 01.
3) Select page: 2, address: 02, and check that the data is "00".
4) Select page: 2, address: 01, set data: 13, and press the PAUSE button of the adjusting remote commander.
5) Place a ND filter on the lens so that the optimum image is obtain.
6) Select page: 2, address: 01, set data: 29, and press the PAUSE button of the adjusting remote commander.
   (The adjustment data will be automatically input to page: F, addresses: 3E to 42, 76 to 7B.)
8) Select page: 2, address: 02, and check that the data is "01".

Processing after Completing Adjustments

1) Select page: 0, address: 01, and set data: 00.
2) Turn OFF the main power supply (8.4V).
3) Perform "Flange Back Check".

4. Flange Back Check

Subject	Siemens star (2.0 m from the front of the lens) (Luminance: approx. 200 lux)
Measurement Point	Check operation on TV monitor
Measuring Instrument	
Adjustment Page	F
Adjustment Address	3E to 42, 76 to 7B

Switch setting:

1) NIGHT SHOT switch .... OFF

Checking method:

1) Place the Siemens star 2.0m from the front of the lens.
2) To open the IRIS, decrease the luminous intensity to the Siemens star up to a point before noise appear on the image.
3) Select page: 2, address: 40, and set data: 02.
4) Select page: 2, address: 41, and set data: 01.
5) Shoot the Siemens star with the zoom TELE end.
6) Turn on the auto focus.
7) Check that the lens is focused (Note1).
8) Select page: 2, address: 21, and set data: 10.
9) Shoot the Siemens star with the zoom WIDE end.
10) Observe the TV monitor and check that the lens is focused.

Note 1: When the auto focus is ON, the lens can be checked if it is focused or not by observing the data on the page 1 of the adjusting remote commander.

1) Select page: 0, address: 03, and set data: 0F.
2) Page 1 shows the state of the focus.

1 : 00 : XX
→ Odd: Focused
Even: Unfocused

Processing after Completing Adjustments

1) Select page: 2, address: 21, and set data: 00.
2) Select page: 0, address: 03, and set data: 00.
3) Select page: 2, address: 40, and set data: 00.
4) Select page: 2, address: 41, and set data: 00.

5. Picture Frame Setting

Subject	Color bar chart standard picture frame (1.5m from the front of the lens)
Measurement Point	Video output terminal
Measuring Instrument	Oscilloscope and TV monitor
Specified Value	A=B, C=D, t=0 ± 0.1msec

Setting method:

1) Adjust the zoom and the camera direction, and set to the specified position.
2) Mark the position of the picture frame on the monitor display, and adjust the picture frame to this position in following adjustments using "Color bar chart standard picture frame".

1. Horizontal period



2. Vertical period



Fig. 5-1-8.



Fig. 5-1-9.

6. Color Reproduction Adjustment

Adjust the color Separation matrix coefficient so that proper color reproduction is produced.

Subject	Color bar chart standard picture frame
Measurement Point	Video output terminal
Measuring Instrument	Vectorscope
Adjustment Page	F
Adjustment Address	34, 36, F5, F6

Specified Value
All color luminance points should settle within each color reproduction frame.

Note1: NTSC 510H model (CCD-TRV15/ TRV15PK)
NTSC 760H model (CCD-TRV25/ TRV25PK/ TRV35/ TRV65/ TRV65PK/ TRV85/ TRV93/ TRV215/ TRV615/ TRV815)
PAL 510H model (CCD-TRV15E/ TRV15EP)
PAL 760H model (CCD-TRV35E)

Switch setting:
1) NIGHT SHOT switch .... OFF

Adjusting method:
1) Select page: 0, address: 01, and set data: 01.
2) Select page: 2, address: 01, set data: 3D, and press the PAUSE button of the adjusting remote commander.
3) Select page: F, address: 25, set data: 3F, and press the PAUSE button of the adjusting remote commander.
4) Adjust the GAIN and PHASE of the vectorscope, and adjust the burst luminance point to the burst position of the color reproduction frame.
5) Change the data of page: F, address: 34, 36, F5 and F6, and settle each color luminance point in each color reproduction frame.

Note 2: Be sure to press the PAUSE button of the adjusting remote commander before changing the of addresses. If not, the new data will not be written to the memory.

6) Press the PAUSE button of the adjusting remote commander.

Processing after Completing Adjustments
1) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjusting remote commander.
2) Select page: 0, address: 01, and set data: 00.

For NTSC 510H model



For NTSC 760H model



For PAL 510H/PAL 760H model



Fig. 5-1-10.

7. IRIS IN/OUT Adjustment

For the unit to judge if the white balance is indoors or outdoors in auto white balance operations, measure the light level and write it in the EEPROM.
If the level is not correct, the white balance will not be accurate.

Subject	Clear chart (Color bar standard picture frame)
Measurement Point	DDS display of LCD or TV monitor
Measuring Instrument	(Note 1)
Adjustment Page	F
Adjustment Address	3C, 3D

Note 1: The right four digits of the display data at the right bottom side of the LCD and TV monitor is the LIGHT LEVEL data.

00 XX XX
→ Lower two digits
→ Upper two digits

Switch setting:
1) STEADY SHOT (Menu display) .... OFF
2) NIGHT SHOT switch .... OFF

Adjusting method:
1) Select page: 0, address: 01, and set data: 01.
2) Select page: 0, address: 03, and set data: 06.
3) Select page: D, address: 11, and set data: 02, and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address: 40, and set data: 02.
5) Select page: 2, address: 01, set data: 0B, and press the PAUSE button of the adjusting remote commander.
6) Read the DDS display data (Note 1), and take the upper two digits as D_1 and the lower two as D_2.
7) Convert D_1 to decimal notation, and obtain D_1'. (Refer to Table 5-1-2. "Hexadecimal notation - decimal notation conversion table" of "Service mode".)
8) Calculate D_3' using the following equations. (Equations 1 and 2 are for decimal notation calculation).
   When $D_2 \geqq$ D0
   $D_3' = D_1' - 21$ .... Equation 1
   When $D_2 <$ D0
   $D_3' = D_1' - 22$ .... Equation 2
9) Convert D_3' to hexadecimal notation, and obtain D_3.
10) Select page: F, address: 3C, set data: D_3, and press the PAUSE button of the adjusting remote commander.
11) Select page: 2, address: 01, set data: 09, and press the PAUSE button of the adjusting remote commander.
12) Read the DDS display data (Note 1), and take the upper two digits as D_4 and the lower two as D_5.
13) Convert D_4 to decimal notation, and obtain D_4'. (Refer to Table 5-1-2. "Hexadecimal notation - decimal notation conversion table" of "Service mode".)
14) Calculate D_6' using the following equations. (Equations 3 and 4 are for decimal notation calculation).
   When $D_5 \geqq$ F0
   $D_6' = D_4' - 13$ .... Equation 3
   When $D_5 <$ F0
   $D_6' = D_4' - 14$ .... Equation 4
15) Convert D_6' to hexadecimal notation, and obtain D_6.
16) Select page: F, address: 3D, set data: D_6, and press the PAUSE button of the adjusting remote commander.

Processing after Completing Adjustments
1) Select page: D, address: 11, and set data: 00, and press the PAUSE button of the adjusting remote commander.
2) Select page: 0, address: 01, and set data: 00.
3) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address: 40, and set data: 00.
5) Select page: 0, address: 03, and set data: 00.

8. MAX GAIN Adjustment

Setting the minimum illumination.
If it is not consistent, the image level required for taking subjects in low illuminance will not be produced (dark).

Subject	Clear chart (Color bar standard picture frame)
Measurement Point	DDS display of LCD or TV monitor
Measuring Instrument	(Note 1)
Adjustment Page	F
Adjustment Address	31
Specified Value	C0 to FF

Note 1: The right two digits of the display data at the right bottom side of the LCD and TV monitor is the object data.

00 00 XX
→ Object data

Note 2: NTSC 510H model (CCD-TRV15/TRV15PK)
NTSC760H model (CCD-TRV25/TRV25PK/TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815)
PAL 510H model (CCD-TRV15E/15EP)
PAL 760H model (CCD-TRV35E)

Switch setting:
1) STEADY SHOT (Menu display) .... OFF
2) NIGHT SHOT switch .... OFF

Adjusting method:
1) Select page: 0, address: 01, and set data: 01.
2) Select page: D, address: 11, and set data: 02, and press the PAUSE button of the adjusting remote commander.
3) Select of page: 0, address: 03, and set data: 01.
4) Select page: 2, address: 40, and set data: 02.
5) Select page: 2, address: 56, and set data: 40.
6) Select page: 2, address: 01, set data: 19, and press the PAUSE button of the adjusting remote commander.
7) Select page: F, address: 31, set data: [18] <08>, and press the PAUSE button of the adjusting remote commander.
   Note : [ ] : 510H model
   < > : 760H model
8) Check that the DDS display data (Note 1) lies within the specified value.

Processing after Completing Adjustments
1) Select page: D, address: 11, and set data: 00, and press the PAUSE button of the adjusting remote commander.
2) Select page: 0, address: 01, and set data: 00.
3) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address: 40, and set data: 00.
5) Select page: 2, address: 56, and set data: 00.
6) Select page: 0, address: 03, and set data: 00.

9. Auto White Balance Standard Data Input

Subject	Clear chart (Color bar standard picture frame)
Adjustment Page	F
Adjustment Address	70 to 73

Note 1: Perform "Color Reproduction Adjustment" before this adjustment.

Note 2: Check that the data of page: 2, address: 02 is 00. If not, turn the power of the unit OFF/ON.

Switch setting:
1) NIGHT SHOT switch .... OFF

Adjusting method:
1) Select page: 0, address: 01, and set data: 01.
2) Wait for 2 seconds.
3) Select page: 2, address: 01, and set data: 11, and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address: 01, and set data: 0D, and press the PAUSE button of the adjusting remote commander.
   (When the standard data is take in, the data will be automatically input to page: F, address: 70 to 73.)
5) Select page: 2, address: 02, and check that the data is "01".
6) Perform "Auto White Balance Adjustment".

Processing after Completing Adjustments
1) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjusting remote commander.
2) Select page: 0, address: 01, and set data: 00.

10. White Balance Adjustment

Adjust to the proper auto white balance output data.
If it is not correct, auto white balance and color reproducibility will be poor.

Subject	Clear chart (Color bar standard picture frame)
Filter	Filter C14 for color temperature correction
Measurement Point	DDS display of LCD or TV monitor (Note 1)
Measuring Instrument	
Adjustment Page	F
Adjustment Address	3A, 3B
Specified Value	R ratio: 2B40 to 2BC0 B ratio: 5E40 to 5EC0

Note 1: Perform "Auto White Balance Standard Data Input" before this adjustment.

Note 2: The right four digits of the display data at the right bottom side of the LCD and TV monitor is the object data.

00 XXXX
→ Object data

Switch setting:
1) NIGHT SHOT switch .... OFF

Adjusting method:
1) Place the C14 filter for color temperature correction on the lens.
2) Select page: 0, address: 01, and set data: 01.
3) Select page: D, address: 11, and set data: 02, and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address: 01, and set data: 3F, and press the PAUSE button of the adjusting remote commander.
5) Select page: 0, address: 03, and set data: 04.
6) Select page: F, address: 3A, and change the data, and adjust the average value of the DDS display data(Note 2) to the R ratio specified value.
7) Press the PAUSE button of the adjusting remote commander.
8) Select page: 0, address: 03, and set data: 05.
9) Select page: F, address: 3B, and change the data, and adjust the average value of the DDS display data(Note 2) to the B ratio specified value.
10) Press the PAUSE button of the adjusting remote commander.

Processing after Completing Adjustments
1) Select page: D, address: 11, and set data: 00, and press the PAUSE button of the adjusting remote commander.
2) Select page: 0, address: 01, and set data: 00.
3) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjusting remote commander.
4) Select page: 0, address: 03, and set data: 00.

11. White Balance Check

Subject	Clear chart (Color bar standard picture frame)
Filter	Filter C14 for color temperature correction ND filter 1.0 and 0.3
Measurement Point	video output terminal
Measuring Instrument	Vectorscope
Specified Value	Fig. 5-1-11. A to C

Switch setting:

1) NIGHT SHOT switch .... OFF

Checking method:

1) Check that the lens is not covered with either filter.
2) Select page: 2, address: 01, set data: 0F, and press the PAUSE button of the adjusting remote commander.
3) Check that the center of the white luminance point is within the circle shown Fig. 5-1-11.A.
4) Select page: 2, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
5) Select page: 2, address: 01, set data: 23, and press the PAUSE button of the adjusting remote commander.
6) Place the C14 filter on the lens.
7) Check that the center of the white luminance point settles in the circle shown Fig. 5-1-11.B.
8) Remove the C14 filter, and place the ND filter 1.3 (1.0 +0.3) on the lens.
9) Check that the white luminance point stopped moving, and then remove the ND filter 1.3.
10) Check that the center of the white luminance point settles within the circle shown Fig. 5-1-11.C.

Processing after Completing Adjustments

1) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjusting remote commander.



Fig.5-1-11. A



Fig.5-1-11. B



Fig.5-1-11. C

12. Angular Velocity Sensor Sensitivity Adjustment

- This adjustment is performed only when replacing the angular velocity sensor
  Although this adjustment need not be performed when the circuit is damaged, etc , check the operations
- Note down the sensitivity displayed on the angular velocity sensor of the repair parts. At this time, note down also to which board it was attached to
  Be sure to check because if attached incorrectly, the screen will vibrate up and down or left and right during hand-shake correction operations.

Precautions on the Parts Replacement
There are two types of repair parts
Type A ENC03EA or ENC 03JA
Type B . ENC03EB or ENC 03JB
Replace the broken sensor with a same type sensor If replace with other parts, the image will vibrate up and down or left and right during hand-shake correction operations After replacing, re-adjust according to the adjusting method after replacement

Precautions on Angular Velocity Sensor
The sensor incorporates a precision oscillator Handle it with care as if it dropped, the balance of the oscillator will be disrupted and operations will not be performed properly

Adjustment page	F
Adjustment Address	43, 44

Note: The sensor sensitivity of SE451 and SE452 of the SE-66/67 board is written only on the repair parts

Adjusting method·
1) Select page: 0, address 01, and set data 01.
2) Read the sensor sensitivity written on SE451 of the SE-66/67 board, and take this as S_{451}.
3) Read the sensor sensitivity written on SE452 of the SE-66/67 board, and take this as S_{452}
4) Calculate D_{43}' and D_{44}' using the following equation (decimal calculation)
   NTSC model(CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV215/TRV35/ TRV65/ TRV65PK/ TRV85/ TRV93/ TRV615/ TRV815)
   $D_{43}' = 85 / S_{451}$
   $D_{44}' = 90 / S_{452}$
   PAL model (CCD-TRV15E/ TRV15EP/TRV35E)
   $D_{43}' = 118 / S_{451}$
   $D_{44}' = 106 / S_{452}$
5) Convert D_{43}' and D_{44}' into hexadecimal digits, to obtain D_{43} and D_{44} (Round off decimal points)
6) Select page: F, address: 43, set data: D_{43}, and press the PAUSE button of the adjusting remote commander
7) Select page: F, address: 44, set data: D_{44}, and press the PAUSE button of the adjusting remote commander

Processing after Completing Adjustments
1) Select page. 0, address 01, and set data· 00.
2) Check that the steady shot operations have been performed normally.

1-4. COLOR ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENT

(CCD-TRV93)

Note 1: The back light (fluorescent tube) is driven by a high voltage AC power supply. Therefore, do not touch the back light holder to avoid electrical shock.

Note 2: When replacing the LCD unit, be careful to prevent damages caused by static electricity.

[Adjusting connector]

Most of the measuring points for adjusting the viewfinder system are concentrated in CN910 of the VC-195 board.

Connect the measuring instruments via the CPC-7 jig (J-6082-382-A).

The following table shows the Pin No. and signal name of CN910.

Pin No.	Signal Name	Pin No.	Signal Name
1	LANC SIG	9	RF AGC OUT
2	XCPC IN	10	REC RF
3	IR VIDEO	11	RF SWP
4	AFC F0	12	CAP FG
5	BPF MONI	13	EVF BL
6	PB RF	14	EVF BL 4.75V
7	RF AGC IN	15	VCO
8	REG GND	16	EVF VG



Fig.5-1-12.

1. EVF Initial Data Input

Mode	VTR stop
Signal	No signal
Adjustment Page	E
Adjusting Address	C2 to CD

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.

2) Select page: E, and input the data in the following table.

Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data.

3) Select page: 0, address: 01, and set data: 00.

Address	Data	Remark
C2	B0	VCO adjustment
C3	80	Bright adjustment
C4	77	Contrast adjustment
C5	80	White balance adjustment
C6	80	White balance adjustment
C7	68	Fixed value
C8	50	Fixed value
C9	F8	Fixed value
CA	A8	Fixed value
CB	3C	Fixed value
CC	B0	Backlight Consumption Current Adjustment
CD	70	Fixed value

2. VCO Adjustment (VF-119 board)

Set the VCO free-run frequency. If deviated, the EVF screen will be blurred.

Mode	VTR stop
Signal	No signal
Measurement point	Pin ⑮ of CN910 (VCO) on VC-195 board
Measuring instrument	Oscilloscope (DC range)
Adjustment page	E
Adjustment address	C2
Specified value	A = 1.8 ± 0.1Vdc

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 55, and press the PAUSE button of the adjusting remote commander.
3) Check the GND level of the oscilloscope.
5) Select page: E, address: C2, change the data and set the VCO output voltage (A) to the specified value.
4) Press the PAUSE button of the adjusting remote commander.
5) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-13.

3. Bright Adjustment (VF-119 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement point	Pin ⑯ of CN910 (EVF VG) on VC-195 board
Measuring instrument	Oscilloscope
Adjustment page	E
Adjustment address	C3
Specified value	A = 7.2 ± 0.1 V

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 55, and press the PAUSE button of the adjusting remote commander.
3) Select page: E, address: C3, change the data and set the voltage (A) between the reversed waveform pedestal and non-reversed waveform pedestal to the specified value.
4) Press the PAUSE button of the adjusting remote commander.
5) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-14.

4. Contrast Adjustment (VF-119 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ⑯ of CN910 (EVF VG) on VC-195 board
Measuring Instrument	Oscilloscope
Adjustment Page	E
Adjustment Address	C4
Specified Value	A = 2.1 ± 0.1V (NTSC) A = 2.0 ± 0.1V (PAL)

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 55, and press the PAUSE button of the adjusting remote commander.
3) Select page: E, address: C4, change the data and set the voltage (A) between the 7 step peak and the pedestal to the specified value.
4) Press the PAUSE button of the adjusting remote commander.
5) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-15.

5. Backlight Consumption Current Adjustment (VF-120 board)

Set the backlight luminance and color temperature.
If deviated, the image may become dark or bright.

Mode	VTR stop
Signal	No signal
Measurement Point	+ Probe: Pin ⑭ of CN910 (EVF BL 4.75V) on VC-195 board – Probe: Pin ⑬ of CN910 (EVF BL) on VC-195 board
Measuring Instrument	Digital voltmeter
Adjustment Page	E
Adjustment Address	CC
Specified Value	A = 21.0 ± 1.0 mVdc

Note: Adjust 30 seconds after running on the power supply.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 55, and press the PAUSE button of the adjusting remote commander.
3) Select page: E, address: CC, change the data and set the voltage difference (A) between Pin ⑭ of CN910 (EVF BL 4.75V) and Pin ⑬ of CN910 (EVF BL) to the specified value.
4) Press the PAUSE button of the adjusting remote commander.
5) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00.

6. White Balance Adjustment (VF-119 board)

Correct the white balance.
If deviated, the reproduction of the EVF screen may degenerate.

Mode	VTR stop
Signal	No signal
Measurement Point	Check on EVF screen
Measuring Instrument	
Adjustment Page	E
Adjustment Address	C5, C6
Specified Value	The EVF screen should not be colored.

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 51, and press the PAUSE button of the adjusting remote commander.
2) Select page: 2, address: 7D, and set data: 03.
3) Select page: E, address: C5 and C6, set the data to the initial value.

Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data.

Address	C5	C6
Data	80	80

4) Check that the LCD screen is not colored. If colored, change the data of page: E, address: C5 and C6 so that the EVF screen is not colored.

Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data.

5) Select page: 2, address: 7D, and set data: 00.
6) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
7) Select page: 0, address: 01, and set data: 00.

1-5. MONOCHROME ELECTRONIC VIEWFINDER SYSTEM ADJUSTMENTS
(CCD-TRV15/ TRV15PK/ TRV15E/ TRV15EP/ TRV25/ TRV25PK/ TRV35/ TRV35E/ TRV65/ TRV65PK/ TRV85/ TRV215/ TRV615/ TRV815)

Note: NTSC model: CCD-TRV15/ TRV15PK/ TRV25/
TRV25PK/ TRV35/ TRV65/ TRV65PK/
TRV85/ TRV93/ TRV215/ TRV615/ TRV815
PAL model : CCD-TRV15E/ TRV15EP/ TRV35E

1-5-1. Horizontal Slant Check

Mode	Playback
Signal	Alighment tape : For checking operations (WR5-5NSP (NTSC)) (WR5-5CSP (PAL)) Monoscope section
Specified Value	± 1.5 °

Adjusting method:
1) Adjust RV904 (BRIGHT) (VF-99 board) so that the CRT can be seen easily and clearly.
2) Check that the difference between the horizontal line and the tilt of the black mask satisfies the specified value.



Specified value : The image should be within ± 1.5° of the horizontal line.

Fig. 5-1-16.



Fig. 5-1-17.

1-5-2. Centering Adjustment

Mode	Playback
Signal	Alighment tape : For checking operations (WR5-5NSP (NTSC)) (WR5-5CSP (PAL)) Monoscope section
Specified Value	± 4%

Adjusting method:
1) Use the centering adjustment ring and adjust so that the left, right, top, and bottom sides of the display are uniform. (Refer to Fig. 5-1-17.)

Note : As the centering position changes due to earth magnetism, rotate it 360° in the horizontal direction, and adjust with the center section of the modifying position.



Adjustment value : ± 4 %

Fig. 5-1-18.

1-5-3. Focus Adjustment

Mode	Playback
Signal	Alighment tape : For checking operations (WR5-5NSP (NTSC)) (WR5-5CSP (PAL)) Monoscope section

Adjusting method:
1) Adjust the focus ring to obtain the optimum focus. (Refer to Fig. 5-1-17.)

VF-99 BOARD (SIDE A)



1-5-4. Aberration Adjustment

Mode	VTR stop
Signal	Dot pattern
Specified Value	b1≦2 • a1 b2≦0 8 • a2

Adjusting method:

1) Adjust the aberration adjustment ring so that the tracing of the dot satisfies the specified value.
2) If the centering becomes displaced here, perform the centering adjustment from the beginning again



Fig. 5-1-19.

1-5-5. Horizontal Amplitude Adjustment (VF-99 board)

Mode	Playback
Signal	Alighment tape : For checking operations (WR5-5NSP (NTSC)) (WR5-5CSP (PAL)) Monoscope section
Adjusting Element	C909 (SOL901)
Specified Value	± 1 5 °

Adjusting method.

1) Rotate RV903, and adjust the top and bottom sides of the monoscope image to the top and bottom edges of the display
2) Rotate RV904 so that the brightness is the normal level.
3) Solder or unsolder SOL901 pattern of the H size adjustment capacitor (C909) to “short” or “open”, so that the horizontal direction over scan becomes 14 ± 6% (Left and right totals)



SOL901	Size H
Open	Small
Short	Big

VF-99 BOARD (SIDE A)



Fig. 5-1-20.

1-5-6. Vertical Amplitude Adjustment (VF-99 board)

Mode	Playback
Signal	Alighment tape : For checking operations (WR5-5NSP (NTSC)) (WR5-5CSP (PAL)) Monoscope section
Adjusting Element	RV903
Specified Value	10 ± 3%

Adjusting method:

1) Adjust RV903 so that the vertical direction over scan becomes 10 ± 3% (Top and bottom totals)



Fig. 5-1-21.

1-5-7. Brightness Adjustments (VF-99 board)

Mode	Playback
Signal	Alighment tape For checking operations (WR5-5NSP (NTSC)) (WR5-5CSP (PAL)) Monoscope section
Specified Value	RV904

Adjusting method

1) Rotate RV904, and adjust so that the bright/dark sections of the gray scale are displayed correctly (The bright section should be unsatisfactory till the cross hatch appears vague in the monoscope circle. The dark section should be unsatisfactory till the darkest section and the second darkest section of the gray scale cannot be differentiated.)

1-5-8. Horizontal Amplitude, Vertical Amplitude, Focus Check

"1-5-5 Horizontal Amplitude Adjustment" and "1-5-6. Vertical Amplitude Adjustment" should both satisfy the specified values If not, perform the adjustments from the beginning again In this case, perform "1-5-7 Brightness, Contrast Adjustments" again. Moreover, check the focus, and if it found to be vague, perform "1-5-3 Focus Adjustment" and "1-5-4 Aberration Adjustment".

VF-99 BOARD (SIDE A)



1-6. LCD SYSTEM ADJUSTMENT

Note1: The back light (fluorescent tube) is driven by a high voltage AC power supply Therefore, do not touch the back light holder to avoid electrical shock

Note2: When replacing the LCD unit, be careful to prevent damages caused by static electricity

Note3: Set the brightness to the center using the LCD BRIGHT button

Note4: 2.5"LCD model:
PD-92board, Ref No 5000 series
3"/3 5"LCD model
PD-93board, Ref No 4000 series

Note5: 2.5" LCD model ·
CCD-TRV15/ TRV15E/ TRV15EP/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV35E/ TRV65/ TRV65PK/ TRV215/ TRV615
3" LCD model · CCD-TRV93
3 5" LCD model CCD-TRV85/ TRV815

[Adjusting connector]

Most of the measuring points for adjusting the LCD display are concentrated in the following connector
CN5501 of the PD-92 board (2.5"LCD model)
CN4501 of the PD-93 board (3"/3 5"LCD model)
Connect the measuring instruments via the multi CPC jig (J-6082-311-A).
The following table shows the Pin No and signal name of the connector

Pin No	Signal name	Pin No	Signal name
1	VB	2	VCO VOLTAGE.
3	VG	4	PANEL COM
5	VR	6	N C
7	SYNC / HD	8	H START
9	GND	10	GND

[LCD type check]

By measuring the resistor value between Pin ⑥ of CN5501/4501 and Pin ⑩ of CN5501/4501, the type of LCD can be discriminated

PD-92board CN5501

Resistor value	LCD type	Model
5 6kΩ	2 5" TYPE S NTSC	CCD-TRV35/ TRV65 TRV65PK/ TRV615
8 2kΩ	2 5" TYPE S PAL	CCD-TRV35E
1 5kΩ	2 5" TYPE C NTSC	CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/TRV215
3 9kΩ	2 5" TYPE C PAL	CCD-TRV15E/ TRV15EP

PD-93board CN4501

Resistor value	LCD type	Model
4.7kΩ	3"/3.5" TYPE S NTSC	CCD-TRV93
1 0kΩ	3"/3.5" TYPE C NTSC	CCD-TRV85/ TRV815

1. LCD Initial Data Input

Mode	VTR stop
Signal	Arbitrary
Adjustment Page	E
Adjustment Address	A5 to A7, B0 to B9, BF, C0, C1, CF, D0 to DD

Adjusting method·
1) Select page 0, address 01, and set data 01
2) Select page D, and input the data in the following table

Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data

3) Select page 0, address· 01, and set data 00

Address	Data	Remark
A5	53	Fixed value
A6	96	Fixed value
A7	68	Fixed value
B0	3F	Fixed value
B1	C8	Fixed value
B2	1F	Fixed value
B3	1F	Fixed value
B4	00	Fixed value
B5	00	Fixed value
B6	Note1	Fixed value
B7	4E	Fixed value
B8	08	Fixed value
B9	00	Fixed value
BF	80	[VCO adjustment] <Fixed value>
C0	Note2	Fixed value
C1	Note3	Fixed value
CF	69/84	Bright adjustment (Note 5)
D0	7A/77	Color adjustment (Note 5)
D1	AA/98	White balance adjustment (Note 5)
D2	9C/7B	White balance adjustment (Note 5)
D3	B1/DC	Contrast adjustment (Note 5)
D4	B1/80	D range adjustment (Note 5)
D5	94/89	V-COM level adjustment (Note 5)
D6	80	VCO adjustment
D7	80	V-COM level adjustment
D8	80	Fixed value
D9	Note4	[Color adjustment] <Fixed value>
DA	80	Fixed value
DB	52	Fixed value
DC	99	Fixed value
DD	99	Fixed value

< > NTSC model only
[ ] PAL model only

Note1: B0 NTSC model
F0· PAL model

Note2: A4 2 5" LCD model
8B 3" LCD model
8D 3 5" LCD model

Note3: D8 2 5" LCD TYPE S model
CF 2 5" LCD TYPE C model
B8 3" LCD model
A9 3 5" LCD model

Note4: 00 NTSC model
7A LCD TYPE S PAL model
77 LCD TYPE C PAL model

Note5: LCD TYPE S/LCD TYPE C

4. Bright Adjustment (PD-92/93 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish)

Mode	VTR stop
Signal	No signal
Measurement point	Pin ③ of CN5501/4501 (VG) of PD-92/93 board External trigger Pin ④ of CN5501/ CN4501 (PANEL COM)
Measuring instrument	Oscilloscope
Adjustment page	E
Adjustment address	CF
Specified value	A = 1.94 ± 0.05V (LCD TYPE S model) A = 1.34 ± 0.05V (LCD TYPE C model)

Note1 : LCD TYPE S model CCD-TRV35/ TRV35E/ TRV65/ TRV65PK/ TRV93/ TRV615
LCD TYPE C model CCD-TRV15/ TRV15PK/ TRV15E/ TRV15EP/ TRV25/ TRV25PK/ TRV85/ TRV215/ TRV815

Adjusting method

1) Select page: 0, address 01, and set data 01
2) Select page: 3, address 01, set data 55, and press the PAUSE button of the adjusting remote commander
3) Select page 2, address 7D, and set data 40
4) Select page E, address CF, change the data and set the voltage (A) between the pedestal and white to the specified value (The data of address CF should be "41" to "BF".)
5) Press the PAUSE button of the adjusting remote commander.
6) Select page· 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander
7) Select page 2, address· 7D, and set data. 00
8) Select page. 0, address 01, and set data 00.



Fig. 5-1-24.

5. Contrast Adjustment (PD-92/93 board)

Set the level of the VIDEO signal for driving the LCD to the specified value. If deviated, the screen image will be blackish or saturated (whitish).

Mode	VTR stop
Signal	No signal
Measurement point	Pin ③ of CN5501/4501 (VG) of PD-92/93 board External trigger · Pin ④ of CN5501/ CN4501 (PANEL COM)
Measuring instrument	Oscilloscope
Adjustment page	E
Adjustment address	D3
Specified value	A = 3.52 ± 0.07V (LCD TYPE S model) A = 2.54 ± 0.07V (LCD TYPE C model)

Note1 : LCD TYPE S model . CCD-TRV35/ TRV35E/ TRV65/ TRV65PK/ TRV93/ TRV615
LCD TYPE C model · CCD-TRV15/ TRV15PK/ TRV15E/ TRV15EP/ TRV25/ TRV25PK/ TRV85/ TRV215/ TRV815

Adjusting method

1) Select page 0, address 01, and set data: 01
2) Select page 3, address· 01, set data: 55, and press the PAUSE button of the adjusting remote commander
3) Select page 2, address 7D, and set data 00
4) Select page· E, address· D3, change the data and set the voltage (A) between the pedestal (0 IRE) and 100 IRE to the specified value
5) Press the PAUSE button of the adjusting remote commander
6) Select page: 3, address 01, set data 00, and press the PAUSE button of the adjusting remote commander.
7) Select page. 0, address 01, and set data 00



Fig. 5-1-25.

6. V-COM Level Adjustment (PD-92/93 board)

Set the common electrode drive signal level of LCD to the specified value.

Mode	VTR stop
Signal	No signal
Measurement point	Pin ④ of CN5501/CN4501 (PANEL COM) of PD-92/93 board
Measuring instrument	Oscilloscope
Adjustment page	E
Adjustment address	D5
Specified value	A = 6.50 ± 0.05V (LCD TYPE S NTSC model) A = 6.43 ± 0.05V (LCD TYPE S PAL model) A = 5.10 ± 0.05V (LCD TYPE C model)

Note1 : Perform “Bright Adjustment” and “Contrast Adjustment” before this adjustment.

Note2 : LCD TYPE S model : CCD-TRV35/ TRV35E/ TRV65/ TRV65PK/ TRV93/ TRV615
LCD TYPE C model : CCD-TRV15/ TRV15PK/ TRV15E/ TRV15EP/ TRV25/ TRV25PK/ TRV85/ TRV215/ TRV815

Adjusting method.

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 55, and press the PAUSE button of the adjusting remote commander.
3) Select page: 2, address: 7D, and set data: 00.
4) Select page: E, address: D5, change the data and set the PANEL COM signal level (A) to the specified value.
5) Press the PAUSE button of the adjusting remote commander.
6) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
7) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-26.

7. Color Adjustment (PD-92/93 board)

Set the color saturation to the standard value. If deviated, the color will be to dark or light.

Mode	VTR stop
Signal	No signal
Measurement point	Pin ③ of CN5501/4501 (VG) of PD-92/93 board External trigger : Pin ④ of CN5501/ CN4501 (PANEL COM)
Measuring instrument	Oscilloscope
Adjustment page	E
Adjustment address	D0 (NTSC) D0, D9 (PAL)
Specified value	2.5" LCD TYPE S model A = 0.05 ± 0.05V (NTSC) A = 0.13 ± 0.05V (PAL) 2.5" LCD TYPE C model A = 0.00 ± 0.05V (NTSC) A = 0.05 ± 0.05V (PAL) 3" LCD TYPE S model : A = 0.05 ± 0.05V (NTSC) 3.5" LCD TYPE C model : A = 0.07 ± 0.05V (NTSC)

Note1: 2.5" LCD TYPE S NTSC model
CCD-TRV35/ TRV65/ TRV65PK/ TRV615
2.5" LCD TYPE S PAL model : CCD-TRV35E
2.5" LCD TYPE C NTSC model
CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV215
2.5" LCD TYPE C PAL model : CCD-TRV15E/ TRV15EP
3" LCD TYPE S model : CCD-TRV93
3.5" LCD TYPE C model : CCD-TRV85/ TRV815

Adjusting method.

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 57, and press the PAUSE button of the adjusting remote commander.
3) Select page: 2, address: 7D, and set data: 20.
4) Select page: E, address: D0, change the data and set the voltage (A) between the green and white to the specified value.
5) Press the PAUSE button of the adjusting remote commander.
6) Only for PAL model, select page: E, address: D9, and set the same data as page: E, address: D0, and press the PAUSE button of the adjusting remote commander.
7) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
8) Select page: 2, address: 7D, and set data: 00.
9) Select page: 0, address: 01, and set data: 00.



Fig. 5-1-27.

8. V-COM Adjustment (PD-92/93 board)

Set the DC bias of the common electrode drive signal of LCD to the specified value.
If deviated, the LCD display will move, producing flicker and conspicuous vertical lines

Mode	VTR stop
Signal	No signal
Measurement point	Check on LCD display
Measuring instrument	
Adjustment page	E
Adjustment address	D7
Specified value	The brightness difference between the section Ⓐ and section Ⓑ is minimum.

Note1 : Perform "Bright Adjustment" and "Contrast Adjustment" before this adjustment.

Adjusting method
1) Select page 0, address: 01, and set data: 01.
2) Select page: 3, address. 01, set data: 51, and press the PAUSE button of the adjusting remote commander.
3) Select page: 2, address: 7D, and set data 87
4) Select page E, address D7, change the data so that the brightness of the section A and that of the section B is equal.
5) Press the PAUSE button of the adjusting remote commander
6) Select page: 3, address: 01, set data 00, and press the PAUSE button of the adjusting remote commander
7) Select page 2, address: 7D, and set data: 00.
8) Select page 0, address 01, and set data. 00



Fig. 5-1-28.

9. White Balance Adjustment (PD-92/93 board)

Correct the white balance
If deviated, the LCD screen color cannot be reproduced

Mode	VTR stop
Signal	No signal
Measurement point	Check on LCD display
Measuring instrument	
Adjustment page	E
Adjustment address	D1, D2
Specified value	The LCD screen should not be colored

Note1: Check the white balance only when replacing the following parts. If necessary, adjust them
1 LCD panel
2 Light induction plate
3 IC5502/4502

Note2 : LCD TYPE S model CCD-TRV35/ TRV35E/ TRV65/ TRV65PK/ TRV93/ TRV615
LCD TYPE C model CCD-TRV15/ TRV15E/ TRV15EP/ TRV15PK/ TRV25/ TRV25PK/ TRV85/ TRV215/ TRV815

Adjusting method:
1) Select page 0, address: 01, and set data 01.
2) Select page: 3, address 01, set data 51, and press the PAUSE button of the adjusting remote commander
3) Select page 2, address 7D, and set data: 03
4) Select page. E, address: D1 and D2, and set the data to the initial value

Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data.

Address	Data			
	LCD TYPE S		LCD TYPE C	
	NTSC	PAL	NTSC	PAL
D1	98	94	99	97
D2	88	81	89	8D

5) Check that the LCD screen is not colored If colored, change the data of page: E, address D1 and D2 so that the LCD screen is not colored

Note: To write in the non-volatile memory (EEPROM), press the PAUSE button of the adjusting remote commander each time to set the data.

6) Select page. 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander
7) Select page 2, address: 7D, and set data 00.
8) Select page. 0, address: 01, and set data: 00

5-2. MECHANICAL SECTION ADJUSTMENT

Mechanism Parts Adjustments

For details on the adjustments and checks of mechanical section and replacements of mechanism parts, refer to the separate volume-"8 mm Video Mechanism Adjustment Manual VII [B Mechanism] ".

2-1. OPERATING WITHOUT A CASSETTE

1) Refer to "Section 2 DISASSEMBLY" and supply the power with the cabinet removed (So that the mechanical deck can be operated)
2) Connect the adjusting remote commander to the LANC terminal
3) Turn on the HOLD switch of the adjusting remote commander.
4) Close the cassette compartment without loading a cassette and complete loading
5) Select page 0, address 01, and set data 01
6) Select page: F, address 2A, and set data 01, and press the PAUSE button of the adjusting remote commander
7) Select page D, address 10, and set data 10, and press the PAUSE button of the adjusting remote commander
8) Disconnect the power supply of the unit
   By carrying out the above procedure, the unit can be operated without loading a cassette
   Be sure to carry out "Processing after Operations" after checking the operations
   Set the data of page D, address 10 to the following if the sensor ineffective mode, forced PLAYER (VTR) power supply ON mode or forced camera power supply ON mode are to be used together
      Forced VTR power supply ON mode . 12
      Forced camera power supply ON mode ... 11

[Processing after Operations]

1) Select page 0, address 01, and set data 01
2) Select page: F, address 2A, and set data 00, and press the PAUSE button of the adjusting remote commander
3) Select page D, address: 10, and set data 00, and press the PAUSE button of the adjusting remote commander
4) Select page: 0, address 01, and set data 00
5) Disconnect the power supply of the unit

2-2. TAPE PATH ADJUSTMENT

1. Preparations for adjustments

1) Clean the tape path face (tape guide, drum, capstan shaft, pinch roller)
2) Connect the adjusting remote commander to the LANC terminal
3) Turn on the HOLD switch of the adjusting remote commander
4) Select page 0, address 01, and set data 01
5) Select page F, address 2A, and set data 04 and press the PAUSE button of the adjusting remote commander
   (Be sure to perform "Processing after operations" after completing adjustments)
6) Connect the oscilloscope
   Channel 1: Pin ⑥ of CN910 of VC-195 board
   External trigger: Pin ⑪ of CN910 of VC-195 board
   (Connect the oscilloscope via the CPC-7 jig (J-6082-382-A))
7) Playback the alignment tape for tracking
   WR5-1NP For NTSC model: CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV65/ TRV65PK/ TRV85/ TRV93/ TRV215/ TRV615/ TRV815
   WR5-1CP: For PAL model CCD-TRV15E/ TRV15EP/ TRV35E
8) Check that the RF waveform of the oscilloscope is flat at both the entrance and the exit
   If not flat, perform necessary adjustment according to the separate "8 mm Video Mechanical Adjustment Manual VII (B Mechanism)".
9) Perform "Processing after operations", after completing adjustments

Pin No.	Signal Name	Pin No	Signal Name
1	LANC SIG	9	RF AGC OUT
2	XCPC IN	10	REC RF
3	IR VIDEO	11	RF SWP
4	AFC F0	12	CAP FG
5	BPF MONI	13	EVF BL
6	PB RF	14	EVF BL 4.75V
7	RF AGC IN	15	VCO
8	REG GND	16	EVF VG

CN910 of VC-195 board

[Processing after operations]

1) Connect the adjusting remote commander, and turn on the HOLD switch
2) Select page: 0, address 01, and set data 01
3) Select page F, address 2A, and set data 00
4) Press the PAUSE buttonA of the adjusting remote commander
5) Select page 0, address 01, and set data 00
6) Remove the power supply from the unit.



Fig. 5-2-1.

5-3. VIDEO SECTION ADJUSTMENTS

When performing adjustments, refer to the layout diagrams for adjustment related parts beginning from page 5-62.

3-1. PREPARATIONS BEFORE ADJUSTMENT

The following adjusting instruments are used for adjusting the video section.

3-1-1. Equipments to be Used

1) TV monitor
2) Oscilloscope: 2 phenomena, band 30 MHz or wider, with delay mode. (Use a 10:1 probe unless specified otherwise.)
3) Frequency counter
4) Pattern generator with video output terminal
5) Digital voltmeter
6) Audio generator
7) Audio level meter
8) Audio distortion meter
9) Audio attenuater
10) Regulated power supply
11) Alignment tape

    [For NTSC model]
    - For tracking adjustment (WR5-1NP)
      Part Code: 8-967-995-02
    - For video frequency characteristics adjustment
      (WR5-7NE) Part Code: 8-967-995-13
    - For checking Standard 8 mode operations
      For LP (WR5-4NL)
      Part Code: 8-967-995-51
      For SP (WR5-5NSP)
      Part Code: 8-967-995-42

      Note: The following alignment tapes can also be used.
      WR5-4NSP (8-967-995-41)
    - For checking Hi8 mode operations
      For SP (WR5-8NSE)
      Part Code: 8-967-995-43
      For LP (WR5-8NLE)
      Part Code: 8-967-995-52
    - For checking AFM stereo operations (WR5-9NS)
      Part Code: 8-967-995-23
      For checking BPF adjustment (WR5-11NS)
      Part Code: 8-967-995-71

    [For PAL model]
    - For tracking adjustment (WR5-1CP)
      Part Code: 8-967-995-07
    - For video frequency characteristics adjustment
      (WR5-7NE) Part Code: 8-967-995-18
    - For checking Standard 8 mode operations
      For LP (WR5-4CL)
      Part Code: 8-967-995-56
      For SP (WR5-5CSP)
      Part Code: 8-967-995-47

      Note: The following alignment tapes can also be used.
      1) WR5-3CL (8-967-995-36)
      2) WR5-4CSP (8-967-995-46)
    - For checking AFM stereo operations (WR5-9CS)
      Part Code: 8-967-995-28
      For checking BPF adjustment (WR5-11CS)
      Part Code: 8-967-995-76
12) Remote commander for adjustment (J-6082-053-B)
13) CPC-7 jig Part Code: J-6082-382-A

    Note : Connect the adjusting remote commander to the LANC jack, and set the HOLD switch to the "ADJ" side.
14) Power code Part Code: J-6082-223-A
15) AFM DEV jig (J-6082-312-A)
16) IR Receiving jig (J-6082-383-A)
17) Extension cable (48P, 0.8mm) (J-6082-188-A)

3-1-2. Precautions on Adjusting

1) The adjustments of this unit are performed in the VTR mode or camera mode
   To set to the VTR mode, set the power switch to "VTR" (or "PLAYER") or set the "Forced VTR Power ON mode" using the adjusting remote commander (Note 1).
   To set to the Camera mode, set the power switch to "CAMERA" or set the "Forced Camera Power ON mode" using the adjusting remote commander (Note 2)
   After completing adjustments, be sure to exit the "Forced VTR Power ON Mode" or "Forced Camera Power ON Mode" (Note 3)
2) By setting the "Forced VTR Power ON mode" or "Forced Camera Power ON mode", the video section can be operate even if even if the front panel block (MA-311/312/331 board, power switch, microphone unit) has been removed When removing the front panel block disconnect the following connector
   1. VC-195 board CN903 (23P 0.5mm)
3) The lens block (CD-197/198 board) need not be connected except during battery end adjustment To remove, disconnect the following connectors
   1 VC-195 board CN501 (16P, 0.5mm)
   2 VC-195 board CN551 (23P, 0 5mm)
4) The intelligent accessory shoe (Intelligent accessory shoe model) or video light (Video light model) need not be assembled If removing it disconnect the following connector.
   1 VC-195 board CN909 (10P, 0.5mm)
5) Cabinet (R) (Camera function switch (CF-50/51board), LCD block, viewfinder) need not be connected But removing the cabinet (R) (removing the VC-195 board CN911) means removing the lithium 3V power supply (CF-50/51 board) , data such as date, time, user-set menus will be lost. After completing adjustments, reset these data If the cabinet (R) has been removed, the self-diagnosis data, data on history of use (total drum rotation time etc.) will be lost. Before removing, note down the self-diagnosis data and data on the history use (Refer to the "Service Mode" for the data on the history use) To remove the cabinet (R), disconnect the following connectors
   1. VC-195 board CN911 (50P, 0 5mm)
   2 DD-105 board CN933 (11P, 1.0mm)

Note 1: Setting the "Forced VTR Power ON" mode
(VTR mode)
1) Select page 0, address 01, and set data· 01.
2) Select page D, address· 10, set data 02, and press the PAUSE button of the adjusting remote commander

The above procedure will enable the VTR power to be turned on with the front panel block removed
After completing adjustments, be sure to exit the "Forced VTR Power ON mode"

Note 2: Setting the "Forced Camera Power ON" mode
(Camera mode)
1) Select page 0, address 01, and set data. 01
2) Select page D, address 10, set data· 01, and press the PAUSE button of the adjusting remote commander.
   The above procedure will enable the camera power to be turned on with the front panel block removed
   After completing adjustments, be sure to exit the "Forced Camera Power ON mode"

Note 3: Exiting the "Forced Power ON" mode
1) Select page 0, address· 01, and set data 01
2) Select page D, address: 10, set data. 00, and press the PAUSE button of the adjusting remote commander
3) Select page 0, address: 01, and set data· 00

3-1-3. Adjusting Connectors

Some of the adjusting points of the video section are concentrated at VC-195 board CN910 Connect the measuring instruments via the CPC-7 jig (J-6082-382-A) The following table lists the pin numbers and signal names of CN910

Pin No	Signal Name	Pin No	Signal Name
1	LANC SIG	9	RF AGC OUT
2	XCPC IN	10	REC RF
3	IR VIDEO	11	RF SWP
4	AFC F0	12	CAP FG
5	BPF MONI	13	EVF BL
6	PB RF	14	EVF BL 4.75V
7	RF AGC IN	15	VCO
8	REG GND	16	EVF VG

Table 5-3-1.



Fig. 5-3-1.

3-1-4. Connecting the Equipments

Connect the measuring instruments as shown in Fig 5-3-2 and perform the adjustments


Connecting the TV Monitor and Regulated Power Supply
Battery terminal
Regulated power supply
8 4±0 1Vdc
Main Unit
TV monitor
VIDEO
Connect when using the camera mode or playing back
VIDEO terminal

Fig. 5-3-2.

3-1-5. Alignment Tape

The following table lists alignment tapes which are available
Use the tape specified in the signal column for each adjustment
If the type of tape to be used for checking operations is not specified, use whichever type

Name	Record -ing mode	Tape type	Tape speed	Usage
Tracking WR5-1NP (NTSC) WR5-1CP (PAL)	Standard 8 mm	MP	SP	Tape path adjustment Switching position adjustment
Video frequency characteristics WR5-7NE (NTSC) WR5-7CE (PAL)	Hi8	ME	SP (NTSC) LP (PAL)	Frequency characteristics adjustment
Operation check (SP mode) WR5-5NSP (NTSC) WR5-5CSP (PAL)	Standard 8 mm	MP	SP	Checking operations
Operation check (SP mode) WR5-8NSE (NTSC) WR5-8CSE (PAL)	Hi8	ME	SP	
Operation check (LP mode) WR5-4NL (NTSC) WR5-4CL (PAL)	Standard 8 mm	MP	LP	
Operation check (LP mode) WR5-8NLE (NTSC) WR5-8CLE (PAL)	Hi8	ME	LP	
AFM stereo Operation check WR5-9NS (NTSC) WR5-9CS (PAL)	Standard 8 mm	MP	SP	AFM stereo Checking operations
BPF adjustment WR5-11NS (NTSC) WR5-11CS (PAL)	Standard 8 mm	MP	SP	BPF adjustment

Tape type
MP .. Particle type metal tape
ME . . Evaporated type metal tape

Table 5-3-2.

Fig. 5-3-3. shows the 75% color bar signals recorded on the alignment tape.

Note: Measure using the VIDEO terminal (Terminated at 75 Ω).


For NTSC model
White (100%)
White (75%)
Yellow
Cyan
Green
Magenta
Red
Blue
Burst signal
0.714V
1V
0.286V
0.286V
Q
I
Horizontal sync signal
Color bar signal wavefom
White
Yellow
Cyan
Green
Magenta
Red
Blue
(75%)
Q
White 100%
I
Black
Color bar Pattem
For PAL model
White (100%)
Yellow
Cyan
Green
Magenta
Red
Blue
0.7V
1V
0.3V
0.3V
Burst signal
Horizontal sync signal
Color bar signal wavefom
White
Yellow
Cyan
Green
Magenta
Red
Blue
Black
(100%)
Color bar Pattem

Fig. 5-3-3. Color Bar Signals of the Alignment Tape

3-1-6. Input/Output Level and Impedance

Video input/output
Phono jack, 1 Vp-p, 75Ω,
unbalanced, sync negative
S video input/output (Hi8 model)
4-pin mini DIN
Luminance signal.
1Vp-p, 75Ω, unbalanced, sync negative
Chrominance signal
0.286Vp-p 75Ω, unbalanced (NTSC)
0 3Vp-p 75Ω, unbalanced (PAL)
Audio input/output
Phono jack,
Input –7 5 dBs, input impedance more than 47 kΩ
Output –7 5 dBs, (at load impedance 47 kΩ), impedance less than 2 2 kΩ

3-1-7. Recording Mode (Standard 8/Hi8) switching (Hi8 model)

The record mode (Standard 8/Hi8) of this unit switches as shown in the following table The playback mode (Standard 8/Hi8) switches automaticaly according to the recording mode of the tape played back.

Tape Used	Recording Mode
ME	Hi8
Hi8 MP	
MP	Standard 8

3-1-8. Service Mode

Additional note on adjustment

Note: After the completion of the all adjustments, cancell the service mode by either of the following ways.

1) Unplug the main power supply and remove the lithium battery (In this case, date and time and menu setting have been set by users are canceled Perform resetting.)
2) After data on page D and F is restored, select page: 0, address 01, and return the data to 00 And when data on page· 3 is changed, return the data to the original condition

1. Test mode setting

Set/release each test mode Select page 0, address· 01, and set data. 01 before setting the data of page D and F.

Page F	Address 2A

Data	Function
00	Normal
01	Test mode Various emergency prohibitions and releases Drum emergency, capstan emergency, loading motor emergency, reel emergency, tape top and end, DEW detection

Page D	Address 10

Data	Function
00	Normal
01	Camera power ON
02	VTR power ON
03	Camera+VTR power ON

* For page D and F, the data set will be recorded in the nonvolatile memory by pressing the PAUSE button on the adjusting remote commander. Take note that, in this case, the test mode will not be released even if the main power has been turned off (8.4 Vdc)

* Be sure to return this address data to 00 after completing adjustments/repairs and press the PAUSE button of the adjusting remote commander. And select page· 0, address 01, and set data. 00.

2. Emergency Memory Address

Page F	Address 10 to 1B

Address	Contents
10	1st EMG code
12	Upper MSW code when the mechanism starts shifting the 1st time Lower MSW code when the 1st emergency occurs
13	Lower Target MSW code of the 1st emergency occurs
14	2nd EMG code
16	Upper. MSW code when the mechanism starts shifting the 2nd time Lower. MSW code when the 2nd emergency occurs
17	Lower. Target MSW code of the 2nd emergency occurs
18	Last EMG code
1A	Upper MSW code when the mechanism starts shifting the last time Lower MSW code when the last emergency occurs
1B	Lower Target MSW code of the last emergency occurs

When there are no emergency, data 00 will be written in the above addresses (10 to 1B). When the first emergency occurs, the data corresponding to the emergency will be written in the address (10 to 13) for this first emergency. In the same way, when the second emergency occurs, the data corresponding to the emergency will be written in the address (14 to 17) for this second emergency.
The data corresponding to the emergency occurring the last will be written in the address (18 to 1B) for this last emergency
Therefore the data of addresses 18 to 1B are renewed each time an emergency occurs.

Note 1: Be sure to rewrite the data of addresses 10 to 1B to 00 after repairs/adjustments

Note 2: When rewriting the data, be sure to press the PAUSE buttton of the remote commander after setting the data.

2-1. EMG CODE (Emergency Code)

The codes shown in the following table which correspond to errors that occur are recorded in addresses 10, 14, and 18

Code	Type of Emergency
00	No error
10	Loading motor time-out during load
11	Loading motor time-out during unload
20	T reel emergency (reel slack) during unloading
21	S reel emergency (reel slack) during unloading
22	T reel emergency
23	S reel emergency
30	FG emergency at the start up of the capstan
31	FG emergency during the normal rotation of the capstan
40	FG emergency at the start up of the drum
41	PG emergency at the start up of the drum
42	FG emergency during the normal rotation of the drum
43	PG emergency during the normal rotation of the drum
44	Phase emergency during the normal rotation of the drum

2-2. MSW Codes

- The lower parts of the data of addresses 12, 16 and 1A represent the MSW codes (mode switch, mechanism position) when errors occurs.
- The upper parts of the data of addresses 12, 16 and 1A represent, when the mechanism position is to be moved, the MSW codes at the start of movement (when moving the loading motor)
- The lower parts of the data of addresses 13, 17 and 1B represent the MSW codes of the desired movement when the mechanism position is to be moved.


← Unloading
Loading →
Mechanism Position
EJECT
BL
USE
BL
LOAD
BL
STOP
BL
TURN
BL
REC/PB
BL
REW
MSB
MODE SW C
MODE SW B
MODE SW A
0001 = 1
0111 = 7
0011 = 3
0111 = 7
0010 = 2
0111 = 7
0110 = 6
0111 = 7
0100 = 4
0111 = 7
0000 = 0
0111 = 7
0101 = 5
LS Chassis Movement Range
Release of Pinch Roller
Pinch Roller Pressing
Release of Cassette Compartment Lock

Mechanism Position	MSW Code	Contents
EJECT	1	Position at which the cassette compartment lock is released The mechanism will not move any further in the unloading direction
BL	7	BLANC code Between two codes The mechanism will not be stopped by this code while it is operating.
USE	3	EJECT completion position When the cassette is ejected, the mechanism will stop at this position.
LOAD	2	Code during loading/unloading Code that is used while the LS chassis is moving
STOP	6	Normal stop position. The pinch roller separates, the tension regulator returns, and the brakes of both reels turn on.
TURN	4	Position at which is used when the pendulum gear swings from S to T or from T to S.
RECP/PB	0	PB, REC, CUE, REV, PAUSE, FF positions The pinch roller is pressed and tension regulator is on
REW	5	REW position REW are carried at this position The mechanism will not move any further in the loading direction

3. Bit value discrimination

Bit values must be discriminated using the display data of the adjusting remote commander for the following items Use the table below to discriminate if the bit value is "1" or "0".


Adjusting remote commander display
0:00:00
Page
Address
Determine the values of bit 3 tobit 0
Determine the values of bit 7 tobit 4

	Remote controller display	Bit value			
		bit 3 or bit 7	bit 2 or bit 6	bit 1 or bit 5	bit 0 or bit 4
	0	0	0	0	0
	1	0	0	0	1
	2	0	0	1	0
	3	0	0	1	1
	4	0	1	0	0
	5	0	1	0	1
	6	0	1	1	0
	7	0	1	1	1
Ⓐ→	8	1	0	0	0
	9	1	0	0	1
	A (A)	1	0	1	0
	B (b)	1	0	1	1
	C (c)	1	1	0	0
	D (d)	1	1	0	1
Ⓑ→	E (E)	1	1	1	0
	F (F)	1	1	1	1

(Example) If the remote commander display data is "8E", bit values from bit7 to bit4 can be discriminated from column Ⓐ, and those from bit3 to bit0 from column Ⓑ

4. Switch check (1)

Page 3	Address 43

Bit	Function	When bit value=1	When bit value=0
0	VTR MODE SW	OFF	ON
1	CAM MODE SW	OFF	ON
2	START/STOP SW	OFF	ON
3	EJECT SW	OFF	ON
4	CC DOWN SW	OFF	ON
5			
6			
7			

Using method

1) Select page 3, address 43
2) By discriminating the bit value of display data, the state of the switches can be discriminated.

5. Switch check (2)

Page 3	Address 60 to 66

Using method
1) Select page: 3, address 60 to66
2) By discriminating the display data, the pressed key can be discriminated

Address	Data							
	00 to 0D	0E to 29	2A to 46	47 to 68	69 to 90	91 to BE	BF to EA	EB to FF
60 (AD0 IC604 (93))	LASER LINK (FK-8500 S008)	STOP (FK-8500 S001)	FF (FK-8500 S003)	REC (FK-8500 S005, 007)	EDIT SEARCH (+) (FK8500 S009)	EDIT SEARCH (–) (FK8500 S010)		No key input
61 (AD1 IC604 (94))		PAUSE (FK-8500 S002)	REW (FK-8500 S004)	PLAY (FK-8500 S006)				No key input
62 (AD2 IC604 (95))		PICTURE EFFECT (CF-50/51 S006)	MENU (CF-50/51 S010)	EXECUTE (CF-50/51 S015)	TIME (CF-50/51 S021)	5sec REC (CF-50/51 S024)	PUSHING REC (CF-50/51 S024)	NORMAL REC (CF-50/51 S024)
64 (AD4 IC604 (97))			EXPOSURE (CF-50/51 S012)	BACK LIGHT (CF-50/51 S017)	FADER (CF-51 S027 or MF-8500 S002)	FOCUS INFINITY (MF/MR-8500 S001)	FOCUS AUTO (MF/MR-8500 S001)	FOCUS MANUAL (MF/MR-8500 S001)
65 (AD5 IC604 (98))	DATE (CF-50/51 S003)	COUNTER RESET (CF-50/51 S008)	END SEARCH (CF-50/51 S013)	TITLE (CF-50/51 S018)	DISPLAY (CF-50/51 S022)			No key input
66 (AD6 IC604 (99))	PROGRAM AE (CF-50/51 S004)	BRIGHT(+) (PD-92 S5801 PD-93 S4801)	BRIGHT(–) (PD-92 S5802 PD-93 S4802)	VOLUME(+) (PD-92 S5803 PD-93 S4803)	VOLUME(–) (PD-92 S5804 PD-93 S4804)	PANEL REVERSE (FP-642)	PANEL CLOSE (FP-642)	PANEL NORMAL (FP-642)

6. Headphone jack check

Page 3	Address 45

Bit	Function	When bit value=1	When bit value=0
1	Headphone jack	Headphone jack is used	

Using method
1) Select page. 3, address 45
2) By discriminating the bit value of display data, the state of the headphone jack can be discriminated.

7. Input/output selection check

Page 3	Address 49

Bit	Function	When bit value=1	When bit value=0
1			
2			
3			
4	MIC jack	MIC jack is used	
5	AUDIO terminal	Monaural	Stereo
6	VIDEO terminal	VIDEO terminal is used	
7	S VIDEO terminal		S VIDEO terminal is used

Using method.
1) Select page 3, address: 49
2) By discriminating the bit value of display data, the state of the input/output selection can be discriminated

8. LED, LCD (display window) check

Page 3	Address 05	Bit5

Using method:

1) Select page 3, address: 05, and set the bit value of Bit5 to "1"
2) Check that all LED are lit and all segments of LCD (display window) are lit.
3) Select page: 3, address 05, and set the bit value of Bit5 to "0"

9. Record of Use Check

Page 3	Address A2 to AA

Address	Function		Remarks
A2	Drum rotation counted time (BCD code)	Hour (H)	1000th place digit and 100th place digit of counted time (decimal digit)
A3		Hour (L)	10th place digit and 1st place digit of counted time (decimal digit)
A4		Minute	
A5	User initial power on date (BCD code)	Year	After setting the clock, set the date of power on next
A6		Month	
A7		Day	
A8	Final condensation occurrence date (BCD code)	Year	
A9		Month	
AA		Day	

Using method

1) The record of use data is displayed at page 3, addresses A2 to AA.

Note: This data will be erased when the coin lithium battery is removed (reset)

3-2. SYSTEM CONTROL SYSTEM ADJUSTMENT

1. Initialization of D, E, F Page Data

If the D, E, F page data is erased due to some reason, perform "1-2. INITIALIZATION OF D, E, F PAGE DATA", of "5-1. CAMERA SECTION ADJUSTMENT".

2. Battery End Adjustment (VC-195 board)

Set the battery end voltage.
If the voltage is incorrect, the life of the battery will shorten.
The image at the battery end will also be rough.

Mode	Camera recording
Subject	Arbitrary
Measurement Point	LCD display of the adjusting remote commander
Measuring Instrument	
Adjustment Page	D
Specified value	30 to 34

Note 1: The lens block and cabinet (R) must be connected.

Switch setting
1) AUTO FOCUS .... OFF
2) LCD screen .... Closed
3) NIGHT SHOT .... OFF
   (NIGHT SHOT model)
4) VIDEO LIGHT .... OFF
   (VIDEO LIGHT model)

Connection:
1) Connect the regulated power supply and the digital voltmeter to the battery terminal as shown in Fig. 5-3-4.

Adjusting method:
1) Adjust the output voltage of the regulated power supply so that the digital voltmeter display is 6.1±0.1Vdc.
2) Turn off the power supply.
3) Turn on the HOLD switch of the adjusting remote commander.
4) Turn on the power supply.
5) Load a cassette, and set to the camera recording mode.
6) Select page: 0, address: 01, and set data: 01.
7) Decrease the output voltage of the regulated power supply so that the digital voltmeter display is 5.30±0.01Vdc.
8) Select page: 3, address: 5D, read the data, and this data is named Dref.
9) Select page: D, address: 30, set data: Dref, and then press the PAUSE button of the adjusting remote commander.
10) Convert Dref to decimal notation, and obtain Dref '. (Refer to Table 5-1-2. "Hexadecimal-decimal conversion table")
11) Calculate D_{31}', D_{32}', D_{33}' and D_{34}' using following equations (decimal calculation), convert it to a hexadecimal number, and input each adjustment address.

Address: D_{31}	$D_{31}' = Dref' + 5$
Address: D_{32}	$D_{32}' = Dref' + 32$
Address: D_{33}	$D_{33}' = Dref' + 53$
Address: D_{34}	$D_{34}' = Dref' + 64$

Note 3: After setting each data, be sure to press the PAUSE button.

12) Select page: 0, address: 01, and set data: 00.



Fig. 5-3-4.

3-3. SERVO SYSTEM ADJUSTMENTS

1. CAP FG Offset Adjustment (VC-195 board)

Improve the capstan servo characteristic. If it is not correct. jitters will increase.

Mode	Camera recording (SP mode)
Subject	Arbitrary
Measurement Point	Pin ⑫ of CN910 (CAP FG)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	69
Specified value	Duty = 50±1%

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 2, address: 01, and set data: 81, and press the PAUSE button of the adjustment remote commander. (to start up automatic CAP FG offset adjustment.)
3) Select page: 2, address: 02, and check that the data is "01".
4) Check that Duty of CAP FG signal satisfies the specified value. If not, select page: 2, address: 01, set data: 00, and press the PAUSE button, and then, repeat steps 2) to 4).
5) Select page: 2, address: 01, and set data: 00, and press the PAUSE button of the adjustment remote commander.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-3-5.

2. Switching Position Adjustment (VC-195 Board)

If deviated in this cases switching noise or jitter on the played back screen.

Mode	Playback
Signal	Alignment tape: For tracking adjustment (WR5-1NP (NTSC)) (WR5-1CP (PAL))
Measurement Point	CH1: Pin ⑪ of CN910 (RF SWP) CH2: Pin ⑥ of CN910 (PB RF)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	7C, 7D
Specified Value	t1 = 0±10μsec

Note 1: NTSC MODEL: CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV65/ TRV65PK/ TRV85/ TRV93/ TRV215/ TRV615/ TRV815
PAL MODEL: CCD-TRV15E/ TRV15EP/ TRV35E

Adjusting Method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: F, address: 2A, and set data: 20, and press the PAUSE button of the adjustment remote commander.
3) Select page: F, address: 7C, change the data and minimize "t1", and then press the PAUSE button of the adjustment remote commander. (Coarse adjustment)
4) Select page: F, address: 7D, change the data and adjust so that the switching position (t1) becomes the specified value. (Fine adjustment)
5) Press the PAUSE button of the adjustment remote commander.
6) Select page: F, address: 2A, and set data: 00, and press the PAUSE button of the adjustment remote commander.
7) Select page: 0, address: 01, and set data: 00.



Fig. 5-3-6.

3. NTSC LP Mode Switching Position Adjustment (VC-195 Board) (CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

If deviated in this cases switching noise or jitter on the LP mode played back screen.

Mode	Playback
Signal	Alignment tape: For tracking adjustment (WR5-1NP (NTSC))
Measurement Point	CH1: Pin ⑪ of CN910 (RF SWP) CH2: Pin ⑥ of CN910 (PB RF)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	7E, 7F
Specified Value	t1 = 0±10μsec

Adjusting Method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: F, address: 2A, set data: 60, and then press the PAUSE button of the adjustment remote commander.
3) Select page: F, address: 7E, change the data and minimize "t1", and then press the PAUSE button of the adjustment remote commander. (Coarse adjustment)
4) Select page: F, address: 7F, change the data and adjust so that the switching position (t1) becomes the specified value. (Fine adjustment)
5) Select page: F, address: 2A, set data: 00, and then press the PAUSE button of the adjustment remote commander.
6) Press the PAUSE button of the adjustment remote commander.
7) Select page: 0, address: 01, and set data: 00.



Fig. 5-3-7.

3-4. VIDEO SYSTEM ADJUSTMENTS

Video system adjustments must be performed in the following order.

[Adjusting Order]

1. 28MHz origin oscillation adjustment
2. AFC f0 adjustment
3. Filter f0 adjustment
4. Y OUT level adjustment
5. C OUT level adjustment
6. RP filter f0 adjustment
7. Hi8 REC Y current adjustment
8. Standard REC Y current adjustment
9. Hi8 REC L level adjustment
10. Standard8 REC L level adjustment
11. REC C current adjustment

1. 28 MHz Origin Oscillation Adjustment (VC-195 board)

Set the frequency of the clock for synchronization.
If deviated, the synchronization will be disrupted and the color will become inconsistent.

Mode	VTR stop
Signal	No signal
Measurement Point	Pin (66) of IC202 or pin ⑫ of IC501
Measuring Instrument	Frequency counter
Adjustment Page	F
Adjustment Address	2C
Specified Value	Pin (66) of IC202 : f=3579545±17Hz (NTSC) f=4433618.75±17Hz (PAL) Pin ⑫ of IC501 : f=14318181±68Hz (NTSC) f=14187500±55Hz (PAL)

Note 1: NTSC MODEL: CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV65/ TRV65PK/ TRV85/ TRV93/ TRV215/ TRV615/ TRV815
PAL MODEL: CCD-TRV15E/ TRV15EP/ TRV35E

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 41, and press the PAUSE button of the adjusting remote commander.
3) Select page: 2, address: 61, and set data: 30.
4) Select page: F, address: 2C, change the data and set the clock frequency(f) to the specified value.
5) Press the PAUSE button of the adjusting remote commander.
6) Select page: 2, address: 61, and set data: 10.
7) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00.

2. AFC f0 Adjustment (VC-195 board)

Adjust the pull-in range of the A/D converted clock generator during playback

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ④ of CN910 (AGC f0)
Measuring Instrument	Digital voltmeter
Adjustment Page	F
Adjustment Address	4A
Specified Value	A = 2 10±0 05Vdc

Adjusting method.

1) Select page. 0, address 01, and set data 01.
2) Select page 3, address. 01, set data: 4D, and press the PAUSE button of the adjusting remote commander
3) Select page F, address: 4A, change the data and set the DC voltage (A) to the specified value
4) Press the PAUSE button of the adjusting remote commander
5) Select page 3, address. 01, set data: 00, and press the PAUSE button of the adjusting remote commander
6) Select page 0, address: 01, and set data: 00.

3. Filter f0 Adjustment (VC-195 board)

Minimize the chroma signal residual components during composite video signal input.

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ③ of CN910 (IR VIDEO)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	4D
Specified Value	Minimum residual chroma signal components (Bellow 12mV)

Switch setting.

LASER LINK . . . . ON (Red LED is lit)

Adjusting method

1) Select page 0, address. 01, and set data 01
2) Select page 3, address: 01, set data. 4F, and press the PAUSE button of the adjusting remote commander.
3) Select page: F, address: 4D, change the data and minimize the residual chroma signal components (A)
4) Press the PAUSE button of the adjusting remote commander.
5) Select page 3, address: 01, set data. 00, and press the PAUSE button of the adjusting remote commander.
6) Select page 0, address: 01, and set data 00



Fig. 5-3-8.

4. Y OUT Level Adjustment (VC-195 board)

Set the Y signal output level.

Mode	VTR stop
Signal	No signal
Measurement Point	Hi8 model : Y signal terminal of S VIDEO terminal (75Ω terminated) Standard 8 model : VIDEO terminal (75Ω terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	49
Specified Value	A = 286±5mV (NTSC) A = 300±5mV (PAL)

Note 1: Insert the plug into the S video terminal (Hi8 model)

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 41, and press the PAUSE button of the adjusting remote commander.
3) Select page: 2, address: 61, and set data: 30.
4) Select page: F, address: 49, change the data and set the SYNC level (A) to the specified value.
5) Press the PAUSE button of the adjusting remote commander.
6) Select page: 2, address: 61, and set data: 10.
7) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
8) Select page: 0, address: 01, and set data: 00.

Hi8 model



Standard 8 model



Fig. 5-3-9.

5. C OUT Level Adjustment (VC-195 board)

Set the chroma signal output level.

Mode	VTR stop
Signal	No signal
Measurement Point	Hi8 model : Chroma signal terminal of S VIDEO terminal (75Ω terminated) Standard 8 model : VIDEO terminal (75Ω terminated)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	4B
Specified Value	A = 286±5mV (NTSC) A = 300±5mV (PAL)

Note 1: Insert the plug into the S video terminal (Hi8 model)

Adjusting method:

1) Select page: 0, address: 01, and set data: 01.
2) Select page: 3, address: 01, set data: 41, and press the PAUSE button of the adjusting remote commander.
3) Select page: 2, address: 61, and set data: 30.
4) Select page: F, address: 4B, change the data and set the burst level (A) to the specified value.
5) Press the PAUSE button of the adjusting remote commander.
6) Select page: 2, address: 61, and set data: 10.
7) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
8) Select page: 0, address: 01, and set data: 00.

Hi8 model



Standard 8 model



Fig. 5-3-10.

6. RP Filter f0 Adjustment (VC-195 board)

Adjust the LPF of the playback RF amplifier

Mode	VTR stop
Signal	No signal
Measurement Point	Pin ⑨ of CN910 (RF AGC OUT)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	4E
Specified Value	A = Below 10mVp-p

Connection

1) Input a 14.2MHz, 400mVp-p CW signal to Pin ⑦ of CN910 (RF AGC IN)



Transistor	*General NPN transistor (2SC403 etc)*
47Ω resistor	*1-249-401-11*
1kΩ resistor	*1-249-417-11*
15kΩ resistor	*1-249-431-11*
0.01μF capacitor	*1-101-004-00*

Fig. 5-3-11.

Adjusting method

1) Select page 0, address 01, and set data: 01
2) Select page: 3, address: 01, set data 35, and press the PAUSE button of the adjusting remote commander.
3) Only for Standard8 model, select page D, address 15, after memorizing the data , set the bit value of bit0 to "1" (Refer to "3 Bit value discrimination" of "3-1-8 Service mode")
4) Select page F, address: 4E, change the data and minimize the 14.2 MHz signal level (A).
5) Press the PAUSE button of the adjusting remote commander
6) Select page D, address 15, and set the data memorized at step 3), and press the PAUSE button of the adjusting remote commander
7) Select page. 3, address: 01, set data 00, and press the PAUSE button of the adjusting remote commander
8) Select page 0, address: 01, and set data 00



Fig. 5-3-12.

7. Hi8 REC Y Current Adjustment (VC-195 board) (CCD-TRV85/TRV93/TRV615/TRV815)

Adjust the Y FM signal recording current

Mode	VTR recording (SP mode)
Signal	No signal
Measurement Point	Pin ⑩ of CN910 (REC RF)
Measuring Instrument	Oscilloscope (20 MHz BW LIMIT OFF)
Adjustment Page	F
Adjustment Address	53 to 5A
Specified Value	A = 160±5mV (NTSC)

Adjusting method

1) Insert a tape, set to recording mode
2) Select page 0, address 01, and set data: 01
3) Select page F, address 5C, after note down the data , set data: FF, and press the PAUSE button of the adjusting remote commander
4) Select page F, address 65, after note down the data , set data 00, and press the PAUSE button of the adjusting remote commander
5) Select page 3, address 01, set data: 41, and press the PAUSE button of the adjusting remote commander.
6) Select page F, address: 54, change the data and set the Y signal level (A) to the specified value
7) Press the PAUSE button of the adjusting remote commander
8) Select page. F, address 54, and read the data (D_{54})
9) Calculate the adjustment data (hexadecimal) from the following equations (hexadecimal calculation), and input each adjustment address. (Refer to Table 5-1-2 Hexadecimal-Decimal conversion Table)

    Address 53 $D_{53} = D_{54}$
    Address 55 $D_{55} = D_{54} + 10$
    Address 56 $D_{56} = D_{54} + 10$

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander

10) Write the following data in page F, address 57 to 5A

Address	Data
57	A0
58	80
59	90
5A	80

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander.

11) Select page F, address 5C, set the data noted down at step 3), press the PAUSE button of the adjusting remote commander
12) Select page F, address 65, set the data noted down at step 4), press the PAUSE button of the adjusting remote commander.
13) Select page 3, address 01, set data 00, and press the PAUSE button of the adjusting remote commander
14) Select page 0, address. 01, and set data: 00



Fig. 5-3-13.

8. Standard8 REC Y Current Adjustment (VC-195 board) (CCD-TRV15/ TRV15E/ TRV15EP/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV35E/ TRV215)

Adjust the Y FM signal recording current

Mode	VTR recording (SP mode)
Signal	No signal
Measurement Point	Pin ⑩ of CN910 (REC RF)
Measuring Instrument	Oscilloscope (20 MHz BW LIMIT OFF)
Adjustment Page	F
Adjustment Address	53 to 5A
Specified Value	A = 170±5mV (NTSC) A = 185±5mV (PAL)

Note 1: NTSC MODEL CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV215
PAL MODEL. CCD-TRV15E/ TRV15EP/ TRV35E

Preparations only for the model without REC switch

1) Select page 0, address 01, and set data: 01
3) Select page D, address 14, after memorizing the data, set the bit value of bit1 to "1" (Refer to "3 Bit value discrimination" of "3-1-8 Service mode").
4) Select page. D, address 15, after memorizing the data , set the bit value of bit7 to "0"
5) Turn off the HOLD switch of the adjusting remote commander, and press the REC buttons and set to recording mode.

Adjusting method

1) Insert a tape, set to recording mode
2) Select page: 0. address 01, and set data: 01
3) Select page: F. address 5C, after note down the data , set data FF, and press the PAUSE button of the adjusting remote commander
4) Select page F, address 65, after note down the data , set data 00, and press the PAUSE button of the adjusting remote commander
5) Select page 3, address 01, set data 41, and press the PAUSE button of the adjusting remote commander
6) Select page. F, address 54, change the data and set the Y signal level (A) to the specified value
7) Press the PAUSE button of the adjusting remote commander
8) Select page: F, address 54, and read the data (D_{54})
9) Calculate the adjustment data (hexadecimal) from the following equations (hexadecimal calculation), and input each adjustment address (Refer to Table 5-1-2 Hexadecimal-Decimal conversion Table)

Address 53 $D_{53} = D_{54}$
Address 55 $D_{55} = D_{54}$
Address 56 $D_{56} = D_{54}$

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander

10) Write the following data in page F, address: 57 to 5A

Address	Data	
	NTSC	PAL
57	80	80
58	80	80
59	80	80
5A	80	80

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander

11) Select page F, address 5C, set the data noted down at step 3), press the PAUSE button of the adjusting remote commander
12) Select page F, address: 65, set the data noted down at step 4), press the PAUSE button of the adjusting remote commander
13) Select page 3, address 01, set data 00, and press the PAUSE button of the adjusting remote commander
14) Select page 0, address. 01, and set data 00

Processing after completed adjustment only for the model without REC switch

1) Select page 0, address. 01, and set data 01
2) Select page· D, address 14, and set the data memorized at step 3) of "Preparations only for the model without REC switch"
3) Press the PAUSE button of the adjusting remote commander
4) Select page D, address 15, and set the data memorized at step 4) of "Preparations only for the model without REC switch"
5) Press the PAUSE button of the adjusting remote commander.
6) Select page 0, address. 01, and set data 00



Fig. 5-3-14.

9. Hi8 REC L Level Adjustment (VC-195 board) (CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

Set the recording levels of the REC AFM signal and REC ATF signal. If the level is too low, the audio S/N will deteriorated, tracking will not be stable, or SP/LP will not be discriminated properly. If too high, color beets will be produced on the self-recording/playback image.

Mode	VTR recording (SP mode)
Signal	No signal
Measurement Point	Pin ⑩ of CN910 (REC RF)
Measuring Instrument	Oscilloscope (20MHz BW LIMIT: OFF)
Adjustment Page	F
Adjustment Address	5B to 64
Specified Value	A = 10.1±0.6mV (NTSC)

Note 1: Do not insert a plug into the AUDIO (R) terminal.

Connection:
1) Remove C085 (0.01µF, Pin ⑯ of IC202).

Note: After completing "REC L Level Adjustment" and "REC C Current Adjustment", replace C085 with new parts (1-162-970-11 CERAMIC CHIP 0.01µF 10% 25V).

Adjusting method:
1) Insert Hi8 ME tape, set to recording mode.
2) Select page: 0, address: 01, and set data: 01.
3) Select page: F, address: 5B, set data: FF, and press the PAUSE button of the adjusting remote commander.
4) Select page: F, address: 65, set data: 00, and press the PAUSE button of the adjusting remote commander.
5) Select page: F, address: 5C, change the data and set the REC AFM signal level (A) to the specified value.
6) Press the PAUSE button of the adjusting remote commander.
7) Select page: F, address: 5C, read the data (D_{5C}).
8) Calculate the adjustment data (hexadecimal) from the following equations (hexadecimal calculation), and input each adjustment address. (Refer to Table 5-1-2. Hexadecimal-Decimal conversion Table.)

Address: 5B $D_{5B} = D_{5C}$
Address: 5D $D_{5D} = D_{5C} - 0C$
Address: 5E $D_{5E} = D_{5C} - 0C$
Address: 5F $D_{5F} = D_{5C} + 12$
Address: 60 $D_{60} = D_{5C} + 12$
Address: 61 $D_{61} = D_{5C} + 13$
Address: 62 $D_{62} = D_{5C} + 13$

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander.

9) Write the following data in page: F, address: 63 to 64.

Address	Data
63	7C
64	78

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander.

10) Select page: 0, address: 01, and set data: 00.
11) Perform "REC C Current Adjustment".


0.67 µsec
Center of the luminance line width
A
Center of the luminance line width

Fig. 5-3-15.

10. Standard8 REC L Level Adjustment (VC-195 board) (CCD-TRV15/ TRV15E/ TRV15EP/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV35E/ TRV215)

Set the recording levels of the REC AFM signal and REC ATF signal If the level is too low, the audio S/N will deteriorated, tracking will not be stable, or SP/LP will not be discriminated properly If too high, color beets will be produced on the self-recording/playback image

Mode	VTR recording (SP mode)
Signal	No signal
Measurement Point	Pin ⑩ of CN910 (REC RF)
Measuring Instrument	Oscilloscope (20MHz BW LIMIT OFF)
Adjustment Page	F
Adjustment Address	5B to 64
Specified Value	A = 9 6±0 6mV (NTSC) A = 9 3±0 5mV (PAL)

Note 1: NTSC MODEL· CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV215
PAL MODEL CCD-TRV15E/ TRV15EP/ TRV35E

Note 2: Do not insert a plug into the AUDIO (R) terminal.

Connection
1) Remove C085 (0 01μF, Pin ⑯ of IC202).

Note: After completing "REC L Level Adjustment" and "REC C Current Adjustment", replace C085 with new parts (1-162-970-11 CERAMIC CHIP 0 01μF 10% 25V).

Preparations only for the model without REC switch
1) Select page 0, address· 01, and set data 01
3) Select page: D, address· 14, after memorizing the data, set the bit value of bit1 to "1". (Refer to "3 Bit value discrimination" of "3-1-8 Service mode")
4) Select page D, address 15, after memorizing the data , set the bit value of bit7 to "0"
5) Turn off the HOLD switch of the adjusting remote commander, and press the REC buttons and set to recording mode.

Adjusting method
1) Insert Srandrd8 MP tape, set to recording mode
2) Select page 0, address· 01, and set data· 01
3) Select page F, address 5B, set data FF, and press the PAUSE button of the adjusting remote commander
4) Select page F, address: 65, set data: 00, and press the PAUSE button of the adjusting remote commander.
5) Select page F, address· 5C, change the data and set the REC AFM signal level (A) to the specified value
6) Press the PAUSE button of the adjusting remote commander
7) Select page· F, address 5C, read the data (D_{5C})
8) Calculate the adjustment data (hexadecimal) from the following equations (hexadecimal calculation), and input each adjustment address. (Refer to Table 5-1-2 Hexadecimal-Decimal conversion Table)
   Address 5B $D_{5B} = D_{5C}$
   Address· 5D $D_{5D} = D_{5C}$
   Address. 5E $D_{5E} = D_{5C}$
   Address: 5F $D_{5F} = D_{5C}$
   Address: 60 $D_{60} = D_{5C}$
   Address: 61 $D_{61} = D_{5C}$
   Address. 62 $D_{62} = D_{5C}$

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander

9) Write the following data in page· F, address· 63 to 64.

Address	Data	
	NTSC	PAL
63	80	80
64	80	80

Note: After setting each data, be sure to press the PAUSE button of the adjusting remote commander.

10) Select page 0, address 01, and set data: 00
11) Perform "REC C Current Adjustment".

Processing after completed adjustment only for the model without REC switch.
1) Select page 0, address: 01, and set data 01
2) Select page· D, address: 14, and set the data memorized at step 3) of "Preparations only for the model without REC switch"
3) Press the PAUSE button of the adjusting remote commander
4) Select page. D, address: 15, and set the data memorized at step 4) of "Preparations only for the model without REC switch"
5) Press the PAUSE button of the adjusting remote commander
6) Select page: 0, address 01, and set data· 00


0 67μsec
Center of the luminance line width
A
Center of the luminance line width

Fig. 5-3-16.

11. REC C Current Adjustment (VC-195 board)

Set the recording current levels of the REC Chroma signal If it is too low, chroma signal noise in played back picture will increased If too high, Y signal noises will increase and white modulation noises will be produced

Mode	VTR recording (SP mode)
Signal	No signal
Measurement Point	Pin ⑩ of CN910 (REC RF)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	65
Specified Value	Hi8 model A = 34 6±1 2mV (NTSC) Standard8 model A = 30.9±1 1mV (NTSC) A = 30 0±1 1mV (PAL)

Note 1: NTSC HI8 model CCD-TRV65/ TRV65PK/ TRV85/
TRV93/ TRV615/ TRV815
NTSC Standard8 model CCD-TRV15/ TRV15PK/
TRV25/ TRV25PK/ TRV35/
TRV215
PAL Standard8 model: CCD-TRV15E/ TRV15EP/
TRV35E

Connection:
1) Remove C085 (0.01μF, Pin ⑯ of IC202)

Note: After completing “REC L Level Adjustment” and “REC C Current Adjustment”, replace C085 with new parts (1-162-970-11 CERAMIC CHIP 0 01μF 10% 25V).

2) Connect Pin ① of IC001 and GND with a 0 01F capacitor
0.01μF capacitor· 1-101-004-00

Preparations only for the model without REC switch:
1) Select page. 0, address 01, and set data 01.
2) Select page D, address· 14, after memorizing the data, set the bit value of bit1 to “1”. (Refer to “3. Bit value discrimination” of “3-1-8. Service mode”)
3) Select page. D, address. 15, after memorizing the data , set the bit value of bit7 to “0”
4) Turn off the HOLD switch of the adjusting remote commander, and press the REC buttons and set to recording mode

Adjusting method
1) Insert a tape, set to recording mode
2) Select page· 0, address. 01, and set data: 01.
3) Select page 3, address. 01, set data· 41, and press the PAUSE button of the adjusting remote commander.
4) Select page: 2, address 61, and set data: 30.
5) Select page: F, address 65, change the data and set the REC chroma signal level (A) to the specified value.
6) Press the PAUSE button of the adjusting remote commander.
7) Select page 2, address: 61, and set data. 10
8) Select page 3, address· 01, set data 00, and press the PAUSE button of the adjusting remote commander.
9) Select page· 0, address 01, and set data. 00.

Processing after completed adjustment only for the model without REC switch
1) Select page 0, address. 01, and set data. 01
2) Select page D, address. 14, and set the data memorized at step 3) of “Preparations only for the model without REC switch”
3) Press the PAUSE button of the adjusting remote commander
4) Select page D, address 15, and set the data memorized at step 4) of “Preparations only for the model without REC switch”
5) Press the PAUSE button of the adjusting remote commander
6) Select page 0, address 01, and set data 00.



Fig. 5-3-17.

3-5. IR TRANSMITTER ADJUSTMENTS (CCD-TRV35/ TRV65/ TRV65PK/ TRV85/ TRV93/ TRV615/TRV815)

Adjust using a IR receiver jig (J-6082-383-A)

Switch setting
LASER LINK . . . (Red LED is lit)

1. IR Video Carrier Frequency Adjustment (VC-195 board)

Mode	Camera standby
Subject	Arbitrary
Measurement Point	Pin ⑤ of CN003 of IR receiver jig (RF) (Or Pin ⑯ of IC751 of VC-195 board)
Measuring Instrument	Frequency counter
Adjustment Page	F
Adjustment Address	68
Specified Value	f = 11.85±0.05MHz

Connection of Equipment
Connect the measuring device as shown in the following figure, and adjust.



Fig. 5-3-18.

Adjusting method
1) Select page. 0, address: 01, and set data: 01
2) Select page: 3, address: 01, set data: 37, and press the PAUSE button of the adjusting remote commander.
3) Select page. F, address: 68, change the data, and set the video carrier frequency (f) to the specified value.
4) Press the PAUSE button of the adjusting remote commander.
5) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00

2. IR Video Deviation Adjustment (VC-195 board)

Mode	Camera standby
Subject	Arbitrary
Measurement Point	VIDEO OUT terminal of IR receiver jig (Terminated at 75Ω)
Measuring Instrument	Oscilloscope
Adjustment Page	F
Adjustment Address	66
Specified Value	A = 0.87±0.04V

Connection of Equipment
Connect the measuring device as shown in the following figure, and adjust.



Fig. 5-3-19.

Adjusting method
1) Select page: 0, address: 01, and set data: 01
2) Select page: 3, address: 01, set data: 39, and press the PAUSE button of the adjusting remote commander.
3) Select page: F, address: 66, and change the data, set the video signal amplitude (A) to the specified value.
4) Press the PAUSE button of the adjusting remote commander.
5) Select page: 3, address: 01, set data: 00, and press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00



Fig. 5-3-20.

3. IR Audio Deviation Adjustment (VC-195 board)

Mode	VTR recording
Signal	Audio signal 400Hz, -7.5dBs L or R of AUDIO terminal Video signal Color bar signal : VIDEO terminal
Measurement Point	AUDIO L terminal and AUDIO R terminal of IR receiver jig (Terminated at 47kΩ)
Measuring Instrument	Audio level meter
Adjustment Page	F
Adjustment Address	67
Specified Value	Signal level -7 5±2.0dBs

Connection of Equipment

Connect the measuring device as shown in the following figure, and adjust

Preparations only for the model without REC switch·

1) Select page 0, address: 01, and set data 01
2) Select page D, address 14, after memorizing the data, set the bit value of bit1 to "1". (Refer to "3. Bit value discrimination" of "3-1-8 Service mode").
3) Select page D, address· 15, after memorizing the data , set the bit value of bit7 to "0"
4) Turn off the HOLD switch of the adjusting remote commander, and press the REC buttons and set to recording mode.

Adjusting method

1) Select page: 0, address. 01, and set data. 01.
2) Connect the audio level meter to the AUDIO L terminal of the IR receiver jig
3) Select page F, address: 67, change the data and set the 400Hz audio signal level to the specified value.
4) Press the PAUSE button of the adjusting remote commander.
5) Connect the audio level meter to the AUDIO R terminal of the IR receiver jig.
6) Check that the 400Hz audio signal level is within the specified value. If outside, repeat from step 2)
7) Select page. 0, address: 01, and set data. 00

Processing after completed adjustment: only for the model without REC switch·

1) Select page 0, address: 01, and set data. 01
2) Select page D, address: 14, and set the data memorized at step 3) of "Preparations only for the model without REC switch".
3) Press the PAUSE button of the adjusting remote commander.
4) Select page. D, address 15, and set the data memorized at step 4) of "Preparations only for the model without REC switch".
5) Press the PAUSE button of the adjusting remote commander
6) Select page 0, address: 01, and set data· 00



Fig. 5-3-21.

3-6. STEREO AUDIO SYSTEM ADJUSTMENT (CCD-TRV65/TRV65PK/TRV85/TRV93/TRV615/ TRV815)

- Perform the adjustment using the color bar signal as a video signal input for VIDEO terminal
- The items to be adjusted for the R channel will be indicated within the [ ], in regard to the adjusting items to be adjusted for both L and R channels.
- Set the Hi-Fi sound switch in the menu display to "STEREO" position unless specified otherwise

Note:

1) When inputting the audio signal, input the same signal to both the L and R channels, unless specified otherwise
2) Be sure to insert the plug (Shorting plug or dummy plug, etc) into the AUDIO terminal (Right) If the plug is not inserted, the monaural mode well be set, and correct adjustments can not be carried out
   [Monaural mode]
   During recording .... REC AFM RF 1.7MHz carriear will not be output.
   During playback .... The L+R signal will be output from the AUDIO terminal (Left)

[Connecting the measuring instruments for the audio]

Connect the audio system measuring instruments in addition to the video system measuring instruments as shown in Fig. 5-3-22, and perform adjustments at the power switch [VTR] or [PLAYER] position

[Adjustment Procedure]

1) 1.5 MHz deviation adjustment
2) 1.7 MHz deviation adjustment
3) BPF adjustment



In Recording
Pattern generator
Video output (75 Ω)
Main unit
VIDEO
L
AUDIO
R
Audio oscillator
600 Ω
Attenuator
600 Ω (270 Ω (1-249-410-11) + 330 Ω (1-249-411-11))
In Playback
Main unit
VIDEO
L
AUDIO
R
Audio level meter or distortion meter
47kΩ
47kΩ 1-249-437-11
TV monitor
47kΩ 1-249-437-11
When connecting AFM DEV jig
Stabilized power supply (+7Vdc to +9Vdc)
+
-
TP27 (GND)
TP28 (DC)
Ⓑ Ⓐ
INV←→SIN
S3
AFM DEV jig (J-6082-312-A)
Oscilloscope
CH1
CH2
TP33(GND)
TP32(R OUT 1) Ⓑ
TP31(L OUT 1) Ⓐ
TP30(R OUT 2)
TP29(L OUT 2)
S2
PAL←→NT
ST
S1
BIL
Red
J1(R)
White
J2(L)
J3
TP26
TP24
TP25
TP1(GND)
TP2(R OUT) Ⓑ
TP3(L OUT) Ⓐ
CN2
CN1
Use the CPC-7 jig (J-6082-382-A)
0.01 µF (1-101-004-00)
IC301 ㉙ PIN (REC AFM)
CN910 ⑪ PIN (RF SWP)
CN910 ⑧ PIN (GND)
To Audio terminal
White
L
Red
R
VC-195 board
Ⓐ 1.5MHz deviation adjustment
Ⓑ 1.7MHz deviation adjustment

Fig. 5-3-22.

1. 1.5 MHz Deviation Adjustment (VC-195 board)

Sets the spectrum of the L-ch ((L+R)/2 signal) level modulated during recording. If deviated, the crosstalk signal of the audio signal will occur and the audio level will drop during both playback and recording.

Mode	VTR recording
Signal	Input the AFM DEV jig output signal to the left and right audio input terminal
Measurement Point	CH1: AFM DEV jig TP31 CH2: AFM DEV jig TP3
Measuring Instrument	Oscilloscope ADD mode CH2 INV mode
Adjustment Page	F
Adjustment Address	45
Specified Value	The level difference between CH1 signal and CH2 signal should be minimum.

Connection:

1) Connect TP24 and TP26 of the AFM DEV jig to CN910 of the VC-195 board.
   TP24(GND) .... Pin ⑧ of CN910
   TP26(RF SWP) .... Pin ⑪ of CN910
2) Connect TP25 (REC AFM) of the AFM DEV jig to Pin ㉙ of IC301 with a 0.01µF capacitor (1-101-004-00).
3) Connect the audio output terminal (J1 and J2) of the AFM DEV jig to AUDIO terminal of the unit.
4) Connect TP28 (DC), TP27 (GND) of the AFM DEV jig to the DC power supply (+7Vdc to +9Vdc).
5) Set the AFM DEV jig switches to the following positions.
   S1 .... BIL Position
   S2 .... NT Position
   S3 .... SIN Position

Adjusting method :

1) Match the vertical ranges of CH1 and CH2 of the oscilloscope to each other.
2) Set the oscilloscope to the ADD mode and CH2 to the INV (invert) mode.
3) Select page: 0, address: 01, and set data: 01.
4) Select page: F, address: 45, change the data and minimize the audio signal level difference (A).
5) Press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-3-23.

2. 1.7 MHz Deviation Adjustment (VC-195 board)

Sets the spectrum of the R-ch ((L-R)/2 signal) level modulated during recording. If deviated, the crosstalk signal of the audio signal will occur and the audio level will drop during both playback and recording.

Mode	VTR recording
Signal	Input the AFM DEV jig output signal to the left and right audio input terminal
Measurement Point	CH1: AFM DEV jig TP32 CH2: AFM DEV jig TP2
Measuring Instrument	Oscilloscope ADD mode CH2 normal mode
Adjustment Page	F
Adjustment Address	46
Specified Value	The level difference between CH1 signal and CH2 signal should be minimum.

Connection:

1) Connect TP24 and TP26 of the AFM DEV jig to CN910 of the VC-195 board.
   TP24 (GND) .... Pin ⑧ of CN910
   TP26 (RF SWP) .... Pin ⑪ of CN910
2) Connect TP25 (REC AFM) of the AFM DEV jig to Pin ㉙ of IC301 with a 0.01µF capacitor (1-101-004-00).
3) Connect the audio output terminal (J1 and J2) of the AFM DEV jig to AUDIO terminal of the unit.
4) Connect TP28 (DC), TP27 (GND) of the AFM DEV jig to the DC power supply (+7Vdc to +9Vdc).
5) Set the AFM DEV jig switches to the following positions.
   S1 .... BIL Position
   S2 .... NT Position
   S3 .... INV Position

Adjusting method :

1) Match the vertical ranges of CH1 and CH2 of the oscilloscope to each other.
2) Set the oscilloscope to the ADD mode and CH2 to the normal mode.
3) Select page: 0, address: 01, and set data: 01.
4) Select page: F, address: 46, change the data and minimize the audio signal level difference (A).
5) Press the PAUSE button of the adjusting remote commander.
6) Select page: 0, address: 01, and set data: 00.



Fig. 5-3-24.

3. BPF f0 Adjustment (VC-195 board)

Sets the BPF passing frequency so that the AFM signal can separate from the playback RF signal properly. If deviated the mono/stereo mode will be differentiated incorrectly, and noises and distortions will increase during high volume playback

Mode	Playback
Signal	Alignment tape For BPF adjustment (WR5-11NS)
Measurement Point	Audio output terminal left or right
Measuring Instrument	distortion meter
Adjustment Page	F
Adjustment Address	47
Specified Value	The Main and Sub channel distortion rate should be almost the same (within±1%) and minimum

Adjusting method

1) Select page· 0, address. 01, and set data: 01
2) Set the Hi-Fi sound switch (menu display) to “2”.
3) Select page: F, address· 47, change the data and minimize the distortion rate
4) Press the PAUSE button of the adjusting remote commander.
5) Set the Hi-Fi sound switch (menu display) to “1”
6) Select page F, address: 47, change the data and minimize the distortion rate
7) Press the PAUSE button of the adjusting remote commander
8) Repeat steps 2) to 7) and set the data of address: 47 so that the distortions rates when the Hi-Fi sound switch is set to “2” and set to “1” respectively are almost the same and minimum.
9) Press the PAUSE button of the adjusting remote commander.
11) Select page: 0, address· 01, and set data. 00
12) Set the Hi-Fi sound switch to “STEREO”

3-7. MONAURAL AUDIO SYSTEM ADJUSTMENT MONAURAL (CCD-TRV15/TRV15E/TRV15EP/TRV15PK/TRV25/TRV25PK/TRV35/TRV35E/TRV215)

[Connecting the measuring instruments for the audio]
Connect the audio system measuring instruments besides the video system measuring instruments as shown Fig 5-3-25

- Connection of Audio generator and attenuator



Parts cord 600 Ω
270 (1-249-410-11) + 330 (1-249-411-11)

- Connection of Audio level meter or distortion meter



Parts cord 47kΩ 1-249-437-11

Fig. 5-3-25.

1. 1.5 MHz Deviation Adjustment (VC-195 board)

Adjust to the optimum audio FM signal distortion
If the adjustment is not correct, its playback level will differ from that of other units.

Mode	Playback
Signal	Alignment tape. For checking the operation (WR5-5NSP (NTSC)) (WR5-5CSP (PAL))
Measurement Point	Audio output terminal
Measuring Instrument	Audio level meter
Adjustment Page	F
Adjustment Address	45
Specified Value	−7 5±0.5dBs

Note 1: NTSC model CCD-TRV15/ TRV15PK/ TRV25/ TRV25PK/ TRV35/ TRV215
PAL model: CCD-TRV15E/ TRV15EP/ TRV35E

Adjusting method

1) Select page. 0, address: 01, and set data 01
2) Select page. F, address 45, change the data and set the 400Hz signal level to the specified value.
3) Press the PAUSE button of the adjusting remote commander
4) Select page: 0, address 01, and set data 00

2. BPF Adjustment (VC-195 board)

Adjust to the optimum audio BPF characteristics of the IC
If the adjustment is not correct, the distortion rate and S/N ratio will worsen

Mode	Playback
Signal	Alignment tape. For BPF adjustment (WR5-11NS (NTSC)) (WR5-11CS (PAL))
Measurement Point	Audio output terminal
Measuring Instrument	distortion meter
Adjustment Page	F
Adjustment Address	47
Specified Value	The distortion rate should be and minimum

Adjusting method :

1) Select page: 0, address 01, and set data 01
2) Select page F, address· 47, change the data and minimize the distortion rate
3) Press the PAUSE button of the adjusting remote commander
4) Select page 0, address· 01, and set data 00

3-8. ARRANGEMENT DIAGRAM FOR ADJUSTMENT PARTS

VC-195 BOARD (SIDE A)


CN909
10
1
CN551
23
1
CN501
2
1
16
15
IC604
50
26
51
25
75
1
76
100
IC202
132
89
133
88
176
45
1
44
CN911
50
1
C085
IC001
16
1
17
64
32
49
33
48
IC301
48
33
49
32
64
17
1
16

VC-195 BOARD (SIDE B)


IC501
48
37
1
36
12
25
13
24
CN910
1
16
IC751
36
25
37
24
48
13
1
12

SECTION 6
REPAIR PARTS LIST

6-1. EXPLODED VIEWS

NOTE

- Items marked “ ” are not stocked since they are seldom required for routine service Some delay should be anticipated when ordering these items
- The mechanical parts with no reference number in the exploded views are not supplied

- Abbreviation
  Canadian model is abbreviated as CND
  Chinese model is abbreviated as CN
  Brazilian model is abbreviated as BR
  East European model is abbreviated as EE
  Hong Kong model is abbreviated as HK
  North European model is abbreviated as NE
  Russian model is abbreviated as RU

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety
Replace only with part number specified

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité
Ne les remplacer que par une pièce portant le numéro spécifié

6-1-1. CABINET (L) BLOCK ASSEMBLY



Ref No	Part No	Description	Remark
1	X-3948-205-1	CABINET (L) ASSY (TRV65/TRV65PK/TRV615)	
1	X-3948-207-1	CABINET (L) ASSY (EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
1	X-3948-315-1	CABINET (L) ASSY (TRV85/TRV815/TRV93)	
2	3-969-339-31	BELT, GRIP	
3	3-969-081-01	KNOB, STAND-BY	
4	3-970-854-01	SPRING, STAND-BY	
5	3-302-492-00	SPRING, COMPRESSION	
6	3-948-339-61	TAPPING	
7	3-679-362-11	SCREW	
8	3-962-826-01	SCREW (2X4)	
9	3-968-729-01	SCREW (M2), LOCK ACE, P2	
10	1-475-619-11	SWITCH BLOCK, CONTROL(SS-8500)	
* 11	3-975-532-01	HOLDER, EL	
12	X-3947-199-1	LID ASSY, CASSETTE (TRV85/TRV815/TRV93)	
12	X-3948-219-1	LID ASSY, CASSETTE (TRV65/TRV65PK/TRV615)	
12	X-3948-221-1	LID ASSY, CASSETTE (TRV15 US,CND/TRV25/TRV215)	
12	X-3948-223-1	LID ASSY, CASSETTE (TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35 E,HK/TRV15E/TRV35E)	
13	3-713-786-21	SCREW (M2X3)	
14	1-475-617-11	SWITCH BLOCK, CONTROL(FK-8500) (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
14	1-475-617-31	SWITCH BLOCK, CONTROL (FK-8500)(TRV35E)	
14	1-475-617-51	SWITCH BLOCK, CONTROL(FK-8500)(TRV35)	
14	1-475-617-71	SWITCH BLOCK, CONTROL(FK-8500) (TRV65/TRV65PK/TRV615)	
14	1-475-618-41	SWITCH BLOCK, CONTROL(FK-8500) (TRV85/TRV815/TRV93)	
15	3-987-717-01	SCREW, TRIPOD	
16	3-987-639-11	CABINET (S) (878)(TRV85/TRV815)	
16	3-987-639-01	CABINET (S (870)) (TRV35/TRV65/TRV65PK/TRV615/TRV35E)	
17	3-987-645-01	CABINET (N) (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
17	3-987-652-11	CABINET (LT)(TRV93)	
18	3-975-522-01	COVER, JACK	
19	1-467-574-21	REMOTE COMMANDER (RMT-708)	
20	3-958-131-01	LID, BATTERY CASE (for RMT-708)	
J001	1-565-276-31	JACK, ULTRA SMALL 1P (LANC)	
S003	1-572-688-11	SWITCH, PUSH (1 KEY) (EJECT)	

6-1-2. FRONT PANEL BLOCK ASSEMBLY (TRV93)


53
52
60
53
53
not supplied
53
not supplied
59
not supplied
58
not supplied
54
57
56
55
MIC901
MIC902
51
LAMP,HALOEEN
XB-3D(DC6V/3W)
VL001

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une piéce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
51	X-3948-170-1	GRILLE (870) ASSY, MICROPHONE	
52	X-3948-276-1	PANEL (887) ASSY, FRONT	
53	3-948-339-61	TAPPING	
54	3-987-882-01	SPRING, TORSION	
55	3-987-632-01	HOLDER, P KNOB	
56	3-973-619-01	SPRING, COMPRESSION	
57	3-987-633-01	BUTTON, LOCK	
58	3-987-631-01	KNOB, P	
59	3-987-642-01	SPRING, CLICK	
60	A-7073-455-A	MA-312(VHIB) BOARD, COMPLETE	
MIC901	1-542-312-11	MICROPHONE (L-CH)	
MIC902	1-542-312-11	MICROPHONE (R-CH)	
⚠VL001	1-517-760-11	LIGHT BLOCK, VIDEO	

6-1-3. FRONT PANEL BLOCK ASSEMBLY (EXCEPT TRV93)


103
102
110
103
103
not supplied
103
not supplied
109
not supplied
108
not supplied
104
107
106
105
MIC901
MIC902
101

Ref No	Part No	Description	Remark
101	X-3948-170-1	GRILLE (870) ASSY, MICROPHONE	
102	X-3948-194-1	PANEL (870) ASSY, FRONT (TRV15/TRV15PK/TRV15E/TRV15EP)	
102	X-3948-196-1	PANEL (870) ASSY, FRONT (TRV35)	
102	X-3948-197-1	PANEL (870) ASSY, FRONT (TRV35E)	
102	X-3948-274-1	PANEL (870) ASSY, FRONT (TRV65/TRV65PK/TRV615)	
102	X-3948-479-1	PANEL (870) ASSY, FRONT (TRV25/TRV25PK/TRV215)	
102	X-3948-275-1	PANEL (887) ASSY, FRONT (TRV85/TRV815)	
103	3-948-339-61	TAPPING	
104	3-987-882-01	SPRING, TORSION	
105	3-987-632-01	HOLDER, P KNOB	
106	3-973-619-01	SPRING, COMPRESSION	
107	3-987-633-01	BUTTON, LOCK	
108	3-987-631-01	KNOB, P	
109	3-987-642-01	SPRING, CLICK	
110	A-7073-402-A	MA-331(VMM) BOARD, COMPLETE (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
110	A-7073-411-A	MA-331(VHI) BOARD, COMPLETE (TRV65/TRV65PK/TRV615)	
110	A-7073-430-A	MA-312(VHI) BOARD, COMPLETE (TRV85/TRV815)	
110	A-7073-445-A	MA-311(VMMI) BOARD, COMPLETE(TRV35)	
110	A-7073-451-A	MA-331(VMM0) BOARD, COMPLETE (TRV35E)	
MIC901	1-542-312-11	MICROPHONE (L-CH)	
MIC902	1-542-312-11	MICROPHONE (R-CH) (TRV65/TRV65PK/TRV85/TRV615/TRV815)	

6-1-4. CABINET (R) BLOCK ASSEMBLY (TRV85/TRV815/TRV93)


157
156
151
151
151
158
151
153
159
155
151
151
164
161
165
162
152
SP901
151
166
not supplied
160
not supplied
163
not supplied
not supplied
154
151
151

Ref. No.	Part No.	Description	Remark
151	3-948-339-61	TAPPING	
152	3-965-367-01	SPACER, SP	
153	3-987-769-01	PLATE, HINGE GROUND	
154	1-475-621-11	SWITCH BLOCK, CONTROL(MR-8500)	
* 155	3-987-842-01	SHEET, VF FLEXIBLE RETAINE	
156	3-987-792-01	BASE (887), VF	
157	3-987-783-01	LOCK, TILT	
158	X-3948-267-1	CABINET (R) (887) ASSY	
159	3-959-978-02	CUSHION, PANEL	
160	3-989-121-01	SPRING, TENSION	
161	3-987-739-01	SPRING, LINK PLATE	
162	3-987-744-01	KNOB, IR	
163	3-987-764-01	COVER, IR	
164	1-783-240-11	CABLE, FLEXIBLE FLAT (FFC-236)	
165	A-7073-431-A	CF-51(VH) BOARD, COMPLETE (TRV85/TRV815)	
165	A-7073-456-A	CF-51(VHC) BOARD, COMPLETE (TRV93)	
166	3-987-770-01	PLATE (887), GROUND	
SP901	1-504-753-21	SPEAKER (2.8CM)	

6-1-5. CABINET (R) BLOCK ASSEMBLY (EXCEPT TRV85/TRV815/TRV93)



Ref No	Part No	Description	Remark
201	3-948-339-61	TAPPING	
202	3-965-367-01	SPACER, SP	
203	3-987-742-01	PLATE(878), GROUND	
204	1-475-620-11	SWITCH BLOCK, CONTROL(MF-8500)	
* 205	3-987-842-01	SHEET, VF FLEXIBLE RETAINER	
206	X-3948-603-1	BASE , VF ASSY	
207	3-987-783-01	LOCK, TILT	
208	X-3948-239-1	CABINET (R) (878) ASSY (TRV65/TRV65PK/TRV615)	
208	X-3948-240-1	CABINET (R) (846U) ASSY (TRV15 US,CND/TRV25/TRV215/TRV15E AEP,UK)	
208	X-3948-241-1	CABINET (R) (872) ASSY(TRV35E AEP,UK)	
208	X-3948-242-1	CABINET (R) (871) ASSY (TRV35 E,HK/TRV35E EE,NE,RU,E,HK,AUS,CN)	
208	X-3948-246-1	CABINET (R) (846E) ASSY (TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV15E EE,NE,RU)	
209	3-959-978-21	CUSHION, PANEL (EXCEPT TRV35E/TRV65PK)	
210	3-987-742-01	SPRING, TENSION (TRV65/TRV65PK/TRV615/TRV35E AEP,UK)	
211	3-987-739-01	SPRING, LINK PLATE (TRV35/TRV65/TRV65PK/TRV615/TRV35E)	

Ref No	Part No	Description	Remark
212	3-987-744-01	KNOB, IR (TRV35/TRV65/TRV65PK/TRV615/TRV35E)	
213	3-987-730-01	COVER, IR(TRV65/TRV65PK)	
213	3-987-730-11	COVER, IR (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
213	3-987-730-21	COVER, IR(TRV35/TRV35E)	
213	3-987-730-31	COVER, IR (TRV615)	
214	1-783-240-11	CABLE, FLEXIBLE FLAT (FFC-236)	
215	A-7073-403-A	CF-50(E7V) BOARD, COMPLETE (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
215	A-7073-412-A	CF-50(ESV) BOARD, COMPLETE (TRV35/TRV35E/TRV65/TRV65PK/TRV615)	
216	3-987-729-01	PLATE, ORNAMENTAL (TRV65/TRV65PK)	
216	3-987-729-11	PLATE, ORNAMENTAL (TRV15/TRV15PK/TRV15E/TRV15EP)	
216	3-987-729-21	PLATE, ORNAMENTAL (TRV25/TRV25PK/TRV35/TRV35E)	
216	3-987-729-41	PLATE, ORNAMENTAL (TRV615)	
216	3-987-729-51	PLATE, ORNAMENTAL (TRV215)	
217	3-987-736-01	LID,MK (TRV15/TRV15PK/TRV15E/TRV25/TRV25PK/TRV215)	
SP901	1-505-291-11	SPEAKER (DIA 2 8CM)	

6-1-6. LCD BLOCK ASSEMBLY(3/3.5INCH) (TRV85/TRV815/TRV93)



not supplied
251
ND801
not supplied
253
252
254
not supplied
255
LCD901
256
263
not supplied
262
not supplied
257
264
269
258
258
265
266
259
ND802
267
260
not supplied
261
263

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

Ref No	Part No	Description	Remark
251	3-948-339-11	SCREW, TAPPING	
252	3-987-593-01	CABINET (M) (885), P (TRV85/TRV815)	
252	3-987-593-11	CABINET (M) (885), P (TRV93)	
253	3-987-594-01	FRAME (885), PANEL	
254	A-7073-432-A	PD-93(CN3 5) BOARD, COMPLETE (TRV85/TRV815)	
254	A-7073-457-A	PD-93(SN3) BOARD, COMPLETE (TRV93)	
255	3-713-786-21	SCREW (M2X3)	
256	3-987-597-01	HOLDER (885), LCD	
257	3-948-339-61	TAPPING	
258	1-668-963-41	FP-642 FLEXIBLE BOARD	
259	1-958-332-11	HARNESS (DP-71)	
260	A-7093-486-A	INDICATION LCD BLOCK ASSY	
261	X-3948-165-1	CABINET (C) (885) H ASSY, P	
262	3-962-826-01	SCREW (2X4)	
263	3-987-601-01	WINDOW (885), LCD (TRV85)	
263	3-987-601-11	WINDOW (885), LCD (TRV93)	
263	3-987-601-51	WINDOW (885), LCD (TRV815)	
264	3-948-339-01	SCREW, TAPPING	
265	X-3948-169-1	HINGE ASSY	
266	3-987-623-01	CLAMP, HARNESS	
267	3-987-626-01	COVER (C) (885), HINGE	
268	3-987-625-11	COVER (M), HINGE	
269	4-981-286-01	SCREW(M1 7x2), IB LOCK	
LCD901	1-803-032-21	INDICATOR MODULE, LIQUID CRYST (TRV85/TRV815)	
LCD901	1-803-037-21	INDICATOR MODULE, LIQUID CRYST (TRV93)	
⚠ND801	1-517-753-11	TUBE, FLUORESCENT,COLD CATHODE (TRV93)	
⚠ND801	1-517-754-11	TUBE, FLUORESCENT,COLD CATHODE (TRV85/TRV815)	
⚠ND802	1-517-759-11	LIGHT, BACK	

6-1-7. LCD BLOCK ASSEMBLY (2.5INCH)(EXCEPT TRV85/TRV815/TRV93)



The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

Ref No	Part No	Description	Remark
301	3-948-339-11	SCREW, TAPPING	
302	X-3948-162-1	CABINET (M) (870) ASSY, P	
303	3-987-582-01	FRAME (870), PANEL	
304	A-7073-413-A	PD-92(SN6) BOARD, COMPLETE (TRV35/TRV65/TRV65PK/TRV615)	
304	A-7073-415-A	PD-92(CN6) BOARD, COMPLETE (TRV15/TRV15PK/TRV25/TRV25PK/TRV215)	
304	A-7073-452-A	PD-92(SP6) BOARD, COMPLETE (TRV35E)	
304	A-7073-460-A	PD-92(CP6) BOARD, COMPLETE (TRV15E/TRV15EP)	
305	3-713-786-21	SCREW (M2X3)	
306	3-987-584-01	HOLDER (870), LCD	
307	3-948-339-61	TAPPING	
308	1-668-963-41	FP-642 FLEXIBLE BOARD	
309	1-958-379-11	HARNESS (DP-70)	
310	A-7093-473-A	INDICATION LCD BLOCK ASSY (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
310	A-7093-509-A	INDICATION LCD BLOCK ASSY (TRV35/TRV35E)	
310	A-7093-486-A	INDICATION LCD BLOCK ASSY (TRV65/TRV65PK/TRV615)	
311	X-3948-158-1	CABINET (C) (870) ASSY, P (TRV65/TRV65PK)	
311	X-3948-159-1	CABINET (C) (846) ASSY, P (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
311	X-3948-160-1	CABINET (C) (872) ASSY, P (TRV35/TRV35E)	
311	X-3948-161-1	CABINET (C) (878D) ASSY, P (TRV615)	
312	3-962-826-01	SCREW (2X4)	
313	3-987-625-01	COVER (M), HINGE	
314	3-948-339-01	SCREW, TAPPING	
315	X-3948-169-1	HINGE ASSY	
316	3-987-623-01	CLAMP, HARNESS	
317	3-987-624-01	COVER (C) (870), HINGE (TRV65/TRV65PK/TRV615)	
317	3-987-624-11	COVER (C) (870), HINGE(TRV35/TRV35E)	
317	3-987-624-21	COVER (C) (870), HINGE (TRV15E/TRV15EP)	
317	3-987-624-31	COVER (C) (870), HINGE (TRV15/TRV15PK/TRV25/TRV25PK/TRV215)	
318	3-987-585-01	SHEET, MODEL NAME(TRV65)	
318	3-987-585-11	SHEET, MODEL NAME(TRV15/TRV15PK)	
318	3-987-585-21	SHEET, MODEL NAME(TRV25)	
318	3-987-585-31	SHEET, MODEL NAME(TRV35)	
318	3-987-585-41	SHEET, MODEL NAME(TRV35E)	
318	3-987-585-51	SHEET, MODEL NAME(TRV15E)	
318	3-987-586-01	SHEET, MODEL NAME(TRV615)	
318	3-987-586-11	SHEET, MODEL NAME(TRV215)	
LCD901	1-803-035-21	INDICATOR MODULE, LIQUID CRYST (TRV35/TRV65/TRV65PK/TRV615/TRV35E)	
LCD901	1-803-040-21	INDICATOR MODULE, LIQUID CRYST (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
⚠ND801	1-517-751-11	TUBE, FLUORESCENT,COLD CATHODE (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
⚠ND801	1-517-752-11	TUBE, FLUORESCENT,COLD CATHODE (TRV35/TRV65/TRV65PK/TRV615/TRV35E)	
⚠ND802	1-517-759-11	LIGHT, BACK (TRV65/TRV65PK/TRV615)	

6-1-8. EVF BLOCK ASSEMBLY (COLOR EVF) (TRV93)



The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une piéce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
351	3-968-729-61	SCREW (M2X3), LOCK ACE, P2	
352	X-3948-235-1	CABINET (FRONT) (884) ASSY,EVF	
353	A-7073-438-A	VF-120 BOARD BOARD, COMPLETE	
354	A-7073-439-A	LB-54 BOARD BOARD, COMPLETE	
* 355	3-987-667-01	SHEET, VF LIGHT INTERCEPTION	
* 356	3-987-666-01	SHEET (860), INSULATING, VF	
357	X-3948-236-1	CABINET(REAR)(SC)(884)ASSY,EVF	
358	X-3948-229-1	LENS ASSY (860), VF	
* 359	3-960-302-11	CUSHION (1), LCD	
360	A-7073-437-A	VF-119 BOARD , COMPLETE	
362	1-668-962-11	FP-638 FLEXIBLE BOARD	
363	X-3946-886-1	HOLDER ASSY, PRISM	
LCD902	8-753-023-37	LCX024AK	
⚠ND5351	1-517-414-51	FLUORESCENT TUBE (0.55 INCH)	

6-1-9. EVF BLOCK ASSEMBLY (B/W EVF) (EXCEPT TRV93)



The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une piéce portant le numéro spécifié.

Ref. No.	Part No.	Description	Remark
401	X-3944-966-1	FINDER ASSY	
402	3-963-391-01	EYE CUP	
403	X-3948-278-1	CABINET (REAR) (878) B ASSY	(EXCEPT TRV85//TRV815)
403	X-3948-281-1	CABINET (REAR) (887) B ASSY	(TRV85/TRV815)
404	3-968-729-61	SCREW (M2X3), LOCK ACE, P2	
405	3-975-898-01	SCREW (T), F LOCK	
406	3-977-292-01	MASK, CRT	
407	3-725-130-01	COVER, HINGE VOLTAGE	
408	1-783-241-11	CABLE, FLEXIBLE FLAT (FFC-235)	
409	A-7056-774-A	VF-99(HP) BOARD, COMPLETE	(TRV15E/TRV15EP/TRV35E)
409	A-7066-792-A	VF-99(VHL4) BOARD, COMPLETE	(EXCEPT TRV15E/TRV15EP/TRV35E)

Ref. No.	Part No.	Description	Remark
410	X-3948-279-1	HOLDER (878) ASSY, CRT	
* 411	3-987-844-01	SHEET, VF (B/W) ELECTROSTATIC	
412	X-3948-277-1	CABINET (FRONT) (878) B ASSY	(TRV65/TRV65PK/TRV615)
412	X-3948-280-1	CABINET (FRONT) (887) B ASSY (TRV85)	
412	X-3948-362-1	CABINET (FRONT) (846) B ASSY	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
412	X-3948-363-1	CABINET (FRONT) (872) B ASSY	(TRV35/TRV35E)
412	X-3948-366-1	CABINET (FRONT) (887D) B ASSY (TRV815)	
413	3-948-339-61	TAPPING	
* 414	3-987-843-01	SHEET, VF FLEXIBLE LOCK	
⚠V901	1-452-673-31	CRT ASSY (M01KXX90WB)(EXCEPT TRV93)	

6-1-10. MAIN BOARDS ASSEMBLY



Ref No	Part No	Description	Remark
451	A-7073-404-A	SE-66(V) BOARD, COMPLETE	(TRV15/TRV15PK/TRV15E/TRV15EP)
451	A-7073-409-A	SE-66(VH) BOARD, COMPLETE	(TRV65/TRV65PK/TRV615)
451	A-7073-434-A	SE-67(VH) BOARD, COMPLETE	(TRV85/TRV815/TRV93)
451	A-7073-443-A	SE-66(VMM) BOARD, COMPLETE	(TRV25/TRV25PK/TRV215/TRV35/TRV35E)
452	1-668-957-11	FP-621 FLEXIBLE BOARD	
453	3-713-786-21	SCREW (M2X3)	
* 454	3-987-675-01	FRAME (B), MD	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
454	X-3948-224-1	FRAME (B) ASSY, MD	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
* 455	3-989-122-01	SHEET, LENS INSULATING	
456	A-7073-405-A	PJ-83(M) BOARD, COMPLETE	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
456	A-7073-410-A	PJ-83(H) BOARD, COMPLETE	(TRV65/TRV65PK/TRV615)
456	A-7073-433-A	PJ-84(H) BOARD, COMPLETE	(TRV85/TRV815/TRV93)
457	1-668-956-11	FP-620 FLEXIBLE BOARD	
458	1-668-960-11	FP-629 FLEXIBLE BOARD	
459	A-7073-454-A	VL-19 BOARD, COMPLETE (TRV93)	
* 460	3-987-718-01	PROTECTOR, HS FLEXIBLE	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
461	1-668-961-11	FP-632 FLEXIBLE BOARD (TRV93)	
462	3-987-719-01	BRACKET, SHOE	(TRV15 BR/TRV15PK/TRV25PK/TRV215 CND/TRV35/TRV65/TRV615/ TRV85/TRV815/TRV15E/TRV35E)
463	1-774-867-31	CONNECTOR,EXTERNAL(HOT SHOE)8P	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
463	X-3946-197-1	SHOE ASSY(TRV35/TRV35E)	
464	1-668-978-11	FP-633 FLEXIBLE BOARD	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
465	A-7093-449-A	VC-195(VHIOU) BOARD, COMPLETE	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
465	A-7093-450-A	VC-195(VMMIOU) BOARD, COMPLETE(TRV35)	
465	A-7093-451-A	VC-195(7VMMU) BOARD, COMPLETE	(TRV25/TRV25PK/TRV215)
465	A-7093-452-A	VC-195(7VZU) BOARD, COMPLETE	(TRV15/TRV15PK)
465	A-7093-455-A	VC-195(VMMOP) BOARD, COMPLETE (TRV35E)	
465	A-7093-456-A	VC-195(VZOP) BOARD, COMPLETE	(TRV15E/TRV15EP)
465	A-7093-459-A	VC-195(VHCIBOU) BOARD, COMPLETE (TRV93)	
466	A-7073-408-A	DD-105(VMMIF) BOARD, COMPLETE	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
466	A-7073-416-A	DD-105(VMMI) BOARD, COMPLETE	(TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35 E,HK/TRV15E/TRV35E)
466	A-7073-417-A	DD-105(VMMIF) BOARD, COMPLETE	(TRV15 US,CND/TRV25/TRV215)
466	A-7073-453-A	DD-105(VCIBF) BOARD, COMPLETE (TRV93)	
467	1-668-958-11	FP-622 FLEXIBLE BOARD	
468	3-987-711-01	FRAME (A), MD	
* 469	3-987-716-01	PROTECTOR, LS FLEXIBLE	
470	3-948-339-61	TAPPING	
471	2-532-810-00	CUSHION	
SE451	1-803-041-11	SENSOR, ANGULAR VELOCITY (YAW)	
SE452	1-803-041-21	SENSOR, ANGULAR VELOCITY (PITCH)	

6-1-11. BATTERY PANEL AND CCD BLOCK ASSEMBLY



Be sure to read "Note on the CCD Imager replacement" on page 4–9 when changing the CCD imager.

Ref No	Part No	Description	Remark
501	X-3948-171-1	PANEL ASSY, BATTERY (EXCEPT TRV15 BR/TRV85/TRV93/TRV815)	
501	X-3948-172-1	PANEL ASSY, BATTERY (TRV85/TRV815/TRV93)	
501	X-3948-461-1	PANEL ASSY, BATTER (TRV15 BR)	
502	3-975-752-01	LID (BT), CPC	
503	3-962-826-01	SCREW (2X4)	
× 504	3-987-683-01	LID, BATTERY	
505	3-968-729-61	SCREW (M2X3), LOCK ACE, P2	
506	3-987-656-01	LID, JACK	
507	3-713-791-51	SCREW (M1 7X3 5), TAPPING, P2	
508	1-694-384-11	TERMINAL BOARD, BATTERY	
509	3-987-679-01	SHEET METAL (LOWER), STRAP	
510	1-668-959-11	FP-623 FLEXIBLE BOARD	
511	3-318-203-11	SCREW (B1 7X6), TAPPING	
512	A-7073-407-A	CD-197 BOARD, COMPLETE (EXCEPT TRV85/TRV93/TRV815)	
512	A-7073-435-A	CD-198 BOARD, COMPLETE (TRV85/TRV815/TRV93)	
513	3-953-817-01	RUBBER (F), SEAL (TRV15/TRV15PK/TRV15E/TRV15EP)	
513	3-968-054-11	RUBBER (FM), SHIELD (EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)	
514	1-758-084-21	FILTER BLOCK, OPTICAL (EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)	
514	1-758-133-21	FILTER BLOCK, OPTICAL (TRV15/TRV15PK/TRV15E/TRV15EP)	
515	3-978-981-11	ADAPTOR (FK), CCD FITTING	
516	8-848-722-01	DEVICE, LENS LSV-600A(SOC) (TRV35/TRV65/TRV65PK/TRV615/TRV85/TRV815/TRV93/TRV35E)	
516	8-848-724-01	DEVICE, LENS LSV-601A(SOC) (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
517	3-987-712-01	FRAME, LENS	
518	3-948-339-61	TAPPING	
IC401	A-7030-862-A	CCD BLOCK ASSY (TRV15/TRV15PK)	
IC401	A-7030-865-A	CCD BLOCK ASSY (TRV25/TRV25PK/TRV215/TRV35/TRV65/TRV65PK/TRV615/TRV85/ TRV815/TRV93)	
IC401	A-7030-871-A	CCD BLOCK ASSY (TRV35E)	
IC401	A-7030-874-A	CCD BLOCK ASSY (TRV15E/TRV15EP)	

6-1-12. DEVICE LENS (LSV-600A/LSV-601A)


551
NIGHT SHOT Model
CCD-TRV35/TRV35E/TRV65
/TRV65PK/TRV85/TRV815
/TRV93
554
557
555
556
M906
552
M905
553
552
552
553

Ref No	Part No	Description	Remark
551	8-848-722-01	DEVICE, LENS LSV-600A(SOC)(NIGHT SHOT) (TRV35/TRV65/TRV65PK/TRV615/TRV85/TRV815/TRV93/TRV35E)	
551	8-848-724-01	DEVICE, LENS LSV-601A(SOC) (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
552	3-713-791-51	SCREW (M1 7X3 5), TAPPING, P2	
553	3-713-791-41	SCREW (M1 7X5), TAPPING, PS	
554	3-979-029-01	LEVER, IR	

Ref No	Part No	Description	Remark
555	2-327-405-01	WASHER	
556	3-623-756-21	SCREW (B1 7x5), P	
557	3-979-037-11	SPRING, RETURN	
M905	1-763-047-11	MOTOR, FOCUS STEPPING	
M906	1-763-046-11	MOTOR, ZOOM STEPPING	

6-1-13. CASSETTE COMPARTMENT ASSEMBLY


704
708
708
711
705
706
703
709
707
708
712
702
710
701
LS CHASSIS BLOCK SECTION (See page 6-14)
MECHANISM CHASSIS BLOCK SECTION (See page 6-15)

Ref. No.	Part No.	Description	Remark
701	A-7040-421-A	DAMPER ASSY	
702	7-624-102-04	STOP RING 1.5, TYPE -E	
703	X-3945-400-X	CASSETTE COMPARTMENT ASSY	
704	3-965-587-03	SPRING, TENSION	
705	3-965-584-08	RETAINER, GOOSENECK	
706	3-976-055-01	SCREW (M1.4X1)	

Ref. No.	Part No.	Description	Remark
707	X-3945-399-1	GEAR ASSY, GOOSENECK	
708	3-947-503-01	SCREW (M1.4X2.5)	
709	3-331-007-21	WASHER	
710	3-727-176-01	WASHER, STOPPER	
711	3-973-268-01	SPRING, TENSION	
712	3-971-076-01	FASTENER, D	

6-1-14. LS CHASSIS ASSEMBLY


762
793
772
771
S002
S001
778
779
773
780
761
775
777
781
760
A
774
782
D001
767
776
784
FP-249
(not supplied)
765
769
769
785
766
768
770
758
778
759
783
758
786
787
758
757
758
789
752
753
754
788
763
A
756
791
792
751
755
790
764

Ref No	Part No	Description	Remark
751	A-7040-419-A	BASE (S) BLOCK ASSY, GUIDE	
752	A-7040-418-B	BASE (T) BLOCK ASSY, GUIDE	
753	3-965-559-01	STOPPER (T)	
754	3-965-557-01	STOPPER (T), GB	
755	3-965-558-01	STOPPER (S)	
756	3-965-556-01	STOPPER (S), GB	
757	3-965-553-01	RAIL, GUIDE	
758	3-947-503-01	SCREW (M1 4X2 5)	
759	3-965-573-01	RETAINER, TG4	
760	1-658-213-11	FP-355 FLEXIBLE BOARD	
761	3-965-552-01	HOLDER (T), SENSOR	
762	1-657-786-13	FP-221 FLEXIBLE BOARD	
763	3-965-551-01	HOLDER (S), SENSOR	
764	1-658-214-11	FP-356 FLEXIBLE BOARD	
765	A-7040-417-A	ARM BLOCK ASSY, TG4	
766	3-965-574-01	SPRING, TORSION	
767	3-965-575-01	SPRING (PINCH), TORSION	
768	3-965-568-01	GUIDE, LOCK	
769	3-965-562-01	SPRING (RATCHET), TENSION	
770	3-965-581-03	RATCHET, T	
771	X-3945-394-1	ARM ASSY, PINCH	
772	X-3945-398-2	DECK ASSY, REEL, T	
773	3-965-648-01	SPRING (PINCH), TENSION	
774	3-965-579-01	ROLLER, PINCH PRESS	
775	3-965-563-01	GEAR, T SOFT	
776	3-965-565-01	CLAW, T SOFT	
777	X-3945-397-1	DECK ASSY, REEL, S	
778	X-3945-396-1	BAND ASSY, TENSION REGULATOR	
779	3-945-756-01	SCREW (M1 4X3)	
780	3-965-583-01	ARM, RVS	
781	3-965-580-01	SPRING, TENSION	
782	3-966-384-01	SPRING, T SOFT	
783	3-965-578-01	SPRING, TENSION COIL	
784	3-965-560-01	RATCHET, S	
785	3-965-561-01	PLATE, RELEASE, S RATCHET	
786	X-3945-395-1	ARM ASSY, TG1	
787	3-965-576-01	SPRING (TG1), TENSION	
788	3-965-567-01	LID OPEN	
789	3-965-566-01	COVER, LS GUIDE	
* 790	3-965-577-01	PLATE, CAM, LS	
791	3-965-569-01	ARM, EJ	
792	A-7040-427-A	CHASSIS (S1) ASSY, LS	
* 793	3-972-838-01	SPACER, REEL	
D001	8-719-988-42	DIODE GL453	
S001	1-692-614-11	SWITCH, PUSH (3 KEY) (Hi8 MP, ME/MP, REC PROOF)	
S002	1-572-688-11	SWITCH, PUSH (1 KEY)(C C LOCK)	

6-1-15. MECHANISM CHASSIS ASSEMBLY


M901
809
809
817
810
812
823
805
811
806
M903
828
808
813
814
807
830
813
809
829
821
803
831
824
805
805
815
825
819
816
820
837
815
826
M902
836
S901
827
814
835
822
804
818
not supplied
802
801
832
not supplied
808
833
834

Ref No	Part No	Description	Remark
801	X-3947-343-1	GROUND (IM) ASSY, SHAFT	
802	3-965-550-02	SCREW (M1 7X1 6)	
803	1-657-785-11	FP-248 FLEXIBLE BOARD	
804	3-965-545-01	SPACER, CAPSTAN	
805	3-965-549-01	SCREW (M1 4 X 6 5)	
806	3-966-349-01	HOLDER, FLEXIBLE	
807	3-971-644-01	SLIDER (2), M	
808	3-971-939-01	SCREW (M1 4)	
809	3-947-503-01	SCREW (M1 4X2 5)	
810	A-7040-416-A	BASE BLOCK ASSY, DRUM	
811	3-965-527-01	GEAR, CHANGE	
812	3-965-544-01	GEAR, RELAY	
813	3-331-007-21	WASHER	
814	3-965-546-01	BELT, TIMING	
815	3-965-533-01	ROLLER, LS	
816	3-965-528-01	GEAR, CAM	
817	1-657-784-11	FP-220 FLEXIBLE BOARD	
818	3-965-529-01	PLATE, REGULATOR (LIMITTER ARM T), COIL	
819	3-965-536-01	SPRING (LIMITTER ARM T), COIL	
820	X-3945-388-1	SLIDER ASSY, GL	
821	3-965-532-01	ARM, LS	
822	3-965-535-01	SPRING (LIMITTER ARM S), COIL	
823	3-965-542-01	SHIELD, MOTOR	
824	3-965-539-01	GEAR (A)	
825	3-965-538-01	SLEEVE, MOTOR HOLDER	
826	3-965-540-01	HOLDER, MOTOR	
827	3-965-541-01	SHAFT, WORM	
828	3-321-393-01	WASHER, STOPPER	
829	3-965-724-01	SPRING, TORSION	
830	A-7040-423-A	ROLLER BLOCK ASSY, HC	
831	X-3945-407-1	ARM ASSY, HC ROLLER	
832	3-965-531-01	ARM, GL	
833	3-965-530-01	PLATE (2), REGULATOR, TENSION	
834	X-3947-915-2	CHASSIS ASSY, MECHANICAL	
835	3-965-526-02	ROLLER, LS GUIDE	
836	3-965-547-01	ARM, HC DRIVING	
837	3-965-534-01	PLATE, PRESS, PINCH	
M901	A-7048-851-A	DRUM ASSY (DGH-0D5A-R)(PAL) (TRV15E/TRV15EP/35E)	
M901	A-7048-842-A	DRUM ASSY (DGH-0E1A-R)(NTSC)(5HEAD) (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
M901	A-7048-870-A	DRUM ASSY (DGH-0E3A-R)(NTSC)(3HEAD) (TRV15/TRV15PK/TRV25/TRV25PK/TRV35TRV215)	
M902	8-835-531-32	CAPSTAN ASSY	
M903	X-3945-401-1	MOTOR ASSY, DC (LOADING)	
S901	1-762-436-15	SWITCH, ROTARY (ENCODER)	

6-2. ELECTRICAL PARTS LIST

Note

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety.
Replace only with part number specified.

Les composants identifiés par une marque ⚠ sont critiques pour la sécurité.
Ne les remplacer que par une pièce portant le numéro spécifié.

When indicating parts by reference number, please include the board name.

- Due to standardization, replacements in the parts list may be different from the parts specified in the diagrams or the components used on the set.
- -XX, -X mean standardized parts, so they may have some difference from the original one.
- Items marked "*" are not stocked since they are seldom required for routine service. Some delay should be anticipated when ordering these items.
- RESISTORS
  All resistors are in ohms.
  METAL: Metal-film resistor.
  METAL OXIDE: Metal Oxide-film resistor.
  F: nonflammable
- SEMICONDUCTORS
  In each case, u: μ, for example:
  uA : μA , uPA : μPA , uPB : μPB , uPC : μPC , uPD : μPD
- CAPACITORS
  uF: μF
- COILS
  uH: μH
- Abbreviation
  Canadian model is abbreviated as CND
  East European model is abbreviated as EE
  Hong Kong model is abbreviated as HK
  North European model is abbreviated as NE
  Russian model is abbreviated as RU
  Chinese model is abbreviated as CN
  Tourist model is abbreviated as JE
  Brazilian model is abbreviated as BR
  Australian model is abbreviated as AUS

Ref No	Part No	Description	Remark
	A-7073-407-A	CD-197 BOARD, COMPLETE ************************** (EXCEPT TRV85/TRV93/TRV815) (Ref.No. 4,000 Series)	
	A-7073-435-A	CD-198 BOARD, COMPLETE ************************** (TRV85/TRV93/TRV815) (Ref.No. 9,000 Series) (IC401 is not including to the mounted board)	
		< CAPACITOR >	
C401	1-164-156-11	CERAMIC CHIP 0.1uF 25V	
C405	1-135-210-11	TANTALUM CHIP 4.7uF 20% 10V	
C406	1-135-214-21	TANTAL. CHIP 4.7uF 20% 20V	
		< CONNECTOR >	
CN401	1-766-346-21	CONNECTOR, FFC/FPC 16P	
		< IC >	
IC401	A-7030-862-A	CCD BLOCK ASSY (206 SERVICE)(CCD IMAGR) (TRV15/TRV15PK)	
IC401	A-7030-865-A	CCD BLOCK ASSY (209 SERVICE)(CCD IMAGR) (TRV25/TRV25PK/TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV215/TRV615/TRV815)	
IC401	A-7030-871-A	CCD BLOCK ASSY (211 SERVICE)(CCD IMAGR) (TRV35E)	
IC401	A-7030-874-A	CCD BLOCK ASSY (207 SERVICE)(CCD IMAGR) (TRV15E/TRV15EP)	
		< COIL >	
L401	1-414-757-11	INDUCTOR 100uH	
		< TRANSISTOR >	
Q402	8-729-117-73	TRANSISTOR 2SC4178-F13F14-T1	
		< RESISTOR >	
R404	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R405	1-216-809-11	METAL CHIP 100 5% 1/16W	

Ref No	Part No	Description	Remark
	A-7073-403-A	CF-50(E7V) BOARD, COMPLETE ************************** (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
	A-7073-412-A	CF-50(ESV) BOARD, COMPLETE ************************** (TRV35/TRV35E/TRV65/TRV65PK/TRV615) (Ref.No. 4,000 Series)	
	A-7073-431-A	CF-51(VH) BOARD, COMPLETE ************************** (TRV85/TRV815)	
	A-7073-456-A	CF-51(VHC) BOARD, COMPLETE (TRV93) ************************** (Ref.No. 9,000 Series)	
		< BATTERY HOLDER >	
BH001	1-550-104-11	HOLDER, BATTERY	
		< CONNECTOR >	
CN001	1-778-637-21	CONNECTOR, FFC/FPC (ZIF) 50P	
CN002	1-774-765-11	CONNECTOR, FFC/FPC 8P	
CN003	1-580-055-21	PIN, CONNECTOR 2P	
CN005	1-779-064-11	PIN, CONNECTOR (PC BOARD) 12P	
CN006	1-778-508-21	PIN, CONNECTOR (PC BOARD) 6P	
CN007	1-779-334-11	CONNECTOR, FFC/FPC 20P (TRV93)	
CN008	1-778-283-11	CONNECTOR, FFC/FPC 4P (EXCEPT TRV93)	
		< DIODE >	
D001	8-719-059-57	DIODE MAZJ082DFLSO	
D005	8-719-420-14	DIODE MA8082-TX	
D006	8-719-420-14	DIODE MA8082-TX	
D008	8-719-404-49	DIODE MA111-TX	

Be sure to read "Note on the CCD Imager replacement" on page 4-9 when changing the CCD imager.

Ref No	Part No	Description			Remark
		< TRANSISTOR >			
Q001	8-729-402-42	TRANSISTOR UN5213-TX (EXCEPT TRV93)			
Q003	8-729-230-63	TRANSISTOR 2SD1819A-QRS-TX			
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
Q005	8-729-230-72	TRANSISTOR 2SA1362-YG-EL			
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
		< RESISTOR >			
R003	1-216-833-11	METAL CHIP	10K	5%	1/16W
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
R005	1-216-833-11	METAL CHIP	10K	5%	1/16W
R006	1-216-833-11	METAL CHIP	10K	5%	1/16W
R007	1-216-833-11	METAL CHIP	10K	5%	1/16W
R008	1-216-833-11	METAL CHIP	10K	5%	1/16W
R009	1-216-833-11	METAL CHIP	10K	5%	1/16W
R013	1-216-822-11	METAL CHIP	1 2K	5%	1/16W
R015	1-216-822-11	METAL CHIP	1 2K	5%	1/16W
R016	1-216-822-11	METAL CHIP	1 2K	5%	1/16W
R019	1-216-823-11	METAL CHIP	1 5K	5%	1/16W
R020	1-216-823-11	METAL CHIP	1 5K	5%	1/16W
R022	1-216-823-11	METAL CHIP	1 5K	5%	1/16W
R023	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R025	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R026	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R029	1-216-828-11	METAL CHIP	3 9K	5%	1/16W
R031	1-216-828-11	METAL CHIP	3 9K	5%	1/16W
R032	1-216-828-11	METAL CHIP	3 9K	5%	1/16W
R036	1-216-832-11	METAL CHIP	8 2K	5%	1/16W
R038	1-216-832-11	METAL CHIP	8 2K	5%	1/16W
R039	1-216-838-11	METAL CHIP	27K	5%	1/16W
R041	1-216-838-11	METAL CHIP	27K	5%	1/16W
R049	1-216-849-11	METAL CHIP	220K	5%	1/16W
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
R050	1-216-853-11	METAL CHIP	470K	5%	1/16W
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
R051	1-216-837-11	METAL CHIP	22K	5%	1/16W
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
R052	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
R053	1-216-864-11	METAL CHIP	0	5%	1/16W
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
		< SWITCH >			
S003	1-762-851-21	SWITCH, KEY BOARD (DATE)			
S004	1-771-029-21	SWITCH, TACTILE (PROGRAM AE)			
S006	1-762-851-21	SWITCH, KEY BOARD (PICTURE EFFECT)			
S008	1-762-851-21	SWITCH, KEY BOARD (COUNTER RESET)			
S010	1-762-851-21	SWITCH, KEY BOARD (MENU)			
S012	1-771-029-21	SWITCH, TACTILE (EXPOSERE)			
		(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
S013	1-762-851-21	SWITCH, KEY BOARD (END SEARCH)			
S015	1-771-025-21	SWITCH, ROTARY (ENCODER) (SEL/PUSH ENCH)			
S017	1-771-029-21	SWITCH, TACTILE (BACK LIGHT)			
S018	1-762-851-21	SWITCH, KEY BOARD (TITLE)			
S021	1-762-851-21	SWITCH, KEY BOARD (TIME)			
S022	1-762-851-21	SWITCH, KEY BOARD (DISPLAY)			
S024	1-762-648-21	SWITCH, SLIDE (START/STOP MODE)			
S027	1-771-029-21	SWITCH, TACTILE (FADER)(TRV85/TRV815/TRV93)			

Ref No	Part No	Description				Remark
	A-7073-408-A	DD-105(VMMIF) BOARD, COMPLETE				
		(TRV65/TRV65PK/TRV85/TRV615/TRV815)				
	A-7073-416-A	DD-105(VMMI) BOARD, COMPLETE				
		(TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)				
	A-7073-417-A	DD-105(VMMIF) BOARD, COMPLETE				
		(TRV15 US,CND/TRV25/TRV215)				
	A-7073-453-A	DD-105(VCIBF) BOARD, COMPLETE (TRV93)				
		(Ref No 2,000 Series)				
		< CAPACITOR >				
C801	1-162-967-11	CERAMIC CHIP	0 0033uF	10%	50V	
C802	1-162-960-11	CERAMIC CHIP	220PF	10%	50V	
C803	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V	
C804	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V	
C805	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V	
C806	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V	
C807	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V	
C808	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V	
C809	1-162-967-11	CERAMIC CHIP	0 0033uF	10%	50V	
C810	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V	
C811	1-162-965-11	CERAMIC CHIP	0 0015uF	10%	50V	
C812	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V	
C813	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V	
C814	1-104-913-11	TANTAL CHIP	10uF	20%	16V	
C815	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V	
C816	1-119-751-91	TANTAL CHIP	22uF	20%	16V	
C817	1-113-991-11	TANTAL CHIP	33uF	20%	16V	
C819	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V	
C820	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V	
C821	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V	
C822	1-104-913-11	TANTAL CHIP	10uF	20%	16V	
C823	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C824	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C825	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C826	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C827	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V	
C828	1-162-962-11	CERAMIC CHIP	470PF	10%	50V	
C829	1-162-966-11	CERAMIC CHIP	0 0022uF	10%	50V	
C830	1-162-966-11	CERAMIC CHIP	0 0022uF	10%	50V	
C831	1-164-489-11	CERAMIC CHIP	0 22uF	10%	16V	
C832	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C833	1-162-974-11	CERAMIC CHIP	0 01uF		50V	
C834	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C836	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C837	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C838	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C840	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V	
C841	1-135-157-21	TANTALUM CHIP	10uF	20%	6 3V	
C843	1-135-157-21	TANTALUM CHIP	10uF	20%	6 3V	
C844	1-135-157-21	TANTALUM CHIP	10uF	20%	6 3V	
C846	1-135-157-21	TANTALUM CHIP	10uF	20%	6 3V	

Ref. No.	Part No.	Description	Remark
C847	1-164-506-11	CERAMIC CHIP 4.7uF	16V
C848	1-164-506-11	CERAMIC CHIP 4.7uF	16V
C849	1-135-157-21	TANTALUM CHIP 10uF 20%	6.3V
C850	1-135-157-21	TANTALUM CHIP 10uF 20%	6.3V
C851	1-135-157-21	TANTALUM CHIP 10uF 20%	6.3V
C852	1-164-505-11	CERAMIC CHIP 2.2uF	16V
C853	1-165-319-11	CERAMIC CHIP 0.1uF	50V
C854	1-135-157-21	TANTALUM CHIP 10uF 20%	6.3V (TRV93)
C855	1-135-157-21	TANTALUM CHIP 10uF 20%	6.3V
C856	1-109-982-11	CERAMIC CHIP 1uF 10% (TRV65/TRV65PK/TRV85/TRV615/TRV815)	10V
C857	1-135-157-21	TANTALUM CHIP 10uF 20%	6.3V
C860	1-107-826-11	CERAMIC CHIP 0.1uF 10%	16V
C861	1-162-970-11	CERAMIC CHIP 0.01uF 10%	25V (TRV93)
C861	1-165-176-11	CERAMIC CHIP 0.047uF 10%	16V (EXCEPT TRV93)
C862	1-164-227-11	CERAMIC CHIP 0.022uF 10%	25V
C863	1-164-227-11	CERAMIC CHIP 0.022uF 10%	25V
C864	1-113-985-11	TANTAL. CHIP 10uF 20%	20V
C865	1-164-505-11	CERAMIC CHIP 2.2uF	16V
C866	1-164-505-11	CERAMIC CHIP 2.2uF	16V
C867	1-164-346-11	CERAMIC CHIP 1uF	16V (TRV93)
C868	1-135-214-21	TANTAL. CHIP 4.7uF 20%	20V
C869	1-164-505-11	CERAMIC CHIP 2.2uF	16V
C871	1-135-157-21	TANTALUM CHIP 10uF 20%	6.3V
C872	1-164-227-11	CERAMIC CHIP 0.022uF 10%	25V
C873	1-164-227-11	CERAMIC CHIP 0.022uF 10%	25V
C875	1-164-489-11	CERAMIC CHIP 0.22uF 10%	16V
C876	1-107-826-11	CERAMIC CHIP 0.1uF 10%	16V
C877	1-107-826-11	CERAMIC CHIP 0.1uF 10%	16V
		< CONNECTOR >	
CN801	1-580-756-21	PIN, CONNECTOR 7P	
CN931	1-691-520-11	CONNECTOR, BOARD TO BOARD 48P	
CN932	1-766-346-21	CONNECTOR, FFC/FPC 16P	
CN933	1-778-509-21	PIN, CONNECTOR (PC BOARD) 11P	
CN934	1-766-673-21	CONNECTOR, FFC/FPC 12P	
CN935	1-764-709-11	CONNECTOR, FFC/FPC (LIF) 10P	
		< DIODE >	
D801	8-719-067-36	DIODE MA3ZD1200LS0	
D802	8-719-067-36	DIODE MA3ZD1200LS0	
D803	8-719-067-36	DIODE MA3ZD1200LS0	
D804	8-719-067-36	DIODE MA3ZD1200LS0	
D805	8-719-067-36	DIODE MA3ZD1200LS0	
D806	8-719-027-76	DIODE 1SS357-TPH3	
D807	8-719-067-36	DIODE MA3ZD1200LS0	
D809	8-719-027-77	DIODE MA796-TX	
D810	8-719-027-76	DIODE 1SS357-TPH3	
D812	8-719-027-76	DIODE 1SS357-TPH3	
D813	8-719-420-14	DIODE MA8082-TX	
D814	8-719-420-14	DIODE MA8082-TX	
D815	8-719-420-14	DIODE MA8082-TX	
D816	8-719-027-76	DIODE 1SS357-TPH3	
D817	8-719-421-27	DIODE MA728-TX	
D818	8-719-027-76	DIODE 1SS357-TPH3	
D819	8-719-027-76	DIODE 1SS357-TPH3 (TRV65/TRV65PK/TRV85/TRV615/TRV815)	
D932	8-719-045-87	DIODE MA4Z082WA-(K8) SO	
D933	8-719-045-87	DIODE MA4Z082WA-(K8) SO	
D934	8-719-045-87	DIODE MA4Z082WA-(K8) SO	
D935	8-719-045-87	DIODE MA4Z082WA-(K8) SO	
D936	8-719-045-87	DIODE MA4Z082WA-(K8) SO	
D938	8-719-420-14	DIODE MA8082-TX	
		< FERRITE BEAD >	
FB931	1-414-228-11	FERRITE 0UH	
FB932	1-414-228-11	FERRITE 0UH	
FB933	1-414-228-11	FERRITE 0UH	
FB934	1-414-228-11	FERRITE 0UH	
		< IC >	
IC801	8-759-384-78	IC SN104241PM-TEB	
IC802	8-759-492-30	IC MB3817PFV-G-BND	
		< COIL >	
L804	1-412-056-11	INDUCTOR CHIP 4.7uH	
L805	1-424-674-11	COIL, CHOKE 22uH	
L806	1-409-532-41	COIL, CHOKE 33uH	
L806	1-424-675-11	COIL, CHOKE 33uH	
L807	1-424-674-11	COIL, CHOKE 22uH	
L808	1-424-674-11	COIL, CHOKE 22uH	
L809	1-424-674-11	COIL, CHOKE 22uH	
L810	1-414-396-21	INDUCTOR 4.7uH	
L811	1-414-396-21	INDUCTOR 4.7uH	
L812	1-414-396-21	INDUCTOR 4.7uH	
L813	1-414-396-21	INDUCTOR 4.7uH	
L814	1-414-396-21	INDUCTOR 4.7uH	
L815	1-414-396-21	INDUCTOR 4.7uH	
L816	1-414-396-21	INDUCTOR 4.7uH (TRV93)	
L817	1-414-396-21	INDUCTOR 4.7uH	
L818	1-414-396-21	INDUCTOR 4.7uH	
L819	1-414-400-11	INDUCTOR 22uH	
L820	1-424-674-11	COIL, CHOKE 22uH	
		< FILTER >	
LF801	1-411-957-11	FILTER, COMMON MODE	
		< FUSE, IC LINK >	
⚠PS801	1-533-760-21	FUSE (SMD) 1.4A (EXCEPT TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)	
⚠PS801	1-533-761-21	LINK, IC (SMD) 1.4A (TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)	
⚠PS802	1-533-760-21	FUSE (SMD) 1.4A (EXCEPT TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)	
⚠PS802	1-533-761-21	LINK, IC (SMD) 1.4A (TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)	
⚠PS803	1-533-760-21	FUSE (SMD) 1.4A (EXCEPT TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref No	Part No	Description	Remark
⚠PS803	1-533-761-21	LINK, IC (SMD) 1 4A	(TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)
⚠PS804	1-533-760-21	FUSE (SMD) 1 4A	(EXCEPT TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)
⚠PS804	1-533-761-21	LINK, IC (SMD)	(TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)
⚠PS805	1-533-760-21	FUSE (SMD) 1 4A	(EXCEPT TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)
⚠PS805	1-533-761-21	LINK, IC (SMD) 1 4A	(TRV15 E,HK,BR/TRV15PK/TRV25PK/TRV35/TRV15E/TRV15EP/TRV35E)
⚠PS806	1-533-760-21	FUSE (SMD) 1 4A	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

< TRANSISTOR >

Ref No	Part No	Description	Remark
Q801	8-729-024-48	TRANSISTOR 2SK1830-TE85L	
Q802	8-729-041-69	TRANSISTOR MMSF5P02HDR2	
Q803	8-729-804-41	TRANSISTOR 2SB1122-ST-TD	
Q804	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q805	8-729-024-48	TRANSISTOR 2SK1830-TE85L	
Q806	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q807	8-729-804-41	TRANSISTOR 2SB1122-ST-TD	
Q808	8-729-043-94	TRANSISTOR CPH3106-TL	
Q809	8-729-043-94	TRANSISTOR CPH3106-TL	
Q810	8-729-043-94	TRANSISTOR CPH3106-TL	
Q812	8-729-041-24	TRANSISTOR NDS355AN	
Q813	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q814	8-729-043-94	TRANSISTOR CPH3106-TL	
Q815	8-729-043-94	TRANSISTOR CPH3106-TL	
Q817	8-729-041-24	TRANSISTOR NDS355AN	
Q819	8-729-043-94	TRANSISTOR CPH3106-TL	
Q820	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
Q823	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q824	8-729-042-56	TRANSISTOR MGSF3455VT1	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
Q826	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q827	8-729-037-61	TRANSISTOR UN9113J-(K8) SO	
Q828	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q829	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q830	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q831	8-729-041-23	TRANSISTOR NDS356AP	
Q832	8-729-041-23	TRANSISTOR NDS356AP	
Q833	8-729-041-23	TRANSISTOR NDS356AP	
Q834	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q835	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q836	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q837	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)(TRV93)	
Q838	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q839	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q840	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q841	8-729-037-53	TRANSISTOR 2SA1832F-Y/GR(TPL3)(TRV93)	
Q842	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q843	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q844	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q845	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q846	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)(TRV93)	
Q847	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	

Ref No	Part No	Description	Remark
Q848	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q849	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q850	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q851	8-729-041-69	TRANSISTOR MMSF5P02HDR2	
Q852	8-729-017-61	TRANSISTOR 2SB1581-T1	
Q853	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q854	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q855	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q856	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q932	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q933	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q934	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	

< RESISTOR >

Ref No	Part No	Description	Remark
R801	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R802	1-218-893-11	RES,CHIP 82K 0 50% 1/16W	
R803	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R804	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R805	1-216-835-11	METAL CHIP 15K 5% 1/16W	
R806	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R807	1-216-839-11	METAL CHIP 33K 5% 1/16W	
R808	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R809	1-216-813-11	METAL CHIP 220 5% 1/16W	
R810	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R811	1-218-883-11	RES,CHIP 33K 0 50% 1/16W	
R812	1-218-901-11	RES,CHIP 180K 0 50% 1/16W	
R813	1-216-857-11	METAL CHIP 1M 5% 1/16W	
R814	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R815	1-216-813-11	METAL CHIP 220 5% 1/16W	
R816	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R817	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R818	1-216-813-11	METAL CHIP 220 5% 1/16W	
R819	1-218-887-11	RES,CHIP 47K 0 50% 1/16W	
R820	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R821	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R822	1-216-150-91	RES,CHIP 10 5% 1/8W	
R824	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R825	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R826	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R827	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R828	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	
R829	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R830	1-218-883-11	RES,CHIP 33K 0 50% 1/16W	
R831	1-216-841-11	METAL CHIP 47K 5% 1/16W	
R832	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R833	1-216-839-11	METAL CHIP 33K 5% 1/16W	
R834	1-218-883-11	RES,CHIP 33K 0 50% 1/16W	
R835	1-218-879-11	RES,CHIP 22K 0 50% 1/16W	
R836	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R837	1-216-825-11	METAL CHIP 2 2K 5% 1/16W	
R838	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R839	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R840	1-216-839-11	METAL CHIP 33K 5% 1/16W	
R841	1-216-834-11	METAL CHIP 12K 5% 1/16W	
R842	1-216-849-11	METAL CHIP 220K 5% 1/16W	
R843	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R845	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R849	1-216-837-11	METAL CHIP 22K 5% 1/16W	

Ref No	Part No	Description			Remark
R850	1-216-857-11	METAL CHIP	1M	5%	1/16W
R852	1-216-823-11	METAL CHIP	1 5K	5%	1/16W
R853	1-216-849-11	METAL CHIP	220K	5%	1/16W
R854	1-216-841-11	METAL CHIP	47K	5%	1/16W
R859	1-216-845-11	METAL CHIP	100K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV615/TRV815)
R864	1-216-857-11	METAL CHIP	1M	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV615/TRV815)
R865	1-216-841-11	METAL CHIP	47K	5%	1/16W
R866	1-216-837-11	METAL CHIP	22K	5%	1/16W
R867	1-216-296-91	SHORT	0	(TRV93)	
R868	1-216-849-11	METAL CHIP	220K	5%	1/16W
R870	1-216-857-11	METAL CHIP	1M	5%	1/16W
R871	1-216-857-11	METAL CHIP	1M	5%	1/16W
R872	1-216-845-11	METAL CHIP	100K	5%	1/16W
R873	1-216-841-11	METAL CHIP	47K	5%	1/16W
R874	1-216-857-11	METAL CHIP	1M	5%	1/16W
R875	1-216-849-11	METAL CHIP	220K	5%	1/16W
R876	1-216-845-11	METAL CHIP	100K	5%	1/16W
R878	1-216-857-11	METAL CHIP	1M	5%	1/16W
R879	1-216-837-11	METAL CHIP	22K	5%	1/16W
R880	1-218-895-11	RES,CHIP	100K	0 50%	1/16W
R881	1-216-864-11	METAL CHIP	0	5%	1/16W
R882	1-218-903-11	RES,CHIP	220K	0 50%	1/16W
R883	1-216-841-11	METAL CHIP	47K	5%	1/16W
R884	1-216-845-11	METAL CHIP	100K	5%	1/16W
R885	1-216-845-11	METAL CHIP	100K	5%	1/16W
					(TRV93)
R887	1-216-849-11	METAL CHIP	220K	5%	1/16W
R888	1-216-845-11	METAL CHIP	100K	5%	1/16W
R889	1-216-841-11	METAL CHIP	47K	5%	1/16W
					(TRV93)
R890	1-216-845-11	METAL CHIP	100K	5%	1/16W
R891	1-218-895-11	RES,CHIP	100K	0 50%	1/16W
R892	1-218-903-11	RES,CHIP	220K	0 50%	1/16W
R893	1-216-835-11	METAL CHIP	15K	5%	1/16W
R894	1-216-861-11	METAL CHIP	2 2M	5%	1/16W
					(TRV93)
R895	1-216-837-11	METAL CHIP	22K	5%	1/16W
R896	1-218-903-11	RES,CHIP	220K	0 50%	1/16W
R897	1-218-891-11	RES,CHIP	68K	0 50%	1/16W
R898	1-218-895-11	RES,CHIP	100K	0 50%	1/16W
					(TRV93)
R899	1-218-883-11	RES,CHIP	33K	0 50%	1/16W
					(TRV93)
R900	1-218-895-11	RES,CHIP	100K	0 50%	1/16W
R901	1-218-887-11	RES,CHIP	47K	0 50%	1/16W
R902	1-216-864-11	METAL CHIP	0	5%	1/16W
R903	1-216-845-11	METAL CHIP	100K	5%	1/16W
R904	1-216-849-11	METAL CHIP	220K	5%	1/16W
R905	1-218-901-11	RES,CHIP	180K	0 50%	1/16W
R906	1-216-833-11	METAL CHIP	10K	5%	1/16W
R907	1-218-903-11	RES,CHIP	220K	0 50%	1/16W
R908	1-216-841-11	METAL CHIP	47K	5%	1/16W
R910	1-216-833-11	METAL CHIP	10K	5%	1/16W
R911	1-218-883-11	RES,CHIP	33K	0 50%	1/16W
R912	1-218-879-11	RES,CHIP	22K	0 50%	1/16W
R913	1-216-857-11	METAL CHIP	1M	5%	1/16W

Ref No	Part No	Description			Remark
R914	1-216-811-11	METAL CHIP	150	5%	1/16W
R915	1-216-853-11	METAL CHIP	470K	5%	1/16W
R916	1-216-864-11	METAL CHIP	0	5%	1/16W
					(TRV93)
R917	1-216-864-11	METAL CHIP	0	5%	1/16W
					(EXCEPT TRV93)
R918	1-216-849-11	METAL CHIP	220K	5%	1/16W
R921	1-216-296-91	SHORT	0		
R922	1-216-296-91	SHORT	0		
R923	1-216-296-91	SHORT	0		
R924	1-216-849-11	METAL CHIP	220K	5%	1/16W
R932	1-216-841-11	METAL CHIP	47K	5%	1/16W
R933	1-216-821-11	METAL CHIP	1K	5%	1/16W
R934	1-216-821-11	METAL CHIP	1K	5%	1/16W
R935	1-216-821-11	METAL CHIP	1K	5%	1/16W
R936	1-216-821-11	METAL CHIP	1K	5%	1/16W
R937	1-216-821-11	METAL CHIP	1K	5%	1/16W
R938	1-216-821-11	METAL CHIP	1K	5%	1/16W
R939	1-216-821-11	METAL CHIP	1K	5%	1/16W
R940	1-216-819-11	METAL CHIP	680	5%	1/16W
R941	1-216-821-11	METAL CHIP	1K	5%	1/16W
R942	1-216-821-11	METAL CHIP	1K	5%	1/16W
R943	1-216-029-00	METAL CHIP	150	5%	1/10W
		< TRANSFORMER >			
⚠T801	1-429-565-21	TRANSFORMER, CONVERTER			

Ref No	Part No	Description	Remark
	1-658-213-11	FP-355 FLEXIBLE PRINT BOARD ******************************	
			(Ref No 10,000 Series)
		< DIODE >	
D001	8-719-988-42	DIODE GL453S	

Ref No	Part No	Description	Remark
	1-658-214-11	FP-356 FLEXIBLE BOARD **********************	
			(Ref No 10,000 Series)
	3-965-551-01	HOLDER (S), SENSOR	
	3-965-552-01	HOLDER (T), SENSOR	
		< HALL ELEMENT >	
H001	8-719-033-37	ELEMENT, HALL HW-105C	
H002	8-719-033-37	ELEMENT, HALL HW-105C	
		< TRANSISTOR >	
Q001	8-729-907-25	PHOTO TRANSISTOR PT4850F	
Q002	8-729-907-25	PHOTO TRANSISTOR PT4850F	
		< SWITCH >	
S001	1-692-614-11	SWITCH, PUSH (3 KEY)	
			(Hi8MP,ME/MP,REC PROOF)
S002	1-572-688-11	SWITCH, PUSH (1 KEY)(C C LOCK)	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

Ref. No.	Part No.	Description			Remark
		FP-433 FLEXIBLE BOARD			
		**********************			
					(Ref. No. 10,000 Series)
		< CAPACITOR >			
C9001	1-164-004-11	CERAMIC CHIP	0.1uF	10%	25V
C9002	1-164-005-11	CERAMIC CHIP	0.47uF		25V
C9003	1-164-360-11	CERAMIC CHIP	0.1uF		16V
		< DIODE >			
D9001	8-719-038-33	DIODE THS120-TE85L			
		< RESISTOR >			
R9001	1-216-789-11	METAL CHIP	2.2	5%	1/16W
R9002	1-216-840-11	METAL CHIP	39K	5%	1/16W
R9003	1-216-857-11	METAL CHIP	1M	5%	1/16W

Ref. No.	Part No.	Description			Remark
	A-7073-439-A	LB-54 BOARD, COMPLETE (TRV93)			
		*******************************			
					(Ref. No. 10,000 Series)
		< CAPACITOR >			
C5351	1-113-642-11	TANTAL CHIP	47uF	20%	10V
C5352	1-115-566-11	CERAMIC CHIP	4.7uF	10%	10V
C5353	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C5354	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C5355	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
C5356	1-163-020-00	CERAMIC CHIP	0.0082uF	10%	50V
		< CONNECTOR >			
CN5351	1-784-564-11	CONNECTOR, BOARD TO BOARD 12P			
		< COIL >			
L5351	1-412-031-11	INDUCTOR CHIP	47uH		
L5352	1-412-029-11	INDUCTOR CHIP	10uH		
		< FLUORECENT INDICATOR >			
⚠ND5351	1-517-414-51	FLUORESCENT TUBE (0.55 INCH)			
		< TRANSISTOR >			
Q5351	8-729-039-24	TRANSISTOR FX216-TL1			
		< RESISTOR >			
R5351	1-216-839-11	METAL CHIP	33K	5%	1/16W
		< TRANSFORMER >			
⚠T5351	1-426-848-51	TRANSFORMER, INVERTER			

Ref. No.	Part No.	Description			Remark
	A-7073-445-A	MA-311(VMMI) BOARD, COMPLETE (TRV35)			
		******************************			
					(Ref. No. 3,000 Series)
	A-7073-430-A	MA-312(VHI) BOARD, COMPLETE			
		****************************			
					(TRV85/TRV815)
	A-7073-455-A	MA-312(VHIB) BOARD, COMPLETE (TRV93)			
		******************************			
					(Ref. No. 9,000 Series)
	A-7073-402-A	MA-331(VMM) BOARD, COMPLETE			
		****************************			
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
	A-7073-411-A	MA-331(VHI) BOARD, COMPLETE			
		****************************			
					(TRV65/TRV65PK/TRV615)
	A-7073-451-A	MA-331(VMMO) BOARD, COMPLETE (TRV35E)			
		******************************			
					(Ref No. 4,000 Series)
		< CAPACITOR >			
C301	1-107-686-11	TANTAL CHIP	4.7uF	20%	16V
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C302	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C303	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C304	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C305	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C306	1-135-259-11	TANTAL CHIP	10uF	20%	6.3V
C321	1-107-725-11	CERAMIC CHIP	0.1uF	10%	16V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C322	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C323	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C324	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C325	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C326	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C327	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C328	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C329	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C330	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C331	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C332	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C333	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C334	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C335	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité. Ne les remplacer que par une pièce portant le numéro spécifié.

Ref No	Part No	Description	Remark
C336	1-162-927-11	CERAMIC CHIP 100PF 5% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C337	1-135-259-11	TANTAL CHIP 10uF 20% 6 3V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C338	1-162-964-11	CERAMIC CHIP 0 001uF 10% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C339	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C340	1-162-927-11	CERAMIC CHIP 100PF 5% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C341	1-110-563-11	CERAMIC CHIP 0 068uF 10% 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C342	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C343	1-162-970-11	CERAMIC CHIP 0 01uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C344	1-164-004-11	CERAMIC CHIP 0 1uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C345	1-107-826-11	CERAMIC CHIP 0 1uF 10% 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C346	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C348	1-164-004-11	CERAMIC CHIP 0 1uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C349	1-107-826-11	CERAMIC CHIP 0 1uF 10% 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C350	1-135-259-11	TANTAL CHIP 10uF 20% 6 3V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C351	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C352	1-162-964-11	CERAMIC CHIP 0 001uF 10% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C353	1-162-927-11	CERAMIC CHIP 100PF 5% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C354	1-110-563-11	CERAMIC CHIP 0 068uF 10% 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C355	1-164-245-11	CERAMIC CHIP 0 015uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C356	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C357	1-164-245-11	CERAMIC CHIP 0 015uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C358	1-164-677-11	CERAMIC CHIP 0 033uF 10% 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C359	1-162-968-11	CERAMIC CHIP 0 0047uF 10% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C360	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C361	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C362	1-164-677-11	CERAMIC CHIP 0 033uF 10% 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C363	1-162-968-11	CERAMIC CHIP 0 0047uF 10% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C364	1-164-245-11	CERAMIC CHIP 0 015uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C365	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C366	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C367	1-164-227-11	CERAMIC CHIP 0 022uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C368	1-164-245-11	CERAMIC CHIP 0 015uF 10% 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C369	1-162-962-11	CERAMIC CHIP 470PF 10% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C370	1-162-962-11	CERAMIC CHIP 470PF 10% 50V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C371	1-164-346-11	CERAMIC CHIP 1uF 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C372	1-164-346-11	CERAMIC CHIP 1uF 16V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C373	1-164-156-11	CERAMIC CHIP 0 1uF 25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
C376	1-135-259-11	TANTAL CHIP 10uF 20% 6 3V	
C377	1-162-966-11	CERAMIC CHIP 0 0022uF 50V	
C378	1-165-128-11	CERAMIC CHIP 0 22uF 16V	
		< CONNECTOR >	
* CN301	1-695-320-21	PIN, CONNECTOR (1 5MM)(SMD) 2P	
* CN302	1-695-320-21	PIN, CONNECTOR (1 5MM)(SMD) 2P (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
CN303	1-779-334-11	CONNECTOR, FFC/FPC 20P	
		< DIODE >	
D301	8-719-061-86	DIODE DCR2810 (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
D302	8-749-060-65	DIODE DCC3810 (EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
D303	8-719-061-82	DIODE TLSU1002(TPX1,SONY)	
D305	8-719-404-49	DIODE MA111-TX	
D309	8-719-067-44	DIODE CL-310IRS-X-T (TRV35E)	
D322	8-719-420-14	DIODE MA8082-TX	
D323	8-719-404-49	DIODE MA111-TX	
		< FUSE >	
⚠F301	1-533-874-11	FUSE, MICRO 200mA, 24V (EXCEPT TRV15/TRV15PKTRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
		< IC >	
IC301	8-749-012-83	IC RS-180-T	
IC321	8-759-339-63	IC NJM2118V-TE2 (EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
IC322	8-759-494-54	IC AN2900FH-EB (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
		< JACK >	
J301	1-568-027-11	JACK, SMALL TYPE (MIC PLUG IN POWER) (EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
J301	1-691-737-11	JACK (SMALL TYPE)(HEADPHONE) (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
		< COIL >	
L301	1-216-295-91	SHORT 0 (TRV35E)	
L301	1-414-754-11	INDUCTOR 10uH (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
		< TRANSISTOR >	
Q301	8-729-420-24	TRANSISTOR 2SB1218A-QRS-TX (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
Q301	8-729-422-51	TRANSISTOR UN5110-QRS-TX (TRV35E)	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une piéce portant le numéro spécifié

Ref No	Part No	Description	Remark
Q302	8-729-122-63	TRANSISTOR 2SA1226-T1E4	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q303	8-729-140-75	TRANSISTOR 2SD999-T1-CLCK	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
Q304	8-729-402-42	TRANSISTOR UN5213-TX	
Q305	8-729-402-42	TRANSISTOR UN5213-TX	(TRV35E)
Q321	8-729-230-63	TRANSISTOR 2SD1819A-QRS-TX	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q322	8-729-420-24	TRANSISTOR 2SB1218A-QRS-TX	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< RESISTOR >	
R301	1-216-823-11	METAL CHIP 1 5K 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R302	1-216-810-11	METAL CHIP 120 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R303	1-216-825-11	METAL CHIP 2 2K 5% 1/16W	(TRV35E)
R304	1-216-309-00	METAL CHIP 5 6 5% 1/10W	(TRV35E)
R304	1-216-311-00	METAL CHIP 6 8 5% 1/10W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R305	1-216-302-00	METAL CHIP 2 7 5% 1/10W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R306	1-216-864-11	METAL CHIP 0 5% 1/16W	
R308	1-216-837-11	METAL CHIP 22K 5% 1/16W	(TRV93)
R309	1-216-847-11	METAL CHIP 150K 5% 1/16W	(TRV93)
R310	1-216-824-11	METAL CHIP 1 8K 5% 1/16W	
R311	1-216-805-11	METAL CHIP 47 5% 1/16W	
R312	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R314	1-216-821-11	METAL CHIP 1K 5% 1/16W	(TRV35E)
R315	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R321	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R322	1-216-864-11	METAL CHIP 0 5% 1/16W	
R323	1-216-864-11	METAL CHIP 0 5% 1/16W	
R324	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R325	1-216-864-11	METAL CHIP 0 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R326	1-216-825-11	METAL CHIP 2 2K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R327	1-216-837-11	METAL CHIP 22K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R328	1-216-837-11	METAL CHIP 22K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R329	1-216-829-11	METAL CHIP 4 7K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R330	1-216-830-11	METAL CHIP 5 6K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R331	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R332	1-216-809-11	METAL CHIP 100 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R333	1-216-838-11	METAL CHIP 27K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R334	1-216-838-11	METAL CHIP 27K 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R335	1-216-839-11	METAL CHIP 33K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R336	1-216-836-11	METAL CHIP 18K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R337	1-216-835-11	METAL CHIP 15K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R338	1-216-835-11	METAL CHIP 15K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R339	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R340	1-216-825-11	METAL CHIP 2 2K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R341	1-216-821-11	METAL CHIP 1K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R342	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R343	1-216-829-11	METAL CHIP 4 7K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R344	1-216-833-11	METAL CHIP 10K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R345	1-216-821-11	METAL CHIP 1K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R346	1-216-825-11	METAL CHIP 2 2K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R347	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R348	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R349	1-216-832-11	METAL CHIP 8 2K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R350	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R351	1-216-838-11	METAL CHIP 27K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R352	1-216-839-11	METAL CHIP 33K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R353	1-216-839-11	METAL CHIP 33K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R354	1-216-829-11	METAL CHIP 4 7K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R355	1-216-833-11	METAL CHIP 10K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R356	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R357	1-216-832-11	METAL CHIP 8 2K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R358	1-216-838-11	METAL CHIP 27K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R359	1-216-835-11	METAL CHIP 15K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R360	1-216-835-11	METAL CHIP 15K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R361	1-216-835-11	METAL CHIP 15K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R362	1-216-835-11	METAL CHIP 15K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R363	1-216-830-11	METAL CHIP 5 6K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R364	1-216-839-11	METAL CHIP 33K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R365	1-216-836-11	METAL CHIP 18K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R366	1-216-839-11	METAL CHIP 33K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

Ref No	Part No	Description			Remark
R367	1-216-818-11	METAL CHIP	560	5%	1/16W
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R368	1-216-864-11	METAL CHIP	0	5%	1/16W
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			

< SWITCH >

Ref No	Part No	Description
S301	1-692-605-11	SWITCH, SLIDE (VIDEO LIGHT (ON/AUTO/OFF)(TRV93)
S302	1-771-040-21	SWITCH, PUSH (POWER (VTR/PLAYER))
S303	1-771-039-11	SWITCH, PUSH (POWER (CAMERA))

Ref No	Part No	Description
	A-7073-413-A	PD-92(SN6) BOARD, COMPLETE
		**************************
		(TRV35/TRV65/TRV65PK/TRV615)
	A-7073-415-A	PD-92(CN6) BOARD, COMPLETE
		**************************
		(TRV15/TRV15PK/TRV25/TRV25PK/TRV215)
	A-7073-452-A	PD-92(SP6) BOARD, COMPLETE (TRV35E)
		**************************
	A-7073-460-A	PD-92(CP6) BOARD, COMPLETE
		**************************
		(TRV15E/TRV15EP)
		(Ref No 10,000 Series)

< CAPACITOR >

Ref No	Part No	Description			Remark
C5501	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5502	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5503	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5504	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5505	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5506	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
C5507	1-104-851-11	TANTAL CHIP	10uF	20%	10V
C5508	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5509	1-135-180-21	TANTALUM CHIP	3 3uF	20%	6 3V
C5511	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C5512	1-104-851-11	TANTAL CHIP	10uF	20%	10V
C5513	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5514	1-110-501-11	CERAMIC CHIP	0 33uF	10%	16V
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
C5514	1-115-339-11	CERAMIC CHIP	0 1uF	10%	50V
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)			
C5515	1-110-501-11	CERAMIC CHIP	0 33uF	10%	16V
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
C5515	1-115-339-11	CERAMIC CHIP	0 1uF	10%	50V
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)			
C5516	1-110-501-11	CERAMIC CHIP	0 33uF	10%	16V
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
C5516	1-115-339-11	CERAMIC CHIP	0 1uF	10%	50V
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)			
C5517	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5518	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C5519	1-104-851-11	TANTAL CHIP	10uF	20%	10V
C5520	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5601	1-135-259-11	TANTAL CHIP	10uF	20%	6 3V
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
C5602	1-107-687-11	TANTAL CHIP	3 3uF	20%	20V
C5603	1-110-501-11	CERAMIC CHIP	0 33uF	10%	16V
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
C5603	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)			
C5604	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5605	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5607	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
C5608	1-164-357-11	CERAMIC CHIP	1000PF	5%	50V
C5610	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C5612	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C5614	1-162-959-11	CERAMIC CHIP	330PF	5%	50V
		(TRV35TRV35E/TRV65/TRV65PK/TRV615)			
C5615	1-162-957-11	CERAMIC CHIP	220PF	5%	50V
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)			
C5616	1-107-682-11	CERAMIC CHIP	1uF	10%	16V
C5618	1-113-994-11	TANTAL CHIP	6 8uF	20%	16V
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)			
C5619	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)			
C5620	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5621	1-135-177-21	TANTALUM CHIP	1uF	20%	20V
C5622	1-107-682-11	CERAMIC CHIP	1uF	10%	16V
C5623	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
		(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)			
C5624	1-107-688-11	TANTAL CHIP	1 5uF	20%	10V
C5625	1-107-688-11	TANTAL CHIP	1 5uF	20%	10V
C5633	1-162-967-11	CERAMIC CHIP	0 0033uF	10%	50V
C5701	1-104-911-11	TANTAL CHIP	33uF	20%	10V
C5702	1-164-346-11	CERAMIC CHIP	1uF		16V
C5703	1-164-664-11	CERAMIC CHIP	0 033uF	10%	50V
C5704	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
⚠C5705	1-113-521-11	CERAMIC CHIP	12PF	10%	3KV
C5706	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5801	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V

< CONNECTOR >

Ref No	Part No	Description
* CN5501	1-573-984-11	CONNECTOR, BOARD TO BOARD 10P
CN5601	1-691-362-11	CONNECTOR, FFC/FPC (ZIF) 24P
CN5701	1-764-709-11	CONNECTOR, FFC/FPC (LIF) 10P
CN5801	1-750-360-21	CONNECTOR, FFC/FPC (ZIF) 24P
CN5802	1-778-509-21	PIN, CONNECTOR (PC BOARD) 11P
CN5803	1-778-508-21	PIN, CONNECTOR (PC BOARD) 6P
CN5804	1-779-064-11	PIN, CONNECTOR (PC BOARD) 12P
CN5805	1-766-336-21	CONNECTOR, FFC/FPC 6P

< DIODE >

Ref No	Part No	Description
D5603	8-713-102-80	DIODE 1T369-01-T8A
D5604	8-719-976-96	DIODE MA8047-H-TX
D5605	8-713-102-80	DIODE 1T369-01-T8A
D5703	8-719-058-86	DIODE PG1101H-TR
D5704	8-719-404-49	DIODE MA111-TX

< IC >

Ref No	Part No	Description
IC5501	8-759-364-05	IC M62376GP-65AD
IC5502	8-759-486-77	IC IR3Y37M4
IC5601	8-759-491-12	IC CM7017L2-T4
		(TRV15/TRV15E/TRV15EP/TRV25/TRV215 US)
IC5601	8-759-495-00	IC LZ9GH184
		(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
IC5601	8-759-530-20	IC CM7017L3-T4
		(TRV15PK/TRV25PK/TRV215 CND)

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une piéce portant le numéro spécifié

Ref No	Part No	Description				Remark
IC5602	8-759-327-01	IC	NJM062V(TE2)			
IC5701	8-759-075-70	IC	TA75S393F-TE85R			
IC5801	8-759-494-53	IC	BU9729K-E2			
		< COIL >				
L5501	1-414-754-11	INDUCTOR	10uH			
L5502	1-414-754-11	INDUCTOR	10uH			
L5503	1-414-754-11	INDUCTOR	10uH			
L5601	1-414-754-11	INDUCTOR	10uH			(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
L5603	1-414-754-11	INDUCTOR	10uH			
L5604	1-414-754-11	INDUCTOR	10uH			
L5605	1-412-957-11	INDUCTOR	33uH			
L5701	1-409-536-41	COIL, CHOKE	150uH			
		< TRANSISTOR >				
Q5501	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX			
Q5601	8-729-402-42	TRANSISTOR	UN5213-TX			
Q5602	8-729-402-42	TRANSISTOR	UN5213-TX			
Q5604	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX			(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
Q5605	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX			
Q5606	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX			
Q5607	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX			
Q5608	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX			
Q5701	8-729-039-43	TRANSISTOR	FP216-TL			
Q5702	8-729-015-74	TRANSISTOR	UN5111-TX			
		< RESISTOR >				
R5501	1-216-840-11	METAL CHIP	39K	5%	1/16W	
R5505	1-216-841-11	METAL CHIP	47K	5%	1/16W	
R5512	1-216-837-11	METAL CHIP	22K	5%	1/16W	
R5513	1-216-834-11	METAL CHIP	12K	5%	1/16W	
R5516	1-216-837-11	METAL CHIP	22K	5%	1/16W	
R5517	1-216-835-11	METAL CHIP	15K	5%	1/16W	
R5518	1-216-839-11	METAL CHIP	33K	5%	1/16W	
R5520	1-216-852-11	METAL CHIP	390K	5%	1/16W	
R5521	1-216-834-11	METAL CHIP	12K	5%	1/16W	
R5522	1-216-840-11	METAL CHIP	39K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5522	1-216-843-11	METAL CHIP	68K	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5528	1-218-895-11	RES,CHIP	100K	0 50%	1/16W	
R5531	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R5532	1-216-841-11	METAL CHIP	47K	5%	1/16W	
R5533	1-216-864-11	METAL CHIP	0	5%	1/16W	
R5537	1-216-823-11	METAL CHIP	1 5K	5%	1/16W	(TRV15/TRV15PK/TRV25/TRV25PK/TRV215)
R5537	1-216-828-11	METAL CHIP	3 9K	5%	1/16W	(TRV15E/TRV15EP)
R5537	1-216-830-11	METAL CHIP	5 6K	5%	1/16W	(TRV35/TRV65/TRV65PK/TRV615)
R5537	1-216-832-11	METAL CHIP	8 2K	5%	1/16W	(TRV35E)
R5541	1-216-825-11	METAL CHIP	2 2K	5%	1/16W	
R5542	1-216-824-11	METAL CHIP	1 8K	5%	1/16W	
R5544	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R5602	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5603	1-216-864-11	METAL CHIP	0	5%	1/16W	
R5604	1-216-864-11	METAL CHIP	0	5%	1/16W	
R5605	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5607	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5608	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5610	1-216-842-11	METAL CHIP	56K	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5610	1-216-845-11	METAL CHIP	100K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5612	1-216-833-11	METAL CHIP	10K	5%	1/16W	
R5613	1-216-841-11	METAL CHIP	47K	5%	1/16W	
R5615	1-216-839-11	METAL CHIP	33K	5%	1/16W	
R5616	1-216-857-11	METAL CHIP	1M	5%	1/16W	
R5617	1-216-833-11	METAL CHIP	10K	5%	1/16W	
R5621	1-216-857-11	METAL CHIP	1M	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5622	1-216-864-11	METAL CHIP	0	5%	1/16W	
R5625	1-218-891-11	RES,CHIP	68K	0 50%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5625	1-218-895-11	RES,CHIP	100K	0 50%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5627	1-218-895-11	RES,CHIP	100K	0 50%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5627	1-218-901-11	RES,CHIP	180K	0 50%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5628	1-216-864-11	METAL CHIP	0	5%	1/16W	
R5629	1-216-833-11	METAL CHIP	10K	5%	1/16W	
R5630	1-216-821-11	METAL CHIP	1K	5%	1/16W	
R5632	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5636	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5635	1-216-829-11	METAL CHIP	4 7K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5636	1-216-837-11	METAL CHIP	22K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5637	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5638	1-216-833-11	METAL CHIP	10K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5639	1-216-833-11	METAL CHIP	10K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5640	1-216-845-11	METAL CHIP	100K	5%	1/16W	
R5641	1-216-839-11	METAL CHIP	33K	5%	1/16W	
R5642	1-216-829-11	METAL CHIP	4 7K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5643	1-216-845-11	METAL CHIP	100K	5%	1/16W	
R5644	1-216-839-11	METAL CHIP	33K	5%	1/16W	
R5645	1-216-844-11	METAL CHIP	82K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5646	1-216-844-11	METAL CHIP	82K	5%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5647	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5648	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5651	1-218-883-11	RES,CHIP	33K	0 50%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5652	1-216-864-11	METAL CHIP	0	5%	1/16W	(TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5652	1-218-879-11	RES,CHIP	22K	0 50%	1/16W	(TRV35/TRV35E/TRV65/TRV65PK/TRV615)

Ref No	Part No	Description			Remark
R5653	1-218-883-11	RES,CHIP	33K	0 50%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5654	1-218-879-11	RES,CHIP	22K	0 50%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5657	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5658	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5659	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5660	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5661	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5663	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5664	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5665	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5666	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5667	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5668	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5669	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5670	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5671	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5672	1-216-849-11	METAL CHIP	220K	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5673	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5674	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35PK/TRV35E/TRV65/TRV65PK/TRV315/TRV615)
R5676	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5678	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5679	1-216-805-11	METAL CHIP	47	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5680	1-216-805-11	METAL CHIP	47	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5681	1-216-805-11	METAL CHIP	47	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5682	1-216-805-11	METAL CHIP	47	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5683	1-216-805-11	METAL CHIP	47	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5684	1-216-805-11	METAL CHIP	47	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5685	1-216-845-11	METAL CHIP	100K	5%	1/16W
R5686	1-216-845-11	METAL CHIP	100K	5%	1/16W
R5688	1-216-864-11	METAL CHIP	0	5%	1/16W
R5692	1-216-837-11	METAL CHIP	22K	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5692	1-216-841-11	METAL CHIP	47K	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5693	1-216-848-11	METAL CHIP	180K	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5693	1-216-853-11	METAL CHIP	470K	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5694	1-216-839-11	METAL CHIP	33K	5%	1/16W
R5695	1-216-833-11	METAL CHIP	10K	5%	1/16W
R5696	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV35/TRV35E/TRV65/TRV65PK/TRV615)
R5697	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5698	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)
R5703	1-216-055-00	METAL CHIP	1 8K	5%	1/10W
R5704	1-216-055-00	METAL CHIP	1 8K	5%	1/10W
R5705	1-216-845-11	METAL CHIP	100K	5%	1/16W
R5706	1-216-831-11	METAL CHIP	6 8K	5%	1/16W
R5707	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5708	1-216-810-11	METAL CHIP	120	5%	1/16W
R5709	1-216-817-11	METAL CHIP	470	5%	1/16W
R5710	1-216-864-11	METAL CHIP	0	5%	1/16W
R5801	1-216-823-11	METAL CHIP	1 5K	5%	1/16W
R5802	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R5803	1-216-828-11	METAL CHIP	3 9K	5%	1/16W
R5804	1-216-832-11	METAL CHIP	8 2K	5%	1/16W
R5805	1-216-838-11	METAL CHIP	27K	5%	1/16W
R5806	1-216-822-11	METAL CHIP	1 2K	5%	1/16W
R5807	1-216-809-11	METAL CHIP	100	5%	1/16W
R5808	1-216-809-11	METAL CHIP	100	5%	1/16W
R5811	1-216-864-11	METAL CHIP	0	5%	1/16W
R5812	1-216-855-11	METAL CHIP	680K	5%	1/16W

< SWITCH >

Ref No	Part No	Description
S5801	1-692-088-41	SWITCH, TACTILE (LCD BRIGHT +)
S5802	1-692-088-41	SWITCH, TACTILE (LID BRIGHT -)
S5803	1-692-088-41	SWITCH, TACTILE (VOLUME +)
S5804	1-692-088-41	SWITCH, TACTILE (VOLUME -)

< TRANSFORMER >

Ref No	Part No	Description
⚠T5701	1-429-547-31	TRANSFORMER, INVERTER

A-7073-432-A PD-93(CN3 5) BOARD, COMPLETE
****
(TRV85/TRV815)

A-7073-457-A PD-93(SN3) BOARD, COMPLETE (TRV93)
****

(Ref No 10,000 Series)

< CAPACITOR >

Ref No	Part No	Description			Remark
C4501	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4502	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4503	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C4504	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C4505	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C4506	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
C4507	1-104-851-11	TANTAL CHIP	10uF	20%	10V
C4508	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4509	1-135-180-21	TANTALUM CHIP	3 3uF	20%	6 3V
C4511	1-107-682-11	CERAMIC CHIP	1uF	10%	16V

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une piéce portant le numéro spécifié

Ref No	Part No	Description			Remark
C4512	1-104-851-11	TANTAL CHIP	10uF	20%	10V
C4513	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4514	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
C4515	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
C4516	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
C4517	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4518	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C4519	1-104-851-11	TANTAL CHIP	10uF	20%	10V
C4520	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4602	1-107-687-11	TANTAL CHIP	3 3uF	20%	20V
C4603	1-110-501-11	CERAMIC CHIP	0 33uF	10%	16V (TRV85/TRV815)
C4603	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V (TRV93)
C4604	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4605	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4607	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
C4608	1-164-357-11	CERAMIC CHIP	1000PF	5%	50V
C4610	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C4612	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C4614	1-162-959-11	CERAMIC CHIP	330PF	5%	50V (TRV93)
C4615	1-162-957-11	CERAMIC CHIP	220PF	5%	50V (TRV93)
C4616	1-107-682-11	CERAMIC CHIP	1uF	10%	16V
C4618	1-113-994-11	TANTAL CHIP	6 8uF	20%	16V (TRV93)
C4619	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V (TRV93)
C4620	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C4621	1-135-177-21	TANTALUM CHIP	1uF	20%	20V
C4622	1-107-682-11	CERAMIC CHIP	1uF	10%	16V
C4623	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C4624	1-107-688-11	TANTAL CHIP	1 5uF	20%	10V
C4625	1-107-688-11	TANTAL CHIP	1 5uF	20%	10V
C4633	1-162-967-11	CERAMIC CHIP	0 0033uF	10%	50V
C4701	1-104-911-11	TANTAL CHIP	33uF	20%	10V
C4702	1-164-346-11	CERAMIC CHIP	1uF		16V
C4703	1-164-664-11	CERAMIC CHIP	0 033uF	10%	50V
C4704	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V
⚠C4705	1-113-520-11	CERAMIC CHIP	10PF	10%	3KV (TRV93)
⚠C4705	1-113-521-11	CERAMIC CHIP	12PF	10%	3KV (TRV85/TRV815)
C4706	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C4801	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
		< CONNECTOR >			
* CN4501	1-573-984-11	CONNECTOR, BOARD TO BOARD 10P			
CN4601	1-691-362-11	CONNECTOR, FFC/FPC (ZIF) 24P			
CN4701	1-764-709-11	CONNECTOR, FFC/FPC (LIF) 10P			
CN4801	1-750-360-21	CONNECTOR, FFC/FPC (ZIF) 24P			
CN4802	1-778-509-21	PIN, CONNECTOR (PC BOARD) 11P			
CN4803	1-778-508-21	PIN, CONNECTOR (PC BOARD) 6P			
CN4804	1-779-064-11	PIN, CONNECTOR (PC BOARD) 12P			
CN4805	1-766-336-21	CONNECTOR, FFC/FPC 6P			

Ref No	Part No	Description			Remark
		< DIODE >			
D4603	8-713-102-80	DIODE 1T369-01-T8A			
D4604	8-719-976-96	DIODE MA8047-H-TX			
D4605	8-713-102-80	DIODE 1T369-01-T8A			
D4704	8-719-404-49	DIODE MA111-TX			
		< IC >			
IC4501	8-759-364-05	IC M62376GP-65AD			
IC4502	8-759-486-77	IC IR3Y37M4			
IC4601	8-759-491-15	IC LZ9GH164 (TRV93)			
IC4601	8-759-530-20	IC CM7017L3-T4 (TRV85/TRV815)			
IC4602	8-759-327-01	IC NJM062V(TE2)			
IC4701	8-759-075-70	IC TA75S393F-TE85R			
IC4801	8-759-494-53	IC BU9729K-E2			
		< COIL >			
L4501	1-414-754-11	INDUCTOR	10uH		
L4502	1-414-754-11	INDUCTOR	10uH		
L4503	1-414-754-11	INDUCTOR	10uH		
L4601	1-414-754-11	INDUCTOR	10uH (TRV85/TRV815)		
L4603	1-414-754-11	INDUCTOR	10uH		
L4604	1-414-754-11	INDUCTOR	10uH		
L4605	1-412-951-11	INDUCTOR	10uH (TRV85/TRV815)		
L4605	1-412-954-11	INDUCTOR	18uH (TRV93)		
L4701	1-409-536-41	COIL, CHOKE	150uH		
		< TRANSISTOR >			
Q4501	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX		
Q4601	8-729-402-42	TRANSISTOR	UN5213-TX		
Q4602	8-729-402-42	TRANSISTOR	UN5213-TX		
Q4604	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX (TRV93)		
Q4605	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX		
Q4606	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX		
Q4607	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX		
Q4608	8-729-420-24	TRANSISTOR	2SB1218A-QRS-TX		
Q4701	8-729-039-43	TRANSISTOR	FP216-TL		
Q4702	8-729-015-74	TRANSISTOR	UN5111-TX		
		< RESISTOR >			
R4501	1-216-840-11	METAL CHIP	39K	5%	1/16W
R4505	1-216-841-11	METAL CHIP	47K	5%	1/16W
R4512	1-216-837-11	METAL CHIP	22K	5%	1/16W
R4513	1-216-834-11	METAL CHIP	12K	5%	1/16W
R4516	1-216-837-11	METAL CHIP	22K	5%	1/16W
R4517	1-216-835-11	METAL CHIP	15K	5%	1/16W
R4518	1-216-839-11	METAL CHIP	33K	5%	1/16W
R4520	1-216-852-11	METAL CHIP	390K	5%	1/16W
R4521	1-216-834-11	METAL CHIP	12K	5%	1/16W
R4522	1-216-840-11	METAL CHIP	39K	5%	1/16W (TRV93)
R4522	1-216-843-11	METAL CHIP	68K	5%	1/16W (TRV85/TRV815)
R4528	1-218-895-11	RES,CHIP	100K	0 50%	1/16W
R4531	1-216-821-11	METAL CHIP	1K	5%	1/16W
R4532	1-216-841-11	METAL CHIP	47K	5%	1/16W
R4533	1-216-864-11	METAL CHIP	0	5%	1/16W

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

PD-93

Ref No	Part No	Description			Remark
R4534	1-216-805-11	METAL CHIP	47	5%	1/16W
R4535	1-216-805-11	METAL CHIP	47	5%	1/16W
R4536	1-216-805-11	METAL CHIP	47	5%	1/16W
R4537	1-216-821-11	METAL CHIP	1K	5%	1/16W (TRV85/TRV815)
R4537	1-216-829-11	METAL CHIP	4 7K	5%	1/16W (TRV93)
R4541	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R4542	1-216-824-11	METAL CHIP	1 8K	5%	1/16W
R4544	1-216-821-11	METAL CHIP	1K	5%	1/16W
R4602	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4603	1-216-864-11	METAL CHIP	0	5%	1/16W
R4604	1-216-864-11	METAL CHIP	0	5%	1/16W
R4606	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4607	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4608	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4610	1-216-842-11	METAL CHIP	56K	5%	1/16W (TRV85/TRV815)
R4610	1-216-845-11	METAL CHIP	100K	5%	1/16W (TRV93)
R4612	1-216-833-11	METAL CHIP	10K	5%	1/16W
R4613	1-216-841-11	METAL CHIP	47K	5%	1/16W
R4615	1-216-839-11	METAL CHIP	33K	5%	1/16W
R4616	1-216-857-11	METAL CHIP	1M	5%	1/16W
R4617	1-216-833-11	METAL CHIP	10K	5%	1/16W
R4621	1-216-857-11	METAL CHIP	1M	5%	1/16W (TRV93)
R4622	1-216-864-11	METAL CHIP	0	5%	1/16W
R4625	1-218-887-11	RES,CHIP	47K	0 50%	1/16W (TRV85/TRV815)
R4625	1-218-891-11	RES,CHIP	68K	0 50%	1/16W (TRV93)
R4627	1-218-897-11	RES,CHIP	120K	0 50%	1/16W
R4628	1-216-864-11	METAL CHIP	0	5%	1/16W
R4629	1-216-833-11	METAL CHIP	10K	5%	1/16W
R4630	1-216-821-11	METAL CHIP	1K	5%	1/16W
R4632	1-216-864-11	METAL CHIP	0	5%	1/16W
R4635	1-216-829-11	METAL CHIP	4 7K	5%	1/16W (TRV93)
R4636	1-216-837-11	METAL CHIP	22K	5%	1/16W (TRV93)
R4636	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4637	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4638	1-216-833-11	METAL CHIP	10K	5%	1/16W (TRV93)
R4639	1-216-833-11	METAL CHIP	10K	5%	1/16W (TRV93)
R4640	1-216-845-11	METAL CHIP	100K	5%	1/16W
R4641	1-216-839-11	METAL CHIP	33K	5%	1/16W
R4642	1-216-829-11	METAL CHIP	4 7K	5%	1/16W (TRV93)
R4643	1-216-841-11	METAL CHIP	47K	5%	1/16W (TRV85/TRV815)
R4643	1-216-842-11	METAL CHIP	56K	5%	1/16W (TRV93)
R4644	1-216-839-11	METAL CHIP	33K	5%	1/16W
R4645	1-216-844-11	METAL CHIP	82K	5%	1/16W (TRV93)
R4646	1-216-844-11	METAL CHIP	82K	5%	1/16W (TRV93)
R4647	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4648	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4651	1-218-883-11	RES,CHIP	33K	0 50%	1/16W (TRV93)
R4652	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4652	1-218-879-11	RES,CHIP	22K	0 50%	1/16W (TRV93)
R4653	1-218-883-11	RES,CHIP	33K	0 50%	1/16W (TRV93)
R4654	1-218-879-11	RES,CHIP	22K	0 50%	1/16W (TRV93)
R4657	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4658	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4659	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4660	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4661	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4663	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4664	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4665	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4666	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4667	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4668	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4669	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4670	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4671	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4672	1-216-836-11	METAL CHIP	18K	5%	1/16W (TRV85/TRV815)
R4673	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4674	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4676	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4677	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4678	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV85/TRV815)
R4679	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4680	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)
R4681	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV93)

Ref No	Part No	Description	Remark
R4682	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV85/TRV815)
R4683	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV85/TRV815)
R4684	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV85/TRV815)
R4685	1-216-842-11	METAL CHIP 56K 5% 1/16W	(TRV85/TRV815)
R4685	1-216-845-11	METAL CHIP 100K 5% 1/16W	(TRV93)
R4686	1-216-842-11	METAL CHIP 56K 5% 1/16W	(TRV85/TRV815)
R4686	1-216-845-11	METAL CHIP 100K 5% 1/16W	(TRV93)
R4688	1-216-864-11	METAL CHIP 0 5% 1/16W	
R4692	1-216-839-11	METAL CHIP 33K 5% 1/16W	(TRV93)
R4692	1-216-842-11	METAL CHIP 56K 5% 1/16W	(TRV85/TRV815)
R4693	1-216-844-11	METAL CHIP 82K 5% 1/16W	(TRV85/TRV815)
R4693	1-216-850-11	METAL CHIP 270K 5% 1/16W	(TRV93)
R4694	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R4695	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R4696	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV93)
R4697	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV85/TRV815)
R4698	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV85/TRV815)
R4703	1-216-055-00	METAL CHIP 1 8K 5% 1/10W	
R4704	1-216-055-00	METAL CHIP 1 8K 5% 1/10W	
R4705	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R4706	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	
R4707	1-216-837-11	METAL CHIP 22K 5% 1/16W	
R4708	1-216-810-11	METAL CHIP 120 5% 1/16W	
R4709	1-216-817-11	METAL CHIP 470 5% 1/16W	
R4710	1-216-816-11	METAL CHIP 390 5% 1/16W	
R4801	1-216-823-11	METAL CHIP 1 5K 5% 1/16W	
R4802	1-216-825-11	METAL CHIP 2 2K 5% 1/16W	
R4803	1-216-828-11	METAL CHIP 3 9K 5% 1/16W	
R4804	1-216-832-11	METAL CHIP 8 2K 5% 1/16W	
R4805	1-216-838-11	METAL CHIP 27K 5% 1/16W	
R4806	1-216-822-11	METAL CHIP 1 2K 5% 1/16W	
R4807	1-216-809-11	METAL CHIP 100 5% 1/16W	
R4808	1-216-809-11	METAL CHIP 100 5% 1/16W	
R4811	1-216-864-11	METAL CHIP 0 5% 1/16W	
R4812	1-216-855-11	METAL CHIP 680K 5% 1/16W	
		< SWITCH >	
S4801	1-692-088-41	SWITCH, TACTILE (LCD BRIGHT +)	
S4802	1-692-088-41	SWITCH, TACTILE (LCD BRIGHT -)	
S4803	1-692-088-41	SWITCH, TACTILE (VOLUME +)	
S4804	1-692-088-41	SWITCH, TACTILE (VOLUME -)	
		< TRANSFORMER >	
⚠T4701	1-429-507-31	TRANSFORMER, INVERTER	

Ref No	Part No	Description	Remark
	A-7073-405-A	PJ-83(M) BOARD, COMPLETE ************************	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
	A-7073-410-A	PJ-83(H) BOARD, COMPLETE ************************	(TRV65/TRV65PK/TRV615) (Ref No 4,000 Series)
	A-7073-433-A	PJ-84(H) BOARD, COMPLETE ************************	(TRV85/TRV93/TRV815) (Ref No 9,000 Series)
		< CAPACITOR >	
C101	1-110-569-11	TANTAL CHIP 47uF 20% 6 3V	
		< CONNECTOR >	
* CN101	1-764-521-11	CONNECTOR, FFC/FPC (ZIF) 12P	
		< DIODE >	
D101	8-719-059-57	DIODE MAZJ082DFLSO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
D102	8-719-059-57	DIODE MAZJ082DFLSO	
D103	8-719-059-57	DIODE MAZJ082DFLSO	
D104	8-719-420-14	DIODE MA8082-TX	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
D105	8-719-059-57	DIODE MAZJ082DFLSO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
D106	8-719-059-57	DIODE MAZJ082DFLSO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< JACK >	
J101	1-537-747-21	TERMINAL BOARD (S VIDEO/VIDEO/AUDIO)	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
J101	1-537-747-41	TERMINAL BOARD (VIDEO/AUDIO)	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< COIL >	
L101	1-414-072-11	INDUCTOR 1uH	
L102	1-216-295-91	SHORT 0	
L103	1-216-295-91	SHORT 0	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L104	1-216-295-91	SHORT 0	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< TRANSISTOR >	
Q101	8-729-101-07	TRANSISTOR 2SB798-T1-DLDK	
Q102	8-729-230-63	TRANSISTOR 2SD1819A-QRS-TX	
		< RESISTOR >	
R101	1-216-864-11	METAL CHIP 0 5% 1/16W	
R102	1-216-138-00	METAL CHIP 3 3 5% 1/8W	
R103	1-216-830-11	METAL CHIP 5 6K 5% 1/16W	
R104	1-216-820-11	METAL CHIP 820 5% 1/16W	
R105	1-216-836-11	METAL CHIP 18K 5% 1/16W	
R106	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une piéce portant le numéro spécifié

Ref. No.	Part No.	Description	Remark
R107	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R108	1-216-821-11	METAL CHIP 1K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R109	1-216-821-11	METAL CHIP 1K 5% 1/16W	
	A-7073-404-A	SE-66(V) BOARD, COMPLETE ************************	(TRV15/TRV15PK/TRV15E/TRV15EP)
	A-7073-409-A	SE-66(VH) BOARD, COMPLETE **************************	(TRV65/TRV65PK/TRV615)
	A-7073-443-A	SE-66(VMM) BOARD, COMPLETE ****************************	(TRV25/TRV25PK/TRV35/TRV35E/TRV215) (Ref No. 4,000 Series)
	A-7073-434-A	SE-67(VH) BOARD, COMPLETE **************************	(TRV85/TRV815/TRV93) (Ref No. 9,000 Series)
		< CAPACITOR >	
C451	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C452	1-164-004-11	CERAMIC CHIP 0.1uF 10% 25V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C453	1-104-847-11	TANTAL. CHIP 22uF 20% 4V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C454	1-104-847-11	TANTAL. CHIP 22uF 20% 4V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C457	1-164-343-11	CERAMIC CHIP 0.056uF 10% 25V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C458	1-164-343-11	CERAMIC CHIP 0.056uF 10% 25V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C459	1-164-343-11	CERAMIC CHIP 0.056uF 10% 25V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C460	1-110-666-11	ELECT CHIP 22uF 20% 6.3V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C461	1-164-343-11	CERAMIC CHIP 0.056uF 10% 25V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C462	1-110-666-11	ELECT CHIP 22uF 20% 6.3V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C464	1-110-501-11	CERAMIC CHIP 0.33uF 10% 16V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C465	1-135-259-11	TANTAL. CHIP 10uF 20% 6.3V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
C466	1-162-970-11	CERAMIC CHIP 0.01uF 10% 25V	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
		< CONNECTOR >	
CN451	1-691-348-11	CONNECTOR, FFC/FPC (ZIF) 10P	
CN451	1-766-646-21	CONNECTOR, FFC/FPC 10P	
		< DIODE >	
D451	8-719-059-57	DIODE MAZJ082DFLSO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
D452	8-719-059-57	DIODE MAZJ082DFLSO	

Ref. No.	Part No.	Description	Remark
		< IC >	
IC451	8-759-489-19	IC uPC6756GR-8JG-E2	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
		< JACK >	
J451	1-695-514-11	JACK (SMALL TYPE) 1P (EARPHONES)	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
J451	1-695-514-21	JACK (SMALL TYPE) 1P (HEAD PHONES)	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< COIL >	
L451	1-414-754-11	INDUCTOR 10uH	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
L453	1-216-295-91	SHORT 0	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L454	1-216-295-91	SHORT 0	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< RESISTOR >	
R451	1-216-837-11	METAL CHIP 22K 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R452	1-216-837-11	METAL CHIP 22K 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R453	1-216-837-11	METAL CHIP 22K 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R454	1-216-837-11	METAL CHIP 22K 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R455	1-216-864-11	METAL CHIP 0 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R456	1-216-857-11	METAL CHIP 1M 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R458	1-216-833-11	METAL CHIP 10K 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R459	1-216-857-11	METAL CHIP 1M 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R461	1-216-835-11	METAL CHIP 15K 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R463	1-216-809-11	METAL CHIP 100 5% 1/16W	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
		< SENSOR >	
SE451	1-803-041-31	SENSOR, ANGULAR VELOCITY (PITCH)	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
SE452	1-803-041-41	SENSOR, ANGULAR VELOCITY (YAW)	(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
	A-7093-449-A	VC-195(VHIOU) BOARD, COMPLETE ******************************	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
	A-7093-450-A	VC-195(VMMIOU) BOARD, COMPLETE ********************************	(TRV35)
	A-7093-451-A	VC-195(7VMMU) BOARD, COMPLETE ******************************	(TRV25/TRV25PK/TRV215)
	A-7093-452-A	VC-195(7VZU) BOARD, COMPLETE ****************************	(TRV15/TRV15PK)

Ref No	Part No	Description			Remark
	A-7093-455-A	VC-195(VMM0P) BOARD, COMPLETE (TRV35E)			
		*******************************			
	A-7093-456-A	VC-195(VZ0P) BOARD, COMPLETE			
		*****************************			
					(TRV15E/TRV15EP)
	A-7093-459-A	VC-195(VHCIBOU) BOARD, COMPLETE (TRV93)			
		********************************			
					(Ref No 1,000 Series)
		< CAPACITOR >			
C001	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C004	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C006	1-104-752-11	TANTAL. CHIP	33uF	20%	6.3V
C007	1-104-752-11	TANTAL. CHIP	33uF	20%	6.3V
C008	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C009	1-164-217-11	CERAMIC CHIP	150PF	5%	50V
C010	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C011	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C012	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C013	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C014	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C015	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C016	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C017	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C018	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C019	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
C020	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C021	1-164-156-11	CERAMIC CHIP	0.1uF		25V
C022	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C023	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C024	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C025	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C026	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C027	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C028	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V
C029	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C030	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C031	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C032	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C033	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V
C034	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C035	1-162-920-11	CERAMIC CHIP	27PF	5%	50V
C036	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C037	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C038	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C039	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C040	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C041	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V
C042	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C043	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C048	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C049	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C050	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C052	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C053	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C055	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C058	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V
C059	1-164-217-11	CERAMIC CHIP	150PF	5%	50V
C060	1-163-809-11	CERAMIC CHIP	0.047uF	10%	25V
C061	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C062	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
C065	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C068	1-162-921-11	CERAMIC CHIP	33PF	5%	50V
C069	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C070	1-162-908-11	CERAMIC CHIP	3PF	0.25PF	50V
C071	1-104-752-11	TANTAL. CHIP	33uF	20%	6.3V
C072	1-162-958-11	CERAMIC CHIP	270PF	5%	50V
C073	1-164-392-11	CERAMIC CHIP	390PF	5%	50V
C074	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C075	1-162-959-11	CERAMIC CHIP	330PF	5%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C075	1-164-315-11	CERAMIC CHIP	470PF	5%	50V
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C076	1-162-921-11	CERAMIC CHIP	33PF	5%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C078	1-162-928-11	CERAMIC CHIP	120PF	5%	50V
C079	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C080	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C080	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C081	1-162-916-11	CERAMIC CHIP	12PF	5%	50V
C082	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V
C083	1-162-924-11	CERAMIC CHIP	56PF	5%	50V
					(TRV15E/TRV15EP/TRV35E)
C083	1-162-925-11	CERAMIC CHIP	68PF	5%	50V
					(TRV15/TRV15PK/TRV25/TRV25PK/TRV215/TRV35)
C083	1-162-926-11	CERAMIC CHIP	82PF	5%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C085	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C086	1-115-156-11	CERAMIC CHIP	1uF		10V
C088	1-162-925-11	CERAMIC CHIP	68PF	5%	50V
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C088	1-162-957-11	CERAMIC CHIP	220PF	5%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C089	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C089	1-162-923-11	CERAMIC CHIP	47PF	5%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C090	1-162-958-11	CERAMIC CHIP	270PF	5%	50V
C152	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C156	1-164-677-11	CERAMIC CHIP	0.033uF	10%	16V
C157	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C158	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C159	1-164-346-11	CERAMIC CHIP	1uF		16V
C160	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V
C161	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V

VC-195

Ref. No.	Part No.	Description				Remark
C162	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C163	1-135-180-21	TANTALUM CHIP	3.3uF	20%	6.3V	
C164	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C166	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C168	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C169	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C170	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C171	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C172	1-110-501-11	CERAMIC CHIP	0.33uF	10%	16V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C173	1-164-227-11	CERAMIC CHIP	0.022uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C174	1-164-217-11	CERAMIC CHIP	150PF	5%	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C175	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C177	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C178	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C179	1-162-919-11	CERAMIC CHIP	22PF	5%	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C180	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	
C181	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C182	1-135-149-21	TANTALUM CHIP	2.2uF	20%	10V	
C183	1-135-149-21	TANTALUM CHIP	2.2uF	20%	10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C184	1-115-156-11	CERAMIC CHIP	1uF		10V	
C185	1-126-246-11	ELECT CHIP	220uF	20%	4V	
C187	1-126-246-11	ELECT CHIP	220uF	20%	4V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C188	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	
C190	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
C191	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C192	1-104-852-11	TANTAL. CHIP	22uF	20%	6.3V	
C202	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	
C204	1-162-964-11	CERAMIC CHIP	0.001uF	10%	50V	
C205	1-115-156-11	CERAMIC CHIP	1uF		10V	
C206	1-162-967-11	CERAMIC CHIP	0.0033uF	10%	50V	
C207	1-162-965-11	CERAMIC CHIP	0.0015uF	10%	50V	
C209	1-162-915-11	CERAMIC CHIP	10PF	0.5PF	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C209	1-162-921-11	CERAMIC CHIP	33PF	5%	50V	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C210	1-162-922-11	CERAMIC CHIP	39PF	5%	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C211	1-135-181-21	TANTALUM CHIP	4.7uF	20%	6.3V	
C212	1-164-392-11	CERAMIC CHIP	390PF	5%	50V	
C217	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C218	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V	
C219	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C224	1-162-927-11	CERAMIC CHIP	100PF	5%	50V	
C225	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C226	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C227	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	
C229	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C230	1-115-156-11	CERAMIC CHIP	1uF		10V	
C232	1-164-156-11	CERAMIC CHIP	0.1uF		25V	
C233	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	
C234	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C235	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C237	1-164-156-11	CERAMIC CHIP	0.1uF		25V	
C239	1-115-156-11	CERAMIC CHIP	1uF		10V	
C243	1-115-156-11	CERAMIC CHIP	1uF		10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C244	1-115-156-11	CERAMIC CHIP	1uF		10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C245	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C246	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C247	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	
C250	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	
C301	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	
C302	1-135-201-11	TANTALUM CHIP	10uF	20%	4V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C307	1-135-151-21	TANTALUM CHIP	4.7uF	20%	4V	
C308	1-135-259-11	TANTAL. CHIP	10uF	20%	6.3V	
C309	1-135-318-11	TANTAL. CHIP	33uF	20%	4V	
C310	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	
C312	1-107-823-11	CERAMIC CHIP	0.47uF	10%	16V	
C313	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C316	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	
C317	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C318	1-104-847-11	TANTAL. CHIP	22uF	20%	4V	
C319	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	
C320	1-107-826-11	CERAMIC CHIP	0.1uF	10%	16V	
C321	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C322	1-163-017-00	CERAMIC CHIP	0.0047uF	5%	50V	
C323	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C325	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C326	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C327	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C328	1-164-232-11	CERAMIC CHIP	0.01uF		50V	
C329	1-162-970-11	CERAMIC CHIP	0.01uF	10%	25V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C332	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C331	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C333	1-162-968-11	CERAMIC CHIP	0.0047uF	10%	50V	
C334	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C335	1-115-467-11	CERAMIC CHIP	0.22uF	10%	10V	
C336	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C337	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C338	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C339	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C340	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	
C341	1-109-982-11	CERAMIC CHIP	1uF	10%	10V	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C342	1-165-176-11	CERAMIC CHIP	0.047uF	10%	16V	

Ref No	Part No	Description			Remark
C344	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C346	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C347	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C349	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C371	1-104-908-11	TANTAL CHIP	47uF	20%	4V
C372	1-104-908-11	TANTAL CHIP	47uF	20%	4V
C378	1-135-259-11	TANTAL CHIP	10uF	20%	6 3V
C380	1-135-259-11	TANTAL CHIP	10uF	20%	6 3V
C381	1-164-346-11	CERAMIC CHIP	1uF		16V
C382	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V
C383	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C384	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C385	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C386	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C387	1-104-847-11	TANTAL CHIP	22uF	20%	4V
C388	1-162-961-11	CERAMIC CHIP	330PF	10%	50V
C402	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C404	1-162-915-11	CERAMIC CHIP	10PF	0 5PF	50V
C405	1-162-915-11	CERAMIC CHIP	10PF	0 5PF	50V
C406	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C410	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C411	1-162-969-11	CERAMIC CHIP	0 0068uF	10%	25V
C412	1-162-969-11	CERAMIC CHIP	0 0068uF	10%	25V
C414	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C415	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C416	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C417	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C418	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C419	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C420	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C451	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C452	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C453	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C454	1-162-968-11	CERAMIC CHIP	0 0047uF	10%	50V
C455	1-162-968-11	CERAMIC CHIP	0 0047uF	10%	50V
C456	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C457	1-162-968-11	CERAMIC CHIP	0 0047uF	10%	50V
C458	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C459	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C460	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C461	1-165-176-11	CERAMIC CHIP	0 047uF	10%	16V
C462	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C463	1-165-176-11	CERAMIC CHIP	0 047uF	10%	16V
C464	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C465	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C467	1-162-968-11	CERAMIC CHIP	0 0047uF	10%	50V
C468	1-165-176-11	CERAMIC CHIP	0 047uF	10%	16V
C469	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C470	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V
C471	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V
C472	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C473	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V
C474	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V
C475	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V
C476	1-165-176-11	CERAMIC CHIP	0 047uF	10%	16V
C478	1-165-176-11	CERAMIC CHIP	0 047uF	10%	16V
C480	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V
C483	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C484	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C485	1-164-505-11	CERAMIC CHIP	2 2uF		16V
C486	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C487	1-162-957-11	CERAMIC CHIP	220PF	5%	50V
C488	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C489	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C501	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C502	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V
C503	1-162-919-11	CERAMIC CHIP	22PF	5%	50V
C504	1-162-922-11	CERAMIC CHIP	39PF	5%	50V
C506	1-115-156-11	CERAMIC CHIP	1uF		10V
C507	1-115-156-11	CERAMIC CHIP	1uF		10V
C508	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C509	1-135-214-21	TANTAL CHIP	4 7uF	20%	20V
C510	1-135-201-11	TANTALUM CHIP	10uF	20%	4V
C511	1-164-232-11	CERAMIC CHIP	0 01uF		50V
C512	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C513	1-115-156-11	CERAMIC CHIP	1uF		10V
C514	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V
C515	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
C516	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C517	1-115-467-11	CERAMIC CHIP	0 22uF	10%	10V
C518	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V
C519	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C520	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C521	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C522	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C523	1-115-467-11	CERAMIC CHIP	0 22uF	10%	10V
C524	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C525	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C526	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C527	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C528	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C529	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C530	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C531	1-104-847-11	TANTAL CHIP	22uF	20%	4V
C532	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C533	1-162-917-11	CERAMIC CHIP	15PF	5%	50V
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
C552	1-162-968-11	CERAMIC CHIP	0 0047uF	10%	50V
C553	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C554	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C555	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C556	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C557	1-162-962-11	CERAMIC CHIP	470PF	10%	50V
C558	1-115-467-11	CERAMIC CHIP	0 22uF	10%	10V
C559	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C560	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C561	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C562	1-162-966-11	CERAMIC CHIP	0 0022uF	10%	50V
C563	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C564	1-104-752-11	TANTAL CHIP	33uF	20%	6 3V
C565	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C566	1-115-156-11	CERAMIC CHIP	1uF		10V
C567	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V
C569	1-164-004-11	CERAMIC CHIP	0 1uF	10%	25V

Ref No	Part No	Description	Remark
C570	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C571	1-104-851-11	TANTAL CHIP 10uF 20%	10V
C572	1-104-851-11	TANTAL CHIP 10uF 20%	10V
C605	1-135-091-00	TANTALUM CHIP 1uF 20%	16V
C607	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C610	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C611	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C612	1-119-749-91	TANTAL CHIP 33uF 20%	4V
C613	1-104-851-11	TANTAL CHIP 10uF 20%	10V
C615	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C616	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C617	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C618	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C619	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C620	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C621	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C622	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C623	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C624	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V
C625	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C626	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C627	1-164-227-11	CERAMIC CHIP 0 022uF 10%	25V
C628	1-162-919-11	CERAMIC CHIP 22PF 5%	50V
C629	1-162-917-11	CERAMIC CHIP 15PF 5%	50V
C630	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C634	1-164-156-11	CERAMIC CHIP 0 1uF	25V (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C636	1-164-156-11	CERAMIC CHIP 0 1uF	25V
C637	1-162-964-11	CERAMIC CHIP 0 001uF 10%	50V
C751	1-135-201-11	TANTALUM CHIP 10uF 20%	4V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C752	1-135-259-11	TANTAL CHIP 10uF 20%	6 3V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C753	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C754	1-107-823-11	CERAMIC CHIP 0 47uF 10%	16V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C755	1-107-823-11	CERAMIC CHIP 0 47uF 10%	16V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C756	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C757	1-135-201-11	TANTALUM CHIP 10uF 20%	4V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C758	1-109-982-11	CERAMIC CHIP 1uF 10%	10V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C759	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C760	1-135-181-21	TANTALUM CHIP 4 7uF 20%	6 3V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C761	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C762	1-164-668-11	CERAMIC CHIP 510PF 5%	50V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C763	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C764	1-135-259-11	TANTAL CHIP 10uF 20%	6 3V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C765	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C766	1-109-982-11	CERAMIC CHIP 1uF 10%	10V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C767	1-107-826-11	CERAMIC CHIP 0 1uF 10%	16V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C768	1-162-909-11	CERAMIC CHIP 4PF 0 25PF	50V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C769	1-107-823-11	CERAMIC CHIP 0 47uF 10%	16V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C770	1-107-823-11	CERAMIC CHIP 0 47uF 10%	16V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C771	1-162-921-11	CERAMIC CHIP 33PF 5%	50V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C772	1-109-982-11	CERAMIC CHIP 1uF 10%	10V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C773	1-162-922-11	CERAMIC CHIP 39PF 5%	50V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C774	1-109-982-11	CERAMIC CHIP 1uF 10%	10V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C775	1-107-826-11	CERAMIC CHIP 0 1uF 10%	16V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C776	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C777	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C778	1-162-970-11	CERAMIC CHIP 0 01uF 10%	25V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
C781	1-104-847-11	TANTAL CHIP 22uF 20%	4V (TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

< CONNECTOR >

Ref No	Part No	Description	Remark
CN001	1-691-354-21	CONNECTOR, FFC/FPC (ZIF) 16P	
CN001	1-766-677-21	CONNECTOR, FFC/FPC 16P	
CN501	1-779-332-11	CONNECTOR, FFC/FPC 16P	
CN551	1-766-353-21	CONNECTOR, FFC/TRVFPC 23P	
CN901	1-691-346-11	CONNECTOR, FFC/FPC (ZIF) 8P	
CN901	1-766-644-21	CONNECTOR, FFC/FPC 8P	
CN902	1-766-673-21	CONNECTOR, FFC/FPC 12P	
CN903	1-691-361-11	CONNECTOR, FFC/FPC (ZIF) 23P	
CN903	1-766-353-21	CONNECTOR, FFC/FPC 23P	
CN904	1-691-374-11	CONNECTOR, FFC/FPC 10P	
CN905	1-691-348-11	CONNECTOR, FFC/FPC (ZIF) 10P	
CN905	1-766-646-21	CONNECTOR, FFC/FPC 10P	
CN906	1-691-350-21	CONNECTOR, FFC/FPC (ZIF) 12P	
CN906	1-766-673-21	CONNECTOR, FFC/FPC 12P	
CN907	1-766-346-21	CONNECTOR, FFC/FPC 16P	
CN908	1-691-353-21	CONNECTOR, FFC/FPC (ZIF) 15P	
CN908	1-766-345-21	CONNECTOR, FFC/FPC 15P	
CN909	1-766-621-21	CONNECTOR, FFC/FPC 10P	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
CN910	1-766-346-21	CONNECTOR, FFC/FPC 16P	
CN911	1-778-637-21	CONNECTOR, FFC/FPC (ZIF) 50P	
CN912	1-691-354-21	CONNECTOR, FFC/TRVFPC (ZIF) 16P	
CN914	1-691-542-21	CONNECTOR, BOARD TO BOARD 48P	

< DIODE >

Ref No	Part No	Description	Remark
D002	8-719-404-49	DIODE MA111-TX	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
D201	8-719-055-86	DIODE KV1470TL1-3	
D202	8-719-055-86	DIODE KV1470TL1-3	
D371	8-719-404-49	DIODE MA111-TX	
D502	8-713-102-28	DIODE 1T379-04-T8A	

Ref No	Part No	Description	Remark
D551	8-719-404-49	DIODE MA111-TX	
D601	8-719-421-27	DIODE MA728-TX	
D602	8-719-421-27	DIODE MA728-TX	
D604	8-719-404-49	DIODE MA111-TX	
D608	8-719-404-49	DIODE MA111-TX	
D609	8-719-049-09	DIODE 1SS367-T3SONY	
D610	8-719-421-27	DIODE MA728-TX	
D910	8-719-059-57	DIODE MAZJ082DFLSO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
D911	8-719-420-14	DIODE MA8082-TX	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< FERRITE BEAD >	
FB001	1-414-229-11	FERRITE 0UH	
FB002	1-414-229-11	FERRITE 0UH	
FB003	1-414-229-11	FERRITE 0UH	
FB004	1-414-229-11	FERRITE 0UH	
FB151	1-414-228-11	FERRITE 0UH	
FB152	1-414-921-11	FERRITE 0UH	
FB201	1-414-228-11	FERRITE 0UH	
FB202	1-414-228-11 •	FERRITE 0UH	
FB203	1-414-228-11	FERRITE 0UH	
FB204	1-414-228-11	FERRITE 0UH	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
FB205	1-414-228-11	FERRITE 0UH	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
FB206	1-414-228-11	FERRITE 0UH	
FB501	1-414-228-11	FERRITE 0UH	
FB503	1-500-284-21	FERRITE 0UH	
FB504	1-500-284-21	FERRITE 0UH	
FB505	1-500-284-21	FERRITE 0UH	(TRV15/TRV15PK/TRV15E/TRV15EP)
FB506	1-414-228-11	FERRITE 0UH	
		< IC >	
IC001	8-752-079-46	IC CXA2084R-T6	
IC151	8-752-078-82	IC CXA2030R-T6	
IC152	8-759-169-02	IC MB88344BPFV-G-BND-ER	
IC201	8-759-494-73	IC MB90097PFV-G-104-BND	
IC202	8-759-494-55	IC MB87F126PFF-G-BND	
IC204	8-752-390-52	IC CXD3124R-T6	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
IC301	8-759-494-29	IC AN2982FH-EB	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
IC301	8-759-494-30	IC AN2984FH-EB	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
IC371	8-759-494-52	IC BA7783FS-E2	
IC401	8-759-445-94	IC AK6480AM-E2	
IC402	8-759-499-08	IC MB91191PFF-G-BND-ER	
IC451	8-759-327-67	IC LB1950V-TLM	
IC452	8-759-327-61	IC LB8112V-TLM	(EXCEPT TRV15E/TRV15EP/TRV35E)
IC452	8-759-327-62	IC TA8482FN-EL	(TRV15E/TRV15EP/TRV35E)
IC501	8-752-384-70	IC CXD2486R-T4	
IC502	8-759-462-43	IC AD9800JCSTRL	
IC551	8-759-444-87	IC NJM324V(TE2)	
IC552	8-759-351-46	IC MPC17A34RVMEL (NTSC)	(EXCEPT TRV15E/TRV15EP/TRV35E)
IC552	8-759-475-79	IC uPD16833AG3-E2 (PAL)	(TRV15E/TRV15EP/TRV35E)

Ref No	Part No	Description	Remark
IC602	8-759-424-79	IC S-8423YFS-T2	
IC603	8-759-059-05	IC TL1596CPW-ELM1000	
IC604	8-759-494-75	IC S579C14PZ-8500-TEB	
IC751	8-759-498-52	IC LA9511W-TBM	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
		< COIL >	
L001	1-414-406-11	INDUCTOR 220uH	
L002	1-412-952-11	INDUCTOR 12uH	
L003	1-414-406-11	INDUCTOR 220uH	
L004	1-414-754-11	INDUCTOR 10uH	
L005	1-412-948-11	INDUCTOR 5 6uH	
L006	1-412-963-11	INDUCTOR 100uH	
L008	1-412-280-31	INDUCTOR 330uH	
L009	1-410-656-11	INDUCTOR CHIP 150uH	
L010	1-410-657-21	INDUCTOR CHIP 180uH	
L011	1-412-956-21	INDUCTOR 27uH	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L012	1-412-955-11	INDUCTOR 22uH	
L013	1-412-944-11	INDUCTOR 2 7uH	
L015	1-412-951-11	INDUCTOR 10uH	
L016	1-412-946-11	INDUCTOR 3 9uH	
L017	1-414-754-11	INDUCTOR 10uH	
L018	1-410-656-11	INDUCTOR CHIP 150uH	
L019	1-412-957-11	INDUCTOR 33uH	
L152	1-412-939-11	INDUCTOR 1uH	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L153	1-414-754-11	INDUCTOR 10uH	
L154	1-414-754-11	INDUCTOR 10uH	
L155	1-414-754-11	INDUCTOR 10uH	
L156	1-414-754-11	INDUCTOR 10uH	
L201	1-414-754-11	INDUCTOR 10uH	
L202	1-414-754-11	INDUCTOR 10uH	
L203	1-414-754-11	INDUCTOR 10uH	
L204	1-410-658-31	INDUCTOR CHIP 220uH	
L205	1-412-955-11	INDUCTOR 22uH	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L205	1-412-957-11	INDUCTOR 33uH	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L206	1-412-945-11	INDUCTOR 3 3uH	
L207	1-414-754-11	INDUCTOR 10uH	
L209	1-414-754-11	INDUCTOR 10uH	
L402	1-414-754-11	INDUCTOR 10uH	
L501	1-414-398-11	INDUCTOR 10uH	
L502	1-216-295-91	SHORT 0	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L502	1-412-955-11	INDUCTOR 22uH	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L552	1-414-398-11	INDUCTOR 10uH	
L553	1-414-754-11	INDUCTOR 10uH	
L555	1-414-754-11	INDUCTOR 10uH	
L602	1-414-754-11	INDUCTOR 10uH	
L751	1-412-948-11	INDUCTOR 5 6uH	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L752	1-412-957-11	INDUCTOR 33uH	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
L753	1-412-957-11	INDUCTOR 33uH	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

VC-195

Ref No	Part No	Description	Remark
		< TRANSISTOR >	
Q001	8-729-031-69	TRANSISTOR 2SA1965-TL	
Q002	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q003	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q004	8-729-031-69	TRANSISTOR 2SA1965-TL	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q005	8-729-031-69	TRANSISTOR 2SA1965-TL	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q006	8-729-031-69	TRANSISTOR 2SA1965-TL	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q007	8-729-031-69	TRANSISTOR 2SA1965-TL	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q008	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q009	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q010	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q011	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q012	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q017	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q019	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q020	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q021	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q022	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q023	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q024	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q025	8-729-043-40	TRANSISTOR 2SC4627J-C(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q026	8-729-031-69	TRANSISTOR 2SA1965-TL	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q027	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q028	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q029	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q030	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q032	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q033	8-729-031-69	TRANSISTOR 2SA1965-TL	
Q034	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q036	8-729-043-40	TRANSISTOR 2SC4627J-C(K8) SO	
Q038	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q039	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q040	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q041	8-729-230-72	TRANSISTOR 2SA1362-YG-EL	
Q042	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q043	8-729-031-69	TRANSISTOR 2SA1965-TL	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q044	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q151	8-729-037-61	TRANSISTOR UN9113J-(K8) SO	
Q153	8-729-040-77	TRANSISTOR 2SC5376-B(TE85L)	
Q154	8-729-040-77	TRANSISTOR 2SC5376-B(TE85L)	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q156	8-729-040-77	TRANSISTOR 2SC5376-B(TE85L)	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q202	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q203	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q204	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q205	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q208	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q213	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q214	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q215	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q216	8-729-037-52	TRANSISTOR 2SC4738F-Y/GR(TPL3)	(TRV93)
Q217	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q218	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q301	8-729-042-74	TRANSISTOR UN9216J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q302	8-729-042-74	TRANSISTOR UN9216J-(K8) SO	
Q305	8-729-042-61	TRANSISTOR UN9115J-(K8) SO	
Q306	8-729-042-73	TRANSISTOR UN9215J-(K8) SO	
Q307	8-729-042-73	TRANSISTOR UN9215J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q308	8-729-037-61	TRANSISTOR UN9113J-(K8) SO	
Q309	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q310	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q371	8-729-042-74	TRANSISTOR UN9216J-(K8) SO	
Q372	8-729-042-74	TRANSISTOR UN9216J-(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q452	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q453	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q454	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q455	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q456	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q501	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q551	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	
Q552	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q553	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q607	8-729-041-43	TRANSISTOR HN1L02FU(TE85R)	
Q608	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	
Q609	8-729-037-52	TRANSISTOR 2SD2216J-QR(K8) SO	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q610	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	
Q611	8-729-037-74	TRANSISTOR UN9213J-(K8) SO	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q619	8-729-037-53	TRANSISTOR 2SB1462J-QR(K8) SO	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
Q620	8-729-042-58	TRANSISTOR UN9111J-(K8) SO	
		< RESISTOR >	
R001	1-216-864-11	METAL CHIP 0 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R002	1-216-864-11	METAL CHIP 0 5% 1/16W	(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R003	1-216-806-11	RES,CHIP 56 5% 1/16W	
R004	1-216-818-11	METAL CHIP 560 5% 1/16W	
R005	1-216-809-11	METAL CHIP 100 5% 1/16W	
R006	1-216-825-11	METAL CHIP 2.2K 5% 1/16W	
R007	1-216-829-11	METAL CHIP 4.7K 5% 1/16W	
R008	1-216-814-11	METAL CHIP 270 5% 1/16W	
R009	1-216-813-11	METAL CHIP 220 5% 1/16W	
R010	1-216-828-11	METAL CHIP 3.9K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R011	1-216-828-11	METAL CHIP 3.9K 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)

Ref. No.	Part No.	Description			Remark
R012	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R013	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R014	1-216-837-11	METAL CHIP	22K	5%	1/16W
R015	1-216-839-11	METAL CHIP	33K	5%	1/16W
R016	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R017	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R018	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R019	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R020	1-216-837-11	METAL CHIP	22K	5%	1/16W
R021	1-216-837-11	METAL CHIP	22K	5%	1/16W
R023	1-216-837-11	METAL CHIP	22K	5%	1/16W
R025	1-216-837-11	METAL CHIP	22K	5%	1/16W
R026	1-216-816-11	METAL CHIP	390	5%	1/16W
R027	1-216-816-11	METAL CHIP	390	5%	1/16W
R029	1-216-837-11	METAL CHIP	22K	5%	1/16W
R031	1-216-837-11	METAL CHIP	22K	5%	1/16W
R032	1-216-816-11	METAL CHIP	390	5%	1/16W
R033	1-216-816-11	METAL CHIP	390	5%	1/16W
R034	1-216-864-11	METAL CHIP	0	5%	1/16W
R035	1-216-841-11	METAL CHIP	47K	5%	1/16W
R037	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R038	1-216-841-11	METAL CHIP	47K	5%	1/16W
R039	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R040	1-216-864-11	METAL CHIP	0	5%	1/16W
R043	1-216-833-11	METAL CHIP	10K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R045	1-216-845-11	METAL CHIP	100K	5%	1/16W
R046	1-216-821-11	METAL CHIP	1K	5%	1/16W
R047	1-216-864-11	METAL CHIP	0	5%	1/16W
R048	1-216-864-11	METAL CHIP	0	5%	1/16W
R049	1-216-833-11	METAL CHIP	10K	5%	1/16W
R050	1-216-837-11	METAL CHIP	22K	5%	1/16W
R051	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R052	1-216-833-11	METAL CHIP	10K	5%	1/16W
R055	1-216-829-11	METAL CHIP	4.7K	5%	1/16W (EXCEPT TRV15E/TRV15EP/TRV35E)
R055	1-216-830-11	METAL CHIP	5.6K	5%	1/16W (TRV15E/TRV15EP/TRV35E)
R056	1-216-855-11	METAL CHIP	680K	5%	1/16W
R057	1-216-819-11	METAL CHIP	680	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R057	1-216-864-11	METAL CHIP	0	5%	1/16W (EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R058	1-216-853-11	METAL CHIP	470K	5%	1/16W
R059	1-216-821-11	METAL CHIP	1K	5%	1/16W
R060	1-216-837-11	METAL CHIP	22K	5%	1/16W
R061	1-216-833-11	METAL CHIP	10K	5%	1/16W
R062	1-216-818-11	METAL CHIP	560	5%	1/16W
R063	1-216-817-11	METAL CHIP	470	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R063	1-216-818-11	METAL CHIP	560	5%	1/16W (EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R064	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R064	1-216-864-11	METAL CHIP	0	5%	1/16W (EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R065	1-216-833-11	METAL CHIP	10K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R066	1-216-823-11	METAL CHIP	1.5K	5%	1/16W (TRV15E/TRV15EP/TRV35E)
R066	1-216-825-11	METAL CHIP	2.2K	5%	1/16W (EXCEPT TRV15E/TRV15EP/TRV35E)
R067	1-216-817-11	METAL CHIP	470	5%	1/16W
R068	1-216-817-11	METAL CHIP	470	5%	1/16W
R069	1-216-864-11	METAL CHIP	0	5%	1/16W
R072	1-216-864-11	METAL CHIP	0	5%	1/16W
R073	1-216-821-11	METAL CHIP	1K	5%	1/16W
R074	1-216-816-11	METAL CHIP	390	5%	1/16W
R075	1-216-817-11	METAL CHIP	470	5%	1/16W
R076	1-216-816-11	METAL CHIP	390	5%	1/16W
R077	1-216-814-11	METAL CHIP	270	5%	1/16W (TRV15E/TRV15EP/TRV35E)
R077	1-216-815-11	METAL CHIP	330	5%	1/16W (TRV15/TRV15PK/TRV25/TRV25PK/TRV215/TRV35/TRV35PK/TRV315)
R078	1-216-815-11	METAL CHIP	330	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R079	1-216-815-11	METAL CHIP	330	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R080	1-216-813-11	METAL CHIP	220	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R081	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R082	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R083	1-216-820-11	METAL CHIP	820	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R084	1-216-833-11	METAL CHIP	10K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R085	1-216-833-11	METAL CHIP	10K	5%	1/16W
R087	1-216-821-11	METAL CHIP	1K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R088	1-216-864-11	METAL CHIP	0	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R092	1-216-809-11	METAL CHIP	100	5%	1/16W
R093	1-216-833-11	METAL CHIP	10K	5%	1/16W
R094	1-216-815-11	METAL CHIP	330	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R095	1-216-839-11	METAL CHIP	33K	5%	1/16W
R096	1-216-813-11	METAL CHIP	220	5%	1/16W
R098	1-216-817-11	METAL CHIP	470	5%	1/16W
R099	1-216-817-11	METAL CHIP	470	5%	1/16W
R101	1-216-837-11	METAL CHIP	22K	5%	1/16W
R102	1-216-834-11	METAL CHIP	12K	5%	1/16W
R103	1-216-816-11	METAL CHIP	390	5%	1/16W
R104	1-216-828-11	METAL CHIP	3.9K	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R105	1-216-814-11	METAL CHIP	270	5%	1/16W (EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R105	1-216-819-11	METAL CHIP	680	5%	1/16W (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R106	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R107	1-216-833-11	METAL CHIP	10K	5%	1/16W
R109	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R110	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
R112	1-216-833-11	METAL CHIP	10K	5%	1/16W
R113	1-216-825-11	METAL CHIP	2.2K	5%	1/16W

Ref. No.	Part No.	Description			Remark
R152	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R154	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R157	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R161	1-216-804-11	METAL CHIP	39	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R162	1-216-803-11	METAL CHIP	33	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R165	1-216-803-11	METAL CHIP	33	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R166	1-216-804-11	METAL CHIP	39	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R167	1-216-803-11	METAL CHIP	33	5%	1/16W
R170	1-216-804-11	METAL CHIP	39	5%	1/16W
R175	1-216-836-11	METAL CHIP	18K	5%	1/16W
					(TRV15E/TRV15EP/TRV35E)
R175	1-216-837-11	METAL CHIP	22K	5%	1/16W
					(EXCEPT TRV15E/TRV15EP/TRV35E)
R176	1-216-837-11	METAL CHIP	22K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R177	1-216-821-11	METAL CHIP	1K	5%	1/16W
R178	1-216-821-11	METAL CHIP	1K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R179	1-216-815-11	METAL CHIP	330	5%	1/16W
R180	1-216-815-11	METAL CHIP	330	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R183	1-218-876-11	RES,CHIP	16K	0.50%	1/16W
R184	1-218-847-11	RES,CHIP	1K	0.50%	1/16W
R202	1-216-833-11	METAL CHIP	10K	5%	1/16W
R203	1-216-814-11	METAL CHIP	270	5%	1/16W
R205	1-216-835-11	METAL CHIP	15K	5%	1/16W
R206	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R208	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R210	1-216-809-11	METAL CHIP	100	5%	1/16W
R211	1-216-830-11	METAL CHIP	5.6K	5%	1/16W
R212	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R214	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R215	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R216	1-216-811-11	METAL CHIP	150	5%	1/16W
R217	1-216-864-11	METAL CHIP	0	5%	1/16W
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R218	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R219	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R220	1-216-815-11	METAL CHIP	330	5%	1/16W
R222	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
					(TRV93)
R223	1-216-821-11	METAL CHIP	1K	5%	1/16W
R224	1-216-831-11	METAL CHIP	6.8K	5%	1/16W
R225	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R226	1-216-820-11	METAL CHIP	820	5%	1/16W
R227	1-216-811-11	METAL CHIP	150	5%	1/16W
R228	1-216-813-11	METAL CHIP	220	5%	1/16W
R229	1-216-805-11	METAL CHIP	47	5%	1/16W
R230	1-216-812-11	METAL CHIP	180	5%	1/16W
R231	1-216-812-11	METAL CHIP	180	5%	1/16W
R232	1-216-815-11	METAL CHIP	330	5%	1/16W
R233	1-216-824-11	METAL CHIP	1.8K	5%	1/16W
R234	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R236	1-216-825-11	METAL CHIP	2.2K	5%	1/16W

Ref. No.	Part No.	Description			Remark
R237	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R238	1-216-832-11	METAL CHIP	8.2K	5%	1/16W
R239	1-216-827-11	METAL CHIP	3.3K	5%	1/16W
R240	1-216-857-11	METAL CHIP	1M	5%	1/16W
R241	1-216-828-11	METAL CHIP	3.9K	5%	1/16W
R242	1-216-845-11	METAL CHIP	100K	5%	1/16W
R243	1-216-845-11	METAL CHIP	100K	5%	1/16W
R244	1-216-845-11	METAL CHIP	100K	5%	1/16W
R245	1-216-840-11	METAL CHIP	39K	5%	1/16W
R246	1-216-835-11	METAL CHIP	15K	5%	1/16W
R247	1-216-817-11	METAL CHIP	470	5%	1/16W
R248	1-216-822-11	METAL CHIP	1.2K	5%	1/16W
R249	1-216-833-11	METAL CHIP	10K	5%	1/16W
R250	1-216-295-91	SHORT	0		
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R251	1-216-833-11	METAL CHIP	10K	5%	1/16W
R252	1-216-821-11	METAL CHIP	1K	5%	1/16W
R253	1-216-845-11	METAL CHIP	100K	5%	1/16W
R254	1-216-864-11	METAL CHIP	0	5%	1/16W
R255	1-216-833-11	METAL CHIP	10K	5%	1/16W
R256	1-216-845-11	METAL CHIP	100K	5%	1/16W
R257	1-216-295-91	SHORT	0		
R302	1-216-817-11	METAL CHIP	470	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R303	1-216-817-11	METAL CHIP	470	5%	1/16W
R304	1-216-817-11	METAL CHIP	470	5%	1/16W
R305	1-216-817-11	METAL CHIP	470	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R308	1-216-864-11	METAL CHIP	0	5%	1/16W
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R311	1-216-841-11	METAL CHIP	47K	5%	1/16W
R313	1-216-864-11	METAL CHIP	0	5%	1/16W
R314	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
R315	1-216-823-11	METAL CHIP	1.5K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R316	1-216-841-11	METAL CHIP	47K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R317	1-216-845-11	METAL CHIP	100K	5%	1/16W
R318	1-216-845-11	METAL CHIP	100K	5%	1/16W
R319	1-216-845-11	METAL CHIP	100K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R320	1-216-849-11	METAL CHIP	220K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R321	1-216-843-11	METAL CHIP	68K	5%	1/16W
R322	1-216-845-11	METAL CHIP	100K	5%	1/16W
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R322	1-216-849-11	METAL CHIP	220K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R323	1-216-837-11	METAL CHIP	22K	5%	1/16W
R325	1-216-849-11	METAL CHIP	220K	5%	1/16W
					(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R325	1-216-851-11	METAL CHIP	330K	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R331	1-216-864-11	METAL CHIP	0	5%	1/16W
R343	1-216-864-11	METAL CHIP	0	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R371	1-216-821-11	METAL CHIP	1K	5%	1/16W
R373	1-216-809-11	METAL CHIP	100	5%	1/16W
					(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R374	1-216-809-11	METAL CHIP	100	5%	1/16W

Ref No	Part No	Description			Remark
R375	1-216-834-11	METAL CHIP	12K	5%	1/16W
R376	1-216-834-11	METAL CHIP	12K	5%	1/16W
R377	1-216-834-11	METAL CHIP	12K	5%	1/16W
R378	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R379	1-216-852-11	METAL CHIP	390K	5%	1/16W
R382	1-216-837-11	METAL CHIP	22K	5%	1/16W
R383	1-216-837-11	METAL CHIP	22K	5%	1/16W
R384	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R385	1-216-826-11	METAL CHIP	2 7K	5%	1/16W
R386	1-216-849-11	METAL CHIP	220K	5%	1/16W
R402	1-216-821-11	METAL CHIP	1K	5%	1/16W
R403	1-216-845-11	METAL CHIP	100K	5%	1/16W
R404	1-216-845-11	METAL CHIP	100K	5%	1/16W
R405	1-216-845-11	METAL CHIP	100K	5%	1/16W
R406	1-216-845-11	METAL CHIP	100K	5%	1/16W
R407	1-216-845-11	METAL CHIP	100K	5%	1/16W
R409	1-216-845-11	METAL CHIP	100K	5%	1/16W
R410	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R412	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R414	1-216-864-11	METAL CHIP	0	5%	1/16W
R415	1-216-821-11	METAL CHIP	1K	5%	1/16W
R416	1-216-821-11	METAL CHIP	1K	5%	1/16W
R417	1-216-821-11	METAL CHIP	1K	5%	1/16W
R418	1-216-821-11	METAL CHIP	1K	5%	1/16W
R419	1-216-839-11	METAL CHIP	33K	5%	1/16W
R420	1-216-833-11	METAL CHIP	10K	5%	1/16W
R421	1-216-833-11	METAL CHIP	10K	5%	1/16W
R424	1-216-841-11	METAL CHIP	47K	5%	1/16W
R425	1-216-853-11	METAL CHIP	470K	5%	1/16W
R426	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R427	1-216-841-11	METAL CHIP	47K	5%	1/16W
R428	1-216-841-11	METAL CHIP	47K	5%	1/16W
R429	1-216-811-11	METAL CHIP	150	5%	1/16W
R430	1-216-813-11	METAL CHIP	220	5%	1/16W
R431	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R432	1-216-845-11	METAL CHIP	100K	5%	1/16W
R433	1-216-845-11	METAL CHIP	100K	5%	1/16W
R434	1-216-853-11	METAL CHIP	470K	5%	1/16W
R435	1-216-853-11	METAL CHIP	470K	5%	1/16W
R440	1-216-841-11	METAL CHIP	47K	5%	1/16W
R441	1-216-845-11	METAL CHIP	100K	5%	1/16W
R452	1-217-671-11	METAL CHIP	1	5%	1/10W
R453	1-217-671-11	METAL CHIP	1	5%	1/10W
R454	1-217-671-11	METAL CHIP	1	5%	1/10W
R455	1-216-833-11	METAL CHIP	10K	5%	1/16W
R456	1-216-833-11	METAL CHIP	10K	5%	1/16W
R457	1-216-833-11	METAL CHIP	10K	5%	1/16W
R458	1-216-808-11	METAL CHIP	82	5%	1/16W
R459	1-216-864-11	METAL CHIP	0	5%	1/16W
R460	1-216-864-11	METAL CHIP	0	5%	1/16W
R461	1-216-853-11	METAL CHIP	470K	5%	1/16W
R462	1-216-853-11	METAL CHIP	470K	5%	1/16W
R463	1-216-853-11	METAL CHIP	470K	5%	1/16W
R464	1-216-851-11	METAL CHIP	330K	5%	1/16W
R465	1-216-845-11	METAL CHIP	100K	5%	1/16W
R466	1-216-841-11	METAL CHIP	47K	5%	1/16W
R467	1-216-833-11	METAL CHIP	10K	5%	1/16W

Ref No	Part No	Description			Remark
R468	1-216-833-11	METAL CHIP	10K	5%	1/16W
R469	1-216-841-11	METAL CHIP	47K	5%	1/16W
R470	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R471	1-216-833-11	METAL CHIP	10K	5%	1/16W
R472	1-216-833-11	METAL CHIP	10K	5%	1/16W
					(EXCEPT TRV15E/TRV15EP/TRV35E)
R472	1-216-837-11	METAL CHIP	22K	5%	1/16W
					(TRV15E/TRV15EP/TRV35E)
R473	1-216-841-11	METAL CHIP	47K	5%	1/16W
R474	1-216-817-11	METAL CHIP	470	5%	1/16W
R475	1-216-838-11	METAL CHIP	27K	5%	1/16W
R476	1-216-817-11	METAL CHIP	470	5%	1/16W
R477	1-216-864-11	METAL CHIP	0	5%	1/16W
R479	1-216-864-11	METAL CHIP	0	5%	1/16W
R480	1-216-864-11	METAL CHIP	0	5%	1/16W
R481	1-216-864-11	METAL CHIP	0	5%	1/16W
R482	1-216-830-11	METAL CHIP	5 6K	5%	1/16W
					(TRV15E/TRV15EP/TRV35E)
R482	1-216-833-11	METAL CHIP	10K	5%	1/16W
					(EXCEPT TRV15E/TRV15EP/TRV35E)
R483	1-216-836-11	METAL CHIP	18K	5%	1/16W
R484	1-217-671-11	METAL CHIP	1	5%	1/10W
R485	1-217-671-11	METAL CHIP	1	5%	1/10W
R486	1-216-845-11	METAL CHIP	100K	5%	1/16W
R487	1-216-827-11	METAL CHIP	3 3K	5%	1/16W
R488	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R490	1-216-023-00	METAL CHIP	82	5%	1/10W
R502	1-216-798-11	RES,CHIP	12	5%	1/16W
R503	1-216-798-11	RES,CHIP	12	5%	1/16W
R504	1-216-845-11	METAL CHIP	100K	5%	1/16W
R505	1-216-864-11	METAL CHIP	0	5%	1/16W
R506	1-216-857-11	METAL CHIP	1M	5%	1/16W
R508	1-216-809-11	METAL CHIP	100	5%	1/16W
R509	1-216-864-11	METAL CHIP	0	5%	1/16W
R510	1-216-809-11	METAL CHIP	100	5%	1/16W
R511	1-216-809-11	METAL CHIP	100	5%	1/16W
					(TRV15/TRV15PK/TRV15E/TRV15EP)
R512	1-216-853-11	METAL CHIP	470K	5%	1/16W
R513	1-216-825-11	METAL CHIP	2 2K	5%	1/16W
R514	1-216-821-11	METAL CHIP	1K	5%	1/16W
R515	1-216-864-11	METAL CHIP	0	5%	1/16W
R522	1-216-864-11	METAL CHIP	0	5%	1/16W
R525	1-216-864-11	METAL CHIP	0	5%	1/16W
R526	1-216-864-11	METAL CHIP	0	5%	1/16W
R527	1-216-864-11	METAL CHIP	0	5%	1/16W
					(EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)
R529	1-216-864-11	METAL CHIP	0	5%	1/16W
R551	1-216-841-11	METAL CHIP	47K	5%	1/16W
R554	1-216-843-11	METAL CHIP	68K	5%	1/16W
R555	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R556	1-216-001-00	METAL CHIP	10	5%	1/10W
R557	1-216-843-11	METAL CHIP	68K	5%	1/16W
R558	1-216-295-91	SHORT	0		
R560	1-216-821-11	METAL CHIP	1K	5%	1/16W
R561	1-216-853-11	METAL CHIP	470K	5%	1/16W
R562	1-216-849-11	METAL CHIP	220K	5%	1/16W
R563	1-216-853-11	METAL CHIP	470K	5%	1/16W
R564	1-216-853-11	METAL CHIP	470K	5%	1/16W
R565	1-216-833-11	METAL CHIP	10K	5%	1/16W

VC-195

Ref No	Part No	Description			Remark
R566	1-216-835-11	METAL CHIP	15K	5%	1/16W
R567	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R569	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
R570	1-216-841-11	METAL CHIP	47K	5%	1/16W
R571	1-216-837-11	METAL CHIP	22K	5%	1/16W
R572	1-216-845-11	METAL CHIP	100K	5%	1/16W
R573	1-216-815-11	METAL CHIP	330	5%	1/16W
R574	1-216-821-11	METAL CHIP	1K	5%	1/16W
R575	1-216-821-11	METAL CHIP	1K	5%	1/16W
R576	1-216-821-11	METAL CHIP	1K	5%	1/16W
R577	1-216-833-11	METAL CHIP	10K	5%	1/16W
R579	1-216-821-11	METAL CHIP	1K	5%	1/16W
R582	1-216-864-11	METAL CHIP	0	5%	1/16W
R603	1-216-845-11	METAL CHIP	100K	5%	1/16W
R604	1-216-813-11	METAL CHIP	220	5%	1/16W
R605	1-216-841-11	METAL CHIP	47K	5%	1/16W
R606	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R608	1-216-845-11	METAL CHIP	100K	5%	1/16W
R610	1-216-821-11	METAL CHIP	1K	5%	1/16W
R611	1-216-825-11	METAL CHIP	2.2K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R612	1-216-853-11	METAL CHIP	470K	5%	1/16W
R613	1-216-821-11	METAL CHIP	1K	5%	1/16W
R614	1-216-821-11	METAL CHIP	1K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R618	1-216-853-11	METAL CHIP	470K	5%	1/16W
R619	1-216-853-11	METAL CHIP	470K	5%	1/16W
R620	1-216-853-11	METAL CHIP	470K	5%	1/16W
R621	1-216-853-11	METAL CHIP	470K	5%	1/16W
R622	1-216-853-11	METAL CHIP	470K	5%	1/16W
R624	1-216-853-11	METAL CHIP	470K	5%	1/16W
R625	1-216-845-11	METAL CHIP	100K	5%	1/16W
R627	1-216-853-11	METAL CHIP	470K	5%	1/16W
R628	1-216-841-11	METAL CHIP	47K	5%	1/16W
R629	1-216-833-11	METAL CHIP	10K	5%	1/16W
R630	1-216-826-11	METAL CHIP	2.7K	5%	1/16W
R631	1-216-845-11	METAL CHIP	100K	5%	1/16W
R632	1-216-857-11	METAL CHIP	1M	5%	1/16W
R633	1-216-853-11	METAL CHIP	470K	5%	1/16W
R634	1-216-853-11	METAL CHIP	470K	5%	1/16W
R635	1-216-857-11	METAL CHIP	1M	5%	1/16W
R636	1-216-857-11	METAL CHIP	1M	5%	1/16W
R637	1-216-845-11	METAL CHIP	100K	5%	1/16W
R638	1-216-845-11	METAL CHIP	100K	5%	1/16W
R639	1-216-845-11	METAL CHIP	100K	5%	1/16W
R642	1-216-821-11	METAL CHIP	1K	5%	1/16W
R643	1-216-857-11	METAL CHIP	1M	5%	1/16W
R644	1-216-841-11	METAL CHIP	47K	5%	1/16W
R645	1-216-845-11	METAL CHIP	100K	5%	1/16W
R646	1-216-853-11	METAL CHIP	470K	5%	1/16W
R647	1-216-853-11	METAL CHIP	470K	5%	1/16W
R648	1-216-853-11	METAL CHIP	470K	5%	1/16W
R649	1-216-857-11	METAL CHIP	1M	5%	1/16W
R650	1-219-570-11	RES,CHIP	10M	5%	1/16W
R651	1-216-845-11	METAL CHIP	100K	5%	1/16W
R652	1-216-853-11	METAL CHIP	470K	5%	1/16W
R653	1-216-853-11	METAL CHIP	470K	5%	1/16W

Ref No	Part No	Description			Remark
R654	1-216-817-11	METAL CHIP	470	5%	1/16W
R655	1-216-853-11	METAL CHIP	470K	5%	1/16W
R662	1-216-841-11	METAL CHIP	47K	5%	1/16W
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R663	1-216-853-11	METAL CHIP	470K	5%	1/16W
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R665	1-216-853-11	METAL CHIP	470K	5%	1/16W
		(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R666	1-216-821-11	METAL CHIP	1K	5%	1/16W
R667	1-216-821-11	METAL CHIP	1K	5%	1/16W
R668	1-216-821-11	METAL CHIP	1K	5%	1/16W
R669	1-216-821-11	METAL CHIP	1K	5%	1/16W
R670	1-216-821-11	METAL CHIP	1K	5%	1/16W
R671	1-216-821-11	METAL CHIP	1K	5%	1/16W
R672	1-216-821-11	METAL CHIP	1K	5%	1/16W
R673	1-216-821-11	METAL CHIP	1K	5%	1/16W
R675	1-216-821-11	METAL CHIP	1K	5%	1/16W
R676	1-216-821-11	METAL CHIP	1K	5%	1/16W
R677	1-216-821-11	METAL CHIP	1K	5%	1/16W
R678	1-216-821-11	METAL CHIP	1K	5%	1/16W
R679	1-216-821-11	METAL CHIP	1K	5%	1/16W
R680	1-216-845-11	METAL CHIP	100K	5%	1/16W
R681	1-216-821-11	METAL CHIP	1K	5%	1/16W
R682	1-216-821-11	METAL CHIP	1K	5%	1/16W
R683	1-216-821-11	METAL CHIP	1K	5%	1/16W
R684	1-216-821-11	METAL CHIP	1K	5%	1/16W
R685	1-216-821-11	METAL CHIP	1K	5%	1/16W
R686	1-216-821-11	METAL CHIP	1K	5%	1/16W
R687	1-216-821-11	METAL CHIP	1K	5%	1/16W
R689	1-216-864-11	METAL CHIP	0	5%	1/16W
		(EXCEPT TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R690	1-216-821-11	METAL CHIP	1K	5%	1/16W
R691	1-216-845-11	METAL CHIP	100K	5%	1/16W
R692	1-216-853-11	METAL CHIP	470K	5%	1/16W
R693	1-216-821-11	METAL CHIP	1K	5%	1/16W
R726	1-216-864-11	METAL CHIP	0	5%	1/16W
R752	1-216-841-11	METAL CHIP	47K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R753	1-216-841-11	METAL CHIP	47K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R755	1-216-837-11	METAL CHIP	22K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R756	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R757	1-216-829-11	METAL CHIP	4.7K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R758	1-216-833-11	METAL CHIP	10K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R759	1-216-833-11	METAL CHIP	10K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R760	1-216-835-11	METAL CHIP	15K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R761	1-216-857-11	METAL CHIP	1M	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R763	1-218-879-11	RES,CHIP	22K	0.50%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R764	1-216-815-11	METAL CHIP	330	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			
R765	1-216-821-11	METAL CHIP	1K	5%	1/16W
		(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)			

Ref No	Part No	Description	Remark
R767	1-216-817-11	METAL CHIP 470 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R768	1-216-847-11	METAL CHIP 150K 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R770	1-216-847-11	METAL CHIP 150K 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R771	1-216-818-11	METAL CHIP 560 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R772	1-216-831-11	METAL CHIP 6 8K 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R773	1-216-817-11	METAL CHIP 470 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R774	1-216-840-11	METAL CHIP 39K 5% 1/16W	(TRV35/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R775	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV15E/TRV15EP/TRV35E)
R917	1-216-837-11	METAL CHIP 22K 5% 1/16W	(EXCEPT TRV93)
R917	1-216-841-11	METAL CHIP 47K 5% 1/16W	(TRV93)
R918	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R919	1-216-837-11	METAL CHIP 22K 5% 1/16W	(TRV35)
R919	1-216-841-11	METAL CHIP 47K 5% 1/16W	(TRV25/TRV25PK/TRV215)
R919	1-216-842-11	METAL CHIP 56K 5% 1/16W	(TRV15/TRV15PK)
R919	1-216-845-11	METAL CHIP 100K 5% 1/16W	(TRV15E/TRV15EP/TRV35E/TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
R920	1-216-837-11	METAL CHIP 22K 5% 1/16W	(TRV15E/TRV15EP)
R920	1-216-841-11	METAL CHIP 47K 5% 1/16W	(TRV35E)
R920	1-216-843-11	METAL CHIP 68K 5% 1/16W	(TRV15/TRV15PK)
R920	1-216-845-11	METAL CHIP 100K 5% 1/16W	(TRV25/TRV25PK/TRV215/TRV35)
R921	1-216-845-11	METAL CHIP 100K 5% 1/16W	
R922	1-217-671-11	METAL CHIP 1 5% 1/10W	
R923	1-217-671-11	METAL CHIP 1 5% 1/10W	
R924	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R925	1-216-821-11	METAL CHIP 1K 5% 1/16W	
R926	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV65/TRV65PK/TRV85/TRV615/TRV815)
R927	1-216-864-11	METAL CHIP 0 5% 1/16W	(TRV93)
		< VIBRATOR >	
X151	1-767-028-21	VIBRATOR, CRYSTAL (14 318MHz)	(TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)
X401	1-760-655-41	VIBRATOR, CRYSTAL (20MHz)	
X501	1-760-320-11	VIBRATOR, CRYSTAL (28 6363MHz)	(EXCEPT TRV15E/TRV15EP/TRV35E)
X501	1-760-321-11	VIBRATOR, CRYSTAL (28 375MHz)	(TRV15E/TRV15EP/TRV35E)
X601	1-579-907-21	VIBRATOR, CERAMIC (20MHz)	
X602	1-760-458-21	VIBRATOR, CRYSTAL (32 798kHz)	

Ref No	Part No	Description	Remark
	A-7066-792-A	VF-99(VHL4) BOARD, COMPLETE ***************************	(EXCEPT TRV15E/TRV15EP/TRV35E/TRV93)
	A-7056-774-A	ED PWB, VF-99(HP) BOARD, COMPLETE **********************************	(TRV15E/TRV15EP/TRV35E) (Ref No 10,000 Series)
		< CAPACITOR >	
C901	1-107-854-11	TANTAL CHIP 68uF 20% 6 3V	
C902	1-163-038-91	CERAMIC CHIP 0 1uF 25V	
C903	1-135-145-11	TANTALUM CHIP 0 47uF 10% 35V	
C904	1-162-965-11	CERAMIC CHIP 0 0015uF 10% 50V	
C905	1-104-752-11	TANTAL CHIP 33uF 20% 6 3V	
C906	1-162-638-11	CERAMIC CHIP 1uF 16V	
C907	1-104-563-11	FILM CHIP 0 1uF 5% 16V	
C908	1-162-920-11	CERAMIC CHIP 27PF 5% 50V	
C909	1-163-009-11	CERAMIC CHIP 0 001uF 10% 50V	
⚠C910	1-164-758-11	CERAMIC CHIP 0 0039uF 5% 50V	
⚠C911	1-164-715-11	CERAMIC CHIP 0 0068uF 5% 50V	
C912	1-107-854-11	TANTAL CHIP 68uF 20% 6 3V	
C913	1-135-145-11	TANTALUM CHIP 0 47uF 10% 35V	
C914	1-107-689-21	TANTAL CHIP 1uF 20% 35V	(EXCEPT TRV15E/TRV15EP/TRV35E/TRV93)
C914	1-113-984-11	TANTAL CHIP 1 5uF 20% 35V	(TRV15E/TRV15EP/TRV35E)
C915	1-163-037-11	CERAMIC CHIP 0 022uF 10% 25V	
C916	1-164-611-11	CERAMIC CHIP 0 001uF 10% 500V	
		< CONNECTOR >	
CN901	1-573-506-41	CONNECTOR, FPC (NON ZIF) 4P	
CN902	1-580-057-11	PIN, CONNECTOR 4P	
		< DIODE >	
D901	8-719-951-21	DIODE PR1102W-TR	
D903	8-719-404-49	DIODE MA111-TX	
		< IC >	
IC901	8-759-196-14	IC BA7149F-E2	
		< COIL >	
L901	1-412-031-11	INDUCTOR CHIP 47uH	
L902	1-410-387-11	INDUCTOR CHIP 33uH	
⚠L903	1-411-697-11	COIL, FERRITE (HLC)	
		< TRANSISTOR >	
Q901	8-729-230-63	TRANSISTOR 2SD1819A-QRS-TX	
Q902	8-729-106-68	TRANSISTOR 2SD1615-T1GLGK	
Q903	8-729-216-31	TRANSISTOR 2SA1163G-TE85L	
Q904	8-729-230-63	TRANSISTOR 2SD1819A-QRS-TX	
		< RESISTOR >	
R901	1-216-817-11	METAL CHIP 470 5% 1/16W	
R902	1-216-817-11	METAL CHIP 470 5% 1/16W	
R903	1-216-057-00	METAL CHIP 2 2K 5% 1/10W	
R904	1-216-833-11	METAL CHIP 10K 5% 1/16W	
R905	1-216-822-11	METAL CHIP 1 2K 5% 1/16W	

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

Ref No	Part No	Description			Remark
R906	1-216-813-11	METAL CHIP	220	5%	1/16W
R907	1-216-845-11	METAL CHIP	100K	5%	1/16W
R908	1-216-852-11	METAL CHIP	390K	5%	1/16W
R909	1-216-833-11	METAL CHIP	10K	5%	1/16W
R910	1-216-835-11	METAL CHIP	15K	5%	1/16W
R911	1-216-160-00	RES,CHIP	27	5%	1/8W
R912	1-216-857-11	METAL CHIP	1M	5%	1/16W
R913	1-216-820-11	METAL CHIP	820	5%	1/16W
R914	1-216-813-11	METAL CHIP	220	5%	1/16W
R915	1-216-793-11	RES,CHIP	4 7	5%	1/16W
R916	1-218-879-11	RES,CHIP	22K	0 50%	1/16W
		(EXCEPT TRV15E/TRV15EP/TRV35E/TRV93)			
R916	1-218-881-11	RES,CHIP	27K	0 50%	1/16W
		(TRV15E/TRV15EP/TRV35E)			
R917	1-218-891-11	RES,CHIP	68K	0 50%	1/16W
		(EXCEPT TRV15E/TRV15EP/TRV35E/TRV93)			
R917	1-218-893-11	RES,CHIP	82K	0 50%	1/16W
		(TRV15E/TRV15EP/TRV35E)			
R918	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R919	1-216-839-11	METAL CHIP	33K	5%	1/16W
		(EXCEPT TRV15E/TRV15EP/TRV35E/TRV93)			
R919	1-216-843-11	METAL CHIP	68K	5%	1/16W
		(TRV15E/TRV15EP/TRV35E)			
R920	1-216-837-11	METAL CHIP	22K	5%	1/16W
R921	1-216-795-11	RES,CHIP	6 8	5%	1/16W
R922	1-216-847-11	METAL CHIP	150K	5%	1/16W
R923	1-216-857-11	METAL CHIP	1M	5%	1/16W
R924	1-216-862-11	RES,CHIP	2 7M	5%	1/16W
R925	1-216-862-11	RES,CHIP	2 7M	5%	1/16W
R926	1-216-821-11	METAL CHIP	1K	5%	1/16W
R927	1-216-821-11	METAL CHIP	1K	5%	1/16W
R928	1-216-827-11	METAL CHIP	3 3K	5%	1/16W
R929	1-216-818-11	METAL CHIP	560	5%	1/16W

< VARIABLE RESISTOR >

RV903	1-238-852-11	RES, ADJ, CERMET 470
RV904	1-223-566-11	RES, ADJ, METAL GLAZE 1M

< TRANSFORMER >

⚠T901	1-453-124-11	TRANSFORMER ASSY, FLYBACK

< THERMISTOR >

TH901	1-809-350-21	THERMISTOR, NTC (2125)

< CRT SOCKET >

⚠W901	1-540-019-21	SOCKET ASSY, CRT

A-7073-437-A VF-119 BOARD, COMPLETE (TRV93)

****

(Ref No 10,000 Series)

< CAPACITOR >

C5401	1-135-259-11	TANTAL CHIP	10uF	20%	6 3V
C5402	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5403	1-135-179-21	TANTAL CHIP	2 2uF	20%	16V
C5404	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C5405	1-164-156-11	CERAMIC CHIP	0 1uF		25V

Ref No	Part No	Description			Remark
C5406	1-164-156-11	CERAMIC CHIP	0 1uF		25V
C5407	1-135-181-21	TANTALUM CHIP	4 7uF	20%	6 3V
C5408	1-135-181-21	TANTALUM CHIP	4 7uF	20%	6 3V
C5409	1-135-181-21	TANTALUM CHIP	4 7uF	20%	6 3V
C5410	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5411	1-135-181-21	TANTALUM CHIP	4 7uF	20%	6 3V
C5413	1-107-686-11	TANTAL CHIP	4 7uF	20%	16V
C5414	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5415	1-164-505-11	CERAMIC CHIP	2 2uF		16V
C5416	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V
C5417	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5418	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V
C5419	1-162-967-11	CERAMIC CHIP	0 0033uF	10%	50V
C5420	1-164-357-11	CERAMIC CHIP	1000PF	5%	50V
C5421	1-162-927-11	CERAMIC CHIP	100PF	5%	50V
C5422	1-135-259-11	TANTAL CHIP	10uF	20%	6 3V
C5423	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5424	1-165-112-11	CERAMIC CHIP	0 33uF		16V
C5427	1-165-112-11	CERAMIC CHIP	0 33uF		16V
C5429	1-107-682-11	CERAMIC CHIP	1uF	10%	16V

< CONNECTOR >

CN5401	1-766-350-21	CONNECTOR, FFC/FPC 20P
CN5402	1-691-380-21	CONNECTOR, FFC/FPC 16P

< DIODE >

D5401	8-713-102-80	DIODE 1T369-01-T8A

< IC >

IC5401	8-759-498-53	IC CXA8115R-T4
IC5402	8-759-364-05	IC M62376GP-65AD
IC5404	8-752-389-81	IC CXD2458R-T4

< COIL >

L5401	1-412-951-11	INDUCTOR	10uH
L5402	1-412-951-11	INDUCTOR	10uH
L5403	1-412-959-11	INDUCTOR	47uH
L5404	1-412-949-21	INDUCTOR	6 8uH
L5405	1-412-959-11	INDUCTOR	47uH

< RESISTOR >

R5401	1-216-864-11	METAL CHIP	0	5%	1/16W
R5403	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5405	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5408	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5409	1-216-839-11	METAL CHIP	33K	5%	1/16W
R5415	1-216-864-11	METAL CHIP	0	5%	1/16W
R5416	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5417	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5420	1-216-843-11	METAL CHIP	68K	5%	1/16W
R5421	1-216-839-11	METAL CHIP	33K	5%	1/16W
R5422	1-216-840-11	METAL CHIP	39K	5%	1/16W
R5423	1-216-853-11	METAL CHIP	470K	5%	1/16W
R5424	1-216-840-11	METAL CHIP	39K	5%	1/16W
R5425	1-216-843-11	METAL CHIP	68K	5%	1/16W
R5426	1-216-839-11	METAL CHIP	33K	5%	1/16W

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

Ref No	Part No	Description			Remark
R5429	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5431	1-216-809-11	METAL CHIP	100	5%	1/16W
R5432	1-216-809-11	METAL CHIP	100	5%	1/16W
R5433	1-218-877-11	RES,CHIP	18K	0 50%	1/16W
R5434	1-218-873-11	RES,CHIP	12K	0 50%	1/16W
R5435	1-216-809-11	METAL CHIP	100	5%	1/16W
R5437	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5439	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5440	1-218-905-11	RES,CHIP	270K	0 50%	1/16W
R5441	1-218-877-11	RES,CHIP	18K	0 50%	1/16W
R5444	1-216-835-11	METAL CHIP	15K	5%	1/16W
R5445	1-216-840-11	METAL CHIP	39K	5%	1/16W
R5446	1-216-833-11	METAL CHIP	10K	5%	1/16W
R5447	1-216-833-11	METAL CHIP	10K	5%	1/16W
R5448	1-216-839-11	METAL CHIP	33K	5%	1/16W
R5449	1-216-864-11	METAL CHIP	0	5%	1/16W
R5452	1-216-821-11	METAL CHIP	1K	5%	1/16W
R5458	1-216-864-11	METAL CHIP	0	5%	1/16W
R5460	1-216-864-11	METAL CHIP	0	5%	1/16W
R5468	1-216-864-11	METAL CHIP	0	5%	1/16W
R5469	1-216-864-11	METAL CHIP	0	5%	1/16W
R5470	1-216-864-11	METAL CHIP	0	5%	1/16W
R5471	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5472	1-218-883-11	RES,CHIP	33K	0 50%	1/16W

A-7073-438-A VF-120 BOARD, COMPLETE (TRV93)
****

(Ref No 10,000 Series)

< CAPACITOR >

Ref No	Part No	Description			Remark
C5302	1-104-916-11	TANTAL CHIP	6 8uF	20%	20V
C5303	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V
C5304	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5305	1-104-851-11	TANTAL CHIP	10uF	20%	10V
C5306	1-164-676-11	CERAMIC CHIP	2200PF	5%	16V
C5307	1-135-181-21	TANTALUM CHIP	4 7uF	20%	6 3V
C5308	1-164-227-11	CERAMIC CHIP	0 022uF	10%	25V
C5309	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V
C5310	1-164-217-11	CERAMIC CHIP	150PF	5%	50V
C5311	1-107-826-11	CERAMIC CHIP	0 1uF	10%	16V
C5312	1-109-982-11	CERAMIC CHIP	1uF	10%	10V
C5313	1-165-128-11	CERAMIC CHIP	0 22uF		16V
C5314	1-162-970-11	CERAMIC CHIP	0 01uF	10%	25V

< CONNECTOR >

Ref No	Part No	Description
CN5301	1-691-346-11	CONNECTOR, FFC/FPC (ZIF) 8P
CN5302	1-691-513-11	CONNECTOR, BOARD TO BOARD 12P

< DIODE >

Ref No	Part No	Description
D5301	8-719-043-70	DIODE MA6S121-(TX)
D5302	8-719-056-49	DIODE 1SS370(TE85L)

< IC >

Ref No	Part No	Description
IC5301	8-759-097-75	IC MB3789PFV-G-BND-ER

< COIL >

Ref No	Part No	Description			Remark
L5301	1-412-031-11	INDUCTOR CHIP	47uH		

< TRANSISTOR >

Ref No	Part No	Description			Remark
Q5301	8-729-028-81	TRANSISTOR	RN2305-TE85L		
Q5304	8-729-403-35	TRANSISTOR	UN5113-TX		
Q5305	8-729-402-42	TRANSISTOR	UN5213-TX		

< RESISTOR >

Ref No	Part No	Description			Remark
R5301	1-216-809-11	METAL CHIP	100	5%	1/16W
R5304	1-218-901-11	RES,CHIP	180K	0 50%	1/16W
R5305	1-218-887-11	RES,CHIP	47K	0 50%	1/16W
R5306	1-216-843-11	METAL CHIP	68K	5%	1/16W
R5307	1-216-838-11	METAL CHIP	27K	5%	1/16W
R5308	1-216-847-11	METAL CHIP	150K	5%	1/16W
R5309	1-216-841-11	METAL CHIP	47K	5%	1/16W
R5310	1-216-842-11	METAL CHIP	56K	5%	1/16W
R5311	1-216-850-11	METAL CHIP	270K	5%	1/16W
R5312	1-216-843-11	METAL CHIP	68K	5%	1/16W
R5313	1-216-842-11	METAL CHIP	56K	5%	1/16W
R5314	1-216-850-11	METAL CHIP	270K	5%	1/16W
R5315	1-216-833-11	METAL CHIP	10K	5%	1/16W
R5316	1-216-851-11	METAL CHIP	330K	5%	1/16W
R5317	1-216-845-11	METAL CHIP	100K	5%	1/16W
R5318	1-216-822-11	METAL CHIP	1 2K	5%	1/16W
R5321	1-216-837-11	METAL CHIP	22K	5%	1/16W
R5322	1-216-853-11	METAL CHIP	470K	5%	1/16W
R5324	1-216-864-11	METAL CHIP	0	5%	1/16W

A-7073-454-A VL-19 BOARD, COMPLETE (TRV93)
****

(Ref No 9,000 Series)

< CAPACITOR >

Ref No	Part No	Description			Remark
C151	1-115-566-11	CERAMIC CHIP	4 7uF	10%	10V
C152	1-162-961-11	CERAMIC CHIP	330PF	10%	50V
C153	1-162-964-11	CERAMIC CHIP	0 001uF	10%	50V

< CONNECTOR >

Ref No	Part No	Description
CN151	1-766-619-11	CONNECTOR, FFC/FPC 8P

< COIL >

Ref No	Part No	Description			Remark
L151	1-416-344-11	COIL, CHOKE	10uH		

< TRANSISTOR >

Ref No	Part No	Description			Remark
Q151	8-729-043-94	TRANSISTOR	CPH3106-PM-TL		
Q152	8-729-230-63	TRANSISTOR	2SD1819A-QRS-TX		

< RESISTOR >

Ref No	Part No	Description			Remark
R151	1-216-829-11	METAL CHIP	4 7K	5%	1/16W
R152	1-216-813-11	METAL CHIP	220	5%	1/16W
R153	1-216-821-11	METAL CHIP	1K	5%	1/16W
R154	1-216-845-11	METAL CHIP	100K	5%	1/16W

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une piéce portant le numéro spécifié

Ref. No	Part No	Description	Remark
		MISCELLANEOUS *************	
10	1-475-619-11	SWITCH BLOCK, CONTROL (SS-8500)	
14	1-475-617-11	SWITCH BLOCK, CONTROL (FK-8500) (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
14	1-475-617-31	SWITCH BLOCK, CONTROL (FK-8500)(TRV35E)	
14	1-475-617-51	SWITCH BLOCK, CONTROL (FK-8500)(TRV35)	
14	1-475-617-71	SWITCH BLOCK, CONTROL (FK-8500) (TRV65/TRV65PK/TRV615)	
14	1-475-618-41	SWITCH BLOCK, CONTROL(FK-8500) (TRV85/TRV815/TRV93)	
19	1-467-574-21	REMOTE COMMANDER (RMT-708)	
154	1-475-621-11	SWITCH BLOCK, CONTROL (MR-8500)	
164	1-783-240-11	CABLE, FLEXIBLE FLAT (FFC-236)	
204	1-475-620-11	SWITCH BLOCK,CONTROL (MF-8500) (EXCEPT TRV85/TRV815/TRV93)	
214	1-783-240-11	CABLE, FLEXIBLE FLAT (FFC-236)	
258	1-668-963-41	FP-642FLEXBLE BOARD	
259	1-958-332-11	HARNESS (DP-71)(TRV85/TRV815/TRV93)	
308	1-668-963-11	FP-642 FLEXIBLE BOARD	
309	1-958-379-11	HARNESS (DP-70) (EXCEPT TRV85/TRV815/TRV93)	
362	1-668-962-11	FP-638 FLEXIBLE BOARD (TRV93)	
408	1-783-241-11	CABLE,FLEXIBLE FLAT (FFC-235) (EXCEPT TRV93)	
452	1-668-957-11	FP-621 FLEXBLBOARD	
457	1-668-956-11	FP-620 FLEXIBLE BOARD	
458	1-668-960-11	FP-629 FLEXIBLE BOARD	
461	1-668-961-11	FP-632 FLEXIBLE BOARD (TRV93)	
463	1-774-867-31	CONNECTOR,EXTERNAL(HOT SHOE)8P (TRV65/TRV65PK/TRV85/TRV615/TRV815)	
464	1-668-978-11	FP-633 FLEXIBLE BOARD (TRV65/TRV65PK/TRV85/TRV615/TRV815)	
467	1-668-958-11	FP-622 FLEXIBLE BOARD	
508	1-694-384-11	TERMINAL BOARD, BATTERY	
510	1-668-959-11	FP-623 FLEXBLE BOARD	
514	1-758-084-21	FILTER BLOCK, OPTICAL (EXCEPT TRV15/TRV15PK/TRV15E/TRV15EP)	
514	1-758-133-21	FILTER BLOCK, OPTICAL (TRV15/TRV15PK/TRV15E/TRV15EP)	
516	8-848-722-01	DEVICE, LENS LSV-600A(SOC) (TRV35/TRV35E/TRV65/TRV65PK/TRV615/TRV85/TRV815/TRV93)	
516	8-848-724-01	DEVICE, LENS LSV-601A(SOC) (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
551	8-848-722-01	DEVICE, LENS LSV-600A(SOC) (TRV35/TRV35E/TRV65/TRV65PK/TRV615/TRV85/TRV815/TRV93)	
551	8-848-724-01	DEVICE, LENS LSV-601A(SOC) (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
760	1-658-213-11	FP-355 FLEXIBLE BOARD	
762	1-657-786-13	FP-221 FLEXIBLE BOARD	
764	1-658-214-11	FP-356 FLEXIBLE BOARD	
803	1-657-785-11	FP-248 FLEXIBLE BOARD	
817	1-657-784-11	FP-220 FLEXIBLE BOARD	
D001	8-719-988-42	DIODE GL453	
IC401	A-7030-862-A	CCD BLOCK ASSY (TRV15/TRV15PK)	
IC401	A-7030-865-A	CCD BLOCK ASSY (TRV25/TRV25PK/TRV215/TRV35/TRV65/TRV65PK/TRV615/TRV85/ TRV815/TRV93)	
IC401	A-7030-871-A	CCD BLOCK ASSY (TRV35E)	

Ref. No	Part No	Description	Remark
IC401	A-7030-874-A	CCD BLOCK ASSY (TRV15E/TRV15EP)	
J001	1-565-276-31	JACK, ULTRA SMALL 1P (LANC)	
LCD901	1-803-032-21	INDICATOR MODULE, LIQUID CRYST (TRV85/TRV815)	
LCD901	1-803-035-21	INDICATOR MODULE, LIQUID CRYST (TRV35/TRV65/TRV65PK/TRV615/TRV35E)	
LCD901	1-803-037-21	INDICATOR MODULE, LIQUID CRYST (TRV93)	
LCD901	1-803-040-21	INDICATOR MODULE, LIQUID CRYST (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
LCD902	8-753-023-37	LCX024AK	
M901	A-7048-851-A	DRUM ASSY (DGH-0D5A-R)(PAL) (TRV15E/TRV15EP/35E)	
M901	A-7048-842-A	DRUM ASSY (DGH-0E1A-R)(NTSC)(5HEAD) (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
M901	A-7048-870-A	DRUM ASSY (DGH-0E3A-R)(NTSC)(3HEAD) (TRV15/TRV15PK/TRV25/TRV25PK/TRV35TRV215)	
M902	8-835-531-32	CAPSTAN ASSY	
M903	X-3945-401-1	MOTOR ASSY, DC (LOADING)	
M905	1-763-047-11	MOTOR, FOCUS STEPPING	
M906	1-763-046-11	MOTOR, ZOOM STEPPING	
MIC901	1-542-312-11	MICROPHONE (L-CH)	
MIC902	1-542-312-11	MICROPHONE (R-CH) (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
⚠ND5351	1-517-414-51	FLUORESCENT TUBE (0 55 INCH)(TRV93)	
⚠ND801	1-517-753-11	TUBE, FLUORESCENT,COLD CATHODE (TRV93)	
⚠ND801	1-517-754-11	TUBE, FLUORESCENT,COLD CATHODE (TRV85/TRV815)	
⚠ND801	1-517-751-11	TUBE, FLUORESCENT,COLD CATHODE (TRV15/TRV15PK/TRV15E/TRV15EP/TRV25/TRV25PK/TRV215)	
⚠ND801	1-517-752-11	TUBE, FLUORESCENT,COLD CATHODE (TRV35/TRV65/TRV65PK/TRV615/TRV35E)	
⚠ND802	1-517-759-11	LIGHT, BACK	
S001	1-692-614-11	SWITCH, PUSH (3 KEY) (Hi8 MP, ME/MP, REC PROOF)	
S002	1-572-688-11	SWITCH, PUSH (1 KEY)(C C LOCK)	
S003	1-572-688-11	SWITCH, PUSH (1 KEY) (EJECT)	
S901	1-762-436-15	SWITCH, ROTARY (ENCODER)	
SE451	1-803-041-11	SENSOR, ANGULAR VELOCITY (YAW)	
SE452	1-803-041-21	SENSOR, ANGULAR VELOCITY (PITCH)	
SP901	1-504-753-21	SPEAKER (2 8CM)(TRV85/TRV815/TRV93)	
SP901	1-505-291-11	SPEAKER (DIA 2 8CM) (EXCEPT TRV85/TRV815/TRV93)	
⚠V901	1-452-673-31	CRT ASSY (M01KXX90WB) (EXCEPT TRV93)	
⚠VL001	1-517-760-11	LIGHT BLOCK, VIDEO (TRV93)	

ACCESSORIES & PACKING MATERIALS
****

Ref. No	Part No	Description	Remark
	1-467-574-21	REMOTE, COMMANDER (RMT-708)	
⚠	1-475-599-11	ADAPTOR, AC (AC-L10)	
⚠	1-569-008-11	ADAPTOR, CONVERSION 2P (TRV15 E,HK/TRV15PK/TRV25PK/TRV35 E,HK/TRV35E E,HK)	
⚠	1-573-856-11	ADAPTOR, CONVERSION 2P (TRV35,JE/TRV35E,JE)	
	1-574-039-21	CORD, CONNECTION (A/V connecting cable (Monaural), 1 5m) (TRV15/15PK/TRV25/TRV25PK/TRV215/TRV35/TRV15E/TRV35E)	

Be sure to read "Note on the CCD Imager replacement" on page 4–9 when changing the CCD imager.

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety. Replace only with part number specified	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une pièce portant le numéro spécifié

Ref No	Part No	Description	Remark
*⚠	1-575-131-11	CORD, POWER (TRV15 E,HK/TRV15PK/TRV25PK/TRV35 E,HK/TRV15E AEP,EE,NE,RU/TRV35E AEP,EE,NE,RU,E)	
	1-575-334-11	CORD, CONNECTION (A/V connecting cable (Stereo), 1 5m) (TRV65/TRV65PK/TRV85/TRV93/TRV615/TRV815)	
⚠	1-696-819-11	CORD, POWER (TRV35E AUS)	
⚠	1-751-676-11	CORD, POWER (TRV15 US,CND/TRV25/TRV215/TRV65/TRV615/TRV85)	
	1-764-622-11	ADAPTOR, CONVERSION 21 Pin adaptor (VMC-89) (TRV15E/TRV35E AEP,EE,NE,RU,UK)	
⚠	1-769-608-11	CORD, POWER (TRV15 E,HK/TRV15PK/TRV25PK/TRV35 E,HK/TRV15E AEP,EE,NE,RU/TRV35E AEP,EE,NE,RU,E)	
⚠	1-770-019-11	ADAPTOR, CONVERSION PLUG 3P (TRV15 HK/TRV35 HK)	
⚠	1-775-549-21	CORD, POWER (TRV15 US,CND/TRV25/TRV215/TRV65/TRV615/TRV85/TRV815/TRV93)	
⚠	1-782-476-11	CORD, POWER (TRV35E CN)	
⚠	1-783-374-11	CORD, POWER (TRV15E UK/TRV35E UK,HK)	
	3-861-891-11	MANUAL (3), INSTRUCTION (ENGLISH) (TRV85/TRV815/TRV93)	
	3-861-891-21	MANUAL (3), INSTRUCTION (FRENCH)(93 CND)	
	3-861-901-11	MANUAL,INSTRUCTION(ENGLISH) (TRV15 US,CND/TRV25/TRV215/TRV65/TRV615)	
	3-861-901-21	MANUAL, INSTRUCTION (FRENCH) (TRV15 CND/TRV25 CND/TRV215 CND/TRV65 CND/TRV615 CND)	
	3-861-901-31	MANUAL, INSTRUCTION (ENGLISH) (TRV15 E,HK/TRV15PK/TRV25PK/TRV35 E,HK)	
	3-861-901-41	MANUAL,INSTRUCTION (SPANISH,PORTUGUESE) (TRV15 E,HK/TRV15PK/TRV25PK/TRV35 E,HK)	
	3-861-901-51	MANUAL, INSTRUCTION (CHINESE) (TRV15 E/TRV15PK/TRV25PK/TRV35 E)	
	3-861-901-61	MANUAL, INSTRUCTION (KOREAN)(TRV35 JE)	
	3-861-902-11	MANUAL,INSTRUCTION(ENGLISH,RUSSIAN) (TRV15E EE,NE,RU,UK/TRV35E EE,NE,RU,UK)	
	3-861-902-21	MANUAL, INSTRUCTION (SPANISH,PORTUGUESE)(TRV35E AEP)	
	3-861-902-31	MANUAL, INSTRUCTION (GERMAN,ITALIAN) (TRV15E AEP/TRV35E AEP)	
	3-861-902-41	MANUAL, INSTRUCTION (FRENCH,DUTCH) (TRV15E AEP/TRV35E AEP)	
	3-861-902-51	MANUAL,INSTRUCTION (SWEDISH,POLISH) (TRV15E EE,NE,RU/TRV35E EE,NE,RU)	
	3-861-903-11	MANUAL, INSTRUCTION (ENGLISH,RUSSIAN) (TRV35 E,HK,AUS,CN)	
	3-861-903-21	MANUAL, INSTRUCTION (FRENCH,GERMAN) (TRV35E E,HK,CN)	
	3-861-903-31	MANUAL, INSTRUCTION (ARABIC,PERSIAN) (TRV35E E,CN)	
	3-861-903-41	MANUAL, INSTRUCTION (CHINESE)(TRV35E HK)	
	3-861-903-51	MANUAL, INSTRUCTION (CHINESE)(TRV35E E,CN,JE)	
	3-971-463-01	LABEL, FIRE CAUTION DISCERN (TRV15 US,CND/TRV25/TRV65/TRV85/TRV93 US)	
	3-987-015-01	BELT (VW), STRAP	
*	3-988-397-11	INDIVIDUAL CARTON (TRV15 US,CND)	
*	3-988-397-21	INDIVIDUAL CARTON (TRV25)	
*	3-988-397-31	INDIVIDUAL CARTON (TRV215 US)	
*	3-988-654-01	INDIVIDUAL CARTON (TRV65)	
*	3-988-654-21	INDIVIDUAL CARTON (TRV615)	
*	3-988-654-81	INDIVIDUAL CARTON (TRV15 E,HK)	
*	3-988-654-91	INDIVIDUAL CARTON (TRV35)	
*	3-988-656-01	INDIVIDUAL CARTON (TRV85)	
*	3-988-960-01	BAG, CARRY (TRV15EP/TRV15PK//TRV25PK/TRV65PK)	
	A-7092-699-A	CASE (L) ASSY, BATTERY (TRV93 CND)	
	A-7092-936-A	CASE (L) ASSY (U), BATTERY (TRV15 US,CND/TRV25/TRV65/TRV85/TRV93 US)	
**	NP-F330	BATTERY PACK	

Note

** MARKPARTSIS AVAILABLE AS AN OPTIONAL ACCESSORY

The components identified by mark ⚠ or dotted line with mark ⚠ are critical for safety Replace only with part number specified.	Les composants identifiés par une marque ⚠ sont critiques pour la sécurité Ne les remplacer que par une piéce portant le numéro spécifié

8mm Video MECHANICAL ADJUSTMENT MANUAL VII

B MECHANISM

Video8

Use this mechanical adjustment manual VII together with the service manual of the respective models.



8 MECHANISM DECK

SONY®

MICROFILM

TABLE OF CONTENTS

1. PREPARATION FOR CHECKING, ADJUSTING AND REPLACING THE MECHANISM

1-1. Cassette Compartment Block Assy ················ 3
1-2. How to Operate the Mechanism with the Cassette Compartment Block Assy Removed ·············· 4

2. PERIODIC CHECK AND MAINTENANCE ITEMS

2-1. Rotary Drum Assy Cleaning ···················· 5
2-2. Tape Path Cleaning ···························· 5
2-3. Periodic Check Items ························· 6
2-4. Service Tool List ······························ 7

3. CHECKING, ADJUSTING AND REPLACING THE MECHANISM

3-1. HC Roller Block Assy ························· 8
3-2. Drum Assy ································· 9
3-3. Drum Base Block Assy, Shaft Ground ············ 10
3-4. Gooseneck Retainer, Gooseneck Gear Assy ········ 11
3-5. LS Chassis Block Assy, Mechanical Chassis Block Assy ················· 12
3-6. T Reel Table Assy, T Ratchet, T Soft Gear Block Assy ······················· 15
3-7. Tension Regulator Band Assy, TG1 Arm Assy, S Reel Table Assy, S Ratchet, S Ratchet Release Plate, RVS Arm ················ 16
3-8. Pinch Arm Assy, TG4 Arm Block Assy ············ 17
3-9. LS Cam Plate, LS Guide Cover, Lid Opener, EJ Arm, Lock Guide ························ 18
3-10. Guide Base (S) and (T) Block Assemblies, Guide Rail ································· 19
3-11. DC Motor Assy (Loading) ····················· 21
3-12. Tension Regulator Plate 2, Relay Gear, M Slider Assy ································ 22
3-13. LS Arm, HC Drive Arm, Pinch Press Plate, Tension Regulator Plate ······················· 23
3-14. Cam Gear ································· 24
3-15. GL Slider Assy, GL Arm ····················· 25
3-16. Rotary Switch ······························· 26
3-17. Capstan Motor ······························ 27
3-18. Tension Regulator Position Adjustment ············ 28
3-19. FWD Tape Hold -Back Tension Adjustment ········ 29

4. TAPE PATH ADJUSTMENT

4-1. Preparations for Adjustment ···················· 30
4-2. Tracking Adjustment ························· 31
4-3. No. 4 Guide (TG-4) Adjustment ················ 31
4-4. CUE, REV Waveforms Check ················· 32
4-5. Checks After Adjustments ····················· 32

5. EXPLODED VIEWS

5-1. Cassette Compartment Block Section ············· 34
5-2. LS Chassis Block Section ······················ 35
5-3. Mechanism Chassis Block Section ················ 36

6. PRINTED WIRING BOARD AND SCHEMATIC DIAGRAM ················· 37

7. ELECTRICAL PARTS LIST ················ 38

For the mode selector operation, schematic diagram and parts list, refer to the Supplement-1 Manual.

1. PREPARATION FOR CHECKING, ADJUSTING AND REPLACING THE MECHANISM

For the disassembly procedures of the cabinet and printed wiring boards, please refer to the "DISASSEMBLY" section of the service manual of the respective models.

To re-assemble the mechanical parts which are disassembled in the following sections, perform the disassembly steps in reverse, unless otherwise specified.

The mechanisms are adjusted while set in the USE mode of operation. (Refer to the "Mode Selector Operation Procedure of the Supplement-1 Manual for how to enter the USE mode.)

1-1. Cassette Compartment Block Assy

1. Disassembly Procedure (Refer to Fig. 1.)

1) Set the mechanism to USE mode.
2) Confirm that the Cassette Compartment Block Assy is opened. If it is not opened, open it referring to Fig. a.
3) Remove the claws Ⓐ and Ⓑ of the Damper Assy ① from the chassis.
4) Remove the washer ② from the shaft of the Cassette Compartment near the Drum, next to the loading motor. Remove the shaft of the arm from the slot.
5) Remove the shaft of the arm from the slot Ⓒ of the Cassette Compartment near the Drum, next to the capstan motor. (Refer to Fig. b)
6) Lift up the Cassette Compartment at the Drum side in the direction of the arrow Ⓓ, and remove the arm shaft of the Cassette Compartment from the LS Chassis ④ near the Reel Tables. Remove the Cassette Compartment Assy ③ in the direction of the arrow Ⓔ.

2. Precautions During Re-Assembling

1) After attaching the Tension Spring, confirm that the straight portion at the end of the curved hook of the spring is positioned inside the mechanism. (Refer to Fig. c)
2) Confirm that the claw in the bottom of the shaft near the Reel Table of the Cassette Compartment is hooked to the LS Chassis.
3) Confirm that the claw of the Damper Assy is hooked to the LS Chassis. (Refer to Fig. b)


Ⓐ
Ⓒ
Fig. b
Ⓑ
Ⓔ
Ⓓ
· During re-assembly claw of Damper
Hole of LS Chassis
There must no clearance.
Ⓒ
Ⓐ
Ⓑ
①Damper Assy
Arm shaft near the Reel Deck
Cassette Compartment
④LS Chassis
②washer
Fig. a
Pull the claw.
How to release locking plate.
Tension Spring
Tension Spring
Fig. c

Fig. 1

1-2. How to Operate the Mechanism with the Cassette Compartment Block Assy Removed

1. How to load a cassette tape (Refer to Fig. 2):

1) While referring to section "DISASSEMBLY" of the respective service manual, turn the main power on with the cabinet and camera section removed. (It enables to operate the mechanical deck.)
2) Connect the adjustment remote commander (Ref. No. J-10) and establish the TEST mode.

> Example of establishing the TEST mode: model CCD-TR420E/TR440E.
> Select page: 6, address: 00, set data :01 and press the PAUSE button to release protection.
> Select page: 7, address: 01, set data: 01 and press the PAUSE button.
> After tape loading or other desired operations of mechanism are completed, be sure to perform the following:
> Select page: F, address: 01, set data :00 and press the PAUSE button.
> Select page: 6, address: 00, set data: 00 and press the PAUSE button.

3) Press the push-switch ① knob in the direction of the arrow which sets the machine into loading mode.

☆ PB, FF/REW and CUE/REV operations are possible.

2. How to establish RECORD mode:

1) Press pin of the push-switch ② (ON state) and keep the ON state by fixing with adhesive tape ③.
2) Turn the main power switch ON (select VTR or CAMERA position of in case of camera).
3) Set the RECORD switch to ON.
(When the TEST mode is selected, the rotation detection of the S and T reel tables is muted, and the top end sensor is disable which allow to run the tape.)

3. How to eject a cassette tape:

1) Press the EJECT switch to ON.


The pin which is fixed to the pressed position of the push-switch (3 keys). (Other pins can be pressed too.)
③ Adhesive tape
① Push-switch
② Push switch (3 keys)

Fig. 2

2. PERIODIC CHECK AND MAINTENANCE ITEMS

- Perform the following periodic check and maintenance to ensure that the machine functions continue to operate in peak condition, and to protect the tape and mechanism deck. After completing repair work, perform the following maintenance items regardless of how long the user's machine has been used.

2-1. Rotary Drum Assy Cleaning

Press the cleaning piece (Ref. No. J-2) moistened with cleaning fluid (Ref. No. J-1) lightly on the Rotary Drum Assy. Gently turn the Rotary Drum Assy slowly by hand counter-clockwise to clean the rotary drum.

Caution: Never attempt to turn the head drum motor by turning the main power ON. Also, never turn the drum clockwise by hand. In addition, never move the cleaning piece vertically with respect to the head tips, since this will damage them. Never clean the head drum in any way other than as described above.

2-2. Tape Path Cleaning (Refer to Fig. 3.)

1) Set the mechanism to USE mode. Clean the tape path system (TG-1, TG-2, TG-3, TG-4, pinch roller, capstan shaft) and lower drum using a very thin cotton swab (Ref. No. J-3) moistened with cleaning fluid.

Caution: Take care that the very thin cotton swab (Ref. No. J-3) does not touch the oil or grease of the various link mechanisms.



Fig. 3

2-3. Periodic Check Items

	Maintenance and Inspection Points	Operating Hours										Remarks
		500	1000	1500	2000	2500	3000	3500	4000	4500	5000	
	Cleaning of tape running surface	○	○	○	○	○	○	○	○	○	○	Take care not to get oily.
	Cleaning and degaussing of Rotary Drum Assy	○	○	○	○	○	○	○	○	○	○	Take care not to get oily.
Drive System	Timing Belt	—	☆	—	☆	—	☆	—	☆	—	☆	3-965-546-01
	Capstan Shaft	—	◎	—	◎	—	◎	—	◎	—	◎	Take great care not to let any oil contact the tape running surface.
	Change Gear Shaft Relay Pulley Shaft	—	◎	—	◎	—	◎	—	◎	—	◎	
	Loading Motor	—	☆	—	☆	—	☆	—	☆	—	☆	X-3945-401-1
Performance Check	Abnormal Sound	☆	☆	☆	☆	☆	☆	☆	☆	☆	☆	
	Tape Hold-back Tension Measurement	—	☆	—	☆	—	☆	—	☆	—	☆	
	Brake System	—	☆	—	☆	—	☆	—	☆	—	☆	
	FWD / RVS } Torque Measurement	—	☆	—	☆	—	☆	—	☆	—	☆	

○Cleaning ◎Lubrication ☆Check

Note: When overhauling the machine, replace the parts while referring to the above table.

Note: Regarding oil

- Be sure to use the specified oil. (If the viscosity and other characteristics are different, various troubles may arise.)
  Oil: Sony part No. 7-661-018-18
  (Mitsubishi diamond oil hydro fluid NT-68)
- For the oil lubricated bearings, use oil free from dust or foreign materials. If the oil contains any dust or foreign material, the bearings will wear out quickly or burn out.
- One drop of oil is the amount of oil which forms at the tip of a stick of 2 mm diameter.



Fig. 4

2-4. Service Tool List

Ref. No.	Name	Parts Code	Tool Stamp	Applications
J-1	Cleaning fluid	Y-2031-001-0	——	
J-2	Cleaning piece	2-034-697-00	——	
J-3	Very thin cotton swab (made by Nippon Cotton Swab Inc. (P752D))		——	
J-4	Head demagnetizer	Commercially available	——	
J-5	Dental mirror Spare mirror	J-6080-029-A J-6080-030-1	SL-5052	Tape path
J-6	Alignment tape (NTSC : WR5-1NP) (PAL : WR5-1CP)	8-967-995-02 8-967-995-07	——	Tape path
J-7	FWD/RVS take-up torque cassette	J-6080-824A	GD-2086	
J-8	Screwdriver for tape path adjustment	J-6082-026-A	——	For tape guide adjustment
J-9	FWD/BACK tension adjustment screwdriver	J-6082-187-A	——	
J-10	Remote commander for adjustment	J-6082-053-B	——	Tape path (Setting PATH mode)
J-11	MD process table	J-6082-166-A	——	
J-12	FLOIL Grease SG-941	7-662-001-39	——	
J-13	FLOIL Grease SG-055G	7-651-000-09	——	

Other equipment
- Oscilloscope
- Analog circuit tester (input impedance 20 kΩ)

J-1



J-2



J-3



J-4



J-5



J-6



J-7



J-8



J-9



J-10



J-11



J-12



J-13



3. CHECKING, ADJUSTING AND REPLACING THE MECHANISM

3-1. HC Roller Block Assy (Refer to Fig. 5)

1. Disassembly Procedure

1) Remove the Torsion Spring ① from the cut-out Ⓐ of the motor holder. Hook it to the claw Ⓑ of the HC Arm.
2) Remove the HC Roller Block Assy in the direction shown by Ⓒ.
3) Remove the stop washer ② and remove the HC Roller Block Assy ③.

2. Precautions During Re-Assembly

1) After attaching the HC Roller Block Assy, confirm that both ends of the torsion spring are hooked to Ⓐ and Ⓓ.
2) Align the block so that the cut-out Ⓔ agrees with the rib Ⓕ.


②stop washer
③HC Roller Assy
Ⓔ
Ⓒ
Ⓕ
· Disassembly
①Torsion Spring
Ⓐ
Ⓑ
· Re-Assembly
Ⓐ
Ⓓ
Ⓑ

Fig. 5

3-2. Drum Assy (Refer to Fig. 6)

1. Disassembly Procedure

1) Set the mechanism to USE mode.
2) Remove the three screws (M 1.4) ① and remove the Drum Assy ②.

Caution: Be careful not to touch the outer circumference of the drum. (Hold the portions Ⓐ and Ⓑ of the drum assy.)

2. Precautions During Re-Assembly

1) Be careful not to touch the outer circumference of the drum. (Hold the portions Ⓐ and Ⓑ of the drum assy.)
2) When tightening the three screws (M 1.4), tighten them in the order Ⓒ, then Ⓓ, then Ⓔ.
3) After attaching the Drum Assy, perform the steps in section "4. TAPE PATH ADJUSTMENT".



Fig. 6

3-3. Drum Base Block Assy, Shaft Ground (Refer to Fig. 7)

1. Disassembly Procedure

1) Remove the Drum Assy referring to section 3-2.
2) Remove the three screws (M 1.4×2.5) ① and remove the Drum Base Block Assy ②.
3) Remove the screw (M 1.7×1.4) ③ and remove the Shaft Ground ④.

Caution 1: Do not hold the spring portion of the Shaft Ground ④.

Caution 2: The loading motor can be removed while the mechanism is in this state. However, do not move any other mechanical parts (especially gears and cams around the rotary switch) when removing the loading motor. (Refer to 3-11.)

2. Precautions During Re-Assembly

1) Do not touch the spring portion of the Shaft Ground ④.
2) When tightening the three screws (M 1.4×2.5), tighten them in the order of Ⓐ, then Ⓑ, then Ⓒ.
3) After re-assembly is completed, perform the steps in section "4. TAPE PATH ADJUSTMENT".



Fig. 7

3-4. Gooseneck Retainer, Gooseneck Gear Assy (Refer to Fig. 8)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the LED ① from the LED holder of the Gooseneck Retainer ③.
(Turn the flexible board 90° outside and remove it upward.)
3) Remove the three screws (M 1.4×2.5) ② and remove the Gooseneck Retainer ③.
4) Remove the stop washer ④ and remove the Gooseneck Gear Assy ⑤.

2. Precautions During Re-Assembly

1) When attaching the Gooseneck Retainer ③, take care that the Gooseneck Retainer ③ does not collide with the tension regulator band. (The tension regulator band must be located inside.)
2) Hook the T-side claw on the guide.


②screw
(M1.4×2.5)
③Gooseneck Retainer
②screw
(M1.4×2.5)
The claw which is hooked on the guide rail.
LED holder
*
①LED
Turn by 90°
* Pay attention not to break the claw.
④stop washer
⑤Gooseneck Gear Assy
Tension Regulator Band

Fig. 8

3-5. LS Chassis Block Assy, Mechanical Chassis Block Assy (Refer to Fig. 9)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
3) Remove the FP-221 flexible board ① from the flexible board holder.
4) Remove the stop ring E1.5 ②.
5) Remove the two screws (M 1.4×2.5) ③ and remove the LS Chassis Block Assy ④ from the Mechanical Chassis Block ⑤ in the direction of the arrow Ⓐ.

Note: The Tension Regulator Plate (2) can easily fall into the Mechanical Chassis Block Assy. Take care not to drop it.

2. Precautions During Re-Assembly

1) Before attaching the LS Chassis Block Assy, confirm that the respective phase-determining holes have been adjusted for correct phase. Also confirm that the specified locations of the Mechanical Chassis Block Assy and the LS Chassis Block Assy are coated with grease SG-055G (Ref. No. J-13). (Refer to Fig. a)
2) When attaching the LS Chassis Block Assy, insert the LS Cam Plate (on the LS chassis side) into the dowel (on the mechanical chassis side). Also insert the TG1 Cam Axis (on the LS chassis side) into the Tension Regulator Plate (2) (on the mechanical chassis side).
3) When attaching these block assemblies, attach them while pressing the TG-1 Arm Assy in the direction toward the TG-2 Guide. (Refer to Fig. b)
4) Pay attention that the TG-1 Arm is not floated.


TG-1 Arm Assy
TG-2
TG-1 Cam shaft
Fig. b
④LS Chassis Assy
③screw (M1.4×2.5)
②stop ring
①FP-221 flexible board
flexible board holder
Ⓐ
Tension Regulator Plate (2)
⑤Mechanism Chassis Block Assy
Hole of Tension Regulator Plate
Confirm that phase determining holes agree.
Hole of HC Drive Arm
: Grease SG-055G (Ref. No. J-13) Coating points
Fig. a

Fig. 9

- **PARTS CONSTITUTING THE LS CHASSIS.**


T Soft Gear,
T Soft Claw
LS Chassis
Tension Spring
S Reel Deck Assy
Tension Spring
(Ratchet)
T Reel Deck Assy
S Ratchet
T Ratchet
S Ratchet
Release Plate
Tension Spring
(Pinch)
Tension Spring
(Ratchet)
Lock Guide
screw M1.4×3
RVS Arm
Tension Spring
(RVS Arm)
Lid Open
Tension Spring
(TG-1)
TG-4 Retainer
Guide Base (S) Assy
Guide Base (T) Assy
Guide Rail
TG-4 Arm Assy
TG-1 Arm Assy
Tension Regulator Band Assy
Pinch Arm Assy

Fig. 10

3-6. T Reel Table Assy, T Ratchet, T Soft Gear Block Assy (Refer to Fig. 11)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
3) Remove the claw of the T Reel Deck Assy ① from the chassis and remove the T Reel Deck Assy from its shaft.
4) Remove the Tension Spring (Ratchet) ② from the LS Chassis and turn the T Ratchet ③ in the direction of the arrow Ⓐ and remove it .
5) Turn the T Soft Gear Block Assy ④ in the direction of the arrow Ⓑ and remove it .

2. Precautions During Re-Assembly

1) Confirm that the protrusions of both the T Soft Gear Block Assy and T Ratchet are securely locked to the LS Chassis.
2) Be careful not to deform the claw.



Fig. 11

3-7. Tension Regulator Band Assy, TG1 Arm Assy, S Reel Table Assy, S Ratchet, S Ratchet Release Plate, RVS Arm (Refer to Fig. 12)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
3) Remove the Tension Spring (TG1) ① from the LS Chassis.
4) Remove the screw (M 1.4×3) ② and remove the Tension Adjustment Block of the Tension Regulator Band Assy ④ form RVS Arm.
5) Release the S Ratchet ⑥ in the direction of the arrow Ⓐ and remove the Tension Regulator Band (while taking care not to bend the band) from the S Reel.
6) Remove the TG1 Arm Assy ③ from the LS Chassis, then remove the claw of the Tension Regulator Band Assy ④. (Refer to Fig. a)
7) Remove the claw of the S Reel Deck Assy ⑤ from the chassis and remove the S Reel Deck Assy from its shaft.
8) Remove the S Ratchet ⑥. (Because it is press-fitted, insert tip of screwdriver into the center of rotation and remove it.
9) Remove the Tension Spring (ratchet) ⑦ from the LS Chassis and remove the S Ratchet Release Plate ⑧.
10) Remove the Tension Spring ⑨ from the LS Chassis and remove the RVS Arm ⑩ by turning it..

2. Precautions During Re-Assembly

1) Confirm that the dowel of the S Ratchet Release Plate is inserted into the groove of the S ratchet and confirm that the center of the ratchet is press-fitted into bottom of the shaft. (It can be used again.)
2) When attaching the Tension Regulator Band Assy, take care not to bend it.
3) Pay attention that oil or grease is not spit on the surface of the Tension Regulated Band. (Pay attention also not to touch it with hand directly.)
4) Confirm that the tension regulator band is correctly inserted into the groove of the S Reel Deck Assy ⑤. (Refer to Fig. b)
5) When securing the Tension Adjustment Block using the screw, press it toward the position which gives the least tension, then tighten the fixing screw.
6) Before attaching the TG1 Arm Assy, coat the LS Chassis TG1 boss with oil (1/2 drop).
7) Do not touch the tape guide of the TG1 Arm Assy with bare hands.
8) Confirm that the claw of the S Reel Deck Assy is not deformed.


groove
Fig. b
Tesion Regulator Band Assy
②screw (M 1.4×3)
claw
⑤S Reel Deck Assy
⑥S Ratchet
Tesion Regulator Band Assy
④Tension Regulator Band Assy
tension regulator adjustment block
S Ratchet
Ⓐ
⑧S Ratchet Release Plate
TG-1 Arm Assy
Fig. a
⑩RVS Arm
⑨Tension Spring
⑦Tension Spring
③TG-1 Arm Assy
①Tension Spring (TG-1)
oil

Fig. 12

3-8. Pinch Arm Assy, TG4 Arm Block Assy (Refer to Fig. 13)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
3) Remove the LS Chassis Block Assy referring to section 3-5.
4) Remove the Torsion Spring (pinch) ① from an end of Pinch Arm and hook it on the cut-out Ⓐ of the LS Chassis.
5) Remove the screw (M 1.4×2.5) ② and remove the TG4 Retainer ③.
6) Remove the TG4 Arm Block Assy ④ and remove the Torsion Spring ⑤ while paying attention to the Torsion Spring ⑤.
7) Remove the Pinch Arm Assy ⑥. (Caution: The Pinch Press Roller is easy to drop. Pay attention not to drop it.)
8) Remove the Torsion Spring (pinch) ① from the cut-out of the LS Chassis in the order of Ⓐ then Ⓑ.

2. Precautions During Re-Assembly

1) Before attaching these parts, coat the LS chassis pinch arm boss and TG4 arm boss with grease SG-055G (Ref. No. J-13).
2) Do not touch the tape guide of the TG4 Arm Block Assy and roller of the Pinch Arm Assy with bare hand.
3) After coating the Pinch Press Shaft of the Pinch Arm Assy ③ with grease SG-055G (Ref. No. J-13), attach the Pinch Press Roller.


④TG-4 Arm Block Assy
⑥Pinch Arm Assy
Pinch Press Shaft
Pinch Press Roller
⑤Tension Spring
①Tension Spring (pinch)
Ⓐ
Ⓑ
②screw (M 1.4×2.5)
③TG-4 Retainer
Grease SG-055G (Ref. No. J-13) Coating

Fig. 13

3-9. LS Cam Plate, LS Guide Cover, Lid Opener, EJ Arm, Lock Guide
(Refer to Fig. 14)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
3) Remove the LS Chassis Block Assy referring to section 3-5.
4) Remove the two screws (M 1.4×2.5) ① and remove the the LS Cam Plate ②.
   In this state, write a mark on the screw ① and on the LS Chassis indicating the position of the LS Cam Plate which helps during re-assembly.
5) Remove the LS Guide Cover ③.
6) Remove the Lock Guide ④ in the upward direction. (Refer to Fig. a)
7) Remove the Lid Open ⑤ in the direction of the arrow Ⓒ while pushing Ⓑ portion .
8) Remove the EJ Arm ⑥ . (The EJ Arm ⑥ is press-fitted. If the EJ Arm ⑥ is not damaged, it is not necessary to replace.)

2. Precautions During Re-Assembly

1) After the captioned parts are attached, confirm that the respective claws and dowels are engaged completely.
2) If the EJ Arm ⑥ is removed, be sure to replace it with the new replacement EJ Arm.
3) If any mark is not written when removing the LS Cam Plate ②, adjust and attack it as shown in Fig. b.


Lock Guide
Ⓐ
Fig. a
④Lock Guide
CC Lock Switch
⑥EJ Arm
Position of EJ Arm after it is attached.
Fig. b
0.2mm or less
LS Guide groove
LS Guide Roller
LS Chassis
①screw (M 1.4×2.5)
· After attached
③LS Guide Cover
Tension Regulator Release Plate
⑥EJ Arm
⑤Lid Open
Ⓒ
Ⓑ
○ : Rearof LS Chassis Block Assy Grease SG-055G (Ref. No. J-13) Coating Points.
LS Chassis
②LS Cam Plate

Fig. 14

3-10. Guide Base (S) and (T) Block Assemblies, Guide Rail (Refer to Fig. 15)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
3) Remove the LS Chassis Block Assy referring to section 3-5.
4) While pushing the GB Stoppers (S) and (T) in the direction of arrow Ⓐ, press the guide arm in the direction of the arrow Ⓑ, and turn the Guide Base (S) and (T) Block Assemblies : ① and ② in the direction of the arrow Ⓒ respectively, and remove them.
5) Remove the two screws (M 1.4×2.5) ③ and remove the the Guide Rail Assy ④.
6) Remove the Stopper (S) and (T) : ⑤ and ⑥, then remove the GB Stopper S and T: ⑦ and ⑧.

2. Precautions During Re-Assembly

1) Pay attention not to deform the Guide Rail.
2) Do not touch the tape guide of the Guide Base (S) and (T) Block Assemblies with bare hand.
3) Pay attention not to deform the Stoppers (S) and (T).
4) When attaching the Guide Base (S) and (T) Blocks to the Guide Rail, move back the Guide Bases until the GB Stoppers (S) and (T) are locked. ("Click" sounds.)
5) After the captioned parts are attached, perform section "4. TAPE PATH ADJUSTMENT".


②Guide Base (T)
Block Assy
Ⓑ
Ⓐ Stopper T
Ⓒ
Stopper S
Ⓐ
①Guide Base (S)
Block Assy
Ⓑ
Ⓒ
④Guide Rail Assy
③screw (M1.4×2.5)
⑧GB Stopper (T)
⑤Stopper (S)
⑦GB Stopper
(S)
⑥Stopper (T)

Fig. 15

- **PARTS CONSTITUTING THE MECHANISM CHASSIS**


Relay Gear
LS Arm
Change Gear
washer
Timing Belt
washer
Cam Gear
Pinch Press Plate
Tension Regulator Plate
Tension Regulator Plate (2)
Tension Spring (limiter arm T) (black)
Rotary Switch
DC Motor (Capstan)
DC Motor (Loading)
flexible board holder
GL Slider Assy
HC Drive Arm
M Slider Assy

Fig.16

3-11. DC Motor Assy (Loading)
(Refer to Fig. 17)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the HC Roller Block Assy referring to section 3-1.
3) Remove the Drum Assy referring to section 3-2.
4) Remove the Drum Base Block Assy referring to section 3-3.
5) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
6) Remove the LS Chassis Block Assy referring to section 3-5.
7) Remove soldering from the Ⓐ portion.
8) Remove the screw (M 1.4×2.5) ① and remove the Motor Holder Block Assy ② from the mechanism chassis along with the claw beneath the Motor Holder Block Assy as shown by the arrow Ⓑ.
9) Remove the Motor Shield ③ in the direction of the arrow Ⓒ (by opening the two ★ star marked points).
10) Release the claw on top of the Motor Holder ⑤ and remove the DC Motor Assy ④ in the direction of the arrow Ⓓ.
11) Remove the Motor Holder Sleeve ⑥, Gear A⑦ and Worm Shaft ⑧ in this order.

2. Precautions During Re-Assembly

1) Before attaching the Gear A ⑥, coat the Retainer Shaft Ⓔ with grease SG-055G (Ref. No. J-13).
2) After assembling the Motor Holder Block Assy, coat the six locations shown by Fig. a with grease SG-055G (Ref. No. J-13).
3) The HC Drive Arm is easy to drop. Confirm that it is attacked referring to Fig. 19.


⑥Motor Holder Sleeve
⑦Gear A
⑧Worm Shaft
Ⓔ
Fig. a.
●Grease SG-055G(Ref.No.J-13) coating Position
⑤Motor Holder
claw
Ⓓ
④DC Motor Assy
①screw (M1.4×2.5)
Ⓒ
★
③Motor Shield
Ⓐ
Remove soldering
②Motor Holder Block Assy
Ⓑ

Fig. 17

3-12. Tension Regulator Plate 2, Relay Gear, M Slider Assy (Refer to Fig. 18)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the HC Roller Block Assy referring to section 3-1.
3) Remove the Drum Assy referring to section 3-2.
4) Remove the Drum Base Block Assy referring to section 3-3.
5) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
6) Remove the LS Chassis Block Assy referring to section 3-5.
7) Remove the DC motor referring to section 3-11.
8) Remove the Tension Regulator Plate 2 ①.
9) Remove the Relay Gear ②.
10) Remove the two washers ③. Remove the M Slider Assy ④. At the point, confirm that the LS Roller ⑤ is not dropped.

2. Precautions During Re-Assembly

1) Before attaching the M Slider Assy ④, coat the LS Roller Shaft Ⓐ on the back of the M Slider Assy, the Pinch Press Plate Shaft Ⓑ and the mechanism chassis M Slider Axis Ⓒ with grease SG-055G (Ref. No. J-13). (Refer to Fig. b)
2) While confirming the phase-determining holes, attach the M Slider Assy ④ while paying attention to the claw.
3) Attach the Tension Regulator Plate 2 ① inside the Tension Regulator Plate. (Refer to the asterisk * Marked portion of Fig. a)
4) Before attaching the Relay Gear ②, coat the mechanism chassis Relay Gear Axis Ⓓ with grease SG-055G (Ref. No. J-13).



③washer
Claw
②Relay Gear
Ⓐ
③washer
④M Slider Assy
Phase Determining holes
(See Fig. 11 for detail.)
⑤LS Roller
①Tension Regulator Plate (2)
Ⓒ
Ⓓ
Ⓑ
Tension Regulator Plate
Fig. b
Phase Determining Hole
Cam Gear
Rotary Switch
Phase mark
Fig. a
*
*

Fig. 18

3-13. LS Arm, HC Drive Arm, Pinch Press Plate, Tension Regulator Plate (Refer to Fig. 19)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the HC Roller Block Assy referring to section 3-1.
3) Remove the Drum Assy referring to section 3-2.
4) Remove the Drum Base Block Assy referring to section 3-3.
5) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
6) Remove the LS Chassis Block Assy referring to section 3-5.
7) Remove the DC Motor Assy referring to section 3-11.
8) Remove the Tension Regulator Plate 2, Relay Gear and M Slider Assy referring to section 3-12.
9) Remove the LS Arm ①. At this point, confirm that the LS Roller ② is not dropped.
10) Remove the HC Drive Arm ③, Pinch Press Plate ④ and Tension Regulator Plate ⑤.

2. Precautions During Re-Assembly

1) Before attaching the captioned parts, confirm that phases of the Cam Gear and the Rotary Switch agree. (See Fig. a.)
2) Insert the dowel of the Tension Regulator Plate ⑤ into the groove outside the rotary switch.
3) Before attaching the Pinch Press Plate ④, check for grease on the mechanism chassis Pinch Press Plate Shaft Ⓐ. If grease cannot be found, coat it with grease SG-055G (Ref. No. J-13). After attaching the Pinch Press Plate ④, align its phase hole until it agrees with the phase-determining hole on the mechanism chassis.
4) Insert the dowel of the HC Drive Arm ③ into the groove inside the rotary switch.
5) Before attaching the LS Arm ①, coat the LS roller shaft of the LS Arm ① with grease SG-055G (Ref. No. J-13).


④Pinch Press Plate
③HC Drive Arm
Ⓐ
①LS Arm
②LS Roller
⑤Tension Regulator Plate
Position of groove during re-assembly
LS Arm
Fig. a
Phase Determining Hole
Cam Gear
Rotary Switch
Phase mark
Tension Regulator Plate
Outside Groove
Inside Groove
HC Drive Arm

Fig. 19

3-14. Cam Gear (Refer to Fig. 20)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the HC Roller Block Assy referring to section 3-1.
3) Remove the Drum Assy referring to section 3-2.
4) Remove the Drum Base Block Assy referring to section 3-3.
5) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
6) Remove the LS Chassis Block Assy referring to section 3-5.
7) Remove the DC Motor Assy referring to section 3-11.
8) Remove the Tension Regulator Plate 2, Relay Gear and M Slider Assy referring to section 3-12.
9) Remove the LS Arm and Tension Regulator Plate referring to section 3-13.
10) Remove the Cam Gear ①.

2. Precautions During Re-Assembly

1) Before attaching the Cam Gear ①, align the phase mark on the rotary switch until it agrees with the phase-determining hole Ⓐ on the mechanism chassis, and align the GL Arm's phase mark Ⓑ until it agrees with the phase-determining hole Ⓐ on the mechanism chassis. Coat the mechanism's chassis Gear Axis Ⓐ with grease SG-055G (Ref. No. J-13).
2) Attach the Cam Gear ① so that its phase hole agrees with the phase mark on the rotary switch. (Refer to Fig. a)
3) After the Cam Gear ① is attached, coat the GL Arm Axis Block of the cam gear with grease SG-055G (Ref. No. J-13).

Reference : The phase marks of the Cam Gear and Rotary Switch can also be checked from the rear side of mechanism chassis. It means that the phase can be confirmed after mechanism deck is fully re-assembled.


①Cam Gear
Phase Determining Hole
GL Arm Shaft
Ⓐ
GL Arm Shaft
Mechanism Chassis Phase Hole Ⓑ
Phase Determining Hole Ⓐ of Mechanism Chassis
Fig. a
Phase Determining Hole
Cam Gear
Rotary Switch
Phase mark
○ : Grease SG-055G (Ref. No. J-13) Coating Points

Fig. 20

3-15. GL Slider Assy, GL Arm
(Refer to Fig. 21)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the HC Roller Block Assy referring to section 3-1.
3) Remove the Drum Assy referring to section 3-2.
4) Remove the Drum Base Block Assy referring to section 3-3.
5) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
6) Remove the LS Chassis Block Assy referring to section 3-5.
7) Remove the DC Motor Assy referring to section 3-11.
8) Remove the Tension Regulator Plate 2, Relay Gear and M Slider Assy referring to section 3-12.
9) Remove the LS Arm and Tension Regulator Plate referring to section 3-13.
10) Remove the Cam Gear referring to section 3-14.
11) Remove the GL Slider Assy ① by sliding it in the direction of the arrow Ⓐ.
12) Remove the GL Arm ②.

2. Precautions During Re-Assembly

1) The Tension Spring T③ is colored black and the Tension Spring S④ is colored silver.
2) Coat the position shown in Fig. a of the GL Slider Assy ① with grease SG-055G (Ref. No. J-13).
3) Coat the four points Ⓑ where GL slider is attached on the mechanism chassis with grease SG-055G (Ref. No. J-13).
4) After attaching the GL Arm ② and the GL Slider Assy, align the GL arm phase hole until it agrees with the phase-determining hole on the mechanism chassis.


Align the hole of the GL Slider Assy unit it agrees with the dowel of the Gl Arm.
③Tension Spring, S, (Black)
①GL Slider Assy
Ⓐ
B
S
Fig. a
④Tension Spring, T, (Silver)
②GL Arm
Phase Determining Hole
● : Grease SG-055G (Ref. No. J-13) Coating Point
Ⓑ

Fig. 21

3-16. Rotary Switch (Refer to Fig. 22)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the HC Roller Block Assy referring to section 3-1.
3) Remove the Drum Assy referring to section 3-2.
4) Remove the Drum Base Block Assy referring to section 3-3.
5) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
6) Remove the LS Chassis Block Assy referring to section 3-5.
7) Remove the DC Motor Assy referring to section 3-11.
8) Remove the Tension Regulator Plate 2, Relay Gear and M Slider Assy referring to section 3-12.
9) Remove the LS Arm, Tension Regulator Plate, HC Drive Arm and Pinch Press Plate referring to section 3-13.
10) Remove the Cam Gear referring to section 3-14.
11) Remove soldering the portion Ⓐ on the rear of the Rotary Switch. (Pay attention at this moment that the GL Slider and GL Arm do not drop.)
12) While lifting up the portion Ⓑ about 1 mm (pay attention not to break it), hold the portion Ⓒ and turn it in the direction of the arrow Ⓓ to remove the Rotary Switch.

2. Precautions During Re-Assembly

1) Before attaching the Rotary Switch by soldering on the FP-220 board, insert the portion Ⓑ dowel into the hole on the mechanism chassis. Confirm that the three claws are engaged with the mechanism chassis.



Fig. 22

3-17. Capstan Motor (Refer to Fig. 23)

1. Disassembly Procedure

1) Remove the Cassette Compartment Block Assy referring to section 1-1.
2) Remove the HC Roller Block Assy referring to section 3-1.
3) Remove the Drum Assy referring to section 3-2.
4) Remove the Drum Base Block Assy referring to section 3-3.
5) Remove the Gooseneck Retainer and Gooseneck Gear Assy referring to section 3-4.
6) Remove the LS Chassis Block Assy referring to section 3-5.
7) Remove the DC Motor Assy referring to section 3-11.
8) Remove the Tension Regulator Plate 2, Relay Gear and M Slider Assy referring to section 3-12.
9) Remove the Pinch Press Plate referring to section 3-13.
10) Remove the screw (M 1.4×6.7) ① and remove the Flexible Board Holder ②.
11) Remove the two screws (M 1.4×6.7) ③ and remove the Capstan Motor ④, Timing Belt ⑤ and Capstan Spacer ⑥.
12) Remove the washer ⑦ and remove the Changer Gear ⑧.

2. Precautions During Re-Assembly

1) Confirm that the timing belt is not twisted.
2) Do not touch the capstan with bare hand.
3) Lubricate the mechanism chassis's Change Gear shaft Ⓐ.
4) After attaching the Capstan Motor, perform the capstan azimuth adjustment.


Capstan Motor Stator
Azimuth Adjustment Screw
3.8±0.1mm
Mechanism Chassis


①screw (M 1.4×6.7)
(Used also as Azimuth Adjustment Screw.)
②flexible board holder
③screw (M 1.4×6.7)
③screw
(M 1.4×6.7)
⑤Timing Belt
④Capstan Motor
⑦Washer
⑧Change Gear
⑥Capstan Spacer
Ⓐ

Fig. 23

3-18. Tension Regulator Position Adjustment (Refer to Fig.24)

1. Adjustment Procedure

1) Insert a cassette Tape and run the Tape in PB mode.
2) While tape is running, confirm that the distance between the LS Chassis and TG-1 Guide's top flange is 8.3mm.
3) If not, proceed to step 4).
4) Loosen the screw ① (M 1.4×3).
5) If the TG-1 Guide is located inside the specified position, move position of the Tension Regulator Band Assy using the FWD B.T. Adjustment tool screwdriver (Ref. No. J-9) as shown in the direction of the arrow Ⓐ. If it is located outside, move it in the direction of the arrow Ⓑ.
6) Tighten the screw ① (M 1.4×3).


Tension Regulator Band Assy
①screw (M1.4×3)
Ⓐ
Ⓑ
FWD B.T. Adjustment tool driver
TG-1 Guide
TG-1 Arm Assy
LS Chassis
8.3mm

Fig.24

3-19. FWD Tape Hold-Back Tension Adjustment (Refer to Fig. 25)

1. Adjustment Procedure

1) Insert the torque measurement cassette to the machine.
2) Put the machine in the FWD mode. Confirm that the reading on the S side is in the range from 8.0 to 10.5 g•cm. If the reading is outside the specification range, make the following adjustments.
3) If the reading is higher than the specification, change the TG-1 Tension Spring to the side Ⓐ.
4) If the reading is lower than the specification, change the TG-1 Tension Spring to the side Ⓑ.



Fig. 25

4. TAPE PATH ADJUSTMENT

Purpose:	Adjusts the head linearity.
Adjustment Error:	Noise appears on top and bottom of display when playing back the tape recorded by other machines.



Fig. 26

4-1. Preparations for Adjustments

1) Clean the tape running surface (tape guide, drum, capstan, pinch roller).
2) Connect the adjustment remote commander to the REMOTE terminal (JACK block).
3) Establish the PATH mode using the adjustment remote commander (Track Shift mode)* to cancel auto tracking.
4) Connect an oscilloscope.
   CH1: Test connector PB RF terminal
   External trigger: Test connector PB SWP terminal
5) Playback the tracking alignment tape WR5-1NP (NTSC) or WR5-1CP (PAL) (Ref. No. J-6).
6) Check to see that RF waveform is flat at input and exit sides on oscilloscope.
   If it not flat, perform the following section 4-2 until it is flat.
7) After completing the adjustment, release the PATH mode (Track Shift mode).*.



Fig. 27

* How to enter and exit the Track Shift mode. (In the case of CCD-TR420E/TR440E)

Entering the Track Shift mode

1. Select page : 6, address : 00 set data : 01 and press the PAUSE button.
2. Select page : 7, address : 01 set data : 03 and press the PAUSE button.

Exitting the Track Shift mode

1. Select page : 7, address : 01 set data : 00 and press the PAUSE button.
2. Select page : 6, address : 00 set data : 00 and press the PAUSE button.

4-2. Tracking Adjustment (Refer to Fig. 28.)

1) Playback the tracking alignment tape WR5-1NP (NTSC) or WR5-1CP (PAL) (Ref. No. J-6).
2) Adjust the tape guide No. 2 until the input side waveform becomes flat.
3) Adjust the tape guide No. 3 until the input side waveform becomes flat.

☆ Zenith adjustment screws for the TG-2 and TG-3 do not need to be adjusted.



Fig. 28

4-3. No. 4 Guide (TG-4) Adjustment (Refer to Fig. 29.)

1) Playback a tape in REV mode.
2) Confirm that tape slack does not occur in between the guide No. 3 (TG-3) ① and Capstan ②. If tape slack is found, turn the height adjustment screw ④ of the Guide No. 4 (TG-4) ③ until tape slack is removed.
3) Playback a tape in FWD mode. Confirm that tape slack does not occur in between the guide No. 4 (TG-4) ③ and capstan ②. (Specification = 0.5 mm or less) If tape slack of more than 0.5 mm is found, turn the TG-4 nut ④ until the slack is 0.5 mm or less. Playback tape in REV mode and confirm that tape slack in between the guide No. 3 (TG-3) ① and capstan ② is 0.3 mm or less, the adjustment is complete.



Fig. 29

4-4. CUE, REV Waveforms Check (Refer to Fig. 30.)

1) Playback the tracking alignment tape in REV mode.
   Confirm that pitches between the peaks of the waveform are equally spaced for 5 seconds or longer.
   The pitches are not equally spaced, perform sections "4-2. Tracking Adjustment" and section "4-3. No. 4 Guide Adjustment".
2) Playback the tracking alignment tape in CUE mode.
   Confirm that pitches between the peaks of the waveform are equally spaced for 5 seconds or longer.
   The pitches are not equally spaced, perform section "4-2. Tracking Adjustment".



Fig. 30

4-5. Checks After Adjustments

4-5-1. Tracking Check

1) Confirm that amplitude of the RF waveform decreases to about 3/4 when the machine enters the PATH mode. (Refer to Fig. 31)
2) Confirm that the minimum amplitude (EMIN) of the RF waveform is 65 % or more of the maximum amplitude (EMAX). (Refer to Fig. 32)
3) Confirm that the RF waveform does not have too much fluctuation. (Refer to Fig. 33)



Fig. 31



Fig. 32



Fig. 33

4-5-2. Waveform Build-up Check (Refer to Fig. 34.)

1) Playback the tracking alignment tape.
2) Turn OFF the Track Shift mode.
3) Eject the tape once, insert and load the tape.
4) Start playing back the tape and confirm that the RF waveform builds up in three seconds with flat envelope. Confirm at this time that tape slack does not occur near pinch roller.
5) Playback the tape in CUE/REV and FF/REW modes respectively. Confirm that the RF waveform builds up in three seconds with flat envelope. Confirm at this time that tape slack does not occur near pinch roller.
6) Repeat the check items 3) to 5) again.



Fig. 34

4-5-3. Tape Pass Check (Refer to Fig. 35.)

1) Insert a thin video tape such as P6-120MP (NTSC) or P5-120MP (PAL). Playback the thin tape. Confirm that there is no clearance or curl of 0.3 mm or more at the following points: Upper flange of guide No. 2, upper flange of guide No. 3, upper and lower flanges of guide No. 4.
2) Confirm that there is no clearance or curl of 0.3 mm or more at each tape guide when the FF button is pressed from the playback mode to enter the CUE mode, and when the REW button is pressed from the playback mode to enter the REV mode.



Fig. 35

5-1. Cassette Compartment Block Section


703
704
704
708
705
708
709
707
708
702
701
709
LS CHASSIS BLOCK SECTION (See page 35)
MECHANISM CHASSIS BLOCK SECTION (See page 36)

5-2. LS Chassis Block Section



762
772
771
778
779
S002
773
780
761
775
777
781
760
774
782
D001
A
767
776
FP-249
(not supplied)
765
784
769
769
785
766
768
770
758
778
759
783
758
786
787
758
757
758
789
752
753
788
754
763
A
756
791
792
751
755
790
764

5-3. Mechanism Chassis Block Section


M901
<NOTE>
817
838
809
838
809
810
812
823
805
811
806
808
813
814
M903
828
830
807
813
809
821
829
803
831
824
805
805
815
825
819
816
820
815
826
837
M902
836
S901
827
814
804
835
822
818
802
832
801
808
834
833

NOTE : Part number and model name of DRUM ASSEMBLY are different depending on the each model.